

FEATURES

Network peripheral with 8 inputs and 8 outputs without communication module. It is possible to equip **IND-8 base** with modules: **FTT10A** (Lon Works bus), **485-IG** (485 galvanically isolated bus) and **485** (485 polarized bus) depending on the requirements of the plant.

INPUTS

Double balance inputs for a total of four states: STANDBY, ALARM, SHORT CIRCUIT, and CUT


Each input is completely independent and can be programmed as follows:

- Double balance
- Single balance
- Normally Open
- Normally Closed

The configuration allows to set:

- Detection time
- Self-exclusion on enabling
- Enabling delay
- Alarm delay
- Maximum number of alarms, with the possibility to define the interval
- Maximum number of detections before alarm, with the possibility to define the interval
- Tampering signal exclusion (short circuit and cut)
- Event generation
- Logic zone

The inputs are available on flat cable suitable for the connection to the board **MORS-0**.



MORS-0 has two banks, 8 inputs each that can be easily divided thanks to the pre-incision on the board.

Each bank has:


- Flat cable connector for connection with modules: INC-8 base, IND-8 base and IND-16 base
- Couple of power terminals input
- Power fuse (2A)
- Couple of output power terminals every couple of inputs

OUTPUTS

Open Collector outputs (500mA) on connector for flat cable suitable for the connection to the relay boards MORS-1, and MORS-2 and MORS-3.

Outputs support the following commands:

- Positive security (inverted functioning logic)
- Continuously enabled
- 1Hz pulsing
- 2Hz pulsing
- Standby



SPECIAL FUNCTIONS

Special functions available:

- battery and power control
- signaling of communication fault on output 8

Other information available in the section Installation.

INSTALLATION

IND-8 has been designed to be installed into wall mounting box or rack box, which must be fixed with the 4 spacers 10mm supplied. Fix the board avoiding bending; mechanical stresses can damage the board.

During insertion and removal of connectors, block the board in order to avoid bending. After fixing operations check that line module's board and connectors are completely inserted into their plugs.

COMMISSIONING

Commissioning steps:

- Make sure that the control panel is not powered.
- Set peripheral's number through dip-switches.
- Power the peripheral.
- Check that L2 Led blinks RED fast.
- Press SW1 key until L2 Led becomes GREEN, fixed first and blinking then.
- Check through PC or TAD-M terminal that peripheral is online.

EXCEPTIONS

L2 RED Led on steady

- No communication between peripheral and control panel.
- Check network connections.
- Check that line module and connectors are completely inserted into their plug.
- If the connections are correct, it is possible that the device has in memory the binding of another line or another control panel. In this case, delete the old binding.

L2 Led blinks RED/YELLOW/GREEN

The device has a memory of a binding with a device number different to the current setting. Set the correct peripheral number or delete the old binding.

DELETE BINDING

The cancellation of the binding occurs through software MONITOR or terminaleTAD-FTT. If is impossible delete the bindings use the following procedure:

- remove peripheral power
- press and hold SERVICE key
- reconnect power

The cancellation of the binding is indicated by fast flashing RED LED L2.

LINE MODULE

Check P0 jumper's position on line module.
P0 jumper set the line termination.

For 485IG and 485 modules, jumpers are two. To choose points where add terminations, see technical manual in NETWORK CONFIGURATION paragraph.

INPUTS

Input schemes can be found in SCHEMES INPUT paragraph.

POWER SUPPLY AND BATTERY CONTROL

This control is used when the peripheral is installed in a sub-control panel with separated power supply. When this function is active, the peripheral controls power supply and battery status each hour or when SW1 button is pressed.

Power supply check uses input 1, battery check input 2 and output 1, that can't be used for other functions.


Battery check is enabled setting dip-switch 1 pin 2 ON. IND-CBR scheme contains all indications useful for connections.

COMMUNICATION FAULT SIGNALLING

Enabling this function, peripheral signals on output 8 communication fault. To use this function it's necessary to set dip-switch 1 pin 1 ON and program output 8 with positive security. Whenever communication with the control panel is interrupted, the relay of output 8 will be disabled. This function is used to drive radio-links and alarm signalling with maximum security.

TECHNICAL DATA

Voltage range	9÷15	Vdc
Standby current	75	mA
Maximum output current	500	mA
Operating temperature	-10 ÷ +40	°C
Humidity (without condensate)	75%	-
Dimensions	100x72	mm



SIGNALLING	
L1	Power supply
Green or Red	12V presence
Off	12V fault
L2	Data network test
Fixed red	Communication with the control panel missing
Fast blink Red	Peripheral doesn't have binding
Slow blink Green	Peripheral has binding and is communicating correctly with the control panel
Alternate blink Red/Green/Yellow	Address has been changed after binding. Set the correct address or delete binding and repeat the commissioning procedure.
L3	Microprocessor Test
Red	Microprocessor stop
Green	Microprocessor works correctly
L4	SERVICE
	Enabled when SERVICE key is pressed
CONNECTIONS	
JP1	Power
1	Do not use
2	negative
3	positive + 12V
JP2	Data network
1	Network – WHITE RS- 485
2	Do not use
3	Network - GREEN RS-485
JP3	Outputs 1/8 terminal block
1-8	Output 1....Output 8
JP4	Battery connection
1	Battery positive
2	Battery negative
3	Power supply test
JP5	inputs 1/8
	Used for MORS-0 connection
JP6	Inputs terminal board 1/8
1-8	Output 1.... Output 8
JP12	Output 1/8
	Used to connect relay modules
LON line	
S1A	S1B
	Lon module – FTT10A, 485IG, 485


SETTINGS	
P0	Data network termination configuration
FTT	NC No resistance
	1,2 Free configuration
	2,3 Bus configuration
485	NC Termination disabled
485IG	1,2 Termination enabled, terminal is positioned at one end of 485 bus
DIP 1	Special settings
1	Outputs 8 signals missing communication with the control panel (set positive security on output 8)
2	Battery test
3	Dip 9 peripheral address
4	Dip 10 peripheral address
DIP 2	Peripheral address
...	See peripheral address table
DIP 3	1/8 inputs balance
ON	Removes 10KOhm resistance on input 1 ... 8

BUTTONS	
SW1	SERVICE button
	Press to put the device online

Double balance Normally Closed (N.C.) inputs

This setting provides the maximum protection. Each input provides reports for: STANDBY, ALARM, CUT, SHORT-CIRCUIT. Signallings are provided according to the resistance value between the input and the negative.


STATE	VALUE
STANDBY	from 6,8 to 12 KOhm
ALARM	from 12 to 22 KOhm
CUT	more than 22 KOhm
SHORT CIRCUIT	less than 6,8 KOhm



Single/Double balance Normally Closed (N.C.) inputs

Each input provides reports for: STANDBY, ALARM, CUT, SHORT-CIRCUIT. Signallings are provided according to the resistance value between the input and the negative.


STATE	VALUE
STANDBY	from 6,8 to 12 KOhm
ALARM	more than 10 KOhm
SHORT CIRCUIT	less than 6,8 KOhm



Single/Double balance Normally Closed (N.C.) inputs

Pre-installed 10K resistance on board (for double balancing, simply add the resistance of 4.7K on the detector) that make the inputs a single balance, providing signalling of: standby, alarm, cut. Signalling is given basing on resistance value seen between input and negative.


STATE	VALUE
STANDBY	from 6,8 to 12 KOhm
ALARM	from 12 to 22 KOhm
CUT	more than 22 KOhm



Normally Open (N.O.) technological inputs

Each input provides reports for: STANDBY and ALARM. Signallings are provided according to the resistance value between the input and the negative.


STATE	VALUE
STANDBY	more than 22 KOhm
ALARM	less than 6,8 KOhm




Normally Closed (N.C.) technological inputs

Each input provides reports for: STANDBY and ALARM. Signallings are provided according to the resistance value between the input and the negative.

STATE	VALUE
STANDBY	less than 6,8 KOhm
ALARM	more than 22 KOhm





NOTIFIER ITALIA S.r.l. - A socio unico - 20097 San Donato Milanese (MI) - Via Grandi, 22 - Tel.: 02/518971 - Fax: 02/5189730 - E-mail: notifier@notifier.it
Capitale Sociale € 2.700.000,00 i.v. - C.C.A.A. 1456164 - Trib. Milano Reg. Soc. 348608 - Vol. 8549 Fasc. 8 Codice Fiscale 05108880153 Partita IVA IT 11319700156 (informativa privacy art. 3 Digs 196/03) - **Uffici Regionali:** 10143 **Torino** - Corso Potenza, 6 - Tel.: 011/0650611 - Fax: 011/4531183 E-mail: notifier.torino@notifier.it - 35010 **Limena (PD)** Via IV Novembre, 6/c Int. 9 - Tel.: 049/7663511 - Fax: 049/7663550 E-mail: notifier.padova@notifier.it 40050 **Funo di Argelato (BO)** - Asta Servizi, Bl. 3B, Gall. B n. 85, Centergross - Tel.: 051/0432211 - Fax: 051/6647638 - E-mail: notifier.bologna@notifier.it - 50136 **Firenze** Via B. Telesio, 15 - Tel.: 055/696706 - Fax: 055/6529294 - E-mail: toscana@notifier.it - 00118 **Roma** - Via Del Casale Santarelli, 51 - Tel.: 06/7988021 Fax: 06/79880250 - E-mail: notifier.roma@notifier.it - 80143 **Napoli** - Via G. Porzio, 4 - Centro Direzionale, Isola E2, Scala B, Piano 5° - Int. 19 - Tel.: 081/19493111 Fax: 081/7879159 - E-mail: notifier.napoli@notifier.it - 70125 **Bari** - Via Della Costituente, 29 - Tel.: 080/6180700 - Fax: 080/5648114 - E-mail: notifier.bari@notifier.it - 95126 **Catania** - Viale A. De Gasperi, 187 - Tel.: 095/2279511 - Fax: 095/7120753 - E-mail: notifier.catania@notifier.it

