

# USER MANUAL



Honeywell MeshGuard™

Wireless Gas Detector

**Honeywell**

# Table of Contents

---

Honeywell MeshGuard™ .....	1
<b>Safety</b> .....	<b>4</b>
<b>Standard Kit</b> .....	<b>6</b>
<b>General Information</b> .....	<b>7</b>
<b>Physical Description</b> .....	<b>9</b>
LCD Display .....	10
Specifications .....	11
<b>Operating The MeshGuard</b> .....	<b>13</b>
Turning The MeshGuard On .....	13
Turning The MeshGuard Off .....	15
Low Battery Indicator and Action .....	15
Wireless Communication Indicator .....	16
<b>Operation Modes</b> .....	<b>17</b>
Detection Mode .....	17
Manually Sending Data .....	19
Detection Mode (When Portable Mode Is Enabled) .....	20
Programming Mode .....	21
<b>Diagnostic Mode</b> .....	<b>34</b>
Entering Diagnostic Mode .....	34
Exiting Diagnostic Mode .....	35
Diagnostic Mode Readings .....	35
Diagnostic Mode Programming .....	37
<b>Sensor And Battery Replacement</b> .....	<b>42</b>
Battery replacement .....	43
Sensor Filter Replacement .....	44
Sensor Replacement .....	44
<b>Troubleshooting</b> .....	<b>46</b>

---

<b>Alarm Signal Summary</b> .....	<b>48</b>
<b>Appendix A: Installation</b> .....	<b>50</b>
Magnet-Mount Installation .....	50
Fixed Installation .....	51
Magnetic Mount Alternative Installation .....	55
<b>MeshGuard Sensor Specifications</b> .....	<b>57</b>
<b>Contact</b> .....	<b>60</b>

# 1 Safety

## IMPORTANT! BUMP TEST THE MONITOR BEFORE EACH DAY'S USE

Prior to each day's use, every gas detection monitor should be bump tested to confirm the response of all sensors and activation of all alarms by exposing the monitor to a concentration of target gas that exceeds the low alarm set point. A bump test is also recommended if the monitor has been subjected to physical impact, liquid immersion, an Over Limit alarm event, or custody changes, or anytime the monitor's performance is in doubt.

To ensure greatest accuracy and safety, only bump test and calibrate in a fresh air environment.

The monitor should be calibrated every time it does not pass a bump test, but no less frequently than every six months, depending on use and exposure to gas and contamination, and its operational mode.

- Calibration intervals and bump test procedures may vary due to national legislation.
- Honeywell recommends using calibration gas cylinders containing the gas that is appropriate to the sensor you are using, and in the correct concentration.

### Waste Electrical & Electronic Equipment Disposal

#### EU Directive 2012/19/EU: Waste Electrical and Electronic Equipment (WEEE)



This symbol indicates that the product must not be disposed of as general industrial or domestic waste. This product should be disposed of through suitable WEEE disposal facilities. For more information about disposal of this product, contact your local authority, distributor, or the manufacturer.

## WARNINGS

### Read Before Operating

This manual must be carefully read by all individuals who have or will have the responsibility of using, maintaining, or servicing this product. The product will perform as designed only if it is used, maintained, and serviced in accordance with the manufacturer's instructions.

### FCC Part 15 statement and CE

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Warning

Use only the Lithium battery or external rechargeable battery provided by RAE Systems. This instrument has not been tested in an explosive gas/air atmosphere having an oxygen concentration greater than 21%. Substitution of components may impair suitability for intrinsic safety. Replace batteries only in non-hazardous locations.

STATIC HAZARD: Clean only with a damp cloth.

For safety reasons this equipment must be operated and serviced by qualified personnel only. Read and understand instruction manual completely before operating or servicing. Any rapid up-scale reading followed by a declining or erratic reading may indicate a gas concentration beyond upper scale limit, which may be hazardous.

### Intrinsically Safe Marking



Cl. I, Div. 1, Gr A, B, C, D T4

Ta = -40° C to +50° C

IECEX SIR 19.0015X


Sira 19ATEX2036X

Ex ia IIC T4 Ga

Ex ia I Ma

Ui = 3.6V, Ci=63°F,

Li/Ri=3.5H/ohm



CHAPTER

# 2

## Standard Kit

Monitor with antenna

User's Guide

CD with resources

Maintenance tool


Calibration certificate

Calibration adapter

# 3 General Information

MeshGuard (FTD-2000) is a single toxic gas detector integrated with a wireless mesh network-enabled transmission radio module. It can work as a fixed device or as a portable device. The detector has the option of relaying the wireless signal to other MeshGuards as needed, to bypass obstacles. The MeshGuard's built-in radio board operates on a frequency of 2.4GHz and complies with IEEE 802.15.4 standard. The FTD-2000 works with the FMC-2000 wireless controller on a flexible, robust wireless network to provide reliable, low-cost operation. It also works in a ProRAE.net network with a PC, and it supports point-to-point and point-to-multi-point networks.

Meshguard network with TPPLW



Safety Suite network with PC controller

## Key Features


- Up to 6 months continuous operation
- IEEE 802.15.4 Mesh network functionality with 64-bit encryption
- Robust wireless mesh network with auto network forming and configuration
- Operating distance: up to 300 m (985 ft), line of sight
- Very low-cost installation - no hardwiring involved
- Large area coverage with multi-hop mesh network
- Field-replaceable battery
- Loud audio alarm, 90dB @ 30cm (12")
- Large, easy-to-read continuous display
- Bright red flashing alarm
- Highly resistant to RFI interference
- IP-65 rated for outdoor use in harsh environments
- Sensors supported: See section 14, "MeshGuard Sensor Specifications"
- Field-replaceable sensor.
- User-adjustable high and low alarms
- User-adjustable STEL and TWA alarms (in portable mode)
- Simple calibration




# 4 Physical Description

Note: The physical appearance of the MeshGuard is virtually identical, whether in a metal enclosure or a plastic enclosure. Functionality is identical, regardless of the enclosure.

- 1 LED alarm
- 2 LCD
- 3 Buzzer alarm
- 4 Sensor gas inlet
- 5 Battery cover (on bottom)
- 6 Y/+, MODE, and N/- keys
- 7 Antenna
- Not visible Optional magnetic mount on rear



# LCD Display



- 1\* Zero Calibration
  - 2 Low Battery Indicator
  - 3 Wireless Communication (if on, the monitor is in STD; if blinking, the monitor is RTR)
  - 4\* Short Term Exposure Limit (STEL)
  - 5\* Time Weighted Average (TWA)
  - 6, 8\* High Alarm
  - 7, 8\* Low Alarm
  - 9\* Gas Concentration unit, ppm
  - 10\* Gas Concentration unit, %
  - 11 Save Setting
  - 12,13\* Span Calibration
  - 14 Reading Value
- Remark: Concentration unit is shown as either ppm (9) or % (10).

# Specifications

	FCC Part15
	CE EN 300328
	SRRC (Pending)
RF Certifications	Wireless Approval For UAE In Middle East (TRA REGISTERED No: ER36063/14)
	DEALER No: HONEYWELL INTERNATIONAL MIDDLE EAST - LTD - DUBAI BR
	Wireless Approval for QATAR In Middle East
Display	ictQATAR Type Approval Reg. No.: R-4465
Audible alarm	Customized LCD (1 x 1.5") with backlight
Visual alarm	90dB @ 30cm
Calibration	2 super-bright red LEDs
RF	Two-point field calibration
	IEEE 802.15.4/Zigbee with mesh stack
Operating Range	Up to 300 meters, line of sight
	Up to 1000 meters, line of sight for LoRa
Transmission Power	Up to 18dBm (63mw EIRP)
Receiver Sensitivity	Minimum -95dBm at 2.4GHz
User Interface	Three keys (Y/+, MODE, N/-)
Power Supply	D-size EVE or Xeno Lithium primary battery, +3.6V, 19 Ah
Max Current Consumption	200mA@3.6V during transmission
	<0.5mA@3.6V during standby
	Internal Battery:
	For STD* Mode: up to 6 Months
Operation Time	For RTR** Mode: up to 10 days
	*STD is standard-function device
	**RTR is router-function device
Operating Temperature	<b>-40° to 122° F (-40° to +50° C) for CO, and H<sub>2</sub>S sensors</b>
Humidity	<b>Other sensors: -4° to 122° F (-20° to +50° C)</b> 0% to 95% relative humidity, non-condensing
Dimensions	26.5cm x 9.5cm x 5.5cm (10.5" L x 3.7" W x 2.1" H)
Weight	0.6 kg (1.3 lbs)
Package Mounting	IP-65 Optional stainless-steel bracket mount or magnetic mount

## Radio Specifications

Radio model: RM2400A  
Frequency range: 2.400-  
2.4835GHz  
Modulation: 802.15.4 DSSS  
BPSK

RF power(Tx):  
20dBm  
Data rate:  
250kbps

Radio model: RMLORAB  
Frequency range:  
470~510MHz  
Modulation: 802.15.4 DSSS  
BPSK

RF power(Tx):  
17dBm  
Data rate:  
250kbps

# 5

## Operating The MeshGuard

Make sure the battery is installed before operating the MeshGuard. Refer to page See "Sensor And Battery Replacement" on page 42 for more information. for information on battery installation and replacement.

### Turning The MeshGuard On


Hold down the [MODE] key and release it when the MeshGuard beeps. The monitor is now on, as indicated by the display:




The MeshGuard performs a self-test, followed by warm-up and zero calibration. The display briefly shows the firmware version (for example, "F1.0" means firmware version 1.0, "F2.0" means firmware version 2.0, etc.):



Then the MeshGuard initializes the wireless network and displays this information:



Note: If MeshGuard is unable to find a radio network to connect with, it searches, and the display alternates between “rdo” and “SrH” (for “radio search”). Next, the display tells you that MeshGuard is initiating network communication:




Next, if a network is located, an antenna icon appears (if no network is found, then refer to “Join Mesh Network” on page See "Join Mesh Network" on page 33 for more information.). The current gas concentration reading is also displayed:



Note: When adding a MeshGuard detector to a new network for the first time, it is recommended that you press [Y/+] to manually initiate a search for the network.

The MeshGuard is now operational.



## Turning The MeshGuard Off

Hold down the [MODE] key through the “5...4...3... 2... 1... oFF” sequence. The monitor is off when the display is blank. Release the [MODE] key.




The MeshGuard is now off.

## Low Battery Indicator and Action

The MeshGuard’s battery is designed for up to six months’ life in STD mode (in RTR mode, including the MeshGuard Router’s normal operation, battery life is up to 10 days). When the battery gets low, the MeshGuard beeps once per minute and an empty battery icon appears. It is recommended that the battery be changed immediately, to minimize disruption.



When the battery is completely depleted, the LCD displays “OFF,” and the LED, buzzer and vibration alarm activate once per second. The battery icon also blinks on and off. The MeshGuard shuts down after you press any key, or shuts down automatically if you do not press a key for 60 seconds.



## Wireless Communication Indicator

When wireless communication is turned on, the LCD displays the wireless link status in the upper left corner:



If the MeshGuard finds and joins a wireless network, an antenna icon is shown in the display. If no link or a weak link is established, no antenna icon is shown. Press [Y/+] to search for a network. (See "Join Mesh Network" on page See "Join Mesh Network" on page 33 for more information..)

A flashing antenna means the MeshGuard is in Router Mode (RTR), and the radio is always on.



# 6 Operation Modes

The MeshGuard can operate as a standard (STD) or a router-mode (RTR) device. In STD mode, the MeshGuard transmits data to the host at a set interval (the default is 30 seconds) or anytime an alarm occurs. In RTR mode, the MeshGuard receives data in real time, and it can also work as a router as needed to relay data from STD devices back to the host.

Note: Operating the MeshGuard in RTR mode reduces battery life.

The interval can be changed in Programming Mode. See page See "Programming Mode" on page 21 for more information. for details.

In addition, there is a Detection Mode for standard operation, Programming Mode for making changes to values (such as the High Alarm, etc.), Diagnostic Mode (for servicing and checking the sensor, etc.), and Diagnostic Programming Mode, which is for selecting between STD & RTR modes, etc.


## Detection Mode

The MeshGuard can operate in fixed or portable mode. Whenever you start MeshGuard, it is automatically in fixed Detection Mode, which is the default.


The MeshGuard displays the current reading:



Pressing [MODE] steps through the Detection Mode screens:




OR (for LoRa)




Press [MODE], and it displays the sensor type:



Press [MODE], and it alternates between EUI (Extended Unique Identifier) and its value:



Press [MODE], and it alternates between Pan and ID (Personal Area Network Identifier) and its value:




Press [MODE] to return to the detector reading:



## Manually Sending Data


While the MeshGuard typically sends reading data to the network on a fixed interval, you can send the data anytime.

When the monitor is connected to the network, press the [Y/+] key. The screen displays “lni” and “nEt” one time, and the monitor sends the current sensor data, and returns to the detector reading.



## Detection Mode (When Portable Mode Is Enabled)

When Portable Mode is enabled (see page See "Fixed Or Portable Operation Selection" on page 39 for more information.), pressing [MODE] steps through three more screens, STEL, TWA, and Peak:




The initial screen is the reading display:




Press [MODE], and it displays STEL. The STEL (short-term exposure limit) is the average reading of the gas concentration for the last 15 minutes.


Note: The STEL reading does not appear until 15 minutes have elapsed. If the MeshGuard has not been on for 15 minutes, it displays three dashes:



Press [MODE], and it displays TWA. The TWA (time-weighted average) is the accumulated reading of the gas concentration, divided by 8 hours, since the monitor was turned on.



Press [MODE], and the display indicates the Peak reading by alternating between “P” (for “Peak”) and a numerical value:



Press [MODE] to return to the current reading:



## Programming Mode

Programming Mode allows you to perform any of the following actions (listed in order of appearance):


- Calibrate the MeshGuard
- Changing Preset Limits or Span Gas Values
- Set Pan ID
- Join network or Channel
- Choose communication interval

The menus accessed in Programming Mode are:


- Zero Calibration
- Span Calibration
- High Alarm
- Low Alarm
- STEL (Portable Mode only)
- TWA (Portable Mode only)
- Set Span Value
- Pan ID
- Join Network or Channel
- Communication interval


### Entering Programming Mode

To enter the Programming Mode, press [MODE] and [N/-] for 3 seconds. “Pro” appears in the display:



Pressing [N/-] steps you through all the screens and then returns to the first programming display:






Each display alternates between its name and a status message or value.

Note: You can exit Programming Mode at any time by pressing [MODE]. Also, if you do not make a change within one minute, the MeshGuard exits Programming Mode and returns to Detection Mode. Settings can be changed as follows:

1. When a menu is selected, it flashes between two screens. For example:



2. Press [MODE] to exit Program Mode and return to Detection Mode, or press [N/-] to advance to the next menu.
3. Press [Y/+ ] to enter. The LCD displays “go.”



## Exiting Programming Mode

You may exit Programming Mode anytime and return to Detection Mode in either of these two ways:

- Press [MODE]. MeshGuard exits Program Mode and shows the current reading in Detection Mode.
- Do not press any buttons for 1 minute. MeshGuard automatically exits Programming Mode and returns to Detection Mode, showing the current reading.




## Zero Calibration

When “CAL” and “go” are displayed in alternation, and “ZERO” is shown, the MeshGuard is ready to perform a zero calibration.



Press [Y/+]. The LCD displays “go.”




The display counts down from 10 to 0.



After the countdown reaches 0, the LCD displays “dn,” for “done.” The reading should show 0 (zero). Otherwise, repeat the zero calibration.




Note: To stop zero calibration before the countdown reaches 0, press any key. The LCD displays “no” and advances to the next programming menu, Span calibration.



## Span Calibration

“CAL” and “go” flash in alternation, and “SPAN” is shown. The MeshGuard is now ready to perform a span calibration.




To start calibration, press [Y/+]. The LCD displays “go.”



The MeshGuard waits for 10 seconds so that you have time to connect the calibration gas. Connect the calibration gas adapter to the MeshGuard, and connect the gas cylinder to the adapter. Start the flow of gas.

When the gas flow starts, the LCD displays “gAS” and the span concentration value.




The MeshGuard now counts down to 0.


Note: The countdown time varies according to the type of sensor used in the MeshGuard.




After counting down and reaching 0, the LCD displays “dn.” The reading should be the span concentration value. Otherwise, the span calibration should be repeated.



If the MeshGuard does not detect gas after counting down to 0, the LCD displays “Err” (for “error”). The LED glows red and the buzzer sounds to provide extra warning. The MeshGuard automatically returns to the span calibration display. In this case, you should attempt another calibration. If the span calibration fails a second calibration, the sensor may need to be replaced.




Note: To stop span calibration before the countdown reaches 0, press any key. The LCD displays “no” and advances to the next programming menu, Change High Alarm.



## Change High Alarm

At the menu for changing the High Alarm setting, “Set” and “go” flash in alternation, and both “HIGH” and “ALARM” are shown.



Note: It is not recommended to increase the High Alarm setting above the factory default value.

Note: The High Alarm value varies, depending on different sensor types.

Press [Y/+] to enter and change the setting. Press [MODE] to go back to Detection Mode or [N] to advance to the next menu.

The LCD displays the current value. Change the value if necessary.



To change the value:

1. Press [Y/+] to increase the number and [N/-] to decrease it.
2. Press [MODE] to advance to the next digit.
3. After moving to the last digit and making changes, press [MODE]. A question mark (?) is shown in the display, asking if you want to save the change.
  - Press [Y/+] for yes. The message “dn” means the change is done.
  - Press [N/-] for no. A “no” message means that the change was abandoned.
  - Press [MODE] to return to the first digit.

## Change Low Alarm

At the Change Low Alarm menu, “Set” and “go” flash in alternation, and “LOW” and “ALARM” are visible in the display.



Note: It is not recommended to increase the Low Alarm setting above the factory default value.

Note: The Low Alarm value varies by sensor type.

Press [Y/+] to enter and change the setting. Press [MODE] to exit and return to Detection Mode or [N] to advance to the next menu.

The LCD displays current value. Change the value if necessary.



To change the value:

1. Press [Y/+] to increase the number and [N/-] to decrease it.
2. Press [MODE] to advance to the next digit.
3. After moving to the last digit and making changes, press [MODE]. A question mark (?) is shown in the display, asking if you want to save the change.
  - Press [Y/+] for yes. The message “dn” means the change is done.
  - Press [N/-] for no. A “no” message means that the change was abandoned.
  - Press [MODE] to return to the first digit.

### Change STEL setting (Portable Mode Only)

Note: This menu is only available when the MeshGuard is in Portable Mode. If it is in Fixed Mode, you will not see this menu and cannot change its settings.

“Set” and “go” flash in alternation, and “STEL” is shown.



Note: It is not recommended to increase the STEL Alarm setting above the factory default value.

Note: The STEL Alarm value varies by sensor type.

Press [Y/+] to enter and change the setting, [MODE] to exit and return to Detection Mode, or [N/-] to advance to the next menu.

The LCD displays current value. Change the value if necessary.




To change the value:

1. Press [Y/+] to increase the number and [N/-] to decrease it.
2. Press [MODE] to advance to the next digit.
3. After moving to the last digit and making changes, press [MODE]. A question mark (?) is shown in the display, asking if you want to save the change.
  - Press [Y/+] for yes. The message “dn” means the change is done.
  - Press [N/-] for no. A “no” message means that the change was abandoned.
  - Press [MODE] to return to the first digit.

## Change TWA setting (Portable Mode Only)

Note: This menu is only available when the MeshGuard is in Portable Mode. If it is in Fixed Mode, you will not see this menu and cannot change its settings.

“Set” and “go” flash in alternation, and “TWA” is shown.



Note: It is not recommended to increase the TWA Alarm setting above the factory default value.

Note: The TWA Alarm value varies, depending on different sensor types.

Press [Y/+] to enter and change the setting, [MODE] to exit and return to Detection Mode, or [N/-] to advance to the next menu.

The LCD displays the current value. Change the value if necessary.




To change the value:

1. Press [Y/+] to increase the number and [N/-] to decrease it.
2. Press [MODE] to advance to the next digit.
3. After moving to the last digit and making changes, press [MODE]. A question mark (?) is shown in the display, asking if you want to save the change.
  - Press [Y/+] for yes. The message “dn” means the change is done.
  - Press [N/-] for no. A “no” message means that the change was abandoned.
  - Press [MODE] to return to the first digit.

## Change SPAN value


“Set” and “go” flash in alternation, and “SPAN” and a gas cylinder icon are shown.



Note: The Span value varies, depending on different sensor types.

Press [Y/+] to enter and change the setting, [MODE] to exit and return to Detection Mode, or [N/-] to advance to the next menu.

The LCD displays the current value. Change the value if necessary.



To change the value:

1. Press [Y/+] to increase the number and [N/-] to decrease it.
2. Press [MODE] to advance to the next digit.
3. After moving to the last digit and making changes, press [MODE]. A question mark (?) is shown in the display, asking if you want to save the change.
  - Press [Y/+] for yes. The message “dn” means the change is done.
  - Press [N/-] for no. A “no” message means that the change was abandoned.
  - Press [MODE] to return to the first digit.

## Change Pan ID

Press [Y/+] to enter the menu to make changes to the value.

1. Press [Y/+] to increase the number and [N/-] to decrease it.
2. Press [MODE] to advance to the next digit.
3. After moving to the last digit and making changes, press [MODE]. A question mark (?) is shown in the display, asking if you want to save the change.
  - Press [Y/+] for yes. The message “dn” means the change is done.
  - Press [N/-] for no. A “no” message means that the change was abandoned.
  - Press [MODE] to return to the first digit.



## Join Mesh Network

Press [Y/-] to initiate joining a network. Three bars flash in sequence while it searches. When it is done, it alarms once and displays “dn” for “done.”

## Change Channel (If available. For LoRa)


Press [Y/+] to enter the menu to make changes to the value.

1. Press [Y/+] to increase the number and [N/-] to decrease it.
2. Press [MODE] to advance to the next digit.
3. After moving to the last digit and making changes, press [MODE]. A question mark (?) is shown in the display, asking if you want to save the change.
  - Press [Y/+] for yes. The message “dn” means the change is done.
  - Press [N/-] for no. A “no” message means that the change was abandoned.
  - Press [MODE] to return to the first digit.

## Change Communication Interval

This menu allows you to change the interval between wireless transmissions. “SET” and “ItUL” flash, to indicate that you can change the interval. The interval can be set to 10, 30, 60, 300, or 600 seconds.

Note: The default interval is 30 seconds.



Press [Y/+] to enter and change the setting, [MODE] to exit and return to Detection Mode, or [N/-] to advance to the next MENU.



# 7

## Diagnostic Mode

Diagnostic Mode provides raw data from sensors and about settings.


### Entering Diagnostic Mode

Note: To enter Diagnostic Mode, you must begin with the MeshGuard turned off.

Press and hold [Y/+] and [MODE] until the MeshGuard starts.

The instrument goes through a brief startup, and then displays “dIA” to indicate it is in Diagnostic Mode. It then switches to showing raw data for the sensor (the display shows “rAU” followed by a number).

The following chart shows how to navigate Diagnostic Mode (pressing N/- repeatedly steps through the screens):



## Exiting Diagnostic Mode

Note: You can exit Diagnostic Mode and enter Programming Mode and calibrate the MeshGuard as usual by pressing both [MODE] and [N/-] for three seconds.


Note: You can exit Diagnostic Mode and enter Detection Mode by pressing [MODE] and [Y/+] together for three seconds, or by turning it off and on again. It is not recommended to use the detector in Detection Mode accessed through the Diagnostic Mode. The unit must be turn off and started in normal operation mode.

## Diagnostic Mode Readings

In Diagnostic mode, you can step through readings by pressing [N/-].

### Sensor Raw Count

Sensor Raw Count is indicated by “rAU” followed by a number.



- Press [N/-] to advance to the next reading.

### Battery Raw Count

Battery Raw Count is indicated by “bAt” followed by a number.



- Press [N/-] to advance to the next reading.

### Temperature Raw Count


Temperature Raw Count is indicated by “tNp” followed by a number.



- Press [N/-] to advance to the next reading.

## Zero Raw Count

Zero Raw Count is indicated by “OrC” followed by a number.




- Press [N/-] to advance to the next reading.

## Calibration Delta Counts

Calibration Delta CTS is indicated by “CdC” followed by a number.

- Press [N/-] to return to the first raw count.



## Diagnostic Mode Programming

You can enter a special programming mode from Diagnostic Mode in order to perform advanced programming functions. These include:


- Enable Portable Mode
- Enable Radio

- Enable STD or RTR
- Return MeshGuard to original factory settings
- Enable/disable audible and visible alarms

Note: When the MeshGuard is in this programming mode, if you do not make a change or press a key for 60 seconds, it reverts to the standard Diagnostic Mode.

Important! After you make changes in Diagnostic Mode, it is recommended that you turn off the MeshGuard and turn it on again before using it. Enter this programming mode by first entering Diagnostic Mode. Refer to "Entering Diagnostic Mode," page See "Entering Diagnostic Mode" on page 34 for more information..


Step through the menus by pressing [N/-]. Exit by pressing [MODE], and then shutting off the MeshGuard and restarting it.



### Fixed Or Portable Operation Selection

The first menu is for setting the MeshGuard for fixed or portable operation. In Portable Mode, STEL, TWA, and Peak readings are included.


“SEt” and “ Ptb” flash in alternation, to indicate that the MeshGuard can now be set as fixed or portable. The default value is “fixed.”



Press [Y/+] to enter and change the setting, [MODE] to exit and return to Detection Mode, or [N/-] to go to the next menu.

The LCD displays the current value (enabled or disabled). Change the value if necessary by pressing [Y/+] or [N/-]. Press [MODE] to enter your selection. Press [Y/+] to accept at this screen.

Note: “dIS” means fixed (Portable Mode disabled) and “En” means portable (Portable Mode enabled).



### Radio Enable/Disable

The next menu is for setting turning the MeshGuard’s radio on or off.

“SEt” and “rdo” flash in alternation, to indicate that the MeshGuard radio can be turned on (enabled) or off (disabled). The default value is “on.”



Press [Y/+] to enter and change the setting, [MODE] to exit and return to Detection Mode, or [N/-] to go to the next menu.

The LCD displays the current value (enabled or disabled). Change the value if necessary by pressing [Y/+] or [N/-]. Press [MODE] to enter your selection. Press [Y/+] to accept at this screen.

Note: “dIS” means disabled (radio off) and “En” means on (radio on).





## **Std Enable or Rtr Enable**

Press [Y/+] to toggle the setting from Std to Rtr, and vice versa. Refer to “Operation Modes” on page See "Operation Modes" on page 17 for more information..

## **Factory Setting**

Press [Y/+] to return the MeshGuard to its original factory settings.

Note: This function clears all custom settings and returns all settings their factory default values. This cannot be undone.

## **Audible & Visible Alarm Enable/Disable**

Press [Y/+] to toggle between the MeshGuard’s audible and visible alarms turned on and off.

# 8

## Sensor And Battery Replacement



3-pin end

Hexagonal end

Sensor compartment


Battery compartment

Sensor and battery removal tool  
(P/N 019-2044-000)




## Battery replacement

1. Use the 3-pin end of the tool to unscrew and open the battery cover by turning it counterclockwise.
2. Remove the battery.
3. Insert the new battery with its positive (“+”) pole towards inside of the unit.
4. Replace the battery cover by turning it clockwise with the 3-pin end of the tool.



Battery

Battery cover




Note: Only change internal battery in a safe location and use the battery RAE Systems provided (P/N: 500-0111-000), model ER34615 or XL-205F.

After changing the battery, wait at least 60 seconds before turning the MeshGuard on.

## Sensor Filter Replacement

1. Use the 3-pin end of the tool to unscrew and open the filter holder by turning it counterclockwise.
2. Remove and discard the filter.
3. Place a new filter inside the monitor.
4. Replace the filter holder by turning it clockwise with the 3-pin end of the tool.



Filter

Filter holder

## Sensor Replacement


1. Use the 3-pin end of the tool to unscrew and open the filter holder at the bottom of the monitor.

Sensor

Sensor cover

Filter

Filter holder



2. Use the hexagonal end of the tool to open the remove the sensor cover, turning counterclockwise.
3. Pull the old sensor out.
4. Gently push a new sensor into the compartment.

Important! Ensure that the RAE Systems part number matches the sensor that was removed.

WARNING! Use only the same sensor model as the one installed when the monitor was purchased.

5. Replace the sensor compartment cover using by turning it clockwise, using the hexagonal end of the tool.
6. Replace the filter holder by turning it clockwise, using the 3-pin end of the tool.

Note: Always recalibrate the MeshGuard after service to ensure functionality.

# Troubleshooting

Failure Symptom	Cause	Solution
	Battery charge too low	Replace battery
Cannot turn on	Battery has been changed	Wait at least 60 seconds to turn on MeshGuard
Abnormally high reading	New battery needs to be discharged before use	Check RAE Systems web site for information on batteries
	Incorrect gas calibration	Recalibrate
“- 0” Alarm	Sensor low sensitivity to calibration gas	Replace the sensor
	Sensor zero drift	Perform zero calibration
Controller cannot receive the MeshGuard’s signal	Too much distance between the MeshGuard and the controller.	The distance should be 300 m, line of sight. Deploy RTR MeshGuard or MeshGuard Router(s).
	There is an obstruction between the MeshGuard and the controller.	Relocate the MeshGuard or deploy RTR MeshGuard or MeshGuard Router(s).
	Controller does not receive completed data packet	Press [Y/+] on the detector to force it to send data packets
	Battery is low	Replace battery
	MeshGuard and controller have different Pan ID numbers	Set both units to have the same Pan ID number
No Antenna Icon	There is no reader or	Move the MeshGuard closer to a

controller nearby.

The controller or reader's network has changed.

working controller or reader.

Perform the network searching function in diagnostic mode.

The MeshGuard is out of its RF range.

Move the MeshGuard close to a working controller or reader and Press [Y/+]

Replace battery






Battery is low

Turn MeshGuard off and on again.

Others


Consult RAE Systems Customer Service.

## Alarm Signal Summary

Alarm Mode	When	LCD	Buzzer & LED
Over Range	Gas readings exceed the maximum value of the sensor		3 beeps per second
High Alarm	> high alarm setting		3 beeps per second
Low Alarm	> low alarm setting		2 beeps per second
TWA	> TWA setting		1 beep per second
STEL	> STEL Setting		1 beep per second




Zero Drift < 0 ppm



1 beep per second

Battery Low < 3.2V



1 beep per minute

Battery Exhausted < 3.1V



1 beep per second

Two methods for mounting MeshGuard make it easy to install. The first method uses a magnet that screw onto the rear of the MeshGuard, making ideal for moving from one location to another. The second method uses a specially designed stainless-steel enclosure that is permanently mounted. It protects the MeshGuard from damage in industrial settings.

## Magnet-Mount Installation

Magnet


For

Mounting

MeshGuard

Rear of

MeshGuard



This magnet is powerful enough to support the MeshGuard when it is placed against a flat steel or iron surface.

Important! Keep the magnet away from computer hard drives. The strong magnet can corrupt or erase data on these.


## Fixed Installation

Four reinforced holes in the rear of the enclosure allow for a screw to pass through to the mounting brackets.


Mounting

Holes


Front  
View  
Sensor  
Cover  
Side  
View



The enclosure can be mounted to a vertical or horizontal pole.




Vertical pole





Horizontal pole

Slip the screws through the two holes that are side by side in order to mount the enclosure to a vertical pole. Otherwise slip the screws through the two vertically aligned holes to attach the enclosure to a horizontal pole.

Loosely assemble the clamp parts around the pole. Note that the screws have nuts that fit into the clamp parts. The clamp parts are designed to hold the nut so that you do not need to use a wrench. Hand-tighten the parts until snug.



Tighten the hex screws from the front of the enclosure:




Once the clamp parts and the enclosure are securely held against the pole, stop tightening.

Note: The pole must be between 25mm (1") and 63mm (2.5") in diameter.

Next, place the MeshGuard into the enclosure:

1. Lift up the hinged cover of the enclosure.
2. Slide the MeshGuard into the enclosure from the top.
3. Close the cover of the enclosure.
4. Insert the hex screw into the cover's locking portion, and tighten it.
5. The MeshGuard is now ready to use.




Note: The sensor cover on the bottom of the enclosure can be removed so that the filter and sensor can be inspected without removing the MeshGuard from the enclosure. Simply pull off the cover and follow the maintenance procedures in this guide.


## Magnetic Mount Alternative Installation

The magnet-mount disc can be attached to the steel enclosure instead of the clamps. This approach provides the protection of the enclosure with the ease of installation afforded by the magnetic mounting.

1. Insert screw through magnetic disc.
2. Place the magnetic disc over the bottom hole on the rear of the enclosure.
3. Tighten the screw until the disc is snug.



Side View



Rear View



## MeshGuard Sensor Specifications

Sensor	Normal Range	Resolution	Response Time	Temperature Range
H2S	0 to 100 ppm	0.1 ppm	T <sub>90</sub> < 30 sec T <sub>10</sub> < 30 sec	-20° C to +50° C (-4° F to 122° F)
H2S	0 to 1000 ppm	1 ppm	T <sub>90</sub> < 45 sec T <sub>10</sub> < 45 sec	-40° C to +50° C (-40° F to 122° F)
LEL/ LEL IR*	0 to 100% LEL	1% LEL	T <sub>90</sub> < 30 sec T <sub>10</sub> < 30 sec	-40° C to +50° C (-40° F to 122° F)
CO	0 to 2000 ppm	1 ppm (0 to 2000 ppm)	T <sub>90</sub> < 30 sec T <sub>10</sub> < 30 sec	-40° C to +50° C (-40° F to 122° F)
CO2 IR	0 to 5% vol 0 to 100% vol	0.01% vol 0.1% vol	T <sub>90</sub> < 30 sec T <sub>10</sub> < 30 sec	-40° C to +50° C (-40° F to 122° F)
O2	0 to 25%	0.10%	T <sub>90</sub> < 15 sec T <sub>10</sub> < 15 sec	-20° C to +50° C (-4° F to 122° F)
NH3	0 to 100 ppm	1 ppm	T <sub>90</sub> < 30 sec T <sub>10</sub> < 90 sec	-20° C to +50° C (-4° F to 122° F)
CL2	0 to 10 ppm	0.1 ppm	T <sub>90</sub> < 30 sec T <sub>10</sub> < 30 sec	-20° C to +50° C (-4° F to 122° F)
SO2	0 to 20 ppm 0 to 100 ppm	0.1 ppm 1 ppm	T <sub>90</sub> < 60 sec T <sub>10</sub> < 60 sec	-20° C to +50° C (-4° F to 122° F)

HCN	0 to 50 ppm	0.5 ppm	T <sub>90</sub> < 200 sec T <sub>10</sub> < 200 sec	-20° C to +50° C (-4° F to 122° F)
NO	0 to 250 ppm	0.5 ppm	T <sub>90</sub> < 45 sec T <sub>10</sub> < 45 sec	-20° C to +50° C (-4° F to 122° F)
PH <sub>3</sub>	0 to 20 ppm	0.1 ppm	T <sub>90</sub> < 60 sec T <sub>10</sub> < 60 sec	-20° C to +50° C (-4° F to 122° F)
HCL	0 to 15 ppm	1 ppm	T <sub>90</sub> < 200 sec T <sub>10</sub> < 200 sec	-20° C to +50° C (-4° F to 122° F)
ETO-A	0 to 100 ppm	1 ppm	T <sub>90</sub> < 45 sec T <sub>10</sub> < 10 sec	-20° C to +50° C (-4° F to 122° F)
ETO-B	0 to 10 ppm	0.1 ppm	T <sub>90</sub> < 45 sec T <sub>10</sub> < 10 sec	-20° C to +50° C (-4° F to 122° F)
ETO-C	0 to 500 ppm	10 ppm	T <sub>90</sub> < 45 sec T <sub>10</sub> < 10 sec	-20° C to +50° C (-4° F to 122° F)
NO <sub>2</sub>	0 to 20 ppm	0.1 ppm	T <sub>90</sub> < 45 sec T <sub>10</sub> < 10 sec	-20° C to +50° C (-4° F to 122° F)
HF	0 to 10 ppm	0.1 ppm	T <sub>90</sub> < 200 sec T <sub>10</sub> < 200 sec	-20° C to +50° C (-4° F to 122° F)

- FTD-3000 only.

Ordering Replacement Parts: If you need replacement parts, a list is available online:  
<http://www.raesystems.com>

Year Of Manufacture

To identify the year of manufacture, refer to the serial number of the instrument.

The second to last digit in the serial number indicates the year of manufacture. For example, “M” indicates the manufacturing year is 2010.

Letter	Year
V	2018
W	2019
A	2020
B	2021
C	2022
D	2023
E	2024
F	2025
G	2026
H	2027
I	2028
J	2029
K	2030

# Contact



## Contact Us

Corporate Headquarters

RAE Systems by Honeywell

300 S Tryon St. Suite 500

Charlotte, NC 28202, USA

Phone : +1 888 749 8878

Fax : +1 817 274 8321

[rae-callcenter@honeywell.com](mailto:rae-callcenter@honeywell.com)

## Worldwide Sales Offices

USA/Canada 1.877.723.2878

Europe +800.333.222.44/+41.44.943.4380

Middle East +971.4.450.5852

China +86.10.5885.8788-3000

Asia Pacific +852.2669.0828

**Honeywell**

© June 2022

Tuesday, July 19, 2022

D01-4002-000\_EN\_RevK\_MeshGuard\_UM