NOTIFIER®
by Honeywell

12 Clintonville Road
Northford, CT 06472-1653 USA
203-484-7161 • FAX 203-484-7118
www.notifier.com

BB-17 Battery Box
Product Installation Document


PN 15535:B2 3/3/2011 11-146

Overview

The BB-17 Battery Box may be used to house up to two 17AH batteries. It mounts directly below the FACP cabinet. Knockouts are provided on the top surface of the battery box.

Inventory

The BB-17 Battery Box comes with a cabinet, a box cover, and four self-threading screws.



Installation

1. Remove knockouts in the bottom of the FACP cabinet and the top of the BB-17 cabinet.
2. Align knockouts in FACP and BB-17. Anchor the BB-17 to the wall using 1/4" diameter holes in back of cabinet.
3. Run conduit between the BB-17 cabinet and the FACP cabinet. Make sure there is at least 6" (15.24 cm) of clearance between the BB-17 and the FACP (see illustration at left).
4. Run battery cable through conduit from FACP into battery box. Connect cable to batteries.
5. Secure the BB-17 cover to cabinet using supplied self-threading screws.

