ONYXWORKS V4.62 OR HIGHER

NEW ORDER – UL-LISTED WORKSTATION

	PHASE 1 - ORDERING	PHASE 2 - CONFIGURATION	PHASE 3 - INSTALLATION	PHASE 4 - MAINTAIN
NEW ORDER				
UL-Listed Workstation ***(w/PC Network Card inside UL PC)***	**1)** Submit order to Honeywell Customer Service.	Initial registration - performed by factory. ***To access Workstation Configuration Tool, select Facilities Monitoring > Configuration Tool in UL PC Windows Start Button***	**1)** When ready to install workstation, add workstation on CLSS Site Manager and generate 5-year software license. ***(5-year license included in upfront purchase price for UL Listed workstation)*** **Enables Workstation Operability.** **2)** Activate subscription license on ONYXWorks workstation. See Section 3 in ONYXWorks manual - posted on ESD website.	**1)** After 5 years, purchase renewal software maintenance license on CLSS Site Manager. Good for 5 years (XXX tokens). **2)** Activate renewal license on ONYXWorks workstation.
			www.fire.honeywell.com	
			Note: *There is a self-paced online training module,* ***Workstation Licensing****, located under ⓘ in the upper right-hand Navigation bar on Site Manager. The training module explains how to generate the ONYXWorks software license.*	

Honeywell Confidential - ©2019 by Honeywell International Inc. All rights reserved.

ONYXWORKS V4.62 OR HIGHER

NEW ORDER – NON-LISTED SOFTWARE

	PHASE 1 - ORDERING	PHASE 2 - CONFIGURATION	PHASE 3 - INSTALLATION	PHASE 4 - MAINTAIN
NEW ORDER				
Non-Listed (bring own PC)	**1)** Register CLSS account **2)** Purchase tokens on CLSS Site Mgr **3)** Use tokens to buy Workstation License Feature(s) on CLSS Site Manager.	**1)** Download ONYXWorks software and manual - posted on ESD website. **See Section 3 in ONYXWorks manual.** **2)** Install ONYXWorks software on PC. **3)** Add ONYXWorks workstation on CLSS Site Manager, assign (one-time) activation license feature. **4)** Activate one-time license on ONYXWorks workstation. **Enables access to Workstation Configuration Tool.**	**1)** When ready to install workstation, assign 5-year software maintenance license subscription on CLSS Site Manager. **2)** Activate subscription license on ONYXWorks workstation. **Enables Workstation Operability.**	**1)** After 5 years, purchase renewal software maintenance license on CLSS Site Manager. Good for 5 years (XXX tokens). **2)** Activate renewal license on ONYXWorks workstation.
	www.fire.honeywell.com			
	Note: *There is a self-paced online training module,* ***Workstation Licensing*** *, located under ⓘ in the upper right-hand Navigation bar on Site Manager. The training module explains how to purchase tokens to buy ONYXWorks non-listed software and how to generate the ONYXWorks software license.*			

Honeywell Confidential - ©2019 by Honeywell International Inc. All rights reserved.

ONYXWORKS V4.62 OR HIGHER

UPGRADE – UL-LISTED WORKSTATION *(PURCHASED IN 2015 OR LATER)*

	PHASE 1 - ORDERING	PHASE 2 - UPGRADE LICENSE	PHASE 3 - MAINTAIN
EXISTING INSTALL - UPGRADE FROM [V4.50 or LOWER] TO V4.62 OR HIGHER			
UL-Listed Workstation (**Purchased in 2015 or later**) *(w/PC Network Card inside UL PC)*	**1)** Check back of workstation - Label Part # **51-HFS12-001** to confirm workstation is upgradable. **2)** Check Workstation O/S. If Windows 7, place order with Comark for part number **WIN10-UG.** (Win10 Upgrade Kit)	**1)** Download ONYXWorks software, ONYXWorks manual and Key Migrator Tool Software - posted on ESD Website **2)** Refer to **Appendix A - ONYXWorks Manual** for steps to upgrade. Note: Access to CLSS Site Manager is required.	**1)** After 5 years, purchase renewal software maintenance license on CLSS Site Manager. Good for 5 years (XXX tokens). **2)** Activate renewal license on ONYXWorks workstation.
		www.fire.honeywell.com	
		Note: *There is a self-paced online training module,* ***Workstation Licensing*** *, located under ⓘ in the upper right-hand Navigation bar on Site Manager. The training module explains the steps to upgrade existing ONYXWorks systems and how to generate the ONYXWorks software license.*	

Honeywell Confidential - ©2019 by Honeywell International Inc. All rights reserved.

ONYXWORKS V4.62 OR HIGHER

UPGRADE – UL-LISTED WORKSTATION *(PURCHASED BEFORE 2015)*

	PHASE 1 - ORDERING	PHASE 2 - CONFIGURATION	PHASE 3 - INSTALLATION	PHASE 4 - MAINTAIN
EXISTING INSTALL - UPGRADE FROM [V4.50 or LOWER] TO V4.62 OR HIGHER				
UL-Listed Workstation (**Purchased BEFORE 2015**) *(w/PC Network Card inside UL PC)*	Order new UL Listed ONYXWorks workstation: **1)** Submit order to Honeywell Customer Service. Note: Price is posted in Price Books.	Initial registration - performed by factory. ***To access Workstation Configuration Tool, select Facilities Monitoring > Configuration Tool in UL PC Windows Start Button***	**1)** When ready to install workstation, add workstation on CLSS Site Manager and generate 5-year software license. ***(5-year license included in upfront purchase price for UL Listed workstation)*** **Enables Workstation Operability.** **2)** Activate subscription license on ONYXWorks workstation. See Section 3 in ONYXWorks manual - posted on ESD website.	**1)** After 5 years, purchase renewal software maintenance license on CLSS Site Manager. Good for 5 years (XXX tokens). **2)** Activate renewal license on ONYXWorks workstation.
			www.fire.honeywell.com	
			Note: *There is a self-paced online training module,* ***Workstation Licensing****, located under ⓘ in the upper right-hand Navigation bar on Site Manager. The training module explains the steps to upgrade existing ONYXWorks systems and how to generate the ONYXWorks software license.*	

Honeywell Confidential - ©2019 by Honeywell International Inc. All rights reserved.

ONYXWORKS V4.62 OR HIGHER

UPGRADE – NON-LISTED SOFTWARE

<table>
<tr><th></th><th>PHASE 1 - ORDERING</th><th>PHASE 2 - UPGRADE LICENSE</th><th>PHASE 3 - MAINTAIN</th></tr>
<tr><td>EXISTING INSTALL - UPGRADE FROM [V4.50 or LOWER] TO V4.62 OR HIGHER</td><td></td><td></td><td></td></tr>
<tr><td rowspan="2">Non-Listed (bring own PC)</td><td>No action needed.</td><td>1) Download ONYXWorks software, ONYXWorks manual and Key Migrator Tool Software - posted on ESD Website
2) Refer to Appendix A - ONYXWorks Manual for steps to upgrade.
<u>Note</u>: Access to CLSS Site Manager is required.</td><td>1) After 5 years, purchase renewal software maintenance license on CLSS Site Manager. Good for 5 years (XXX tokens).
2) Activate renewal license on ONYXWorks workstation.</td></tr>
<tr><td></td><td colspan="2">www.fire.honeywell.com

<u>Note</u>: There is a self-paced online training module, Workstation Licensing, located under ⓘ in the upper right-hand Navigation bar on Site Manager. The training module explains the steps to upgrade existing ONYXWorks systems and how to generate the ONYXWorks software license.</td></tr>
</table>

Honeywell Confidential - ©2019 by Honeywell International Inc. All rights reserved.