SMS Technical Bulletin	STB 10136

To: Gent by Honeywell & System Integrators	**Date:** 23/3/2009
	Status: Active
	Type: SI

Product:
Nano RS232 port

Details:
The RS232 port on the Nano is default set to 1200 board rate. The hand held printer that can be bought with the Nano is set to 9600 board rate.
Nano's board rate can not be altered and there are no instruction with the hand held printer on how to adjust the printer board rate.

Action:
This issue is being look at, with the potential that the Nano bard rate will be altered.

If you use the hand held printer here is how to alter it's board rate to 1200

1. Start with printer off
2. Hold down mode button for 5 seconds that status LED will flash 5 times
3. Press the mode button twice, short delay, the status LED will flash 2 times.
4. Press the mode five times, short delay, the status LED will flash 5 times
5. Short delay the printer will fully power up

Name: Peter Dodge