Extinguishing Agent Release Warning Signs to comply to AS1670.5

Part number	Description
CWSO-RR-S1	Surface mount sounder, red, low profile base
CWSO-WW-S1	Surface mount sounder, white, low profile base
CWSO-RR-W1	Surface mount sounder, red, IP65
CWSO-WW-W1	Surface mount sounder, white, IP65

The example is using CWSO-XX-YY sounder

- Disable local buzzer:
  - Move enable buzzer jumper(JP4) on to 1 pin
- Enable Sounder:
  - Move enable sunder jumper(JP3)across both pins
- Set Dip Switches 1-on,2-on,3-off,4-on,5-off and 6 is volume

Note – only 1 sounder per sign can be used and Alarm current increases to 85mA stage 1 and 135mA for stage 2





