

### 1.0 Analog Sensors/Addressable Monitor Modules

The sensors, monitor modules and addressable stations listed in Tables 1 and 1A are compatible with the signaling line circuits in the FCI, E3 Series™ Control Panel, Manual P/N 9000-0574. See Table 1B for a list of compatible sensor bases. This includes the ILI-MB-E3 and ILI-S-E3.

Table 1 Approved Sensors			
Model	Description	Supervisory Current	Alarm Current
ASD-IL2F	Analog Ionization Sensor	.00030 A	.0065 A
ASD-PL2F	Analog Photoelectronic Sensor, Low Profile	.00030 A	.0065 A
ASD-PTL2F	Analog PE Sensor, Low Profile w/thermal	.00030 A	.0065 A
ASD-FILTREXF	Analog Photo. Sensor for harsh environments	.00036 A	.007 A
ADPF	Analog Photo. Sensor, Duct mount	.00036 A	.0065 A
ADPRF	Analog PE Sensor, Duct mount, w/relays	.00036 A	.0065 A
ABD-RT2F	Analog Beam Detector	.002 A	.0085 A
ABD-2F	Analog Beam Detector	.002 A	.0085 A
ATD-L2F/-RL2F	Thermal Sensor, Low Profile	.00030 A	.0065 A
ATD-HL2F	Thermal Sensor, Low Profile	.00030 A	.0065 A
MCS-Acclimate2F	Analog Multi-Criteria Sensor	.00030 A	.0065 A
Table 1-A Approved Addressable Modules, Stations			
Model	Description	Supervisory Current	Alarm Current
AMM-2F	Addressable Monitor Module	.00040 A	.0006 A
AMM-2IF	Addressable Dual Monitor Module	.00075 A	.00475 A
AMM-4F	Addressable Monitor Module	.00040 A	.00575 A
AMM-4SF	Addressable Sub-loop Module	.00030 A	.0054 A
MMI-SF	Addressable Multiple Monitor Module	.00200 A	.040 A
MMI-10F	Addressable Multiple Monitor Module	.00350 A	.055 A
MMO-RF	Addressable Multiple Output Relay Control Module	.00145 A	.032 A
MMO-6SF	Addressable Multiple Output Module	.00225 A	.035 A
AOM-2RF	Addressable Output Relay Control Module	.00030 A	.00030 A
AOM-2SF	Addressable Output Module	.00030 A	.00030 A
AOM-MUXF	Addressable Audio Evac. Module	.00035 A	.007 A
AOM-TELF	Addressable Audio Evac. Module	.0024 A	.0081 A
M500X*	Fault Isolator Module	.00045 A	.005 A (isolated)
Addressable Manual Stations			
MS-7AF	Addressable Manual Station	.00030 A	.0006 A
* Device Listed by System Sensor			

**Table 1-B Sensor Bases**

<b>Model</b>	<b>Description</b>	<b>Supervisory Current</b>	<b>Alarm Current</b>
ADB-F, FL ADB-FF, FLF	Plug-in Base	N/A	N/A
B501B, B210LP*	Plug-in Base	N/A	N/A
B501BH/T*	Sounder base	N/A	N/A
B501*	Base	N/A	N/A
B224RB/B524RB*	Relay Base	.0005 A	.0005 A
B224BI/B524BI*	Isolator Base for Style 7 Operation	.00045 A	.005 A (isolated)
ABD FILTREF	Base for FILTREF sensor	N/A	N/A
*Devices Listed by System Sensor			

**FIRE CONTROL INSTRUMENTS**

16 Southwest Park, Westwood, MA 02090 • Tel 781-471-3000 • Fax: 781-471-3099

[www.firecontrolinstruments.com](http://www.firecontrolinstruments.com)