## **Data Analytics: Interfaces Supported**

### **IDM Enterprise**

IDM Enterprise (direct software interface, no PIT required)

#### For Retail:

InfoGenesis: Hospitality http://hospitality.agilysys.com/solutions/infogenesis\_pos.aspx

Micros 3700 / 8700 / 9700: Widely used in hospitality and retail www.micros.com/Products/

Pinnacle: <a href="http://pinncorp.com/pinnacle/">http://pinncorp.com/pinnacle/</a>

NCR Advanced Checkout Solution (ACS): Widely used in supermarkets and grocery chains

www.ncr.com/products\_and\_services/point\_of\_sale/index.jsp

Retalix Scanmaster; also known as Retalix StoreNext: widely used in small chain supermarkets

http://www.retalix.com/index.cfm?pageid=544 or www.storenext.com

FOX/Neptune POS - clothing chain POS software

#### For Other Industries:

MAXPRO-Net: Allows events to be sent to MAXPRO-Net

IGT Advantage: Slot machine interface www.igt.com

IGT IVS (ticket-in; ticket-out): IGT integrates to Casinolink IVS (ticket in; ticket out) system

http://www.progressivegaming.net/pages/casinolink-wallet.html

Radiant (excl Aloha and Radiant POS for theatres): Petroleum convenience store division.

Radiant POS 6.3 C6 and above; POS 6.6 C1 and POS 6.6 C2 not supported in Compu-Touch

POS or Radiant POS v5 product lines. www.radiantsystems.com/

Wayne Nucleus Base 8 – Gas Station POS system <a href="www.wayne.com/">www.wayne.com/</a>

Jetsort – coin counting

Ballys

# **SmartPIT: Interfaces Supported**

You can use SmartPIT standalone with a DVR or with IDM Professional Edition. Smart Data Filters can be found at: <a href="http://www.honeywellvideo.com/support/downloads/downloads\_pos.html">http://www.honeywellvideo.com/support/downloads/downloads\_pos.html</a>

## For Retail:

ECR Model Number	Special Requirements to work with SmartPIT and Caveats	Sell/Buy This	SmartDataFilter to use
ANY REGISTER that sends out transaction data in serial ASCII RS232C RS 422 4 wire RS 485 2 wire		HASMPIT Use cables and adapters included with SmartPIT	Use SmartPIT to create a Custom SmartDataFilter on site Flt_Generic.flt
Casio QT-6000		HASMPIT Use cables and adapters included with SmartPIT	QT6000.flt
Casio QT-7300		HASMPIT Use cables and adapters included with SmartPIT	CasioQT7300.flt CasioQT7300_ESCPOS.flt CasioQT7300_DSP80.flt
CRS 3000		HASMPIT 1 CRS80 cable per register	CRS3000.flt
Datasym – DS6000RT		HASMPIT Use DAT60 cable	Flt_Generic.flt
Digital Dining		HASMPIT Use cables and adapters included with SmartPIT	Flt_Generic.flt
Fujitsu 2000 with IBM Printer 4610 Suremark		HASMPIT Use cables and adapters included with SmartPIT	Flt_Fujitsu2000PrinterIBM4610SureM arkv1.flt
Gilbarco G Site PC	Journal Port must be activated in ECR software	HASMPIT Plus one GLNew cable per register Cable is RJ off of journal input jack on rear panel of G site controller. If no printer is connected journal port must be activated	Gilbarco_Gilbarco_0423.flt Gilbarco_Gilbarco_GIL1.flt Gilbarco_IBM_printer.flt Gilbarco_IBM_cust3456.flt
Gilbarco Passport Call Display		HASMPIT GIPAS cable	Gilbarco_passport_CD.flt Gilbarco_Passport_GilPPCD.flt
Horizon Software	SmartPIT (MRSP)	HASMPIT HORIZ cable	Flt_Generic.flt
IBM 4694-244	Must have a printer attached and the printer must have a D9 connector	HASMPIT 1 Poley9 cable per register	Use SmartPIT to create a Custom SmartDataFilter on site OR flt_IBM4694Northern.flt

	Special Requirements to work with SmartPIT and		SmartDataFilter
ECR Model Number	Caveats	Sell/Buy This	to use
ICL 2000TP (Fujitsu)		HASMPIT 1 ICL20 cable/register	Flt_Generic.flt
Maitre 'D	Rapid Eye Only	HASMPIT Use cables and adapters included with SmartPIT	Flt_MaitreDMultiplexedPOSDataToR E.flt
Micros 3700		HASMPIT Use cables inc w/ SP	Micros3700.flt
Micros 8700	Printer have RS232 be serial	HASMPIT MIC87 cable	Flt_MIC8700_MIC8700.flt
NCR 7445 Scanmaster		HASMPIT Use NCR7445 Cable	Flt_NCR7445Scanmaster.flt
NCR 7452 Scanmaster		HASMPIT Use cables and adapters included with SmartPIT	Flt_NCR_74XXScanmaster.flt
NCR 7453-1000	Security camera Port1 on NCR needs to be enabled	HASMPIT Use cables and adapters included with SmartPIT	Flt_Generic.flt
NCR 7456-1300	Security camera Port1 on NCR needs to be enabled	HASMPIT Use cables and adapters included with SmartPIT	Flt_Generic.flt
NCR 7456-3200	Security camera Port1 on NCR needs to be enabled	HASMPIT Use cables and adapters included with SmartPIT	Flt_Generic.flt
NCR 7402-1262	Security camera Port1 on NCR needs to be enabled	HASMPIT Use cables and adapters included with SmartPIT	Flt_Generic.flt
NCR 7454 Touchmark		HASMPIT 1 Poley9 cable per register	NCR7454_Win_Touch.flt
NCR 74xx Scanmaster		HASMPIT 1 Poley9 cable per register	NCR_74XXScanmaster.flt
Panasonic 5500WS with external printer		HASMPIT 1 PAN5W cable	Panasonic5500.flt
Panasonic 7500 with printer		HASMPIT 1 Pan7P cable	Panasonic7500.flt
Panasonic JS-135KS		HASMPIT 1 PAN135 cable	Panaso_135KS.flt
Positouch (serial)		HASMPIT Use POSI cable	Flt_PosiTouch.flt
Radiant T160		HASMPIT 1 Poley25 cable	Flt_Radiant.flt

	Special Requirements to work with SmartPIT and		SmartDataFilter
ECR Model Number	Caveats	Sell/Buy This	to use
Samsung SPS 1000 (with printer)		HASMPIT 1 SM100P cable	Flt_Generic.flt
Samsung 5240		HASMPIT 1 SM550 cable	Flt_Generic.flt
Samsung ER-650		HASMPIT Use cables and adapters included with SmartPIT	Flt_Generic.flt
Samsung 5240		HASMPIT Use SM524 cable	Flt_Generic.flt
Samsung 6500II		HASMPIT Use cables and adapters included with SmartPIT	Flt_Samsung_6500.flt
Samsung SERA 7040		HASMPIT Use ER70 cable	Flt_Generic.flt
Sharp UP3300P	Single register application only	1 HASMPIT per register Use S3300P cable	Flt_Generic.flt
Squirrel		1 HASMPIT per register Use SQRRL cable	Flt_Generic.flt
Uniwell 7000		1 HASMPIT per register 1 UNI7T cable per register	Uniwell7000.flt
Uniwell SX-6600		1 HASMPIT per register 1 UNI66 Cable per register	UnivwellSX6600.flt
Uniwell TX-850		1 HASMPIT per register 1 UNI850 Cable per register	UniwellTX850.flt
Verifone Ruby	With external Exron printer (Super System 2)	1 HASMPIT per register 1 Veri-P cable per register	Verifone.flt
Verifone Ruby	With virtual Journal Port (Super System 2)	1 HASMPIT per register 1 Veri-P cable per register	Flt_Generic.flt
Verifone Topaz		1 HASMPIT per register. 1 Veri-P cable per register	Flt_VerfoneTopazVirtualJounal.flt
Wayne Dresser Plus 3		1 HASMPIT Per Register Plus one WPDR3 cable per register	Use SmartPIT to create a Custom SmartDataFilter on site
Wayne Nucleus NT or XP	Only works with Rapid Eye DVR OR Use Fusion AND IDM	1 HASMPIT Per Location (multiplexes the data) WNUB8T Cable	Flt_WayneNucleus.flt

# For Banking:

If you have this ATM	Requirements	SmartPIT Sales Solution
ATM Model	Requirements	A LIA CARDIT (
IP ATM using Diebold 911/912 Protocol	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Opteva 500	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Opteva 520	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Opteva 562	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Opteva 720	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Opteva 740	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Opteva 750	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Opteva 760	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold 1060	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold 1062	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold 1063	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>

If you have this ATM	Requirements	SmartPIT Sales Solution
ATM Model	Requirements	
Diebold 1064	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold 1071	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold 1072	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold 1073	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold 1074	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebolld 1077	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>
Diebold CSP 400	with network connection using IP protocol set for Diebold 911/912 protocol using ASCII characters	1 HASMPIT for up to 8 IP ATMS at same location <sup>1</sup>