



ENC5

INSTALLATION

TOP



1. Install the rack by using 4 screws in a 16"W x 6" H rectangular pattern.
2. Tighten screws to insure a flush fit on the wall. Use appropriate anchors for the material.
3. When using a PRO22E1PS, mount the power supply in the rightmost slot. Follow installation instructions provided with the 4 amp power supply.
4. Mount the PRO22IC in the next rightmost slot. All other I/O's can be placed in any slot.
5. Use the optional PRO22DCC RS485 and power distribution cable or wire each of the RSD485 and 12VDC power cables in parallel using 18ga wire.
6. Wire the PRO2200 controller and I/O using the installation manual supplied.
7. Completely check all wiring connections before powering up the system. **Make sure all power is disconnected before wiring panels!**