NOTIFIER®
FIRE SYSTEMS

VeriFire™

Medium Systems

Document 51249
11/09/2000 Rev: A
ECN 00-478

VeriFire™
Medium Systems

Overview

VeriFire™ Medium Systems software lets you upload or download programs between a PC and the following devices: AFP-100, AFP-200, AFP-300, AFP-400, AFC-600, and UZC-256.

Note: VeriFire™ is not intended for permanent connection to the fire control system.

This document contains instructions for installing *VeriFire* software and running the program's help files. The help files contain instructions for connecting a PC to the fire control device.

Minimum System Requirements

- Windows® 95, 98 or NT
- PC with a 200 MHz MMX processor and 32MB RAM (minimum)
- 256 color monitor (VGA or better)
- CD-Rom drive

VeriFire™ is a trademark of NOTIFIER Fire Systems.
Windows® is a registered trademark of Microsoft Corporation.

Installing the Software

1. Insert the *VeriFire* CD into your PC's CD-Rom drive.
2. From the Windows® Explorer, view the contents of the CD-Rom.
3. Read any *readme* files on the program disk.
4. Open the folder for the upload/download utility to be installed:

   AFP100—*VeriFire* 100 for the AFP-100
   AFP200—*VeriFire* 200 for the AFP-200
   AFP400—*VeriFire* 400 for the AFP-400
   AFC600—*VeriFire* 600 for the AFC-600
   UZC256—PK UZC-256 for the UZC-256

   Note: The directory named "CR" is for internal use only.
5. In the selected folder, double-click on *setup.exe* and follow the on-screen instructions.

Running the Program

From the Windows *Start* menu, select *Programs* and click on the appropriate icon.

Once running the program, press *F1* on your keyboard to access on-line help for details on operating the software.

51249:A 11/09/2000







NOTIFIER®
FIRE SYSTEMS

World Headquarters
12 Clintonville Road, Northford, CT 6472-1653 USA
203-484-7161 • Fax 203-484-7118
www.notifier.com

ISO 9001
CERTIFIED
ENGINEERING & MANUFACTURING

