ONYXWorks® Version 4.62 Software Release Notes

October 15, 2021

ONYXWorks Version 4.62.102 The 'VoIP Paging' feature is now included in the main application for UL-Listed workstations; this feature is no longer a separate add-on.

ONYXWorks Version 4.62.102 includes bug fixes to correct the following issues:

- An improper error message *("Import Failed. Unable to Import from a remote system configured with Test Monitoring.")* when using the Export/Import database command.
- Inclusion of invalid data keys when copying v 3.xx workstation databases to v4.xx"
- The inability to recognize Spanish-language Windows PC Administrator permissions.

- A 'pop-up' box ["File in Use"] has been added to prevent concurrent use of DXF's in AutoCAD and the Workstation Configuration Tool.

Notes:

- **N16 Inspire Panel Support** – PC Network Card (Standard or High-Speed, Wire or Fiber) in ONYXWorks Workstation is required.
- OW Version 4.30 and higher does not support HS-GW-EMPCA gateway hardware. Please refer to Technical Bulletin **TB18-05-01** – HS-GW-EMPCA for additional information.
- OW Version 4.52 and higher uses virtual key licensing. The ONYXWorks software license is deployed on CLSS Site Manager. Please refer to **ONYXWorks – Version 4.52 Launch Bulletin (November 8, 2020)** for additional information.

Requirements:

- **Windows 10 (64 bit) O/S**
- **Noti-Fire-Net version 5.0 or higher**
- **Please reference the table below for compatible embedded gateway firmware, VeriFire Tools and NOTIFIER panel firmware versions.**

Download Instructions:

1. **Download the zip file.**
2. **Save file to workstation PC.**
3. **Backup data (can use PC Monitor application).**
4. **Exit all applications on the PC.**
5. **Open the zip file.**
6. **Run setup.exe**

ONYXWorks 4.62

Product	Firmware
Windows 10 Enterprise 64-bit - UL	Ver-1809,Ver-10
Windows 10 Enterprise 64-bit- Non-UL	Ver-2004
FirstVision - Windows 10	4.62
Workstation	
ONYXWorks-WS	4.62.102
VeriFire Tools	11.40
NCM	
NCM-W-2	10.003.001
HS-NCM-W	30.16.01
HS-NCM-W-2	31.000.46
Gateway	
NFN -GW -PC-W, F	4.62.102
NFN -GW -PC-HNW-2	4.62.102
NFN -GW -PC-HNSF, HNMF	4.62.102
NFN-GW-EM-3	4.53.105
BACnet- GW-3	4.53.105
Modbus -GW	4.53.105
Notifier-Panel	
N16	1067- Ver-3
NFS3030	2.013.002
NFS2-3030	27.001.001
NCA2	27.001.001
NFS2-640 PCA	27.001.002
NFS-320PCA	27.001.002
DVC-EMPCC	8.011.005

Company Internal