

## Incini-Cone v1.1 Spares List

*Contact Eclipse for Ordering Information*

### Model IC0136

00.4360003.01	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

### Model IC0224

00.4360003.02	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

### Model IC0360

00.4360003.03	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

### Model IC0500


00.4360003.04	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

### Model IC0680

00.4360003.05	Firing Cone
00.4360004.13	Igniter Assembly
120051	Peepsight
00.4360004.03	Pilot

### Model IC0900

00.4360003.06	Firing Cone
00.4360004.17	Igniter Assembly
120051	Peepsight
00.4360004.07	Pilot



### Model IC1480

00.4360003.07	Firing Cone
00.4360004.17	Igniter Assembly
120051	Peepsight
00.4360004.07	Pilot

### Model IC1780

00.4360003.08	Firing Cone
00.4360004.18	Igniter Assembly
120051	Peepsight
00.4360004.08	Pilot

### Model IC2690

00.4360003.09	Firing Cone
00.4360004.19	Igniter Assembly
120051	Peepsight
00.4360004.09	Pilot