








Product Family
Miller Descent units (AUS)

Descent can be easily controlled by user or person on the ground.

[Visit MillerFallProtection.com >](http://MillerFallProtection.com)



Product Numbers & Ordering Information

Product Numbers	Details
 M1030015	Escape Master Box only "Highly visible, load density polyethylene deployment container. Empty container only."
 M1030016	Escape Master Complete 25M "Escape master kit. Includes: Load density polyethylene deployment container, 25mtrs of kernmantle rope, descent device fitted to rope, quick release pin on box lid for easy emergency deployment."
 M1030017	Escape Master Complete 20M "Escape master kit. Includes: Load density polyethylene deployment container, 20mtrs of kernmantle rope, descent device fitted to rope, quick release pin on box lid for easy emergency deployment."
 M1030018	Escape Master Complete 15M "Escape master kit. Includes: Load density polyethylene deployment container, 15mtrs of kernmantle rope, descent device fitted to rope, quick release pin on box lid for easy emergency deployment."
 453	"Bosun's chair, marine plywood" "The Bosuns chair is made to suit a wide variety of situations for confined space to working at height. It features a safety body belt, suspension from above the head, spreader frame, adjustable leg straps, marine plywood board seat."

Overview

Key Features

The Escape Master is a descent device which is fitted onto the side of an elevated working platform. It contains kernmantle rope and a descender for quick and easy descent from the working platform in case of an emergency. The highly visible load density polyethylene deployment container has very high impact resistance and will not shatter if it falls to the ground.

Miller Descent units (AUS)

Descent can be easily controlled by the user or person on the ground.

Recommended Industries/Use

- Agriculture
- Chemical
- Construction
- Food Services
- Forestry
- Manufacturing
- Mining
- Municipal Services
- Oil and Gas
- Steel and Metals
- Transportation
- Utilities

Hazards

- Confined Space
- Fall from height

Regulations

- Refer to AS/NZS 1891.4 for information on anchorage selection and strength.

Warranty Information

MILLER FALL PROTECTION PRODUCT TOTAL SATISFACTION ASSURANCE At Sperian Protection, we have been providing quality Miller brand fall protection equipment to millions of workers worldwide since 1945. LIMITED LIFETIME WARRANTY BACKED BY OVER 60 YEARS IN THE FALL PROTECTION BUSINESS We sincerely believe that our fall protection equipment is the best in the world. Our products endure rigorous tests to ensure that the fall protection equipment you trust is manufactured to the highest standards. Miller fall protection products are tested to withstand normal wear and tear, but are not indestructible and can be damaged by misuse. Our Limited Lifetime Warranty does not apply to normal wear and tear or abusive treatment of the product. In the unlikely event that you should discover defects in either workmanship or materials, under our Limited Lifetime Warranty, we will repair or replace the product at our expense. If a replacement is necessary and your product is no longer available, a comparable product will be substituted. Should a product issue surface, contact us at 1300 139 166 (Aust customers) or 0800 322 200 (NZ customers) Manufacturing specifications are subject to change without notice.

Specifications

Material

- Load Density Polyethylene

Lid Dimensions

- W - 202mm, L - 253mm, D - 120mm

Lower box dimensions

- W - 188mm, L - 490mm, D - 105mm

Weight

- 6.2kg (average)

Lengths available

- 15mtr, 20mtr, 25mtr

Literature & Documents

Inspection Procedure Miller Escape Master - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection/Ascenders___Descenders/15711/1033.aspx

Miller Escape Master Inspection Procedure

Instructions Miller Escape Master - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection/Ascenders___Descenders/15710/1033.aspx

Miller Escape Master Instructions

Instructions Bosuns Chair - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection/Ascenders___Descenders/15712/1033.aspx

Bosuns chair instructions

453 Bosun Chair AUS NZ 2016

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection

/Rope_Grabs___Vertical_Lifelines/4294998715/1033.aspx

453 Bosuns Chair_AUS_DS

Escape Master Emergency Decent System AUS NZ 2016

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection/Ascenders___Descenders/4294998717/1033.aspx



Miller Industry Fall Protection Guide Poster - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection/24943/1033.aspx

Industry Fall Protection Guide Post 13 Sperian Protection Australia Pty Ltd 3 Walker St, Braeside, Victoria 3195 Australia
Tel: 1300 139 166 Fax: 1300 362 491 New Zealand Tel: 0800 322 200 www.sperianprotection.com.au POLYESTER
CONSTRUCTION HARNESS WEBBING LANYARD ADJUSTABLE LANYARD MILLER ANCHOR GRIPS™ TIE-OFF ADAPTOR

Training & Proper Use

Please refer to product instructions included with the products prior to use.

Additional Information

marketing.australia@sperianprotection.com or ph: 1300 139 166

Technical Support

1300 139 166 (Aust) or 0800 322 200 (NZ)