









**Product Family**

**Primair 200 Series Hoods**

Hoods for use with Compact Air 200 Series PAPR and CF1000 Series continuous flow airline. Includes Fibre-Metal hard hat with Quick-Lok attachment for welding helmets and faceshields.



**Product Numbers & Ordering Information**

Product Numbers	Details
 PA201E01	<p><b>Primair FM 200 Hood Assembly with E2 Hard Hat</b>                  Primair Assembly with hood. Includes one disposable hood with neck seal and Quick-On loop, one E2 hard hat with ratchet and Quick-Lok connections for Fibre-Metal welding helmets and faceshields, and one package peel-away cover lens.</p>
 PA201P01	<p><b>Primair FM 200 Hood Assembly with P2 Hard Hat</b>                  Primair Assembly with hood. Includes one disposable hood with neck seal and Quick-On loop, one P2 hard hat with ratchet and Quick-Lok connections for Fibre-Metal welding helmets and faceshields, and one package peel-away cover lens.</p>
 PA202	<p><b>Replacement Hood for PA200 Series</b>                  Hood with neck seal, replacement for Primair FM 200 Series. Each replacement hood includes one Quick-On loop. (10/BX)</p>
 PA231E01	<p><b>Primair FM 200 Hood Assembly with E2 Hard Hat and Carbtex Cover</b>                  Primair Assembly with hood. Includes one disposable hood with neck seal and Quick-On loop, one flame resistant Carbtex cover, one E2 hard hat with ratchet and Quick-Lok connections for Fibre-Metal welding helmets and faceshields, and one package peel-away cover lens.</p>
 PA231P01	<p><b>Primair FM 200 Hood Assembly with P2 Hard Hat and Carbtex Cover</b>                  Primair Assembly with hood. Includes one disposable hood with neck seal and Quick-On loop, one flame resistant Carbtex cover, one P2 hard hat with ratchet and Quick-Lok connections for Fibre-Metal welding helmets and faceshields, and one package peel-away cover lens.</p>
 PA232	<p><b>Replacement Carbtex Cover for PA200 Series</b>                  Fire retardant cover for Primair FM 200 Series</p>

**Additional Information**

Replacement hoods and Carbtex cover available.

### Packaging Information

Assembly includes one hood with hardhat.

### Hazardous Materials

Not Applicable

## Overview

### Key Features

Assigned protection factor (APF) of 1000. Available with Carbtex cover for protection from welding sparks and slag. Manifold directs air over lens to reduce fogging. Primair 200 Series hoods for use with Compact Air 200 Series PAPR and CF1000 Series continuous flow airline feature a hard hat with connections for Fibre-Metal welding helmets and faceshields. Ratchet adjustment for more secure and comfortable fit.

### Recommended Industries/Use

- Chemical
- Oil and Gas
- Steel and Metals
- Welding

### Hazards

- Airborne Particulates
- Chemical

### Regulations

- Regulation - Meets ANSI Z89.1 Type 1 Class G for head protection.
- Regulation - NIOSH certified when used with North Compact Air PAPR, CF1000 supplied air assembly, and North hoses and couplers.

### Historical Brand

North

### Warranty Information

Honeywell Safety Products warrants the Primair Series to the original owner to be free from defects in materials and workmanship for a period of one (1) year from the date of original shipment from Honeywell's factory. Honeywell's obligation under this warranty will be, at Honeywell's option, to repair or replace without charge the Primair Series Hood or any of its components found by Honeywell to have been defective during the warranty period, under the following terms: 1) The warranty claim is made (i) by the owner who purchased the Primair Series Hood new from Honeywell or an authorized Honeywell Distributor, and (ii) not more than three (3) months after the end of the warranty period. 2) The Primair Series Hood or component is found by Honeywell to have been defective in normal use and service during the warranty period of one (1) year from the date of purchase by the owner. 3) The Primair Series Hood or component is returned freight prepaid to Honeywell, either to its factory or to a Honeywell authorized service center, and is thereafter returned to the owner freight collect. 4) This warranty does not apply to (i) any respirator or component found by Honeywell to have become defective as a result of any accident, alteration, misuse, abuse, or servicing with parts not approved by Honeywell; or (ii) deterioration or aging of any component made of rubber or other elastomer since such components can be adversely affected by undue exposure to heat, sun, water, chemicals, ozone or other deteriorating elements; (iii) facepiece lens, compressed-air cylinders and parts that become defective through normal use. The decision as to what constitutes normal use shall be made solely by HONEYWELL SAFETY PRODUCTS. 5) To maintain this warranty, the purchaser must perform maintenance and inspections as set forth in the Instruction Manual which shall include prompt replacement or repair of defective parts, and replacement of parts per the maintenance schedule as set forth in the User's Instructions. THE OWNER ASSUMES ALL OTHER RISKS, IF ANY, SUCH AS THE RISK OF ANY DIRECT, INDIRECT OR CONSEQUENTIAL LOSS OR DAMAGE ARISING OUT OF THE USE OF, OR INABILITY TO USE, THE PRODUCT. SERVICING HONEYWELL SAFETY PRODUCTS RESPIRATORS WITH PARTS NOT APPROVED BY HONEYWELL WILL VOID THIS WARRANTY AND THE NIOSH APPROVAL FOR THE RESPIRATOR UNIT. THIS WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED AND MAY NOT BE VARIED OR EXTENDED EXCEPT IN WRITING BY AN AUTHORIZED OFFICIAL OF HONEYWELL SAFETY PRODUCTS

## Specifications

### Headgear

- Polypropylene

### Hood Material

- Spun bond polypropylene, coated spun bond polypropylene

### Specification

- Latex free

**Visor**

- Co-polyester, 0.040 mil

## Training & Proper Use

Refer to User Instructions for use, cleaning and storage.

## Technical Support

800-873-5242