

Technical Note

Recommendation for reducing Flame Detector False and Nuisance Alarms

1998-1029 Rev 1 4/10

All Electro-Optical Flame Detectors are vulnerable to alarming to non-fire sources and reflected non-fire and real fire sources. Installations where there are flares (ground flares or flare stacks) ensure that the flares are not within the Flame Detector's Field of View (FoV). Flares are real fires, often referred to as friendly fires, and strong reflections from these flares can also be detected by an optical flame detector. Aim the Flame Detector, so that a flare is not within the field of view and try to avoid reflections of a flare within the FoV. Additionally, we recommend these steps be taken (in any order) to help mitigate or reduce their occurrence(s).

1. Lower the sensitivity – A higher sensitivity setting has a higher risk or vulnerability of alarming to non-fire and friendly fire sources. Reduce the sensitivity of all flame detectors with reflective surfaces within their FoVs. The factory default setting for the FS20X (UV/Dual IR plus Visible) and FS24X (Triple IR plus Visible) Detectors is Medium sensitivity, or 100 ft. sensitivity to a 1 sq. ft. pan fire. Due to the proximity of the flame detectors with the reflective surfaces and/or flare stacks, we recommend a sensitivity setting of Low. The energy from a flare stack may be reflecting off one or more surfaces. This reflected energy is coming from a real fire and is considered a nuisance alarm and not a false alarm.
2. Reduce the FoV – Focus the detector's FoV on the primary threat area and avoid false and nuisance sources outside the primary threat area. In some cases, a Sun Shade accessory (SH-001) will be adequate for this purpose. In other, more extreme cases, it may be necessary to utilize a Field of View Restrictor accessory (FVR-01) to focus the Flame Detector on the area to be protected. These two accessories are available from Honeywell Analytics.
3. Vote Detectors - Typically, this is the recommendation for most outdoor installations where an alarm from the flame detectors will initiate a suppression release. A spurious trip by single detector should not activate a suppression release system. It is unlikely that two or more spurious conditions will happen simultaneously, therefore, require two or more detectors to alarm to a fire before initiating suppression. The best approach is to vote two detectors that cover the same threat area from opposing perspectives, so that a single detector covering the threat area that alarms to a source outside or beyond the threat area will not initiate suppression by itself.

Technical Note

4. Set a Fire Verification Time (affects the Auxiliary Relay) - All FS20X and FS24X Detectors have a user selectable verification time that can be set via a DIP switch setting on the back of the detector module. Setting a verification time of five, ten, or twenty seconds means that the secondary alarm (Auxiliary Relay) will not activate unless the fire continues to burn during the entire verification time. When that verification time expires and the fire is still burning, the Auxiliary Relay will activate. If the time expires and the fire is not burning, the Auxiliary Relay will not activate. Many non-fire sources are brief or have short time durations, and Verification is a setting that can be employed that may dramatically reduce the occurrence of False and Nuisance Alarms. Fire Verification does not affect the 4-20mA output of the standard version of the FS24X Detector, therefore, any source that causes the first stage Alarm to activate will also generate a 20mA signal level on the 4-20mA output. This is not the case with the FS20X Detector: on Fire Alarm the 4 to 20mA output will rise to 16mA and on Fire Verification the 4 to 20mA output will rise to 20mA.

All the above recommendations will help reduce or mitigate false and nuisance alarms from occurring, but they may not be enough by themselves. Honeywell Analytics has developed a Triple IR Flame Detector that is suitable for use in applications where flares are present, referred to as the dash 5 (-5) version. The -5 version is a replacement for the standard version dash 1 (-1) of the FS24X, however, a detector module purchased before July 19, 2018 and swapped in the field must be accompanied by the addition of a reflector ring onto the FS24X enclosure lid.

It is important to note the -5 version is only available on the 90° FoV FS24X and not the 110° FoV FS24X nor the FS20X. Also, we recommend 90° Field of View Flame Detectors in any high background flare or IR energy applications rather than the wider 110° Field of View units.

The main difference between the -1 and -5 firmware is the ability of the -5 to retreat from alarm within 6 seconds with elevated levels of background IR present. The -5 firmware was developed and validated using:

1. a low sensitivity setting and
2. a ten (10) second verification setting

The -5 FS24X will alarm to the same test fires, at the same distances, with the same response times as the -1 FS24X. In other words, the primary detection algorithms were not altered.

NOTE: *The firmware changes made to the dash 5 version of the FS24X will not prevent the Detector from alarming to Flares within the Detector's Field of View.*

Technical Note

Find out more:

www.honeywellanalytics.com

www.raesystems.com

Contact Honeywell Analytics:

Europe, Middle East, Africa

Life Safety Distribution GmbH
Javastrasse 2
8604 Hegnau
Switzerland
Tel: +41 (0)44 943 4300
Fax: +41 (0)44 943 4398
gasdetection@honeywell.com

Customer Service:

Tel: 00800 333 222 44 (Freephone number)

Tel: +41 44 943 4380 (Alternative number)

Fax: 00800 333 222 55

Middle East Tel: +971 4 450 5800 (Fixed Gas Detection)

Middle East Tel: +971 4 450 5852 (Portable Gas Detection)

Americas

Honeywell Analytics Distribution Inc.
405 Barclay Blvd.
Lincolnshire, IL 60069
USA
Tel: +1 847 955 8200
Toll free: +1 800 538 0363
Fax: +1 847 955 8210
detectgas@honeywell.com

RAE Systems by Honeywell
Phone: 408.952.8200
Toll Free: 1.888.723.4800
Fax: 408.952.8480

Asia Pacific

Honeywell Industrial Safety
7F SangAm IT Tower,
434, Worldcupbuk-ro, Mapo-gu,
Seoul 03922,
Korea
Tel: +82 (0) 2 6909 0300
Fax: +82 (0) 2 2025 0328
India Tel: +91 124 4752700
China Tel: +86 10 5885 8788 3000
analytics.ap@honeywell.com

Technical Services

EMEA: HAexpert@honeywell.com
US: ha.us.service@honeywell.com
AP: ha.ap.service@honeywell.com

Technical Services

ha.us.service@honeywell.com

While every effort has been made to ensure accuracy in this publication, no responsibility can be accepted for errors or omissions. Data may change, as well as legislation, and you are strongly advised to obtain copies of the most recently issued regulations, standards and guidelines. This publication is not intended to form the basis of a contract and the company reserves the right to amend the design and specification without notice.

Technical Note 1998-1029