

Sliding Belt Connector Installation Instructions

* Maximum belt width:
1 15/16" (4.9 cm)



Position the connector so that the "M" button is on the outside of the belt.

Slide the connector onto the belt. Repeat process to install more connectors.



The connectors and clips can be used together (see reverse for clip instructions.) Loop belt through both at the same time to install.

Attachment Clip Installation Instructions


* Maximum belt width:
2 1/4" (5.7 cm)

* 2 required for belt



Always position
the clip so that the
smaller half of the
"8" slot is up.

The "8" slot side
should be on the
inside of the belt.
Slide both clips onto
the belt.



Snap clips onto
Accessory attach-
ment point on the
harness.