



Honeywell


Voyager 1200g Stand Installation



STND-19R02-002-4



STND-23F02-002-4




STND-23F03-002-4

Note: Wing nuts for STND-19R02-002-4 are optional, but recommended.
Screws for STND-19R02-002-4 and STND-23F02-002-4 are optional, but recommended when hard-mounting to a surface.


VG1200-STNDINST Rev B
9/11

Honeywell


Voyager 1200g Stand Installation



STND-19R02-002-4



STND-23F02-002-4



STND-23F03-002-4

Note: Wing nuts for STND-19R02-002-4 are optional, but recommended.
Screws for STND-19R02-002-4 and STND-23F02-002-4 are optional, but recommended when hard-mounting to a surface.

VG1200-STNDINST Rev B
9/11