RP SERIES MOBILE PRINTERS

Accessories Guide

.....

Honeywell



- **3** CHARGERS AND BRACKETS
- **<u>4</u>** BATTERY PACKS
- 4 CASES
- **5** MISCELLANEOUS ACCESSORIES

CHARGERS AND BRACKETS



229041-000

Charger with Retrofit Adapter

Charger with retrofit adapter for MF4Te charger enables users of MF4Te charging brackets to use existing adapter installations for both legacy MF and RPe Series. Regional power supply needs to be ordered separately.).



229042-000

Charger with Single Wall Adapter Kit

Single printer settlement room or a depot mounting bracket enables a single charger to be mounted on the wall or as a desktop application. The printer may be charged in an organized manner with the charging dock removed from busy work areas. Available for both RP2e and RP4e mobile printers. Regional power supply needs to be ordered separately.



229045-000

RP2e Vehicle-Mounted Bracket Charger

An optional accessory designed to both charge the printer as well as keep it secure, yet easily accessible, on a forklift or other vehicle. To charge the printer in a vehicle, we have the following power supply options:

510116-001 - Lighter receptacle adapter

220282-000 – 12 V power converter, 48 V to 60 V forklift



229044-000

RP4e Vehicle-Mounted Bracket Charger

An optional accessory designed to both charge the printer as well as keep it secure, yet easily accessible, on a forklift or other vehicle. To charge the printer in a vehicle, we have the following power supply options:

510116-001 - Lighter receptacle adapter

220282-000 – 12 V power converter, 48 V to 60 V forklift



RP2-QD-0

Four-Bay Charging Dock

The four-bay charging dock charges up to four RP2e mobile printers. Power supply is included.



229043-000

Settlement Room Mounting/Charging Bracket

Multi-charger settlement room or a depot mounting bracket enables up to five RPe printers to be mounted on the wall or as a desktop application. They may be charged in an organized manner with the charging dock. Power supply is integrated; only a regional power cord needs to be ordered.



220540-000

Four-Bay Smart Battery Charger

The four-bay battery charger is a compact charger used to charge RPe Series 4-cell and 2-cell battery packs. This enables the workforce to have charged batteries ready for a full fleet of products. Power supply is not included. Please order 50121667-001 separately.



RP4-QD-0

Four-Bay Charging Dock The four-bay charging dock charges up to four RP4e mobile printers. Power supply is included.

BATTERY PACKS



50166632-001

RP2e Spare Battery Battery for RP2e printer.



50138010-001

RP4e Spare Battery Battery for RP4e printer.

211288-000

RP2e Battery Eliminator

For tabletop applications where the printer does not need a battery, use a battery eliminator accessory.

211289-000

RP4e Battery Eliminator

For tabletop applications where the printer does not need a battery, use a battery eliminator accessory.





50134863-001

RP2e Environmental Soft Case

Thermal soft case used in harsher environments to provide dust and cold protection. Shoulder strap is not included. Please order 210302-000 separately.



750336-000

RP4e Environmental Soft Case

Thermal soft case used in harsher environments to provide dust and cold protection. Shoulder strap is not included. Please order 210302-000 separately.

MISCELLANEOUS ACCESSORIES

280797-000

Swivel Belt Clip (RL Style)

Standard belt clip, included in the box with both the RPe Series and RL Series.

210305-000

Velcro Belt Mount (RL Style)



210302-000

Shoulder Strap



220515-100

AC Adaptors With correct regional plug 12 V at 1.66 A, US plug. 220516-100

Euro Plug



220517-100

UK Plug



220518-100

220521-100

210304-100-SP

Australia Plug

Swiss Plug

USB Cable



510116-001-SP

Lighter Receptacle Adaptor

For more information

sps.honeywell.com

Honeywell Safety and Productivity Solutions

855 S Mint St Charlotte, NC 28202 800-582-4263 www.honeywell.com

RP Series Mobile Printer Accessories Guide LTR \mid Rev B \mid 07/22 © 2022 Honeywell International Inc.

