

UNAMP,4-COND,5-COND,6-COND,4-PIN,5-PIN,6-PIN

4-PIN		5-PIN		6-PIN	
PIN	FUNCTION	PIN	FUNCTION	PIN	FUNCTION
A	(+) EXC.	A	(+) EXC.	A	(+) EXC.
B	(+) SIG.	B	(+) SIG.	B	(+) SIG.
C	(-) SIG.	C	(-) SIG.	C	(-) SIG.
D	(-) EXC.	D	(-) EXC./	D	(-) EXC.
			TEDS GND	E	TEDS GND
		E	TEDS DATA	F	TEDS DATA

* USE TEDS CONNECTIONS WHEN REQUIRED

001-LWR-100

IF THIS IS A PAPER COPY IT IS UNCONTROLLED. VERIFY REVISION BEFORE USE.

PROPRIETARY RIGHTS NOTICE: THIS DRAWING COVERS A PROPRIETARY ITEM AND IS THE PROPERTY OF HONEYWELL. THIS DRAWING IS NOT TO BE COPIED OR USED WITHOUT THE PERMISSION OF HONEYWELL.

UNLESS OTHERWISE SPECIFIED: ALL DIMENSIONS IN INCHES. INTERPRET PER ASME Y14.100-2000 OTHER HONEYWELL STDS MAY APPLY. ALL FILLETS & CORNERS .005R MAX DEBURR & BREAK SHARP CORNERS		A 7/18/2006	PIN E WAS "TEDS DATA", PIN F WAS "TEDS GND" FOR 6 PIN CONN		MGJ	RJG	MGF	
		-	INITIAL RELEASE TO PRODUCTION					
REV	DESCRIPTION	REV BY	CHK BY	APV BY				
AUTOCAD		DRW: DURKIN 12/15/05	CHK: VICARS 05/09/2006	MFG: - -	ENG: OSMITH 05/03/2006			
REV HIST	DO NOT SCALE	Honeywell					HONEYWELL SENSOTEC 2080 ARLINGATE LANE COLUMBUS, OHIO 43228 www.honeywell.com/sensing	
PCB DWG & REV:	.X ±.1	<div style="display: flex; justify-content: space-between;"> EXTERNAL WIRING CODE 100 </div> <div style="display: flex; justify-content: space-between;"> UNAMP, 5 & 6-COND, 5 & 6-PIN 1 </div>					DOCUMENT NUMBER 001-LWR-100	
CHECKOUT PROCED:	.XX ±.01							
SCHEMATIC:	.XXX							
LAYOUT:	±.005							
DRILL PATTERN:	±1/2"	CODE IDENT NO. 51518	SHEET 1 OF 1		SIZE A			