

# Fendall 2000™ Dust Cover Installation

(#32-002015-0000)

1. Inspect package and ensure that it includes the yellow Tyvek® dust cover.
2. Wipe off any dust or debris on the outside of the Fendall 2000 eyewash station.
3. Stretch the dust cover's elastic band over the top of the Eyewash Station. **Fig. 1**
4. Stretch the cover down and around the bottom of the Eyewash Station making sure to leave the waste reservoir hanging freely. **Fig. 2**

**WARNING:** If waste reservoir is not properly compressed and freely hanging, or if the straps are not installed into the hooks, the unit will not function properly on activation. Make sure the area underneath the Eyewash Station is kept clear.

5. Peel back the see-through door.
6. Use a screw driver or a pen on the release button in the center of the station's door.
7. While the button is pressed in, gently pull door open (there should be no resistance).
8. To shut off the alarm, follow the **ALARM SHUT-OFF PROCEDURE (Below)**.
9. Wrap the inner elastic strap over the top lip on the door to the Eyewash Station. **Fig. 3**
10. Push the headrest back to its original position until an audible 'click' is heard. Close the door by pressing the center of the door and a 'click' will be heard confirming the nozzle is engaged.
11. Make sure the dust cover's Velcro® door is securely closed.
12. Unit is now armed and ready for use.

## Alarm Shut-off Procedure

1. Locate small blue button inside door of station.
2. Press and hold button for approximately 3-5 seconds until a beep is heard to disarm the alarm.
3. To rearm alarm, close station door. **ALARM IS NOW ARMED.**



Fig. 1



Fig. 3



Fig. 2