










Product Family
Fendall Pure Flow 1000

The Fendall Pure Flow 1000 emergency eyewash station delivers the required 15 minutes of flushing with a preserved, buffered, saline solution that is superior to tap water for emergency eye care. No plumbing required! Available with standard or 100% sterile saline eyewash solution.



Product Numbers & Ordering Information

Product Numbers	Details
 32-001000-0000	Eyewash Station Only - English Fendall Pure Flow 1000 Station Only English (15-minute) Case Qty: 1 Case Dimentions: 29" x 18" x 31" Case Weight (lbs): 38
 32-001000-0022	Eyewash Station Only - French (Canada) Fendall Pure Flow 1000 Station Only - French Canadian (15 minute) Case Qty: 1 Case Dimentions: 29" x 18" x 31" Case Weight (lbs): 38
 32-001000-0070	Eyewash Station Only - Spanish (Mexico) Fendall Pure Flow 1000 Station Only - Mexican Spanish (15 minute) Case Qty: 1 Case Dimentions: 29" x 18" x 31" Case Weight (lbs): 38
 32-ST1050-0000	Sterile Saline Cartridges (2) Sterile Saline Cartridges for Fendall Pure Flow 1000 Case Qty: 1 set of 2 Case Dimentions: 23.5" x 12.5" x 11.5" Case Weight (lbs): 70
 32-001050-0000	Saline Cartridges (2) - Trilingual Fendall Pure Flow 1000 Saline Cartridges - Tri-lingual (15 minute) Case Qty: 1 set of 2 Case Dimentions: 21" x 13" x 12" Case Weight (lbs): 69
 32-001050-0020	Saline Cartridges (2) - French (Canada) Fendall Pure Flow 1000 Saline Cartridges - Canada (15 minute) Case Qty: 1 set of 2 Case Dimentions: 21" x 13" x 12" Case Weight (lbs): 69
 32-ST1052-0000	Sterile High Humidity Saline Cartridges (2) - Trilingual Sterile Fendall Pure Flow 1000 High Humidity Saline Cartridges- Tri-lingual (15 minute) Case Qty: 1 set of 2 Case Dimentions: 21" x 13" x 12" Case Weight (lbs): 71

Fendall Pure Flow 1000



32-001052-0000

High Humidity Saline Cartridges (2) - Trilingual

Fendall Pure Flow 1000 High Humidity Saline Cartridges-Tri-lingual (15 minute) Case Qty: 1 set of 2 Case Dimentions: 21" x 13" x 12" Case Weight (lbs): 71



32-001015-0000

Dust Cover - Low Profile

**Low Profile Dust Cover Fendall Pure Flow 1000 Case Qty: 1 Case Dimentions: 15" x 12" x 3" Case Weight (lbs): 2



32-001014-0000

Installation Video & Upgrade Kit

Fendall Pure Flow 1000 Installation Video & Upgrade Kit Case Qty: 1 Case Dimentions: 9" x 12" envelope Case Weight (lbs): 2



32-001017-0000

Replacement Part - Tamper Seal

Tamper Seal for Fendall Pure Flow 1000 and Fendall 2000 Case Qty: 1 Case Dimentions: small envelope Case Weight (lbs): <1



32-001018-0000

Replacement Part - Unit Labels - English

Fendall Pure Flow 1000 Unit Labels Eng Case Qty: 1 Case Dimentions: large envelope Case Weight (lbs): <1



32-001019-0000

Replacement Part - Inspection Tag

Fendall Pure Flow 1000 Inspection Tag Case Qty: 1 Case Dimentions: small envelope Case Weight (lbs): <1



32-001012-0000

Replacement Parts - English

Fendall Pure Flow 1000 Replacement Parts - English Case Qty: 1 Case Dimentions: 10.5" x 8" x 5" Case Weight (lbs): 1



32-001012-0022

Replacement Parts - French (Canada)

Fendall Pure Flow 1000 Replacement Parts - French Canadian Case Qty: 1 Case Dimentions: 10.5" x 8" x 5" Case Weight (lbs): 1



32-001012-0070

Replacement Parts - Spanish (Mexico)

Fendall Pure Flow 1000 Replacement Parts - Mexican Spanish Case Qty: 1 Case Dimentions: 10.5" x 8" x 5" Case Weight (lbs): 1



32-001013-0000

Replacement Cover - English

Fendall Pure Flow 1000 Replacement Cover - English Case Qty: 1 Case Dimentions: 18" x 17" x 34" Case Weight (lbs): 8



32-001013-0022

Replacement Cover - French (Canada)

Fendall Pure Flow 1000 Replacement Cover - French Canadian Case Qty: 1 Case Dimentions: 18" x 17" x 34" Case Weight (lbs): 8



32-001013-0070

Replacement Cover - Spanish (Mexico)

Fendall Pure Flow 1000 Replacement Cover - Mexican Spanish Case Qty: 1 Case Dimentions: 18" x 17" x 34" Case Weight (lbs): 8



32-001051-0000

Wall Bracket

Wall bracket for Fendall Pure Flow 1000 Case Qty: 1 Case Dimentions: 7" x 5" x 5" Case Weight (lbs): 1



32-001000-0000

Training Video

Training Video for the Fendall Pureflow 1000



32-ST1050-0000

Training Video

Training Video for the Fendall Pureflow 1000



32-001050-000

Training Video

Training Video for the Fendall Pureflow 1000

Additional Information

Case Dimensions: 29" x 18" x 31", Case Weight: 38 lbs Includes eyewash sign, hang tag, hanging bracket (no fasteners), inspection checklist tag, installation CD, instruction manual, nozzle clip, stop tag, tamper seal, warranty card

Overview

Key Features

The Fendall Pure Flow 1000 emergency eyewash station delivers unequaled eyewash safety, reliability, and value. The patented system delivers contaminant-free and physiologically correct saline solution from factory-sealed cartridges. The Fendall Pure Flow 1000 does not require costly plumbing for affordable, portable placement near most workplace hazards. Patented design delivers a constant flow rate and stream height, and provides 0.4 gpm for 15 minutes as required by ANSI Z358.1-2009. A unique fluid pressure balancing system and nozzles maximize comfort with a soft “ribbon” of saline solution. Factory-sealed cartridges last up to 24 months,* at least four times longer than other primary self-contained eyewash devices.

NOW, WITH EASY-VIEW WINDOW

- Self-contained and easy to install with no plumbing required. Can be easily and affordably placed near most workplace hazards or transported with optional universal cart or stand.
- Factory-sealed fluid cartridges eliminate mixing, measuring, and the opportunity for airborne particles or microorganisms to contaminate the fluid prior to use.
- Unique nozzle design delivers a soft “ribbon” of a preserved, buffered, saline solution superior to tap water for emergency eye care. A 100% sterile saline option is also available.
- Constant flow rate permits thorough flushing with a constant flow rate and stream height that provides 0.4 gpm for entire 15-minute cycle required by ANSI Z358.1-2004.
- Integral fluid reservoir captures waste fluid to eliminate spill hazards and simplify fluid disposal.
- Easy cartridge replacement and cartridges remain sealed until activated. Expiration date is included on activation straps — and cartridge replacement takes less than five minutes.
- Cartridge lasts at least four times longer than other primary, self-contained eyewashes.
- Easy maintenance. ESP RFID technology gives you instant, accurate safety information about the cartridges while the easy view window makes inspection and maintenance
- Easy to install, and instruction manual, video and cartridge components ensure proper installation and maintenance to prevent false activation.

Recommended Industries/Use

- Chemical
- Construction
- Food Services
- Government
- Manufacturing
- Medical
- Military
- Mining
- Municipal Services
- Oil and Gas
- Pharmaceutical
- Steel and Metals
- Transportation
- Utilities

Hazards

- Airborne Particulates
- Biohazard
- Chemical
- Contamination
- Gas, Vapors, Smoke
- Splash

Regulations

- ANSI Z358.1 - Meets ANSI Z358.1 15-minute flushing requirement. SEI Certified

Historical Brand

Fend-All

Warranty Information

Sperian Eye & Face Protection, Inc., warrants that Sperian Eye & Face, Inc. Emergency Eyewash products are free of defects in material and workmanship for one (1) year from the date of shipment under the following conditions: 1. This limited warranty is effective only if the Sperian Eye & Face Protection, Inc. product is installed, maintained and used for the purpose intended and in accordance with the Sperian Eye & Face Protection, Inc. Installation and Operation Manual. 2. Sperian Eye & Face Protection, Inc.'s only obligation under this limited warranty shall be the repair or replacement, without charge, of any products or components, which upon inspection by Sperian Eye & Face Protection, Inc., are determined to be defective in materials or workmanship. 3. This limited warranty does not cover any damage, loss or expense due to damage caused by accident, abuse, improper installation, or improper maintenance. 4. No warranty is provided if any portion of the product covered by this limited warranty is altered or modified without the express written consent of Sperian Eye & Face Protection, Inc.

Specifications**Solution**

- Set of 2 Honeywell Saline solution cartridges; standard pH-balanced, sterile pH-balanced, high humidity

Flow Duration

- 15 minutes

Dimensions

- Reservoir up: 29" L x 30" H x 17 1/4" D, Reservoir down: 29" L x 41" H x 17 1/4" D

Capacity

- 7 gallons

Maintenance

- Replace cartridge every 24 months

Expiration

- 24 month cartridge life from date of manufacture (sold separately)

RFID Enabled

- ESP™ Enabled Safety Products RFID Technology

Easy View Window

- Makes inspection and maintenance quick and easy.

Literature & Documents**Data Sheet PureFlow1000 English**

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/20460/1033.aspx

Data Sheet PureFlow1000 French

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/20461/1033.aspx

HON_Eyewash Cert_of_Compliance-7-2012

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/4294970336/1033.aspx

MSDS_Sterile_Saline_Solution

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/40219/1033.aspx

MSDS Sperian Saline Solution 32-000400, 32-000401, 32-000502, 32-001050, 32-001052 English

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/20420/1033.aspx

Training Video- Fendall PF1000

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35816/1033.aspx

Installation and Operation Manual Pure FLOW 1000 32-001000

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35897/1033.aspx

Installation Manual Pure Flow 1000

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35901/1033.aspx

Installation Manual Pure Flow Saline 32-1050

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35902/1033.aspx

Installation Protective Cover Pure Flow 1000

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35903/1033.aspx

Installation Pure Flow 1000 Sterile Saline 32-ST1050

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35904/1033.aspx

Installation High Humidity Cartridge Brace

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35900/1033.aspx

Warranty Registration

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35949/1033.aspx

Head Position for Pure Flow

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/35969/1033.aspx

Sperian Eyewash Certificate 2010 SEI

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Eye_and_Face_Protection/Emergency_Eyewash/36228/1033.aspx

Training & Proper Use

Unit comes with installation manual and an installation / training CD

Additional Information

Replacement parts and accessories available.

Technical Support

US Sperian Customer Care: 866-257-7374

RELATED PRODUCTS