

ToxiRAE 3 Filter Instructions

A “peel-and-stick” filter can be used on the ToxiRAE 3 in order to keep debris from fouling the sensor. Sheets of 100 filters (part number G01-2013-100) are available from RAE Systems.

Follow these instructions for installation:

1. Peel a filter from the sheet by lifting its tab.



2. Center it over the sensor input (upper right portion of ToxiRAE 3).
3. Gently press down, ensuring it completely adheres.



Important! When the filter appears dirty, replace it with a new one and dispose of the dirty filter.



CAUTION: Readings may be affected by using the filter. Check the difference on your instrument before placing it into use.



RAE Systems, 3775 N. First St.,
San Jose, CA 95134-1708 USA

Tel: 408-952-8200 Fax: 408-952-8480

Email: customerserv@raesystems.com

Web: www.raesystems.com

PN: G01-2013-100-D
Rev A. 11-2008