

# 8680i

## WiFi Software Development Kit



---

# User Guide

---

# Disclaimer

Honeywell International Inc. ("HII") reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of HII.

HII shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material. HII disclaims all responsibility for the selection and use of software and/or hardware to achieve intended results.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.

Copyright © 2018 Honeywell International Inc. All rights reserved.

Web Address: [www.honeywellaidc.com](http://www.honeywellaidc.com)

For patent information, refer to [www.hsmpats.com](http://www.hsmpats.com).

Microsoft® Windows®, Windows NT®, Windows 2000, Windows ME, Windows XP, and the Windows logo are trademarks or registered trademarks of Microsoft Corporation.

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc.

Android™ is a trademark of Google Inc.

Apple is a trademark of Apple Inc., registered in the U.S. and other countries.

Other product names or marks mentioned in this document may be trademarks or registered trademarks of other companies and are the property of their respective owners.

# TABLE OF CONTENTS

Customer Support .....	iii
Technical Assistance .....	iii
Product Service and Repair .....	iii
Limited Warranty .....	iii
<b>Chapter 1 - Get Started .....</b>	<b>1</b>
About This Manual.....	1
System Requirements .....	1
Target Operating Systems.....	1
Use the SDK.....	1
C++ Programming.....	2
C# Programming.....	2
Device Detection.....	2
<b>Chapter 2 - Definitions.....</b>	<b>3</b>
ButtonPressFlag_WiFi .....	3
ButtonPressNotify.....	3
DecodeResult_WiFi .....	3
ELoggingLevel.....	4
FlashResult .....	4
LanguageOptions_WiFi.....	4
MenuCmdResponse .....	5
Return Value .....	5
ScannerInfo_WiFi.....	5
ScannerStatus_WiFi.....	6

SymbPropResponse.....	6
TextColors_WiFi.....	6
TextColorType_WiFi .....	7
TextFontSizes_WiFi.....	7
TextLineType_WiFi .....	8

## Chapter 3 - API ..... 9

API List.....	9
StartServer .....	10
StopServer.....	11
RegCallbacksWithWifi .....	11
UnregResponseCallbackWifi.....	12
SetSymbPropWithWifi.....	12
GetSymbPropWithWifi .....	13
CancelDecodeWifi.....	14
DecodeAsyncWithWifi .....	14
SetLogLevelWifi.....	14
SetDisplayTextWithWifi.....	15
SetDisplayColorWithWifi.....	15
SetTextSizeWithWifi .....	16
EnableNfyBtnPressWithWifi.....	17
EnableNfyBtnPressBarcodeWithWifi.....	17
SendMenuCmdWithWifi.....	18
ShowStatusAlertWithWifi.....	18
GetGen7WifiSDKVersion.....	19
SetLanguageWithWifi .....	19
GetClientAddress.....	19
SetDisplayColorHexWithWifi.....	20
SetFirmwareInfo .....	21
AddFlashingClient .....	21
FlashFirmware.....	21
OnFileTransferring .....	22
OnFileFlashed .....	22

## Chapter 4 - Sample Code .....25

Start/Stop Server .....	25
Start Server .....	25
Stop Server .....	26
Connection/Disconnection .....	27
Handle Connection Event .....	27
Handle Disconnection Event .....	27
Configure Scanner.....	28
Pre-Defined Menu Command Parameters .....	28
Trigger a Scan.....	28
Scan Asynchronously.....	28
Cancel Scan .....	28
Send Menu Command .....	29
Configure Screen Layout .....	29
Set Language .....	29
Set Display Text .....	29
Set Text Color.....	29
Set Text Size .....	30
Configure Text Properties for Up and Bottom Lines .....	30
Configure Text Properties for Single Line.....	30
Show Alert Popup.....	30
Get Version.....	31
Handle Button Press Event.....	31
Flash Firmware .....	32



# Customer Support

## Technical Assistance

To search our knowledge base for a solution or to log in to the Technical Support portal and report a problem, go to [www.hsmcontactsupport.com](http://www.hsmcontactsupport.com).

For our latest contact information, see [www.honeywellaidc.com/locations](http://www.honeywellaidc.com/locations).

## Product Service and Repair

Honeywell International Inc. provides service for all of its products through service centers throughout the world. To obtain warranty or non-warranty service, return your product to Honeywell (postage paid) with a copy of the dated purchase record. To learn more, go to [www.honeywellaidc.com](http://www.honeywellaidc.com) and select **Service & Repair** at the bottom of the page.

## Limited Warranty

For warranty information, go to [www.honeywellaidc.com](http://www.honeywellaidc.com) and click **Get Resources > Product Warranty**.





## About This Manual

The 8680i WiFi Software Development Kit (SDK) provides a set of tools and sample source code to help software developers create Windows® desktop applications for the 8680i Wearable Mini-Mobile Computer using Bluetooth SPP protocol.

The following abbreviations are used in this guide:

- API Application Programming Interface
- SPP Serial Port Profile

## System Requirements

.Net Framework 4.0 must be on the system.

## Target Operating Systems

Microsoft® Windows® 7 and Windows 10, 32 and 64 bit.

## Use the SDK

There are four folders inside the installation folder:

- include
- lib
- bin
- samples

## C++ Programming

- Add the header files **HonScannerWifiAPI.h**, **HonScannerSettings.h** and **HonScannerWifiStructs.h** from the **include** folder into your application project.
- In the C++ desktop application, link the released lib file **Gen7WiFiSDK.lib** under the **lib** folder. **Gen7WiFiSDK.lib** has different versions for 32bit and 64bit. Make sure the right version is integrated into your application.
- The **Gen7WiFiSDK.dll** is in the **bin** folder and the sample projects are in the **samples** folder.

## C# Programming

- Add the **Gen7WiFiSDKAssembly.dll** from the **bin** folder into your desktop application project.

## Device Detection

Refer to the 8680i User Guide for information about connecting to a WiFi network.

The following definitions are in the **HonScannerWiFiStructs.h** file.

## ButtonPressFlag\_WiFi

- Enumeration.

### Button Press Flag Enumerations

Value	Description
NoButtonPressed_WiFi	No button is pressed
LeftButtonPressed_WiFi	Left button is pressed
RightButtonPressed_WiFi	Right button is pressed
BothButtonsPressed_WiFi	Left and right button are pressed

## ButtonPressNotify

- Structure.
- Holds the button pressed notification.

### Button Press Notification Structure

Field	Description
unsigned long      connID	The connection ID for the scanner
ButtonPressFlag_WiFi    whichButtonPressed	Enumeration. Indicates which button is pressed.

## DecodeResult\_WiFi

- Structure.

- Holds the decoded bar code message.

#### Decode Result Structure

Field	Description
unsigned long connID	The connection ID for the scanner
char chCodeID	Honeywell Code ID
char chAimID	AIM ID, the Symbology Identification
char chAimModifier	AIM Modifier character
short nLength	The length of the decode data
char chMessage[2048]	The decode data buffer

## ELoggingLevel

- Enumeration.

#### Logging Level Enumerations

Value	Description
ELL_NONE	No log entries are generated, default value.
ELL_DATA	Log the device communication data information
ELL_ERROR	Log errors and all logs at ELL_DATA level.
ELL_INFO	Log general information and all logs at ELL_ERROR level
ELL_DEBUG	Log all information

## FlashResult

- Enumeration.
- Indicates the firmware flash results of the scanner.

#### Flash Result Enumerations

Value	Description
Success	Flashed firmware successfully
ConnectFailed	Can't connect to the scanner
FileNotFound	The specified firmware file is not found
FileRefusedByDevice	The firmware file is refused by the scanner
FileTransferFailed	Failed to transfer the firmware file to the scanner
FirmwareFlashFailed	Failed to flash the firmware file for the scanner
FlashResponseTimeout	The scanner doesn't response in time

## LanguageOptions\_WiFi

- Enumeration.

- Indicates which language characters display on the scanner screen.

#### Language Options Enumerations

Value	Description
loEnglish_WiFi	English
loCyrillic_WiFi	Cyrillic

## MenuCmdResponse

- Structure.
- Holds the response of menu command execution.

#### Menu Command Response Structure

Field	Description
unsigned long connID	The connection ID for the scanner
unsigned char response[512]	The response of the menu command from the scanner
unsigned long length	The real length of the response

## Return Value

- Enumeration.
- API function result codes.

#### Return Values

Return Value	Description
RESULT_ERR_NOT_INITIALIZE	SDK was not initialized
RESULT_SUCCESS_WIFI	Operation was successful
RESULT_ERR_SERVICE_NOT_STARTED	The TCP socket service was not started
RESULT_ERR_SERVICE_ALREADY_STARTED	The TCP socket service was already started
RESULT_ERR_PARAMETER_WIFI	One of the function parameters was invalid
RESULT_ERR_UNSUPPORTED_WIFI	The operation was not supported by the engine
RESULT_ERR_EXCEPTION_WIFI	An exception was detected in the engine

## ScannerInfo\_WiFi

- Structure.
- Holds the scanner information.

#### Scanner Information Structure

Field	Description
unsigned long connID	The connection ID for the scanner

### Scanner Information Structure (continued)

char	chName[128]	The module name of the scanner
char	chDesc[128]	The description of the scanner
char	chSerialNum[128]	The serial number of the scanner
char	chAppVersion[128]	The application version of the scanner
char	chAppDate[64]	The application date of the scanner
char	chAppTime[64]	The application time of the scanner
char	chBootVersion[128]	The boot version of the scanner
char	chBootDate[64]	The boot date of the scanner
char	chBootTime[64]	The boot time of the scanner

## ScannerStatus\_WiFi

- Enumeration.
- Sets alert popup.

### Scanner Status Enumerations

Value	Description
ssNormal_WiFi	Don't show any popup
ssBadScan_WiFi	Show bad scan alert
ssGoodScan_WiFi	Show good scan popup

## SymbPropResponse

- Structure.
- Holds the symbology property values.

### Symbology Property Structure

Field	Description
unsigned long    connID	The connection ID for the scanner
unsigned long    propID	The ID for the symbology property
unsigned long    value	The value for the specified symbology property
bool            successful	Indicates whether the operation is successful

## TextColors\_WiFi

- Enumeration.

- Sets foreground or background text color.

#### Text Color Enumerations

Value	Description
DefaultColor_WiFi	Background color, default is black. Foreground color, default is white.
Red_WiFi	Red color
Green_WiFi	Green color
Blue_WiFi	Blue color

## TextColorType\_WiFi

- Enumeration.
- Sets foreground or background color on the display.

#### Text Color Type Enumerations

Value	Description
BgColor_WiFi	Background color
FgColorUpLine_WiFi	Foreground color for up line
FgColorBottomLine_WiFi	Foreground color for bottom line

## TextFontSizes\_WiFi

- Enumeration.
- Sets text font size.

#### Text Font Size Enumerations

Value	Description
Small_WiFi	Small size
Medium_WiFi	Medium size, default value.
Large_WiFi	Large size
ExtraLarge_WiFi	Extra large size
SmallBold_WiFi	Small and bold
MediumBold_WiFi	Medium and bold
LargeBold_WiFi	Large and bold
ExtraLargeBold_WiFi	Extra large and bold
SingleLineSmall_WiFi	Small size for single line, only works for the up line
SingleLineMedium_WiFi	Medium size for single line, only works for the up line
SingleLineLarge_WiFi	Large size for single line, only works for the up line

## TextLineType\_WiFi

- Enumeration.
- Sets on which line text should be set on the display.

### Text Line Type Enumerations

<b>Value</b>	<b>Description</b>
UpLine_WiFi	Up line
BottomLine_WiFi	Bottom line



## API List

Windows Native C/C++ APIs are listed below. They have the same return value as defined in [Return Value](#) (page 5). Additional information about APIs is available in the **HonScannerWiFiAPI.h** file.

### C/C++ API List

API	Description
<a href="#">StartServer</a>	Starts the TCP socket server for incoming scanner connections.
<a href="#">StopServer</a>	Stops the TCP socket server and releases the connections.
<a href="#">RegCallbacksWithWifi</a>	Register the Callbacks in the SDK. SDK forwards the events to them.
<a href="#">UnregResponseCallbackWifi</a>	Stop receiving events from the SDK layer.
<a href="#">SetSymbPropWithWifi</a>	Set the symbology settings of the scanner.
<a href="#">GetSymbPropWithWifi</a>	Get the symbology settings from the scanner.
<a href="#">CancelDecodeWifi</a>	Cancel decode action in process.
<a href="#">DecodeAsyncWithWifi</a>	Trigger an asynchronous scan and don't wait for the result.
<a href="#">SetLogLevelWifi</a>	Set the log level for outputting the specified log information.
<a href="#">SetDisplayTextWithWifi</a>	Set the text content to display on the scanner screen through sending a menu command asynchronously.
<a href="#">SetDisplayColorWithWifi</a>	Set the background or foreground color of the text on the scanner screen through sending a menu command asynchronously.
<a href="#">SetTextSizeWithWifi</a>	Set the text font size of the text on the scanner screen through sending a menu command asynchronously.
<a href="#">EnableNfyBtnPressWithWifi</a>	Make the scanner send a notification to the host when one or more scanner buttons are pressed.

### C/C++ API List (continued)

<a href="#">EnableNfyBtnPressBarcodeWithWifi</a>	Make the scanner send a notification to the host when one or more scanner buttons are pressed and bar code data is sent.
<a href="#">SendMenuCmdWithWifi</a>	Send the raw menu command to the scanner asynchronously.
<a href="#">ShowStatusAlertWithWifi</a>	Show the status screen image on the scanner by sending a menu command asynchronously.
<a href="#">GetGen7WifiSDKVersion</a>	Get the current version of the SDK.
<a href="#">SetLanguageWithWifi</a>	Set which language characters are displayed on the scanner.
<a href="#">GetClientAddress</a>	Get the IP address and port of the socket of the connected scanner.
<a href="#">SetDisplayColorHexWithWifi</a>	Set the background or foreground color of the text on the scanner screen with RGB hex code through sending a menu command asynchronously.

The following commands are only for C# version assembly.

### C# API List

API	Description
<a href="#">SetFirmwareInfo</a>	Set the full file path and version of the firmware.
<a href="#">AddFlashingClient</a>	Add the scanner to be flashed.
<a href="#">FlashFirmware</a>	Flash the firmware file to scanners.
<a href="#">OnFileTransferring</a>	This delegate function is invoked when sending a firmware file to the scanner.
<a href="#">OnFileFlashed</a>	This delegate function is invoked when the flash is complete or an exception occurs.

## StartServer

Starts the TCP socket server for incoming scanner connections.

### Parameters

#### **wchar\_t\* lpszBindAddress**

The server IP address.

#### **unsigned long usPort**

The server port number.

### Return Value

RESULT\_SUCCESS\_WIFI if the TCP socket server is successfully started.

RESULT\_ERR\_PARAMETER\_WIFI if the **lpszBindAddress** is null or **usPort** is out of range (1 - 65535).

RESULT\_ERR\_SERVICE\_ALREADY\_STARTED if the TCP server has already started.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_EXCEPTION\_WIFI if the server is not successfully started.

## StopServer

Stops the TCP socket server and releases the connections.

**Note:** *This API waits until all jobs are done then returns. It must be called in a thread because this may take some time and can block the main thread.*

### Parameters

N.A.

### Return Value

RESULT\_SUCCESS\_WIFI if the TCP server is closed successfully.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_EXCEPTION\_WIFI if the server is not successfully stopped.

## RegCallbacksWithWifi

This API allows the application to register a callback to receive the events from the SDK such as bar code responses, disconnect events, button press events, and other responses from the scanner.

### Parameters

#### **OnConnectCallback connCb**

The function pointer that receives the connect events from the SDK layer.

```
typedef void (*OnConnectCallback) (const ScannerInfo_WiFi  
&info);
```

#### **OnDisconnectCallback disconnCb**

The function pointer that receives disconnect events from the SDK layer.

```
typedef void (*OnDisconnectCallback) (const CLIENT_CONNID  
connID);
```

#### **OnDecodeCallback decCb**

The function pointer that receives scan bar code events from the SDK layer.

```
typedef void (*OnDecodeCallback) (const DecodeResult_WiFi  
&decRes);
```

#### **OnPressButtonCallback pressBtnCb**

The function pointer that receives button press events from the SDK layer.

```
typedef void (*OnPressButtonCallback) (const ButtonPressNotify  
&notify);
```

#### **OnGetSymbPropCallback symbPropCb**

The function pointer that receives get/set symbology property events from the SDK layer.

```
typedef void (*OnGetSymbPropCallback) (const SymbPropResponse  
&resp);
```

#### **OnSendMenuCmdCallback menuCmdCb**

The function pointer that receives the menu command responses from the SDK layer.

```
typedef void (*OnSendMenuCmdCallback) (const MenuCmdResponse  
&resp);
```

#### **Return Value**

RESULT\_SUCCESS\_WIFI if successfully registered.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

## **UnregResponseCallbackWifi**

This is used to stop receiving events from the SDK layer.

#### **Parameters**

N.A.

#### **Return Value**

RESULT\_SUCCESS\_WIFI if successfully unregistered.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

## **SetSymbPropWithWifi**

Set the symbol code property in the scanner by sending an asynchronous menu command.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

#### **unsigned long symbolCodeID**

The symbol code properties (found in the *HonScannerSettings.h* file).

#### **unsigned long value**

The new value for the property to set.

### Return Value

RESULT\_SUCCESS\_WIFI if the menu command is successfully sent.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** or **symbolCodeID** are not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command fails.

## GetSymbPropWithWifi

Get the property of the symbol code from the scanner via sending menu command asynchronously.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

#### **Unsigned long symbolCodeID**

The symbol code properties (found in the *HonScannerSettings.h* file).

### Return Value

RESULT\_SUCCESS\_WIFI if the property is successfully retrieved.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** or **symbolCodeID** are not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command fails.

## CancelDecodeWifi

Cancel the decode action in process.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

### Return Value

RESULT\_SUCCESS\_WIFI if the decode is successfully canceled.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command for canceling the decode fails.

## DecodeAsyncWithWifi

Trigger an asynchronous scan and return the scan result with a callback event.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

### Return Value

RESULT\_SUCCESS\_WIFI if the decode menu command is successfully canceled.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command for scanning fails.

## SetLogLevelWifi

Set the log level for the specified log entries output.

### Parameters

#### **EloggingLevel**

Indicates the log level. See [ELoggingLevel](#) for more details.

### Return Value

N.A.

*This API doesn't rely on the connection to scanner, so you can invoke it before invoking [StartServer](#).*

## SetDisplayTextWithWifi

Set the text content to display on the scanner screen by sending an asynchronous menu command.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

#### **TextLineType\_WiFi whichLine**

Enumerations: [UpLine\\_WiFi](#), [BottomLine\\_WiFi](#). See [TextLineType\\_WiFi](#) for more details.

#### **const wchar\_t\* text**

The text to display. Supports Unicode.

### Return Value

RESULT\_SUCCESS\_WIFI if the menu command for setting display text is successfully sent.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct or text is null.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command for setting display text fails.

## SetDisplayColorWithWifi

Set the background or foreground color of the text on the scanner screen by sending an asynchronous menu command.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

### **TextColorType\_WiFi colorType**

Enumerations: [BgColor\\_WiFi](#), [FgColorUpLine\\_WiFi](#), [FgColorBottomLine\\_WiFi](#). See [TextColorType\\_WiFi](#) for more details.

### **TextColors\_WiFi color**

Enumerations: [DefaultColor\\_WiFi](#), [Red\\_WiFi](#), [Green\\_WiFi](#), [Blue\\_WiFi](#). See [TextColors\\_WiFi](#) for more details.

### **Return Value**

RESULT\_SUCCESS\_WIFI if the menu command for setting text color is successfully sent.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command for setting text color fails.

## **SetTextSizeWithWifi**

Set the text font size on the scanner screen by sending an asynchronous menu command.

### **Parameters**

#### **unsigned long connID**

The connection ID for the scanner.

#### **TextLineType\_WiFi whichLine**

Enumerations: [UpLine\\_WiFi](#), [BottomLine\\_WiFi](#). See [TextLineType\\_WiFi](#) for more details.

#### **TextFontSizes\_WiFi fontSize**

Enumerations: [Small\\_WiFi](#), [Medium\\_WiFi](#), [Large\\_WiFi](#). See [TextFontSizes\\_WiFi](#) for more details.

### **Return Value**

RESULT\_SUCCESS\_WIFI if the menu command for setting font size is successfully sent.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command for setting font size fails.



## EnableNfyBtnPressWithWifi

Make the scanner send a notification to the host when one or both of the scanner buttons are pressed. This is done by sending an asynchronous menu command.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

#### **bool enable**

True or false.

### Return Value

RESULT\_SUCCESS\_WIFI if the command for the enable/disable button press is successfully sent.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command for enable/disable button press notification fails.

**Note:** *If you want to receive the button pressed callback event, you should invoke this API when the scanner is connected, for example, in the connected callback function.*

## EnableNfyBtnPressBarcodeWithWifi

Make the scanner send a notification to the host when one or both of the scanner buttons are pressed and bar code data is sent. This is done by sending an asynchronous menu command.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

### Return Value

RESULT\_SUCCESS\_WIFI if the command for enabling notifications is successfully sent.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command enabling/disabling button press notifications and bar code data transmission fails.

## SendMenuCmdWithWifi

Send the raw menu command to the scanner asynchronously.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

#### **const char\* cmd**

The raw text of the menu command.

Add the command prefix such as SYN\_M or SYN\_Y and the command suffix such as RAM(!) or ROM(.

This function can send a series of commands with a separator (;), such as EA8ENA1;C39ENA1;128ENA1. The length of menu command response is limited to 512 so don't make the menu command too long.

### Return Value

RESULT\_SUCCESS\_WIFI if the menu command is successfully executed.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct, or the **cmd** is null or empty.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command fails.

## ShowStatusAlertWithWifi

Show the status image on the scanner screen by an asynchronous menu command.

### Parameters

#### **unsigned long connID**

The connection ID for the scanner.

#### **ScannerStatus\_WiFi status**

The scanner status, such as good scan or bad scan. See [ScannerStatus\\_WiFi](#).

## GetGen7WifiSDKVersion

Get the current version of the SDK.

### Parameters

**char\* version**

The array for receiving the version.

int\* verSize

**[In]** The max size of the returned version array to pass in.

**[Out]** The real size of the returned version array, not larger than the max size passed in.

### Return Value

RESULT\_SUCCESS\_WIFI if the SDK version is successfully retrieved.

RESULT\_ERR\_PARAMETER\_WIFI if the version or **verSize** is null.

RESULT\_ERR\_EXCEPTION\_WIFI if the **version** retrieval fails.

## SetLanguageWithWifi

### Parameters

**unsigned long connID**

The connection ID for the scanner.

**LanguageOptions\_WiFi option**

The language options. See [LanguageOptions\\_WiFi](#).

### Return Value

RESULT\_SUCCESS\_WIFI if the menu command is successfully executed.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command fails.

## GetClientAddress

Get the IP address and port of the socket of the connected scanner.

## Parameters

### **unsigned long connID**

The connection ID for the scanner.

### **wchar\_t\* lpszAddress**

The array for receiving the IP address.

### **int& iAddrLen**

The returned length of IP address.

### **unsigned short& usPort**

The returned port number.

## Return Value

RESULT\_SUCCESS\_WIFI if the IP address and port are successfully retrieved.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct or the **lpszAddress** is null.

RESULT\_ERR\_EXCEPTION\_WIFI if the IP address and port retrieval fails.

## SetDisplayColorHexWithWifi

Set the background or foreground color of the text on the scanner screen by sending an asynchronous menu command.

## Parameters

### **unsigned long connID**

The connection ID for the scanner.

### **TextColorType\_WiFi colorType**

Enumerations: [BgColor\\_WiFi](#), [FgColorUpLine\\_WiFi](#), [FgColorBottomLine\\_WiFi](#). See [TextColorType\\_WiFi](#) for more details.

### **const char\* hexColor**

The RGB hex code string.

## Return Value

RESULT\_SUCCESS\_WIFI if the menu command for setting text color is successfully sent.

RESULT\_ERR\_NOT\_INITIALIZE if the SDK is not successfully initialized.

RESULT\_ERR\_SERVICE\_NOT\_STARTED if the TCP server is not started.

RESULT\_ERR\_PARAMETER\_WIFI if the **connID** is not correct, if **hexColor** is null, or its length is not 6.

RESULT\_ERR\_EXCEPTION\_WIFI if the menu command for setting text color fails.

## SetFirmwareInfo

**Note:** This API is only for C# version assembly.

This sets the full path and version of the firmware file.

### Parameters

#### **string filePath**

The full path of the firmware file.

#### **string version**

The version of the firmware file.

### Return Value

N.A.

## AddFlashingClient

**Note:** This API is only for C# version assembly.

Add the scanner to be flashed.

### Parameters

#### **uint connID**

The connection ID for the scanner.

### Return Value

N.A.

## FlashFirmware

**Note:** This API is only for C# version assembly.

Flash the firmware file to the scanners. The firmware file information is set by [SetFirmwareInfo](#) and the scanners are added by [AddFlashingClient](#). To reduce the network transfer load, schedule 10 threads in a pool to transfer a firmware file to scanners concurrently.

### Parameters

N.A.

### Return Value

N.A.

## OnFileTransferring

**Note:** *This API is only for C# version assembly.*

This delegate function is invoked when sending a firmware file to the scanner.

```
public delegate void OnFileTransferring(ulong connID, int
    sentSize, int totalSize);
```

### Parameters

#### **uint connID**

The connection ID for the scanner.

#### **int sentSize**

The size already sent to the scanner.

#### **int totalSize**

The total size of the firmware file.

### Return Value

N.A.

## OnFileFlashed

**Note:** *This API is only for C# version assembly.*

This delegate function is invoked when the flash is complete or an exception occurs.

```
public delegate void OnFileFlashed(ulong connID, FlashResult
    res);
```

### Parameters

#### **uint connID**

The connection ID for the scanner.

**FlashResult res**

The result of flashing. See [FlashResult](#) for more details.

**Return Value**

N.A.





## Start/Stop Server

### Start Server

```
// Logging doesn't rely on the Server, so we can initialize the level at the
beginning.
SetLogLevelWifi(ELL_DEBUG);

Result_t res = StartServer(strIP, lPort);
If (res == RESULT_SUCCESS)
{
    // Register the callback functions for receiving the events.
    RegCallbacksWithWifi(OnConnect, OnDisconnect,
        OnDecode, OnPressButton,
        OnGetSymbProp, OnSendMenuCmd);
}
```

## Stop Server

The following *CStopServerThread* and *CApp* are the classes of the Desktop application.

```
// The thread is working for stopping server which invokes the StopServer API
// really.
typedef void (*OnStopServerCallback)();

// The callback is invoked to tell the main thread that the stopping server is
// done.
void CStopServerThread::setStopServerCallback(OnStopServerCallback stopSrvCb)
{
    m_pStopSrvCb = stopSrvCb;
}

void CStopServerThread::stopServer()
{
    stopEvent.signal();
}

void CStopServerThread::entry()
{
    while(stopEvent.wait())
    {
        StopServer();
        if(m_pStopSrvCb != nullptr)
            m_pStopSrvCb();

        stopEvent.unsingal();
    }
}

// The main thread of the application to stop server.
CStopServerThread m_stopSrvThread;

void CApp::StopServer()
{
    m_stopSrvThread.setStopServerCallback(OnStopServer);
    m_stopSrvThread.stopServer(); // Stop the server in another thread.
}

// Stop server callback for the thread
void OnStopServer()
{

```

```
        MessageBox("Server stop.");
    }
```

## Connection/Disconnection

### Handle Connection Event

```
// Store the scanner information when it connects to the server in the callback
// function
void OnConnect(const ScannerInfo_WiFi &info)
{
    // Note: The info passed from callback may be released by SDK,
    // so we should deep copy it and store locally.
    ScannerInfo_WiFi scanner;
    memcpy(&scanner, &info, sizeof(ScannerInfo_WiFi));
    m_vcScanners.push(scanner);

    // Enable to receive button pressed callback events once connect to the
    // scanner. Otherwise you can invoke this API wherever as you need.
    EnableNfyBtnPressWithWifi(scanner.ConnID, true);
}
```

### Handle Disconnection Event

```
// Remove the scanner information when it disconnects to the server in the
// callback function
void OnDisconnect(const unsigned long connID)
{
    for(ScannerIT it = m_vcScanners.begin(); it != m_vcScanners.end(); ++it)
    {
        if((*it)->connID == scannerID)
        {
            it = m_vcScanners.erase(it);
            break;
        }
    }
}
```

# Configure Scanner

## Pre-Defined Menu Command Parameters

```
SetSymbPropWithWifi(connID, DEC_EAN8_ENABLED, 1); // Enable EAN-8
SetSymbPropWithWifi(connID, DEC_EAN8_CHECK_DIGIT_TRANSMIT, 1);
SetSymbPropWithWifi(connID, DEC_EAN8_2CHAR_ADDENDA_ENABLED, 0); // Disable 2
char addenda
SetSymbPropWithWifi(connID, DEC_CODE128_MIN_LENGTH, 5); // Set the minimum
length of code 128 to be 5

// Retrieve the symbology property result in the callback function
void OnGetSymbProp(const SymbPropResponse &resp)
{
    if(resp.successful)
        OutputSymbProp(resp);
}
```

## Trigger a Scan

### Scan Asynchronously

```
DecodeAsyncWithWifi(connID); // Send scan command

// Retrieve the scan result in the callback function
void OnDecode(const DecodeResult_WiFi &decRes)
{
    OutputDecodeResult(decRes);
}
```

### Cancel Scan

```
CancelDecodeWifi(connID); // Cancel scan
```

## Send Menu Command

```
#define CMD_SYN_M  "\x16\x4d\x0d"
#define CMD_RAM    "\x21" // !

std::string cmd = "BT_NAM?";
cmd = CMD_SYN_M + cmd + CMD_RAM;
SendMenuCmdWithWifi(connID, cmd.c_str());

// Retrieve the menu command result in the callback function
void OnSendMenuCmd(const MenuCmdResponse &resp)
{
    std::string str((char*)resp.response, resp.length);
    OutputMenuCmdResponse(str);
}
```

## Configure Screen Layout

### Set Language

```
SetLanguageWithWifi(connID, loCyrillic_WiFi); // Set the scanner to be ready to
show Cyrillic
```

### Set Display Text

```
SetDisplayTextWithWifi(connID, UpLine_WiFi, "Welcome"); // Show 'Welcome' at
the up line
SetDisplayTextWithWifi(connID, BottomLine_WiFi, "Bad Code"); // Show 'Bad Code'
at the bottom line
```

### Set Text Color

```
// Show the background color in Red
SetDisplayColorWithWifi(connID, BgColor_WiFi, Red_WiFi);
// Show the foreground color of the up line in Green
SetDisplayColorWithWifi(connID, FgColorUpLine_WiFi, Green_WiFi);

// Show the background color in yellow
SetDisplayColorHexWithWifi(connID, BgColor_WiFi, "ffff00");
// Show the foreground color of the up line in brown
SetDisplayColorHexWithWifi(connID, FgColorUpLine_WiFi, "800000");
```

## Set Text Size

```
// Show the text in Large size at the up line
SetTextSizeWithWifi(connID, UpLine_WiFi, Large_WiFi);
// Show the text in Small size at the bottom line
SetTextSizeWithWifi(connID, BottomLine_WiFi, Small_WiFi);
```

## Configure Text Properties for Up and Bottom Lines

```
// Show 'Welcome' in large size with green foreground and red background at the
// up line
SetDisplayColorWithWifi(connID, BgColor_WiFi, Red_WiFi);
SetDisplayColorWithWifi(connID, FgColorUpLine_WiFi, Green_WiFi);
SetTextSizeWithWifi(connID, UpLine_WiFi, Large_WiFi);
SetDisplayTextWithWifi(connID, UpLine_WiFi, "Welcome");

// Show 'Bad Code' in small size with blue foreground at the bottom line
SetDisplayColorWithWifi(connID, FgColorBottomLine_WiFi, Blue_WiFi);
SetTextSizeWithWifi(connID, BottomLine_WiFi, Small_WiFi);
SetDisplayTextWithWifi(connID, BottomLine_WiFi, "Bad Code");
```

## Configure Text Properties for Single Line

```
// Clear the screen to make sure the old content will not overlap with the new
// content.
SetDisplayTextWithWifi(connID, UpLine_WiFi, "");
SetDisplayTextWithWifi(connID, BottomLine_WiFi, "");

// Show 'Welcome' in large size with green foreground and red background at the
// single line.
// Notes: When using SingleLineSmall_WiFi, SingleLineMedium_WiFi,
// SingleLineLarge_WiFi for font sizes, the SetDisplayTextWithWifi should pass
// UpLine_WiFi for displaying content.
SetDisplayColorWithWifi(connID, BgColor_WiFi, Red_WiFi);
SetDisplayColorWithWifi(connID, FgColorUpLine_WiFi, Green_WiFi);
SetTextSizeWithWifi(connID, UpLine_WiFi, SingleLineLarge_WiFi);
SetDisplayTextWithWifi(connID, UpLine_WiFi, "Welcome");
```

## Show Alert Popup

```
ShowStatusAlertWithWifi(connID, ssGoodScan_WiFi);
```

## Get Version

```
char version[20];
int verLen = 20;
Result_t res = GetGen7WifiSDKVersion(version, &verLen);
if(res == RESULT_SUCCESS)
    Log(CString(version, verLen));
```

## Handle Button Press Event

```
// Should enable this functionality first, so we can receive button pressed
// events.
EnableNfyBtnPressWithWifi(connID, true);
// Handle the button press event in the callback function
void OnPressButton(const ButtonPressNotify &notify)
{
    switch(notify.whichButtonPressed)
    {
        case LeftButtonPressed_WiFi:
            // Do something when left button is pressed
            break;
        case RightButtonPressed_WiFi:
            // Do something when right button is pressed
            break;
    }
}
```

# Flash Firmware

**Note:** *This API is only for C# version assembly.*

```
// The definitions of the delegate functions for flashing
private void OnFwFileTransferring(ulong connID, int sentSize, int totalSize)
{
    Log(string.Format("Scanner [{0}], Bytes transferred:{1}/{2}", connID,
        sentSize, totalSize));

    if (sentSize == totalSize)
        Log(string.Format("Scanner [{0}] is flashing firmware. Please wait...",
            connID));
}

private void OnFwFlashed(ulong connID, FlashResult res)
{
    Log(string.Format("Scanner [{0}], Flash result: {1}", connID,
        res == FlashResult.Success ? "Success. Restarting..." : "Failed"));
}

// Register the delegate functions to API assembly at the beginning.
// apiWrapper is the instance of our WiFi SDK assembly.
public void Init()
{
    apiWrapper.OnTransferring = new OnFileTransferring(OnFwFileTransferring);
    apiWrapper.OnFlashed = new OnFileFlashed(OnFwFlashed);
}

// Flash firmware to the selected scanners
private void btnFlashFW_Click(object sender, EventArgs e)
{
    List<uint> ids = GetSelectedScannerIDs();
    if(ids.count == 0)
        return;
    try
    {
        apiWrapper.SetFirmwareInfo(tbFwPath.Text, tbFwVersion.Text);
        foreach (uint id in ids)
        {
            Log(string.Format("Start to flash firmware, connecting to Scanner
                [{0}] ...", id));

            apiWrapper.AddFlashingClient(id);
        }
    }
}
```



```
    }
    apiWrapper.FlashFirmware();
}
catch (Exception ex)
{
    Log(string.Format("Exception: {0}", ex.Message));
}
}
```





**Honeywell Scanning & Mobility**

9680 Old Bailes Road  
Fort Mill, SC 29707

[www.honeywellaidc.com](http://www.honeywellaidc.com)