Class Series II

Programmer's Manual

Covers the following models: E-Class Mark II E-Class Mark III Basic and Advanced (Serial# 3xxxxxx or earlier) A-Class / A-Class Mark II MP Compact4 Mark II M-Class Mark II H-Class I-Class Ex2





right by our customers.

CG Times (based upon Times New Roman), CG Triumvirate, MicroType, and TrueType are trademarks of the AGFA Monotype Corporation.

PCL, Intellifont, and HP Laser JetII are trademarks of the Hewlett Packard Corporation. Macintosh is a trademark of the Apple Corporation.

Windows is a trademark of the Microsoft Corporation.

All other brand and product names are trademarks, service marks, registered trademarks, or registered service marks of their respective companies.

Information in this manual is subject to change without notice and does not represent a commitment on the part of Datamax-O'Neil Corporation. No part of this manual may be reproduced or transmitted in any form or by any means, for any purpose other than the purchaser's personal use, without the expressed written permission of Datamax-O'Neil Corporation.

All rights reserved

Copyright © 2013, Datamax-O'Neil

Part Number 88-2341-01

Revision L

Contents

1	Overview.		
	Who Sh	ould Use this Manual	1
	The Sco	ppe of this Manual	1
	General	Conventions	3
	Compute	er Entry and Display Conventions	3
	Importar	nt Safety Instructions	3
	Special	Instructions	4
	Typical I	Data Flow Sequence	4
2	Control Co	ode Command Functions	9
	Introductio	n	9
	Attentior	n-Getters	9
	Alternate	e Control Code Modes	10
3	Immediate	e Command Functions	
	Introductio	n	
	SOH #	Reset	
	SOH *	Reset	
	SOH A	Send ASCII Status String	
	SOH a	Send ASCII Extended Status String	12
	SOH B	Toggle Pause	
	SOH C	Stop/Cancel	
	SOH D	SOH Shutdown	
	SOH E	Send Batch Remaining Quantity	
	SOH e	Send Batch Printed Quantity	
	SOH F	Send Status Byte	

4	System-Le	evel Command Functions	17
	Introductio	n	17
	STX A	Set Time and Date	17
	STX a	Enable Feedback Characters	18
	STX B	Get Printer Time and Date Information	18
	STX c	Set Continuous Paper Length	19
	STX E	Set Quantity for Stored Label	19
	STX e	Select Edge Sensor	20
	STX F	Form Feed	20
	STX f	Set Form Stop Position (Backfeed)	20
	STX G	Print Last Label Format	21
	STX I	Input Image Data	21
	STX i	Scalable Font Downloading	22
	STX J	Set Pause for Each Label	23
	STX K	Extended System-Level Commands	23
	STX k	Test RS-232 Port	23
	STX L	Enter Label Formatting Command Mode	23
	STX M	Set Maximum Label Length	24
	STX m	Set Printer to Metric Mode	24
	STX n	Set Printer to Imperial Mode	24
	STX O	Set Start of Print Position	25
	STX o	Cycle Cutter	26
	STX P	Set Hex Dump Mode	26
	STX p	Controlled Pause	26
	STX Q	Clear All Modules	27
	STX q	Clear Module	27
	STX R	Ribbon Saver Control	27
	STX r	Select Reflective Sensor	28
	STX S	Set Feed Speed	28
	STX T	Print Quality Label	28
	STX t	Test DRAM Memory Module	29
	STX U	Label Format String Replacement Field	29
	STX V	Software Switch Settings	31
	STX v	Request Firmware Version	32
	STX W	Request Memory Module Information	32

	STX w	Test Flash Memory Module	33
	STX X	Set Default Module	33
	STX x	Delete File from Module	34
	STX Y	Output Sensor Values	35
	STX y	Select Font Symbol Set	35
	STX Z	Print Configuration Label	36
	STX z	Pack Module	36
5	Extended S	System-Level Command Functions	37
	Introduction	۱	37
	STX K	Memory Configuration	37
		Empty Sensor Calibration	
		1 Manual Media Calibration	
		Quick Media Calibration	
	STX KaF	R Read Data from RFID Tag	40
	STX KaV	V Write Data to RFID Tag	41
	STX Kb	Backfeed Time Delay	41
	STX KC	Get Configuration	42
	STX Kc	Configuration Set	43
	STX KD	Database Configuration	102
	STX Kd	Set File as Factory Default	103
	STX KE	Character Encoding	103
	STX KF	Select Factory Defaults	105
	STX Kf	Set Present Distance	105
	STX KH	Dot Check	106
	STX KJ	Assign Communication Port (MCL)	107
	STX KI	GPIO Input	108
	STX Kn	NIC Reset	108
	STX KO	GPIO Output	109
	STX Kp	Module Protection	110
	STX KQ	Query Memory Configuration	111
	STX Kq	Query Memory Configuration	113
	STX KR	Reset Memory Configuration	114
	STX Kr	Resettable Counter Reset	114
	STX KS	Memory Configuration, Scalable Font Cache	114

STX KtA Write Application Family Identifier (AFI) to Tag	115
STX KtD Write Data Storage Format Identifier (DSFID) to Tag	115
STX KtE Write Electronic Article Surveillance (EAS) Bit	116
STX KtH Read and Feedback Tag Information to Host	116
STX KtR Read Data from RFID Tag	117
STX KtW Write Data to RFID Tag	119
STX KuB Read Data from Gen2 Tag Section	120
STX KuF Send RFID Device Firmware Version	120
STX KuJ Write Data to Gen 2 Tag Section	120
STX KuR Read Data from RFID Tag	121
STX KuW Write Data to RFID Tag	122
STX KV Verifier Enable/Disable	122
STX KW Memory Configuration, Printable Label Width	122
STX Kx Delete Configuration File	123
STX KZ Immediately Set Parameter	123

6 Label Formatting Command Functions 125

Introductio	n	.125
:	Set Cut by Amount	. 125
А	Set Format Attribute	. 126
В	Bar Code Magnification	. 127
С	Set Column Offset Amount	. 127
С	Set Cut by Amount	. 128
D	Set Dot Size Width and Height	. 128
Е	Terminate Label Formatting Mode and Print Label	. 129
е	Recall Printer Configuration	. 129
F	Advanced Format Attributes	. 129
f	Set Present Speed	. 130
G	Place Data in Global Register	. 130
Н	Enter Heat Setting	. 131
J	Justification	. 131
М	Select Mirror Mode	. 132
m	Set Metric Mode	. 132
n	Set Inch (Imperial) Mode	. 132
Р	Set Print Speed	. 133

	р	Set Backfeed Speed	
	Q	Set Quantity of Labels to Print	
	R	Set Row Offset Amount	
	r	Recall Stored Label Format	
	S	Set Feed Speed	
	S	Store Label Format in Module	
	Т	Set Field Data Line Terminator	
	t	Add or subtract date time from the printer date	
	U	Mark Previous Field as a String Replacement Field	
	Х	Terminate Label Formatting Mode	
	у	Select Font Symbol Set	139
	Z	Zero (Ø) Conversion to "0"	
	+ (>)(()	Make Last Field Entered Increment	140
	- (<)())	Make Last Field Entered Decrement	
	۸	Set Count by Amount	
	Special Lab	el Formatting Command Functions	143
	STX D	Print adjusted date	
	STX S	Recall Global Data and Place in Field	
	STX T	Print Time and Date	
7	Font Loadi	ing Command Functions	
	Introductio	n	147
	*c###D	Assign Font ID Number	
)s###W	Font Descriptor	
	*c###E	Character Code	
	(s#W	Character Download Data	148
8	Generating	g Label Formats	
	Introductio	n	149
	Format F	Record Commands	
	Generat	ing Records	
	The Stru	icture of a Record	150
	Record S	Structure Types	
	Advance	ed Format Attributes	

Appendix A167
ASCII Control Chart167
Appendix B
Sample Programs169
Appendix C179
Available Fonts – Sizes, References, and Samples179
Appendix D
Reset Codes
Appendix E
Single Byte Symbol Sets187
Appendix F199
Bar Code Summary Data199
Bar Code Default Widths and Heights202
Appendix G
Bar Code Details205
Appendix H
Single and Double Byte Character Font Mapping251

Appendix I253
Symbol Sets and Character Maps
Double-Byte Symbols, Chinese, Kanji, and Korean
Appendix J
General Purpose Input Output (GPIO) Port Applications257
Appendix K271
Maximum Field & Character Values271
Print Resolutions and Maximum Width & Record Column Values
Column, Present, & Row Adjust Fine Tune Range
Memory Module Identifiers and Allocations274
Appendix L
Speed Ranges275
Appendix M
Commands by Function277
Appendix N
Image Loading279
Appendix O
UPC-A and EAN-13: Variable Price/Weight Bar Codes
Appendix P283
International Language Print Capability (ILPC) Programming Examples

Appendix Q
Plug and Play IDs293
Appendix R
Line Mode 295
Appendix S299
RFID Overview299
Appendix T
WiFi Region Country Codes305
Appendix U
Graphics Display Icon Key
Control Panel Button Sequences
Appendix V
Bar Code Symbology Information Resources
Glossary

1 Overview

Who Should Use this Manual

This manual is intended for programmers who wish to create their own label production software.

The Scope of this Manual

This manual, arranged alphabetically by command, explains Datamax-O'Neil Programming Language (DPL) and its related uses in the writing, loading and storing of programs for the control and production of label formats (designs) for the following printers at, or above, the listed firmware version below:

Printer	Firmware Version
A-Class	11.08
A-Class Mark II	12.07
E-Class Mark II	12.01
E-Class Mark III Basic and Advanced Models	Serial# 3xxxxxx or earlier; Firmware Version 14.07 or greater
EX2	11.08
H-Class	12.071
I-Class	11.08
M-Class Mark II	12.071
MP Compact4 Mark II	14.02

Model distinctions, including configurations (i.e., Display or Non-Display) and equipment types (e.g., GPIO-1, graphics display, RFID, etc.), will be indicated in this text to differentiate command compatibility. The appendices of this manual also contain details that cannot be ignored; the use of any command will require checking for possible exclusionary conditions.



- See the <STX>KC command for information regarding attainment of the printer's firmware version; and then, if necessary, upgrade that firmware. Upgrades are available at <u>http://www.datamax-oneil.com</u>.
- Programming information for Class Series printers (or firmware versions for Class Series printers) not found in this manual can be found in the *Class Series Programmer's Manual* (part number 88-2316-01), except the S-Class printer and the legacy model printers which can be found in the *DPL Programmer's Manual* (part number 88-2051-01); and, for the E-3202 see the *E-3202 Programmer's Manual* (part number 88-2257-01). All manuals can be downloaded from our web site at http://www.datamax-oneil.com.
- References to "Menu Settings" refer either to the set-up menu or to the system menu of the printer; consult to the appropriate *Operator's Manual* for details.
- Where applicable, printer responses to a host device will depend upon the communication port, port settings, and cabling.

This manual contains the following sections and appendices:

OVERVIEW on page 1

Contents, organization, and conventions used in this manual; also includes a typical data flow sequence for the printer.

- CONTROL CODE COMMAND FUNCTIONS on page 9 Description of the attention-getter characters necessary for the printer to receive a command sequence, and available alternate characters and line terminators.
- IMMEDIATE COMMAND FUNCTIONS on page 11 Description of the commands, listed alphabetically, that perform status queries and printer control commands.
- SYSTEM-LEVEL COMMAND FUNCTIONS on page 17 Description of the commands, listed alphabetically, that control the printer and allow scalable font and image downloads.
- EXTENDED SYSTEM-LEVEL COMMAND FUNCTIONS on page 37 Description of the commands (listed alphabetically) that control the printer.
- LABEL FORMATTING COMMAND FUNCTIONS on page 125 Description of commands, listed alphabetically, that control the position of text and images on the media, print or store, and end the formatting process.
- FONT LOADING COMMAND FUNCTIONS on page 145 Description of commands, listed alphabetically, used when downloading font data in PCL-4 compatible bitmaps.
- GENERATING LABEL FORMATS on page 147 Description of the structure of records, the different types, and their use in generating label formats.
- APPENDICES on pages 165 313 These contain details that cannot be ignored including various tables, programming examples, printer default values, and bar code symbology details. See the Table of Contents for specific content information.
- GLOSSARY on page 315 Definitions of words, abbreviations, and acronyms used in this manual.

General Conventions

These are some of the conventions followed in this manual:

- On the header of each page, the name of the section.
- On the footer of each page, the page number and the title of the manual.
- Names of other manuals referenced are in *Italics*. •
- Notes are added to bring your attention to important considerations, tips or helpful suggestions.
- **Boldface** is also used to bring your attention to important information. •
- This manual refers to IBM-PC based keyboard command characters for access to the ASCII character set. Systems based on different formats (e.g., Apple's Macintosh) should use the appropriate keyboard command to access the desired ASCII character. See Appendix A for the ASCII character set.

Computer Entry and Display Conventions

Command syntax and samples are formatted as follows:

- The Courier font in **boldface** indicates the DPL command syntax, and *Italics* are • used to indicate the command syntax parameters.
- Regular Courier font indicates sample commands, files and printer responses. •
- Square brackets ([]) indicate that the item is optional.
- <CR> is used to identify the line termination character. Other strings placed between < > in this manual represent the character of the same ASCII name, and are single-byte hexadecimal values (e.g., <STX>, <CR>, and <0x0D> equal 02, 0D, and 0D, respectively).
- Hexadecimal values are often displayed in "C" programming language conventions (e.g., 0x02 = 02 hex, 0x41 = 41 hex, etc.)

Important Safety Instructions



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions.

Special Instructions

The green check box is intended to alert the user to conventions used within this text or to notable operating details of the printer.

Typical Data Flow Sequence

The typical data flow sequence is summarized in the following bullets and detailed in the table below. Printer Commands data is transmitted to the printer as shown in the table from left to right, top to bottom.

- Status commands
- Configuration commands
- Download commands
- Label format
- Status commands
- Label reprint commands
- Memory cleanup

Printer Commands	Description	Notes	
<soh>A</soh>	"Status" commands: Get Status, Request Memory Module Storage Information	Optional, bidirectional communication required for these commands.	
<stx>WG</stx>			
<stx>O220 <stx>n <stx>V0</stx></stx></stx>	"Configuration" commands, download image	See <stx>Kc to reduce configuration commands transferred</stx>	
<soh>D <stx>IApImagename<cr>image datadata <cr></cr></cr></stx></soh>	"Download" commands, image, fonts	RAM (temporary) or Flash (semi- permanent) memory.	
<stx>L</stx>	Begin label		
D11	Label Header record		
131100000500050Typical text field 01	Label Formatting Data record – Object type, orientation, position, data	Existing label formats may be recalled. Label header records are not required.	
Q0001	Label Quantity		
E	Label Terminate record		

Printer Commands	Description	Notes
<soh>A</soh>	Status command	Optional, bidirectional communication required for these commands.
<stx>U01new data for field 01</stx>	Reprint with New Data Records	Used for fast reprints.
<stx>E0005</stx>		
<stx>G</stx>		
<stx>xImagename<cr> <stx>zA</stx></cr></stx>	Memory cleanup	Typically used for temporary storage.

Commands are available for retrieving stored label formats, updating data, and adding new data. These techniques are used for increasing throughput; see <stx>G, Label Recall Command "r", and Label Save Command "s".

Typical commands used in the various stages shown above are listed in the tables that follow.

Configuration Commands

The following table lists some commands useful in controlling printer configuration. These commands are generally effective only for the current power-up session; toggling power restores the default configuration. See <STX>Kc for changes to the default powerup configuration. Changing the default power-up configuration and saving objects in printer Flash memory can reduce the data transmitted for each label and therefore improve throughput.

Configuration Command	Name	Function
<stx>A Set Date and Time</stx>		Sets Date and Time.
<stx>c Set Continuous Paper Length</stx>		Must be 0000 for gap media; not used for reflective media.
<stx>e</stx>	Set Edge Sensor	Sets sensing for gap or registration hole type stock.

Configuration Command	Name	Function
<stx>Kf</stx>	Set Present Distance	Determines label stop position, head relative. <stx>f edge sensor relative equivalent command, older models.</stx>
<stx>Kc</stx>	Configuration Set	Determines default power-up configuration.
<stx>F</stx>	Send Form Feed	Sets the stop position of the printed label.
<stx>M</stx>	Set Maximum Label Length	Length to search for next gap or reflective mark; not used with continuous media.
<stx>m</stx>	Set to Metric Mode	Subsequent measurements interpreted in metric (most units, mm/10). Label equivalent command can be used.
<stx>n</stx>	Set to Inch Mode	Subsequent measurements interpreted in inches (most units in/100) label equivalent command can be used.
<stx>0</stx>	Set Start of Print Position	Effect is not on the label immediately following command since media position is at Start of Print between labels; <stx>K default position relative 64 in/100 maximum deviation.</stx>
<stx>S</stx>	Set Feed Rate	Sets blank label movement speed.
<stx>v</stx>	Software Switch	Enables optional hardware, cutter, and present sensor.

Download Command	Name	Function
<stx>I Download Image</stx>		Downloads Image to selected memory module.
<stx>i</stx>	Download Scalable Font	Downloads Scalable Font to selected memory module.
<esc> Download Bitmapped Font</esc>		Downloads Bitmapped Font to selected memory module.

Download Commands

Label Header Commands

These commands determine how the label formatting occurs, the print quality and quantity. They are typically issued immediately following the <STX>L start of the label format. The Format Attribute (A) and the Offset (C, R) commands can be changed at any point between format records to achieve desired effects.

Label Header Command	Name
А	Set Format Attribute
с	Column Offset
D	Set Width and Dot Size
Н	Set Heat Setting
М	Set Mirror Mode
P	Set Print Speed
P	Set Backup Speed
Q	Set Quantity
R	Set Row Offset
S	Set Feed Speed

2 Control Code Command Functions

Introduction

The printer requires a special "attention-getter" character in order to receive a command sequence, informing the printer that it is about to receive a command and the type of command it will be. Control Commands, System-Level Commands, and Font Loading Commands have their own unique attention-getter, followed by a command character that directs printer action.

Attention-Getters

The attention-getters (e.g., "SOH") are standard ASCII control labels that represent a one character control code (i.e., ^A or Ctrl A). Appendix A contains the entire ASCII Control Code Chart.

Attention-Getter	ASCII Character	Decimal Value	HEX Value
Immediate Commands	SOH	1	01
System-Level Commands	STX	2	02
Font Loading Commands	ESC	27	1B

Table 2-1: Attention Getter Listings

Easy Control Codes

DPL has been enhanced to accept a 3-character SOH and STX sequence. Easy Control Codes are always enabled, whether in Standard, Alternate, Alternate 2, or Custom Control Code Mode. Two types of sequences have been created to meet any application's requirements. Use these sequences where you normally would use a single SOH or STX character.

Control Character	3 "%" Character Sequence	3 "^"Character Sequence	Command Type
SOH	%01	^01	Control
STX	802	^02	System

Table 2-2: Easy Control Code Listings

Alternate Control Code Modes

For systems unable to transmit certain control codes, Alternate Control Code Modes are available. Configuring the printer to operate in an Alternate Control Code Mode (selected via the Setup Menu, the <STX>KC command or, where applicable, the <STX>KD command) requires the substitution of Standard Control Characters with Alternate Control Characters in what is otherwise a normal data stream.

Control Character Standard		Alternate	Alternate 2	Custom	Command Type
SOH	0x01	0x5E	0x5E		Control
STX	0x02	0x7E	0x7E		System
CR	0x0D	0x0D	0x7C	User Defined	Line Termination
ESC	0x1B	0x1B	0x1B		Font Loading
"Count By" [1]	0x5E	0x40	0x40		Label Formatting

^[1]See Label Formatting Commands, ^ set count by amount.

Table 2-3: Alternate Control Code Listings



Throughout this manual <SOH>, <STX>, <CR>, <ESC>, and ^ will be used to indicate control codes. The actual values will depend on whether standard or alternate control codes are enabled for the particular application.

Alternate Line Terminator Example: Alternate Control Codes provide for substitution of the line terminator, as well as the control characters listed above. For example using Alternate 2, the line terminator < CR> (0x0D) is replaced by | (0x7C). The following is a sample label format data stream for a printer configured for Alternate-2 Control Codes:

~L|1911A10001000101234560|X|~UT01ABCDE|~G|

3 Immediate Command Functions

Introduction

When the printer receives an Immediate Command, its current operation will be momentarily interrupted to respond to the command. Immediate Commands may be issued before or after System-Level commands; however, they may not be issued among Label Formatting Commands or during font or image downloading. Immediate Commands consist of:

- 1. Attention-Getter, 0x01 or 0x5E; see Control Code Command Functions.
- 2. Command Character

SOH # Reset

This command resets the printer. Resetting the printer returns all settings to default and clears both the communications and printing buffers. The command also clears DRAM memory.

Syntax: <SOH>#

Printer Response:	The printer will reset.	
	<xon> T (The T may come before the <xon>)</xon></xon>	

SOH * **Reset** (Display-Equipped Models only)

This command forces a soft reset of the microprocessor, resetting the printer, returning all factory default values, and clearing the communication and print buffers.

Syntax: <SOH>*

Printer Response:	The printer will reset.	
	<pre><xon> R (The R may come before the <xon>)</xon></xon></pre>	

SOH A Send ASCII Status String

This command allows the host computer to check the current printer status. The printer returns a string of eight characters, followed by a carriage return. Each character (see below) indicates an associated condition, either true (Y) or false (N). Byte 1 is transmitted first. See <SOH>F.

Syntax:	<soh>A</soh>
---------	--------------

Sample: <SOH>A

Printer Response: abcdefgh<CR>

Where:

	oss /alu	ible Ies		Interpretation		Transmit Sequence
а	-	Y/N	Y	=	Interpreter busy (imaging)	1
b	-	Y/N	Υ	=	Paper out or fault	2
С	-	Y/N	Y	=	Ribbon out or fault	3
d	-	Y/N	Y	=	Printing batch	4
е	-	Y/N	Y	=	Busy printing	5
f	-	Y/N	Υ	=	Printer paused	6
g	-	Y/N	Υ	=	Label presented	7
h	-	Y/N	Y	=	(Internal) Rewinder out or fault	8

Table 3-1: ASCII Status Bytes

SOH a Send ASCI1 Extended Status String

This command allows the host computer to check an extended current printer status. The printer returns a string of seventeen characters, followed by a carriage return. Most characters (see below) indicate an associated condition, either true (Y) or false (N). Byte 1 is transmitted first. See <SOH>F.

Syntax:	<soh>a</soh>
o y neuxi	

Sample: <SOH>a

Printer Response: abcdefgh:ijklmnop<CR>

Where:

Possible Values		Interpretation			Transmit Sequence	
а	-	Y/N	Υ	=	Interpreter busy (imaging)	1
b	-	Y/N	Υ	=	Paper out or fault	2
С	-	Y/N	Υ	=	Ribbon out or fault	3
d	-	Y/N	Υ	=	Printing batch	4
е	-	Y/N	Y	=	Busy printing	5
f	-	Y/N	Y	=	Printer paused	6
g	-	Y/N	Y	=	Label presented	7
h	-	Y/N	Y	=	Rewinder out or fault	8
	-	:	:	=	Always :	9
i	-	Y/N	Y	=	Cutter Fault	10
j	-	Y/N	Y	=	Paper Out	11
k	-	Y/N	Y	=	Ribbon Saver Fault	12
I	-	Y/N	Υ	=	Print Head Up	13
m	-	Y/N	Υ	=	Top of Form Fault	14
n	-	Y/N	Υ	=	Ribbon Low	15
0	-	Y/N	Y	= N (reserved for future)		16
р	-	Y/N	Y	Y = N (reserved for future)		17
	-	:	:	=	Always :	18
q	-	Y/N	Υ	=	Ready (no data or signal)	19
r	-	Y/N	Υ	=	Waitng for Signal	20
s	-	Y/N	Y	· · · · · · · · · · · · · · · · · · ·		21
t	-	Y/N	Υ	=	Com1 has data not parsed	22
u	-	Y/N	Υ	=	N (reserved for future)	23
v	-	Y/N	Υ	=	N (reserved for future)	24
W	-	Y/N	Y	<pre>/ = N (reserved for future)</pre>		25
х	-	Y/N	Υ	=	N (reserved for future)	26
		<cr></cr>			· · · · · · · · · · · · · · · · · · ·	27

Table 3-1: ASCII Status Bytes

SOH B Toggle Pause

This command toggles the printer's paused state between "On" and "Off." (This is the same function achieved by pressing the PAUSE Key.)

Syntax: <SOH>B

Sample: <SOH>B

Printer Response: This command will illuminate the Paused/Stop Indicator and/or indicate PAUSED on the LCD or graphics display panel, suspend printing, and wait until one of the following occurs:

- The <SOH>B command is sent to the printer.
- The PAUSE Key is pressed.

Upon which the printer will turn the Paused/Stop Indicator "Off" and/or remove PAUSED from the LCD or graphics display, then resume operation from the point of interruption. (If the Receive Buffer is not full, an <XON> character will be transmitted from the printer.)

SOH C Stop/Cancel

This command performs the same function as pressing the STOP/CANCEL Key (i.e., it clears the current format from the print buffer, pauses the printer, and illuminates the Paused/Stop Indicator). (The pause condition is terminated as described under <SOH>B.)

Syntax: <SOH>C

Sample: <SOH>C

- Printer Response: The print buffer is cleared and the Paused/Stop Indicator is illuminated (and/or PAUSED is displayed on the LCD or graphics display) as operations are suspended, until one of the following occurs:
 - The <SOH>B command is sent to the printer; or
 - The PAUSE Key is pressed.

Upon which the printer will turn the Paused/Stop Indicator "Off" and/or remove PAUSED from the LCD or graphics display. (If the Receive Buffer is not full, an <XON> character will be transmitted from the printer.)

SOH D SOH Shutdown

This command is ignored by the printer.

SOH E Send Batch Remaining Quantity

This command causes the printer to return a four-digit number indicating the quantity of labels that remain to be printed in the current batch, followed by a carriage return. Communications latency may cause this value to be higher than actual on some printers.

Syntax:	<soh>E</soh>

Printer response: nnnn<CR>

Where: _____ Are four decimal digits, 0-9999.

SOH e Send Batch Printed Quantity

This command causes the printer to return a four-digit number indicating the quantity of labels that have been printed in the current batch, followed by a carriage return. Communications latency may cause this value to be lower than actual on some printers.

Syntax:	<soh>e</soh>	
Printer response:	nnnn <cr></cr>	
Where:	Are four decimal digits, 0-9999.	

SOH F Send Status Byte

This command instructs the printer to send a single status byte where each bit (1 or 0) represents one of the printer's status flags, followed by a carriage return (see below). If an option is unavailable for the printer, the single bit will always be zero. See <SOH>A.

Syntax:	<soh>F</soh>
---------	--------------

Response format: X<CR>

Where:

 $\ensuremath{``X''}\xspace$ is 0 through $\ensuremath{\texttt{0xef}}\xspace$ with bits as indicated in the <code>`Condition''</code> column below:

Bit [*]	Value	Condition		
8	1 or 0	(Internal) Rewinder out or fault		
7	1 or 0	Label presented		
6	1 or 0	Printer paused		
5	1 or 0	Busy printing		
4	1 or 0	Printing batch		
3	1 or 0	Ribbon out or Fault		
2	1 or 0	Paper out or Fault		
1	1 or 0	Command interpreter busy (imaging)		

*One is the least significant bit.

4 System-Level Command Functions

Introduction

The most commonly used commands are the System-Level Commands. These are used to load and store graphics information, in addition to printer control. System-Level Commands are used to override default parameter values (fixed and selectable) and may be used before or after Immediate Commands but cannot be issued among Label Formatting Commands. System-Level Commands consist of:

- 1. Attention-Getter, 0x02 or 0x7E; see Control Code Command Functions.
- 2. Command Character
- 3. Parameters (if any).

STX A Set Time and Date

This command sets the time and date. The initial setting of the date will be stored in the printer's internal inch counter. This date can be verified by printing a Configuration Label.

Syntax:

<STX>AwmmddyyyyhhMMjjj

Where:

W	1 digit for day of week; 1 = Monday; 7 = Sunday
mm	2 digits for month
dd	2 digits for day
уууу	4 digits for year
hh	2 digits for hour in 24 hour format
MM	2 digits for minutes
ijj	3 digits for Julian date / constant; see notes below.

Sample: <STX>A1020319960855034

Printed response: Mon. Feb 3, 1996, 8:55AM, 034

- When set to 000, the Julian date is automatically calculated; otherwise, the Julian date will print as entered, without daily increments. If factory defaults are restored the actual Julian date will also be restored.
 - Printers without the Real Time Clock option lose the set time/date when power is removed.
 - Response format is variable; see the Special Label Formatting Command <STX>T.

STX a Enable Feedback Characters

This command enables the feedback ASCII hex characters to be returned from the printer following specific events after each completed batch of labels when using serial communications. The default value is "OFF".

Syntax: <STX>a

Printer response: Event dependent. (Also see Appendix D for error codes.)

Where:

Event	Return Characters
Invalid character	0x07 (BEL)
Label printed	0x1E (RS)
End of batch	0x1F (US)

STX B Get Printer Time and Date Information

This command instructs the printer to retrieve its internal time and date information.

Syntax: <STX>B

Sample: <STX>B

Response format: wmmddyyyyhhMMjjj<CR>

Where:

W	1 digit for day of week; 1 = Monday
mm	2 digits for month
dd	2 digits for day
уууу	4 digits for year
hh	2 digits for hour in 24 hour format
MM	2 digits for minutes
jjj	3 digits for Julian date / constant*

* See <STX>A for details and restrictions.

Response sample:

1020319960855034<CR>

STX c Set Continuous Paper Length

This command sets the label size for applications using continuous media. It disables the top-of-form function performed by the Media Sensor. The sensor, however, continues to monitor paper-out conditions. See <STX>M.

Syntax:	<stx>cnnnn</stx>
Where:	nnnn - Specifies the length of the media feed for each label format, in inches/100 or millimeters/10 (see <stx>m).</stx>
Sample:	<stx>c0100</stx>
	The sample above sets a label length of 100, which equals 1.00 inch (assuming Imperial Mode is selected).
This command	d must be reset to zero for edge or reflective sensing operation.

STX E Set Quantity for Stored Label

This command sets the number of labels for printing using the format currently in the print buffer. (The printer automatically stores the most recent format received in the buffer until the printer is reset or power is removed.) When used in conjunction with the <STX>G command, this will print the format.

Syntax:	<stx>Ennnn<cr></cr></stx>			
Where:	<i>nnnnn</i> – A five-digit quantity, including leading zeros.			
	<cr> - 0x0d terminates the name.</cr>			
Sample:	<stx>E00025<cr> <stx>G</stx></cr></stx>			
Printer response:	25 labels of the current format in memory will be printed.			
If no <cr> terminates the command, a four-digit quantity (nnnn) can be entered; and specifying 9999 will cause continuous printing.</cr>				

STX e Select Edge Sensor

This command enables transmissive (see-through) sensing for top-of-form detection of die-cut and holed (notched) media. This sensor will detect a minimum gap of 0.1 inches (2.5 mm) between labels (see the *Operator's Manual* for media requirements). This is the default setting.

Syntax: <STX>e

This command is ignored when <STX>cnnnn is issued with a non-zero value for nnnn.

STX F Form Feed

V

This commands the printer to form feed to the next start of print.

Syntax: <STX>F

Printer response: The printer will form feed.

STX f Set Form Stop Position (Backfeed Command)

This sets the stop position of the printed label, allowing the label to stop at a point past the start-of-print position. When the next label format is sent, the printer motor reverses direction to retract the media to the start-of-print position. If quantities of more than one label are requested, the printer will operate without backfeeding. Backfeed will then only occur when printing has stopped for a few seconds.

Non-Display Models: Option Control must be set via the printer menu to "Host" for this command to have effect.

Display-Equipped Models: This command is not honored; see <STX>Kf and <STX>Kc.

Syntax:	<stx>fnnn</stx>
Where:	 Is a three-digit distance from the Media Sensor, in inches/100 or mm/10. This distance is independent of the start-of-print position (<stx>O), yet it must be greater than the start-of-print position to take effect.</stx>
Sample:	<stx>f230</stx>
	The sample above sets a stop position distance of 230 (2.3 inches from the Media Sensor's eye).

STX G Print Last Label Format

This command prints a previously formatted label and restarts a canceled batch job following the last processed label. This is used when there is a label format in the buffer. The <STX>E command is used to enter the quantity. (Without the <STX>E command, one label will print.)

Syntax: <STX>G

STX I Input Image Data

This command must precede image downloading from the host to the printer. The data that immediately follows the command string will be image data. If any of the 8-bit input formats are to be used, it is necessary to disable the Immediate Command interpreter by executing an <SOH>D command before issuing the <STX>I command. See Appendix N for more information. To print an image, refer to Generating Label Formats.

A-Class (and large display H–Class models): A "ready mode" logo image can be input using this command. The image must be stored on a Flash module. The image name must be "logolab" (lowercase only) in the following DPL command. Also, printer power must be cycled for the new image to appear. The available display area is 312 pixels wide by 94 pixels high. Images larger than this specified width or height will be clipped along the right and/or bottom edges.

		ntio for less module spa	nd BMP images is RLE-2, which results ace usage when downloading gray-scale eas.		
Syntax:	<stx>Iabi</stx>	fnnn <cr>data</cr>			
Where:	a	- Memory Module E	Bank Select (see Appendix K).		
	b	- Data Type (optional), A or omit:			
		ь Value: A omit	Image Data Value Range: ASCII Characters 0-9, A-F, (7 bit) 00-FF, (8 bit)		
	£	- Format Designat	or:		
		f Designator:	Format Type:		
		F	7-bit D-O image load file		
		В	.BMP 8-bit format, flipped, black and white (B&W)		
		b	.BMP 8-bit format, B&W		
		I	.IMG 8-bit format, flipped, B&W		
		i	.IMG 8-bit format, B&W		
		P	.PCX 8-bit format, flipped, B&W		
		р	.PCX 8-bit format, B&W		

nn...n - Up to 16 characters used as an image name.

<CR> - 0x0d terminates the name.

data – Image data

Sample: <SOH>D <STX>IDpTest <CR> data...data <CR>

The sample above instructs the printer to (1) receive an 8-bit PCX image sent by the host in an 8-bit data format, (2) name the image "Test", and (3) store it in Module D (with a .dim file extension).

STX i Scalable Font Downloading

The command structure for downloading TrueType (.TTF) scalable fonts (files may be single-byte or double-byte character systems) is as follows:

Syntax:	<stx>imtnnName<cr>xxxdata</cr></stx>	
Where:	m	 The designator of the module where the font is to be saved; see Appendix K.
	t	 Type of scalable font being downloaded: T = TrueType
	nn	 Two-digit font reference ID. Valid range is 50-99, 9A-9Z, 9a-9z (base 62 numbers).
	Name	- The title, up to 16 characters, for this font.
	<cr></cr>	- 0x0d terminates the Name.
	<i>XXX</i>	 Eight-digit size of the font data, number of bytes, hexadecimal, padded with leading zeros.
	data	- The scalable font data.
Sample:	<stx>iDT52Tree Frog<cr>000087C2data</cr></stx>	
	The sample above downloads a TrueType font to Module D, and assigns it the Font ID of 52 with the name "Tree Frog" and file extension .dtt. The size of the font data is $0x87C2$ bytes long.	
STX J Set Pause for Each Label

This command causes the printer to pause after printing each label. It is intended for use with the peel mechanism or tear bar when the Present Sensor option is not installed. After removing the printed label, the PAUSE Key must be pushed in order to print the next label. (The printer must be reset to clear the <STX>J command.)

Syntax: <stx>J

STX K Extended System-Level Commands

This is an expansion of the System-Level Command structure; see Extended System-Level Commands for more information.

STX k Test RS-232 Port

This command instructs the printer to transmit the Y character from the printer's RS-232 port. (Failure to receive Y could indicate an interfacing problem.)

Syntax: <stx>k

Printer response: Y

STX L Enter Label Formatting Command Mode

This command switches the printer to the Label Formatting Command Mode, where the printer expects to receive only Record Structures and Label Formatting Commands. Immediate, System-Level, and Font Loading commands will be ignored until the label formatting mode is terminated with E, s, or X, (see Label Formatting Commands for additional information).

Syntax: <stx>L

STX M Set Maximum Label Length

This command instructs the printer move media this distance in search of the top-ofform (label edge, notch, black mark, etc.) before declaring a paper fault. A paper fault condition can occur if this setting is too close (within 0.1 inch [2.54 mm]) to the physical length of the label. Therefore, it is a good practice to set this command to 2.5 to 3 times the actual label length used. The minimum value should be at least 5" (127 mm).

Syntax:	<stx>Mnnnn</stx>
Where:	nmm - Is a four-digit length, 0000-9999, in/100 or mm/10. Maximum setting is 9999 (99.99 inches or 2540 mm). The default setting is 16 inches/ 406.4 mm.
Sample:	<stx>M0500</stx>
	The sample above sets a maximum travel distance of 5 inches (unless the printer is in metric mode; see m).

STX m Set Printer to Metric Mode

This command sets the printer to interpret measurements as metric values (e.g., <STX>c0100 will equal 10.0 mm). The default is Imperial (see <STX>n).

Syntax: <stx>m

STX n Set Printer to Imperial Mode

This command sets the printer to interpret measurements as inch values (e.g., <STX>c0100 will equal 1.00 inch), and is the default mode.

Syntax: <STX>n

STX O Set Start of Print (SOP) Position

This command sets the point to begin printing relative to the top-of-form (the label's edge as detected by the Media Sensor). The printer will feed from the top-of-form to the value specified in this command to begin printing.

This value operates independently of the <STX>f command.

Non-Display Models: The printer Options Control must be set (via the menu) to "Host" for this command to have effect.

Display-Equipped Models: If SOP Emulation is set to "enabled" (via the menu), this command sets the point where printing starts, emulating the selected legacy printer's distance, as measured between the media sensor and the print head burn line. In addition, regardless of the SOP Emulation setting, the start of print position can be fine-tuned via the menu: Menu Mode / Print Control / Custom Adjustments / Row Adjust.

Syntax:

<STX>Onnnn

Where:	nnnn -	Is a four-digit offset value in inches/100 or mm/10. The "zero" setting is the default value, and settings below 50 are adjusted back to the default value.
		Non-Display: The default setting is 0220 in Imperial Mode (0559 in Metric Mode).
		Display-Equipped: The default setting is "Off" and the printer assumes the natural SOP position.
Sample (Non-Display models):	<stx>00300</stx>	
		above sets a start of print position of 3.0 inches etric Mode; see <stx>m).</stx>
Sample (Display-Equipped models):	<stx>00210</stx>	
	edge of the or 1.0 inch f	above will begin printing 0.1 inch closer to the leading label if the 220 (Allegro) SOP Emulation was selected, arther away from the leading edge if 110 (ProdPlus) on was selected.

STX o Cycle Cutter

This command will cause the optional cutter mechanism to immediately perform a cut after all previously received commands are executed. The cutter must be installed, enabled and the interlock(s) closed for operation.

Syntax: <STX>o

STX P Set Hex Dump Mode

This command instructs the printer to assume Hex Dump Mode. Instead of a formatted product, data sent following this command will be printed in its raw ASCII format. To capture all data, labels should be at least four inches (102 mm) long and as wide as the maximum print width. This command has the same effect as turning "On" the printer while depressing the FEED Key (return normal operation by manual reset).

Syntax: <stx>P

Printer response is data dependent (layout may vary):

999 999 999 999 999 999 999 999 999 99	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	^L_D11.1 61100003 200010F0 NT 6: AL UALID .1611 00002800 010 CHARA CTERS:1 6100002 400010#\$ %&()*+

STX p Controlled Pause

This command will cause the printer to pause only after all previously received commands are executed, often useful between label batches. (This command will <u>not</u> clear the pause condition; see <SOH>B).

Syntax: <STX>p

STX Q Clear All Modules

This command instructs the printer to clear all Flash and DRAM modules (except as noted); see the corresponding *Operator's Manual* for applicable module options. **All stored data will be destroyed.**

Syntax: <stx>Q



Will not affect Module Y or the ILPC Font module.

STX q Clear Module

This command clears the selected Flash or DRAM module. During normal operations if a module becomes corrupted (identifiable when the printer responds with a "No Modules Available" message to a <STX>W command) it must be cleared. **All stored data will be destroyed.**

Syntax:	<stx>qa</stx>		
Where:	<i>a</i> - Memory module designator; see Appendix K.		
Sample:	<stx>qA</stx>		
	The sample above clears memory Module A.		



Will not affect Module Y or the ILPC Font module.

STX R Ribbon Saver Control

This command enables the operation of the optional Ribbon Saver. It is the only command used to control the Ribbon Saver. Its operation is continuous when enabled. The printer must be set to thermal transfer (ribbon) printing mode then, during operation, the Ribbon Saver engages automatically, lifting when the minimum amount of label white space is exceeded.

Syntax:	<stx>Rx</stx>
Where:	x - y - Enabled (Default = Menu selection.) N - Disabled
Sample:	<stx>RY</stx>
	The sample above will turn the ribbon saver on.



This command is ignored on non-equipped printers.

STX r Select Reflective Sensor

This command enables reflective (black mark) sensing for top-of-form detection of rolled butt-cut, and fan-fold or tag stocks with reflective marks on the underside. This Media Sensor will detect a minimum mark of 0.1 inches (2.54 mm) between labels (see the *Operator's Manual* for media requirements). The end of the black mark determines the top of form. Use the <stx>0 command to adjust the print position.

Syntax: <stx>r

Default setting: Edge sensing

STX S Set Feed Speed

This command controls the output rate of the media when the FEED Key is pressed.

Syntax:	<stx>Sn</stx>		
Where:	п	-	Is a letter value (see Appendix L).

STX T Print Quality Label

This command instructs the printer to produce a Print Quality label, a format comprised of different patterns and bar codes useful in printer setup. To capture all printed information, use the labels as wide as the maximum print width (see Appendix K) and at least four inches (102 mm) long.

Syntax:

<STX>T

Printer response (dot patterns may vary):



STX t Test DRAM Memory Module

This command tests the DRAM module. The printer returns a one-line message stating the module condition (no message is returned if a module is unavailable). The printer must have Feedback Characters enabled for this command to function. Feedback Characters can be enabled via the menu (see the *Operator's Manual* for additional information).

Syntax:	<stx>t</stx>
Response format:	Module D: xxxxK RAM Tested <i>results</i> <cr></cr>
Where:	- Module size in Kbytes.
	results - Test results given as "Good" or "Bad".

STX U Label Format String Replacement Field

This command places new label data into format fields to build a label. Two options are available: Exact Length and Truncated Length.

To easily keep track of fields, place all of the fields to be updated with the command at the beginning of the label format. A maximum of 99 format fields can be updated. Fields are numbered consecutively 01 to 99 in the order received.

Exact Length Replacement Field Functions – The new data string must equal the original string length and contain valid data. When the dynamic data is shorter than the length of the originally defined data field, then field will be padded with blanks (or zero when the Format Record header specifies a numeric bar code).

<stx>Unnsss<cr></cr></stx>			
<i>nn</i> - Is the format field number, 2 digits.			
sss - Is the new string data, followed by a <cr></cr>			
<stx>L</stx>			
1A1100001000100data field 1 <cr></cr>			
161100001100110data field 2 <cr></cr>			
161100001200120data field 3 <cr></cr>			
Q0001			
E			
<stx>U01123<cr></cr></stx>			
<stx>U02New data F2<cr></cr></stx>			
<stx>E0002</stx>			
<stx>G</stx>			

The sample above produces three labels. The first is formatted with the commands between <STX>L and E. The next two labels print with the replacement data contained in the <STX>U commands (see <STX>E and <STX>G). The bar code is the same length: 3 digits and nine spaces.

commands (see <STX>E and <STX>G). The bar code is shortened;

Truncated Length Replacement Field Functions – A variant of the <STX>U command includes the truncate option "T", where dynamic data shorter than the originally defined field length will <u>not</u> be padded and the original maximum field length is maintained for subsequent replacements.

Syntax:	<stx>UTnnsss<cr></cr></stx>			
Where:	<i>nn</i> - Is the format field number, 2 digits.			
	T - Truncate option			
	<i>sss</i> - Is the new string data, followed by a <cr>.</cr>			
Truncated Sample:	<stx>L 1A1100001000100data field 1<cr> 161100001100110data field 2<cr> 161100001200120data field 3<cr> Q0001 E <stx>UT01123<cr> <stx>U02New data F2<cr> <stx>E0002 <stx>G</stx></stx></cr></stx></cr></stx></cr></cr></cr></stx>			
	The sample above produces three labels. The first is formatted with the commands between L and E. The next two labels print with the replacement data contained in the U			

it only has three digits (and no spaces).

Class Series 2 Programmer's Manual

STX V Software Switch Settings

This command controls the printer options, where the appropriate value allows the option(s) to be "On" or "Off." Each option has a corresponding bit whose value is "1" when enabled. The tables below indicate the bit assignments and corresponding command value needed to enable the desired option(s). Printer options are set by entering selections through the menu. The software setting command allows two of these option settings to be modified without returning to the menu.

Syntax:	<stx>Vn</stx>	
Where:	n -	Is a single digit ASCII numeric value from 0-F. The value of n is used to override the power-up option settings. Reset or power-up returns the printer to the original settings.
Sample:	<stx>V5</stx>	

The sample above corresponds to setting Bits 0 and 2, creating a command value of 5. When applied, this enables the Present Sensor and Cutter options.

Bit Assignment	Printer Option
0	Cutter
1	N/A
2	Present Sensor
3	N/A

Table 4-1: Software Switch Bit Assignment

Use the bit assignment table above to determine the command value n in the binary table below (e.g., the command value 5 sets the bits 0 and 2 to "1").

Command Values for Bits Assigned					
	Bit				
n Value	3	2	1	0	
0	0	0	0	0	
1	0	0	0	1	
4	0	1	0	0	
5	0	1	0	1	

 Table 4-2: Software Switch Binary

STX v Request Firmware Version

This command causes the printer to send its version string (same as printed on the configuration label). The version may be different from printer to printer.

Syntax:	<stx>v</stx>
Printer Response:	VER: H-4212-11.04 01/01/2008 <cr></cr>

STX W Request Memory Module Information

This command requests a memory module directory listing. Results may vary depending on printer class, model, or firmware version.

Syntax:	<stx>W[b][c]a</stx>
Where:	<i>b s</i> optional – list file size also
	c e optional – list file extension also
	a – Data type:
	 F = Downloaded fonts G = Graphics (Image) L = Label formats C = Configuration files X = Menu language files N = Plug-ins M = Miscellaneous type files f = Resident fonts p = Resident fonts * = Entire module contents All types
Sample:	<stx>WF</stx>
Printer response (<i>using an H-Class</i>):	MODULE: D <cr> S50 92244ttf50<cr> AVAILABLE BYTES: 945152<cr> MODULE: G<cr> AVAILABLE BYTES: 852480<cr> MODULE: X<cr> AVAILABLE BYTES: 852480<cr> MODULE: Y<cr> AVAILABLE BYTES: 852480<cr></cr></cr></cr></cr></cr></cr></cr></cr></cr>

STX w Test Flash Memory Module

This command tests the Flash module. The time for each test will vary from 20 to 120 seconds, depending upon the size of the module. **All stored data will be destroyed.** If no module is present, there will be no printer response.

Syntax:	<stx>wa</stx>
Where:	<i>a</i> - Module designator; see Appendix K.
Response format:	Module A: xxxxK results
Where:	A - Module tested.
	- Module size in Kbytes.
	<i>results</i> - Test results given as "Good" or "Bad".

STX X Set Default Module

This command, typically used prior to the loading of PCL-4 bitmapped fonts (see Font Loading Commands), is designed to allow the user to select between modules when downloading information. The default module is one of the following:

- 1. The first alpha designator of the existing modules if item 2 has not occurred.
- 2. The module selected by this command.

Syntax:	<stx>Xa</stx>		
Where:	а	-	Module designator; See Appendix

Sample: <STX>XB

The sample above sets B'' as the default module.

Κ.

STX x Delete File from Module

This command removes a specific file from the specified module. The file name is removed from the module directory and thus the file cannot be accessed. The actual storage space occupied by the file is not released. To reclaim deleted file storage space use $\langle STX \rangle_Z$ to pack the module.

Syntax: <STX>xmtnn...n<CR>

Where:

m - Module designator; see Appendix K.

- *t* The file type identification code:
 - G = Image file
 - L = Label format file
 - F = Downloaded bitmapped font file
 - s = Downloaded scalable font file
 - = Configuration file
 - = Language file
 - N = Plug-in file

С

Χ

- M = Miscellaneous file type
- u = Unknown type must use extension if applicable
- *nn...n* The file to delete, where:
 - Font (bitmapped), three character font identifier;
 - Font (scalable), two character font identifier;
 - Graphic name, up to sixteen alphanumeric characters; or,
 - Label format name, up to sixteen alphanumeric characters.

Sample:

<STX>xDS50<CR>

The sample above deletes a downloaded scalable font with ID 50 from Module D.

STX Y Output Sensor Values

This command causes a sensor value response. When <STX>Y is received, the printer will respond with the digitally converted values of the internal analog sensors (see below). To repeat the display of values, send the printer a "SPACE" character (20 hexadecimal); or, send <ESC> to terminate this function.

The printer must have Feedback Characters enabled for this command to function. (Feedback Mode [Characters] can be enabled via command or menu setting; see the <STX>KcFM command or the *Operator's Manual* for additional information).

Syntax:	<stx>y</stx>	
Printer response:	Transmissive AD 0217 Contrast	0048 Reflective ADC: 0000 C: 0204 Paperout ADC: 0000 24 Volt ADC: ADC: 0093 TOF Adjust ADC: 0170 Ribbon ery Level: Good <cr></cr>
Where:	Paperout ADC:	0225 indicates paper is present; 0000 indicates paper is not present.
	Battery level:	Good indicates a sufficient battery charge; Low indicates an insufficient charge.

Equipped sensors vary with printer, model, and options;

 Some readings require printer-controlled paper movement to produce a meaningful value; and,

• Media Sensor readings require the appropriate sensor selection, transmissive (<STX>e) or reflective (<STX>r), and label stock placed in the sensor.

STX y Select Font Symbol Set

This command selects the scalable font symbol set. The selected symbol set remains active until another symbol set is selected. See the <STX>KS command and Appendices E, I, and H for more information. Option dependent and not all symbol sets can be used with all fonts.

Syntax:	<stx>ySxx</stx>
Where:	S- Byte-size designation; see Appendix H:S= Single byte symbol sets.U= Double byte symbol sets.
	xx - Symbol set selection.
Sample:	<stx>ySPM</stx>

The sample above selects the PC-850 multilingual set.

STX Z **Print Configuration Label**

This command causes the printer to produce a Database Configuration Label. To capture all printed information, use the labels as wide as the maximum print width (see Appendix K) and at least four inches (102 mm) long.



Printed information will vary according to printer, model, firmware version, and options.

STX z Pack Module

This command causes the printer to reclaim all storage space associated with all deleted files on the specified module (see <STX>X and <STX>x).

Syntax:	<stx>zm</stx>	
Where:	m	- The module identification character; see Appendix K.
	Valid for I-Class and A-Class	ass only, ignored by all others.

5 Extended System-Level Command Functions

Introduction

Issued in the same context as System-Level Commands, the Extended System-Level Commands expand certain System-Level Commands to provide an extra degree of printer control.

STX K Memory Configuration

This command configures the available DRAM (including any installed optional DRAM) as a method for managing printer memory. Memory can be assigned to specific entities or functions in units of 4KB blocks. The allocation(s) set by this command, draw from the same memory pool, affecting maximum print length and label throughput (see note below). The printer executes the memory configuration specified by the command during the next idle period following its receipt, and is stored in Flash memory then reinstated upon a power-up or reset. If the total requested memory allocation exceeds the configurable memory available, contains no fields, or for configurations not specified, the command will be rejected and the printer will assume its previous configuration. Any of the three fields are optional, and are separated by the colon. Brackets indicate optional fields.

Syntax: <STX>Kix[:jy][:kz]<CR>

Sample: <STX>KM0020:S0015<CR>

The sample above allocates 20*4*1024 bytes for module space and 15*4*1024 bytes for the scalable cache.

Where,

i, j, k are M, S, or W; x, y, z are four-digit maximum numbers of 4K byte blocks or inches/100 or (mm/10) as described below.

- M Represents the start of a sequence (up to five characters) that assigns memory to an Internal Module. If this field does not appear, then the Internal Module is not affected. If no Internal Module exists, it will be created and formatted. Existing Internal Modules will be erased, re-sized and formatted. The number that follows the M is a decimal number (up to four digits) that specifies the size in 4KB blocks of memory to assign to the Internal Module. A value of "0000" will delete the Internal Module (see Appendix J for additional information).
- *s* Represents the start of a sequence (up to five characters) that assigns the amount of internal memory allocated to the smooth scalable font processor. This field is optional; if it does not appear, the current amount of memory assigned to the

smooth scalable font processor will remain unchanged. The allocation must be at least 15 (60KB) to print scalable fonts, and at least 30 for double-byte fonts. The number that follows the S is a decimal number (up to four digits) that specifies the size in 4 KB blocks to assign to the smooth scalable font processor. Any value less than the minimum requirement results in the amount assigned to be zero (0), thereby disabling the printing of smooth scalable fonts. The recommended value is 0025 (100KB).

- Represents the start of a sequence (up to five characters) that sets the printable label width. Setting a width smaller than the natural (maximum) width of the printer effectively extends printable label length. This field is optional; if it does not appear, the current printable label width is left unchanged. The number that follows the W is a decimal number (up to four digits) that specifies the printable label width in either 100^{ths} of an inch or in millimeters, depending on the current units setting of the printer (imperial or metric). If the value specified exceeds the printable width of the printer, the printable label width is set to the maximum. If the value specified is less than the minimum value allowed (200) then the printable label width is set to the minimum allowed value.
 - Label printing requirements may be computed as bytes (label print length times width allocation times print head resolution divided by 8). For maximum throughput, the memory allocated should allow for a minimum of three times the computed requirement, or the available label length (as determined by <STX>KQ command) should be three times the label print length; and,
 - These commands will result in a system reset for the EX2.

STX K}E Empty Sensor Calibration (Non-Display Models only)

This command causes the printer to determine and save the calibration value for an empty media sensor condition. This calibration function should be performed when no material is installed in the media sensor. Depending upon the printer model, different front panel LED flash sequences and printer responses (below) will indicate calibration progress and outcome; see the corresponding printer operator manual for LED flash sequences details.

Printer Response	Alternate
REMOVE STOCK[CR]	N/A
ENTER TO CONTINUE[CR]	N/A
PASSED CALIBRATION[CR]	FAILED CALIBRATION[CR]

STX K}M Manual Media Calibration (Non-Display Models only)

This command causes the printer to save the sampled calibration values as an operator places different portions of label stock within the media sensor. Depending upon the printer model, different front panel LED flash sequences and printer responses (below) will indicate calibration progress and outcome; see the corresponding printer operator manual for LED flash sequences details. Sending <ESC> to the printer instead of <CR> will terminate the process and leave the TOF Sensor values unchanged.

Printer Response	Alternate
LOAD STOCK[CR] ENTER TO CONTINUE[CR]	N/A
LOAD MARK[CR] ENTER TO CONTINUE[CR]	LOAD GAP[CR]
REMOVE STOCK[CR] ENTER TO CONTINUE[CR]	N/A
PASSED CALIBRATION[CR]	FAILED CALIBRATION[CR]

STX K}Q Quick Media Calibration (Non-Display Models only)

This command causes the printer to move media, sample, and then save sensor samples as calibration values. This calibration function should be performed with media installed in the printer. Depending upon the printer model, different front panel LED flash sequences and printer responses (below) will indicate calibration progress and outcome; see the corresponding printer operator manual for LED flash sequences details.

Printer Response	Alternate
FAILED CALIBRATION[CR] ADJUST GAIN SETTING[CR]	N/A
PASSED CALIBRATION[CR]	FAILED CALIBRATION[CR]

STX KaR Read Data from RFID Tag

(Direct Mode – Generic Read/Write Interface)

This command instructs the RFID device to read data from the tag and then place that data into a replaceable field. It is expected that the tag transponder will be within the read / write distance of the RFID programming device; otherwise, "Void" will be printed in the text or bar code label field.

Syntax:	<stx>KaRAaaabbbcdee<cr></cr></stx>		
Where:	 - Optional – for data in the ASCII format. 		
	- The number of bytes to read.		
	 bbb - HF - Starting block number (000 → maximum block number, which is dependent upon the transponder manufacturer). UHF - Should be 000. 		
	<i>c</i> - Command 1. Reserved. Should be 0.		
	d - Command 2. Reserved. Should be 0.		
	 Field number in which to place the data (must be 01, 02, 03, etc.) matching the order of Label Formatting command U. 		
	The 00 value will send read data to the host with no printing.		
Sample:	<stx>L 1911A1802000010TEXT U X <stx>KaR0000010001 <stx>G</stx></stx></stx>		
	The sample above creates a replaceable text field (01), recalls data from the RFID tag block zero (reading only one block), and prints the data in the location specified by the replaceable field. Since there are two digits per each hex value, replaceable fields should be twice as long than if using ASCII data (e.g., the character "A" would be returned as "41").		

STX KaW Write Data to RFID Tag

(Direct Mode - Generic Read/Write Interface)

This command instructs the RFID device to write data to the tag. It is expected that the tag transponder will be within the read / write distance of the RFID programming device; otherwise, a warning will occur and a warning message (Read / Write Fail) will be displayed.

Syntax:	<stx>KaWAaaabbbcdeee<cr></cr></stx>		
Where:	Aaaa -	Optional – for data in the ASCII format, followed by the byte count (000-999).	
	bbb -	 HF – Starting block number (000 → maximum block number, which is dependent upon the transponder manufacturer). UHF – Should be 000. 	
	C -	Command 1. Reserved for Future (should be 0)	
	d -	Command 2. Reserved for Future (should be 0)	
	ее…е -	Data to be encoded on RFID tag (HF – the last used block will be null-padded, if necessary).	
		UHF ASCII formats must be 8 or 12 characters; and,	
		UHF Hexadecimal formats must be 16 or 24 character pairs.	
Sample:	<stx>KaW000</stx>	0054455354[CR]	

The sample above writes the data "TEST" at block zero.

STX Kb Backfeed Time Delay

This command controls the time a printed label is allowed to remain "presented" before being retracted to the start of print position.

Syntax: <STX>Kbnnn<CR>

Where: nnn - Seconds/10

STX KC Get Configuration

This command returns the configuration of the printer. The form of the returned data is similar to that of a printed Configuration Label. **This command should be parsed by KEYWORDS, not character positions.** Each line is terminated by a CR (0x0d) & LF (0x0a).

Syntax: <STX>KC<CR>

Printer response:

CONFIGURATION TUE 02:01PM 01AUG2005 PRINTER KEY: 4308-TB10-010327-494 APPLICATION VERSION: 83-2284-06E 06.06 07/09/2001 BOOT LOADER: 83-2269-03D 03.04 10/30/2000 SYSTEM INFORMATION PRINT BUFFER SIZE: 280 in. FLASH SIZE: 4 MB RAM TEST: PASS OPTIONAL LANGUAGES: FRANCAIS ITALIANO DEUTSCH ESPAÑOL CONFIGURATION FILE: NONE MEDIA SETTINGS MEDIA TYPE THERMAL TRANSFER SENSOR TYPE GAP LABEL LENGTH 04.00 in. MAXIMUM LABEL LENGTH •30.00 in. PAPER OUT DISTANCE 00.25 in. LABEL WIDTH 4.16 in. SENSOR CALIBRATION PAPER SENSOR LEVEL 144 GAP SENSOR LEVEL 30 EMPTY SENSOR LEVEL 0

SENSOR GAIN 10 PRINT CONTROL HEAT 10 PRINT SPEED 6.0in/sec FEED SPEED 6.0in/sec REVERSE SPEED 4.0in/sec ROW OFFSET 00.00 in. COLUMN OFFSET 00.00 in. PRESENT DISTANCE 0.00 in. CUSTOM ADJUSTMENTS: DARKNESS 32 ROW ADJUST 64 DOTS COLUMN ADJUST 0 DOTS PRESENT ADJUST 64 DOTS PRINTER OPTIONS MODULES A: NOT INSTALLED B: NOT INSTALLED D: FORMATTED F: NOT INSTALLED G: FORMATTED X: FORMATTED Y: 83-2296-01C Z: NOT INSTALLED PRESENT SENSOR NOT INSTALLED CUTTER NOT INSTALLED GPIO PORT: NOT INSTALLED SYSTEM SETTINGS

FACTORY SETTING FILE NONE INTERNAL MODULE 1024 KB DEFAULT MODULE D SCALEABLE FONT CACHE 312 KB SINGLE BYTE SYMBOLS PC-850 MULTILINGUAL DOUBLE BYTE SYMBOLS UNICODE ABSOLUTE COUNTER 3782 in. 27MAR2001 RESETTABLE COUNTER 205 in. 27MAR2001 FORMAT ATTRIBUTES XOR IMAGING MODE MULTIPLE LABEL PAUSE MODE DISABLED SELECT SECURITY DISABLED PEEL MODE DISABLED UNITS OF MEASURE IMPERIAL SOP EMULATION DISABLED BACK AFTER PRINT DISABLED MENU LANGUAGE ENGLISH COMMUNICATIONS SERIAL PORT A: BAUD RATE 9600 BPS PROTOCOL BOTH PARITY NONE

DATA BITS 8 STOP BITS 1 SERIAL PORT B: NOT INSTALLED PARALLEL PORT A: PORT DIRECTION UNI-DIRECTIONAL PORT STATUS DISABLED PARALLEL PORT B: PORT DIRECTION BI-DIRECTIONAL PORT STATUS DISABLED NIC ADAPTER: DMXNET INACTIVE HOST SETTINGS: HOST TIMEOUT 10 SEC CONTROL CODES STANDARD CODES FEEDBACK CHARACTERS DISABLED ESC SEQUENCES ENABLED HEAT COMMAND ENABLED SPEED COMMANDS ENABLED DIAGNOSTICS HEX DUMP MODE DISABLED PRINT TEST RATE(min) 0 SENSOR READINGS THR TRAN RIBM 24V 132 141 159 178 PS HD RANK 000 254 000 RIBBON SENSOR LIMITS RIBBON ADC LOW 105 RIBBON ADC HIGH 182 END OF LIST



The format of the displayed information will vary with printer, model, firmware version, and equipped options.

STX Kc Configuration Set

This command specifies the Power-up Configuration parameter values for the printer and is equivalent to using other system commands followed by the <SOH>U. This command is intended for easily configuring a custom setup, but <u>NOT</u> for dynamic configuration changes. Configuration commands are examined for differences relative to the current configuration, and have no impact when no differences exist. Display-equipped models will reset upon completion of a command stream containing parameter value changes, while non-display models reset only for certain functions, such as memory allocation. In any case, no commands should be sent to the printer until this reset is complete. Other command highlights include the following:

- These parameter values are equivalent to changing the respective menu settings and do not affect the factory default settings of the printer.
- If separated by a semi-colon (;), multiple parameter values may be sent in a single command stream; see sample below.
- All values are stored in Flash memory and remain in effect until new values are received or until factory defaults are restored.
- If system commands are sent that override the Power-up Configuration value(s), the Power-up Configuration value(s) will be restored the next time the printer is powered "On" or is reset.
- These parameters are the same as those found in the Setup Menu (non-display models), or as those found in the Menu System (display-equipped models). The respective functions are documented in the appropriate *Operator's* or *Maintenance Manual*. Not all commands are effective on all Class printers.

Illegal or out of range parameter values may have unpredictable results. In addition, media sensing scaling values, TOF Bias, etc. may not be effective on other same-type printers due to hardware tolerances.

Syntax:	<stx>Kcaa₁val₁[;aa₁val₁][;aa_nval_n]<cr></cr></stx>				
Where:	aa_1, aa_1, aa_n - Are two letter parameter names.				
	 val₁, val₁, val_n Are parameter values, with ranges appropriate for the associated parameter. 				
Sample:	<stx>KcPA120;CL600;STC<cr></cr></stx>				
	The sample above sets the Present Adjust to 120 dots, and the Sensor Type to Continuous with a label length of six inches.				

The following table summarizes (alphabetically by name) different Configuration Set command parameters, value ranges, command equivalents and applicability. If no command equivalent is given, or where clarification is required, descriptions immediately follow the table.

	Configuration Set Commands						
<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent		
Alignment Length	AL	0 - 999	1/100 inch	(18)	N/A		
Backup After Print	BA	Y, N	Y = Enabled, N = Disabled	System Settings	N/A		
Backup Delay	BD	0 – 255	1/50 second	System Settings	N/A		
Backup Label	BL	0, 3, 4	0 = Disabled, 3 = Active Low, 4 = Active High	Printer Options	N/A		
Backup (Reverse) Speed	BS or bS	alpha character	Model specific ranges; see Appendix L.	Print Control	ра		
British Pound	ВР	Y, N	Y = Enabled, N = Disabled	N/A	N/A		
Buzzer Enable	BZ	Y, N	Y = Enabled, N = Disabled	System Settings	N/A		

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Column Adjust ^[1]	CA	xxx dots	Resolution specific; see Appendix K, and Column Adjust Fine Tune	Print Control (7)	N/A
Column Adjust Fine Tune	CF	+ / – dots	Resolution specific; see Appendix K.	Print Control	N/A
Column Offset	со	0 - 9999	1/100 in.	Print Control	Cnnnn
Comm Heat Commands	СН	Y, N 1, 0	Y = Enabled, N = Disabled 1 = Enabled, 0 = Disabled	Communications (25) (E-Class - 24)	N/A
Comm Speed Commands	CS	Y, N 1, 0	Y = Enabled, N = Disabled 1 = Enabled, 0 = Disabled	Communications (26) (E-Class - 24)	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Comm TOF Commands	CT	Y, N	Y = Enabled, N = Disabled	Communications	N/A
Continuous Label Length	CL	0 - 9999	1/100 in.	Media Settings (12)	<stx>c</stx>
Control Codes	cc	S, 1, 2	S = Standard, 1 = Alternate, 2 = Alternate-2	Communications (11)	N/A
Cut Behind	СВ	0 - 9	Queued label count	Printer Options	N/A
Cutter Equipped	CE	A/Y, E, N/D A, E/Y, N	A or Y = Auto, E = Enabled, N or D = Disabled A = Auto, E or Y = Enabled, N = Disabled	Printer Options	<stx>v</stx>

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Darkness	DK	1 - 64	N/A	Print Control	N/A
Default Module	DM	D, G A, B	Module Letter	System Settings	<stx>X</stx>
Delay Rate (Test Labels)	DR	0 - 120	Seconds	Diagnostics	N/A
Disable Symbol Set Selection	NS	Y, N	Y = Enabled, N = Disabled	N/A	N/A
Display Mode	GD	S, E	S = Standard, E = Enhanced	System Settings	N/A
Double Byte Symbol Set	DS	2-Byte alpha character	AA – ZZ, printer resident symbol set	System Settings	<stx>y, y<i>Sx</i>x</stx>
DPI Emulation	DE	200, 300, 400, 600	Dots per inch	System Settings	N/A
Empty Sensor Level	EV	0 - 255	N/A	Media Settings	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
End Character	EN	D	N/A	N/A	N/A
End Of Print	EP	1, 2, 3, 4	1 = Low Pulse, 2 = High Pulse, 3 = Active Low, 4 = Active High	Printer Options	N/A
ESC Sequences	ES	Y, N	Y = Enabled, N = Disabled	Communications	N/A
Fault Handling	FH	L, D, R, B	See Table 5-2.	System Settings (24)	N/A
Feed Speed	SS or sS	Alpha character	Model specific ranges; see Appendix L.	Print Control	Sa

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Feedback Mode	FM	Y, N	Y = Enabled, N = Disabled	Communications	<stx>a</stx>
Font Emulation	FE	0, 1, 2	0 = No Substitution 1 = Sub CG Times SA0 2 = Sub User S50	N/A	N/A
Format Attributes	FA	Х, О, Т	X = XOR, O = Opaque, T = Transparent	System Settings	An
Gain Reflective Value	GR	0 - 31	N/A	Media Settings	N/A
Gap / Mark Value	GM	0 – 255	N/A	Media Settings	N/A
Gap Sensor Location (MP Comapct4 Mark II only)	GL	0 or 1	0 = Outer sensor, default 1 = Inner sensor	N/A	<stx>KcGL</stx>
GPIO Equipped	GE	A, V, N, 2	A = Applicator, V = Verifier, N = Disabled, A = Applicator2	Printer Options (23)	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
GPIO Error Pause	GP	E, D	E = Enabled, D = Disabled	Printer Options	N/A
GPIO Slew	GS	0 - 4	0 = Standard, 1 = Low Pulse, 2 = High Pulse, 3 = Active Low, 4 = Active High	Printer Options	N/A
Head Bias	НВ	L, R	L = Leftmost dot is zero, R = Rightmost dot is zero	System Settings	N/A
Head Cleaning	НС	0 – 9999	Inches (or centimeters) multiplied by 1000	Media Settings	N/A
Heat	HE	0 - 30	N/A	Print Control (21)	Hnn
Host Timeout	нт	1 - 60	Seconds	Communications	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Ignore Control Codes	IC	Y, N 1, 0	Y = Enabled, N = Disabled 1 = Enabled, 0 = Disabled	Communications	N/A
Ignore Distances	IE	1,0	1 = Enabled, 0 = Disabled	N/A	N/A
Imaging Mode	IL	M, S	M = Multiple label, S = Single label	System Settings (22)	N/A
Input Mode	EM	0, 1, 3, 7, 9	0 = DPL, 1 = Line, 3 = PL-Z, 7 = PL-B, 9 = Auto	System Settings (19)	N/A
Internal Module	IM	100 – up to max. available; see Appendix K	Kbytes	System Settings (15)	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Label Alignment	LA	N, A, Y	See Table 5-3.	17	N/A
Label Rotation	LR	Y, N	Y = Rotate 180 N = None	System Settings	N/A
Label Store	LM	F, S	F = Fields, S = States & Fields	System Settings	N/A
Label Width	LW	0075 – head width; see Appendix K	1/100 inch	Media Settings (13)	<stx>kw</stx>
Language Select	LS	String	Language Name	System Settings	N/A
Legacy Emulation	LE	N, A, P, L N, A, P, L, M	N = None, A = Allegro, P = Prodigy, L = Prodigy Plus, M = Prodigy Max X = XL	System Settings (20)	N/A
Mark Value	MV	0 – 255	N/A	Media Settings	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Maximum Length Ignore	SM	0, 1	0 = Normal processing, 1 = Ignore	Communications	N/A
Maximum Length	ML	0 - 9999	1/100 inch	Media Settings	<stx>M</stx>
Media Type	МТ	D, T	D = Direct, T = Thermal Transfer	Media Settings (1)	N/A
Menu Mode	MM	U, A	U = User, A = Advanced	System Settings	N/A
Module Command	MCC	Z, G B	See Table 5-4.	N/A	N/A
Network Configuration (for firmware versions 14.00 and later)	NE	G, WE, WIFI, DV1, DV2, SV1	See command (NE) Network Configuration	N/A	N/A
Network Setup (for firmware versions 13.99 and earlier)	NT	A, B, C, D, E, F, G, I, m, N, P, S, T, U, W, w, X, Y, Z, \$	See Table 5-5.	N/A	N/A
No Reprint	NR	Y, N	Y = Enabled, N = Disabled	N/A	N/A
Option Feedback	OF	D, Rx, S	See Table 5-6.	Communications	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Paper Empty	PO	0 - 9999	1/100 inch	Media Settings	N/A
Paper Value	PV	0 – 255	N/A	Media Settings	N/A
Parallel Direction	РР	xz	See Table 5-7.	Communications	N/A
Password Set	PW	A – Z, 0 – 9	Four characters (or, if security is enabled then eight characters).	System Settings	N/A
Pause Mode	РМ	Y, N	Y = Enabled, N = Disabled	System Settings	<stx>J</stx>
Peel Mode	PE	Y, N	Y = Enabled, N = Disabled	System Settings	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Present Adjust [1]	PA	xxx dots	Model specific; see Appendix K, and Present Adjust Fine Tune.	Print Control (8)	N/A
Present Adjust Fine Tune	PJ	+ / - dots	Dots (model specific), see Appendix K.	Print Control	N/A
Present Distance	PD	0 - 400	1/100 inch	Print Control	<stx>Kf</stx>
Present Sensor Equipped	PS	A/Y, E, N/D	A or Y = Auto, E = Enabled, N or D = Disabled	Printer Options (3)	<stx>v</stx>
Print Contrast	PC	0 - 64	N/A	Print Control	N/A
Printer Level	PL	000000 – FFFFFF	Hex Codes	System Settings	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Print Speed	pS	Alpha character	Model specific ranges; see Appendix L.	Print Control	Pa
Query Configuration	QQ	Q, K	N/A	Configuration Label	N/A
Reflective Paper Value	RV	0 - 255	N/A	Media Settings	N/A
Retract Delay	RW	1 - 255	Specified value times ten milliseconds	Printer Options	N/A
Rewinder Adjust	RR	-хх, +уу	Applied torque, where -30 to +15 is the valid range.	Printer Options	N/A
Rewinder Equipped	RM	A/Y, E, N/D	A or Y = Auto, E = Enabled, N or D = Disabled	Printer Options	N/A
RFID Configuration	RI	A, B, D, E, L, M, N, P, R, S, T, U, V, W	See Table 5-8.	Printer Options	N/A
Ribbon Low Diameter	RL	100 - 200	1/100 in.	Media Settings	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Ribbon Low Pause	RP	Y, N	Y = Enabled, N = Disabled	Media Settings	N/A
Ribbon Low Signal	RS	3, 4	3 = Active Low, 4 = Active High	Print Options	N/A
Ribbon Saver Enable	RE	A/Y, E, N/D	A or Y = Auto, E = Enabled, N or D = Disabled	Printer Options	<stx>R</stx>
Row Adjust ^[1]	RA	xxxx dots	Model specific; see Appendix K, and Row Adjust Fine Tune	Print Control (6)	N/A
Row Adjust Fine Tune	RF	+ / - dots	Resolution specific; see Appendix K.	Printer Control	N/A
Row Offset	RO	0 - 9999	1/100 in.	Print Control	R <i>nnnn</i>
SOP Adjust ^[1]	SA	0 - 255 (128 nominal)	N/A, see Row Adjust Fine Tune	N/A	<stx>O</stx>
SOP Emulation	SE	A, L, P, D	A = Allegro, L = Prodigy Plus, P = Prodigy, D = Disable	System Settings	N/A

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Save As Filename	SF	Alphanumeric string	Up to 16 characters	System Settings	N/A
Scalable Font Bolding	FB	1 - 36	N/A	System Settings	N/A
Scalable Font Cache	SC	100 – 8192	Kbytes	System Settings (14)	N/A
Scalable Heap	SH	0 – 9999	Kbytes	N/A	N/A
Scanner Configuration	SN	C, H, M, D, B, V	See Table 5-11.	Printer Options	N/A
Security Lock	Sl	Ν, Υ, Τ	See Table 5-9.	System Settings	N/A
Sensor Gain Value	SG	0 - 32	N/A	Media Settings	N/A
<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
----------------------------------	------------------------	---------------------------	--	---	--
Sensor Type	ST	G, C, R	G = Gap (edge), C = Continuous, R = Reflective	Media Settings (2)	<stx>e, <stx>r, <stx>c</stx></stx></stx>
Serial Port	SP	хуz	See Table 5-12.	Communications 9 & 10	N/A
Single Byte Symbol Set	AS	2-Byte alpha character	AA – ZZ, printer resident symbol set	System Settings	<stx>y, ySxx</stx>
Slew Speed	FS	Alpha character	Model specific ranges; see Appendix L.	Print Control	<stx>KZSx</stx>
Software Switch	SV	Y, N	Y = Processed N = Ignored	Communications	N/A

(continued)

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Start of Print	EQ	3, 4	3 = Active Low, 4 = Active High	Printer Options	N/A
Stop Location	SL	A, H, P, C, T, N	See Table 5-10.	16	N/A
TOF Precedence	TP	Y, N	Y = Enabled, N = Disabled	N/A	N/A
User Label Mode	UD	Y, N	Y = Enabled, N = Disabled	System Settings	N/A
Unit of Measure	UM	M, I	M = Metric, I = Imperial	System Settings (5)	<stx>m, <stx>n</stx></stx>
User Terminator	UT	ON	N/A	N/A	N/A

(continued)

<stx>Kc Parameter Name</stx>	Parameter Pneumonic	Value / Range	Units / Interpretation	Menu Item (or Number) (if available)	Command Equivalent
Verifier Equipped	VE	A/Y, E, N/D	A or Y = Auto, E = Enabled, N or D = Disabled	Printer Options	<stx>KV</stx>
Verifier Type	VT	A, B, C, D	Reserved for future use	N/A	N/A
WiFi Security (for firmware versions 13.99 and earlier. For firmware versions 14.00 and later see Network Setup parameter NE)	WS	A, K, S, L, P, U	See Table 5-14.	N/A	N/A
WiFi Setup (for firmware versions 13.99 and earlier. For firmware versions 14.00 and later see Network Setup parameter NE)	WE	A, C, F, I, L, M, N, P, R, T, V, X	See Table 5-13.	N/A	N/A

1. Commands are provided for backward compatibility on EX2. The KcQQQ command will respond with the new command equivalent; see associated new commands.

2. The EX2 will accept display-equipped module IDs (D & G) as command parameters for upward compatibility; query commands will result in printer responses with module IDs that are non-display compatible, providing backward compatibility.

3. Present distance changes for EX2 will only be accepted if the Stop Location (SL) is set to "Host."

Table 5-1: Configuration Set Commands

<STX>Kc Parameter Overviews

(AL) Alignment Length – This command, critical for small labels when Label Alignment is set to YES, allows a length (measured from leading edge to leading edge of two successive labels) to be entered. The measured length must be provided to the nearest hundredth of an inch. For very small labels, errors of 0.01" can result in noticeable print variations on the labels between the media sensor and the print head. The number of labels that can be fit between the Media Sensor and the print head will magnify any error in label alignment length. Errors in measurement are more favorable on the low side rather than the high side.

Non-Display models: The printer will verify the label position using the provided Alignment Length before printing the first label after power-up.

(AS) Single Byte Symbol Set – This command allows for a default single-byte symbol set. See <STX>y or ySxx for command details.

(BA) Backup After Print – This command determines the timing of the label back up positioning when the present distance is set and the GPIO option or Present Sensor option (including Peel and Present) is enabled. When enabled, the printer immediately backs up the label after the applicator-issued start of print signal is received or the label is removed, resulting in faster throughput. If disabled, the printer will not initiate repositioning until the next label is ready to print (may help prevent the curling of the label edge).

(BD) Backup Delay – This command sets a time delay for the retraction of a presented label in one-fiftieth (1/50) of a second increments.

(BL) Backup Label – This command determines the timing of reverse label motion when the GPIO option is installed and enabled; see Appendix J for details.

(BP) British Pound – This command, when enabled, will automatically switch from the Number symbol (#) found at 0x23 (default PC-850 Multilingual Symbol Set) to the British Pound symbol (£) at 0x9C.

(BS or bS) Backup Speed – This command controls the rate of label movement during backup positioning for start of print, cutting or present distance; see Appendix C for available speed ranges.

(BZ) Buzzer Enable – This command controls the audible signaling device that acknowledges User Interface entries and, if enabled, sounds printer warning and fault conditions.

(CA) Column Adjust – This command fine-tunes the Column Offset setting by shifting both the horizontal start of print position and the Label Width termination point to the right in dots (see Appendix K) to compensate for slight mechanical differences sometimes evident when multiple printers share label formats. Note that the EX2 accepts this command for backward compatibility only, limited in range (28-228). The <stx>KcQQQ response will show the Column Adjust Fine Tune (CF) equivalent value.

(CB) Cut Behind – This command allows the printer to queue a specified number of small labels before a cut is performed to increase throughput.

(CC) Control Codes – This command, depending upon printer type, allows a change to the prefix of the software commands interpreted by the printer:

Value	Units / Interpretation	Control Code Definition
S	Standard Codes	Hex 01 = SOH command; Hex 02 = STX command; count- by = ^; Hex 1B = ESC; Hex 0x0D = Carriage Return
1	Alternate Codes	Hex 5E = SOH command; Hex 7E = STX command; count- by = @; Hex 1B = ESC; Hex 0x0D = Carriage Return
2	Alternate Codes 2	Hex 5E = SOH command; Hex 7E = STX command; count- by = @; Hex 1B = ESC; Hex 0x7C = Carriage Return

(CE) Cutter Equipped – This command allows the printer to sense the cutter option. "A" - automatically senses device presence; if undetected, no error is generated. "E" enables the device, where its presence must be detected; otherwise, a fault is generated. "N" - disables device detection. One of these values is returned in response to <STX>KcQQQ. Note that alternate values are accepted for backward compatibility as follows: For display-equipped models "Y" is equivalent to "A"; and, for non-display models "Y" is equivalent to "E".

(CF) Column Adjust Fine Tune – This command fine-tunes the Column Offset setting by shifting both the horizontal start of print position and the Label Width termination point to the right in dots (see Appendix K) to compensate for slight mechanical differences sometimes evident when multiple printers share label formats.

(CH) Communicated Heat Commands – This command causes the printer to ignore DPL Heat commands; instead, the Heat value is controlled via the menu setting.

(CL) Continuous Label Length – See <STX>c for command details.

(CO) Column Offset – See Cnnnn for command details.

(CS) Communicated Speed Commands – This command causes the printer to ignore DPL speed commands; instead, speed values are controlled via the menu setting.

(CT) Communicated TOF Commands – This command causes the printer to ignore DPL TOF (Gap, Continuous, and Reflective) commands; instead, the sensor type is controlled via the menu setting.

(DE) DPI Emulation – This command allows printers with higher resolutions to emulate lower print resolutions, as follows:

- 600 DPI can emulate 300 and 203 DPI resolutions; and,
- 400 DPI can emulate a 203 DPI resolution.

(DK) Darkness – This command adjusts the length of the print head strobe to finetune the HEAT setting.

(DM) Default Module - See <STX>X for command details.

(DR) Delay Rate – This command sets the number of minutes to delay between multiple batch printings of Quick Test Labels.

(DS) Double Byte Symbol Set – See <STX>y or ySxx for command details.

(EM) Input Mode – This command determines the data processing mode:

Value	Interpretation	Input Mode Interpretation	
0	DPL	Character strings are parsed for standard DPL processing.	
1	Line	No parsing occurs; instead, each carriage return (<cr>) terminated data line is printed according to a stored template (see Appendix S).</cr>	
		Character strings are parsed for PL-Z processing, applicable only if the appropriate firmware is installed, as indicated by a "Z" in the version string (except for H-Class and M-Class Mark II, which is standard).	
3	3 PL-Z	 For RFID, the hardware option, tag type and size should be preselected, and a tag calibration performed. Also, if possible, driver / software options to use "Printer Defaults" should be chosen to minimize potential conflicts. 	
7	PL-B	Character strings are parsed for PL-B processing, applicable only if the appropriate firmware is installed, as indicated by a "B" in the version string.	
		Character strings are automatically parsed and processed according to the identified language.	
9	Auto	A clean file is required, where extra leading characters may cause the language to be unrecognizable; otherwise, the appropriate Input Mode must be selected.	

(EN) End Character – This command terminates a <STX>Kc string.

(EP) End of Print – This command defines the signal output used to signify the End of Print (EOP) process:

Value	Units	End of Print Interpretation
1	Low Pulse	Outputs a low pulse (approximately 30 milliseconds long) following printing.
2	High Pulse	Outputs a high pulse (approximately 30 milliseconds long) following printing.
3	Active Low	Outputs a logic low (zero) following printing.
4	Active High	Outputs a logic high (one) following printing.

(EQ) Start of Print – This command defines the type of signal input required to control the Start of Print (SOP) process:

Value	Units	Start of Print Interpretation	
3	Active Low	SOP signal must go low for at least 50 milliseconds to initiate printing.	
4	Active High	SOP signal must go high for at least 50 milliseconds to initiate printing.	

(ES) ESC Sequences – This command allows data containing invalid ESC control code sequences to be processed (helpful because some systems send a "banner" to the printer). When set to "Disabled," ESC sequences are ignored and the data is processed. Bitmapped font downloads are disabled in this mode.

(EV) Empty Sensor Level – This command sets threshold value for the "Empty" media sensor parameter.

(FA) Format Attribute – See the "An" command for details (Label Formatting Command Functions).

(FB) Scalable Font Bolding – This command sets a bolding factor to fine tune scalable fonts, where one causes the least amount of bolding and thirty-six the most (default value is 8).

(FE) Font Emulation – This command allows font substitution for all internal fonts, allowing a new default font to be defined without changing the host DPL data streams. Selecting a default font that supports a desired character set could match with third party software to print native characters without modifying the PC drivers. In other words, match the PC font with the Printer Font then no interpretation would be required by driver or printer. Depending on host drivers, the user may have to disable Symbol Set commands and modify the Default Symbol set.

(FH) Fault Handling – This command determines the level of user intervention and the disposition of the label being printed when a fault condition (ribbon out, media out, etc.) occurs.

Value	Units / Interpretation	Selection / Definition
	0 = No Reprint	Printing stops and a fault message is displayed. After the problem is corrected, the FEED Key must be pressed to clear the fault. The label in process is <i>not</i> reprinted.
	1 = Standard	Printing stops and a fault message is displayed. After the problem is corrected, the FEED Key must be pressed to clear the fault. The label in process is reprinted.
		Depending upon the RETRY COUNT, one of the following actions when faulted:
		 If the Retry Count has not been exceeded, "VOID" is printed on the label in process and reprinting occurs automatically;
L	2 = Void and Retry	 If the Retry Count has been exceeded, printing stops and a fault message is displayed. After the problem is corrected, the FEED Key must be pressed to clear the fault. The label in process is reprinted; or,
		• If the CANCEL Key is pressed, the operator now has the option of canceling the reprint. To allow reprinting, press the ESCAPE Key; or, to cancel reprinting, press the ENTER Key (and, the entire label batch will be cancelled by pressing the ENTER Key again).
		VOID will not be printed when insufficient text space exists (see VOID DISTANCE, below) or if the fault occurs after the label reaches its Present Distance at, or above, the TOF.

(continued)

Value	Units / Interpretation	Selection / Definition	
		Increases throughput when bar codes reside near the trailing edge of the label (in the direction of FEED).	
	3 = Delayed	 If unreadable, the fault will occur after the next label prints. 	
	Scan Fault	 The label immediately following a faulted label is not scanned for errors. 	
		 VOID AND RETRY and REPRINT are automatically disabled; the job can only be cancelled. 	
	4 = Void Retry & Cont.	VOID is printed on a faulted label, with reprint attempts occurring automatically, until the RETRY COUNT has been exceeded and then that label will be skipped (discarded) and printing will continue to the next label in queue.	
D	Void Distance (.10 - 2.00)	Sets the distance (.10 - 2.00) to backup the faulted label to print "VOID" on its trailing edge, which also indirectly establishes the font size of the void message.	
R	Retry Count (0 – 3)	Establishes the number of times a reprint will be attempted when using the RFID or Scanner option; if the last label printed in this count has been voided, a fault will be declared.	
В	Enable / Disable Y, N	Retract from presented distance prior to feed-clear motion. This option is intended for use with applicator equipment that may require certain GPIO signals for proper operation.	

Table 5-2: Fault Handling Command

Example: <STX>KcFHD112<CR>

The example above configures the printer to back up and print a one-inch tall "VOID" message on a faulted label; if two successive faults occur during the printing of that label, then the FEED Key must be pressed to clear the fault.

(FM) Feedback Mode – See <STX>a for command details.

(FS) Slew Speed – This command controls the rate of label movement between printing areas when the GPIO port is used; see Appendix L for ranges.

(GD) Display Mode – This command controls the size of displayed menu characters, where Enhanced makes them larger.

(GE) GPIO Equipped – This command is used to interface the printer to external controlling devices (see Appendix J):

Value	Units / Interpretation	GPIO Enable Definition
A	Applicator	Enables the standard applicator mode, de-asserting DRDY as soon as last label starts printing, allowing FEED any time, and not de-asserting DRDY when PAUSED.
N	Disabled	Disables the GPIO Port.
V	Verifier	Enables the GPIO Port for a bar code verifier.
2	Applicator2	Enables the alternate applicator mode, where Data Ready (DRDY) is extended to overlap the End Of Print (EOP) signal by about 1 msec when printing the last label; and, where PAUSE or FAULT de-asserts the DRDY signal and inhibits the FEED operation.

(GL) Gap Sensor Location (MP Compact4 Mark II only) – This command will tell the printer which sensor to use when GAP mode is selected either by the <STX>KcSTG; or by <STX>e. Outer Gap sensor is defined as the sensor 6.3mm from the edge of the media, (Outer is default). Inner Gap sensor is defined as the sensor 17.2mm from the edge of the media

(GM) Gap / Mark Value – This command sets threshold value for the media sensor's "gap" or "mark" parameter.

(GP) GPIO Error Pause – This command enables or disables the printer from sending a service required fault to the GPIO output (Applicator Interface CCA, Type 2 only).

(GR) Gain Reflective Value – This command sets the sensitivity of the reflective media sensor.

Value	Slew Interpretation
0	Standard (Active Low)
1	Low Pulse *
2	High Pulse *
3	Slews while low (Active Low)
4	Slews while high (Active High)

(GS) GPIO Slew – This command sets the GPIO slew function and control:

* Pulse must be at least 60 milliseconds in length; functions as if pressing the Feed Key, clearing alarms and advancing media.

(HB) Head Bias – This command instructs the printer to switch the dot zero position, as viewed from the label exit. When dot zero occupies the left-most location on the print head then printing is left justified; and, when dot zero occupies the right-most location, printing is right justified.

(HC) Head Cleaning – This command controls the print head cleaning routine. The entered value specifies the inch (or centimeter) count to reach before prompting a print head cleaning. If the number specified is exceeded three times, the printer will fault until cleaning is initiated.



The number specified is multiplied by one thousand, and zero disables this function.

(HE) Heat – See Hnn for command details.

(HT) Host Timeout – This command controls the number of seconds a communications port must be idle before the printer will process data from a different port or use a different parsing method. The value is also used to "timeout" an image / label format download (i.e., if, at any time, data flow stops before a complete label format is received, the data will be ignored).

(IC) Ignore Control Codes – This command allows the user to remove control codes (< 20 Hex) in the data field. The selected line terminator is processed. When enabled, DPL Control Code (SOH, STX, CR, ESC, and ^) characters are removed from the data string. (Note that some fonts do have printable characters in this range and they will not be printed when enabled.)

(IE) Ignore Distances – This command, when enabled, prevents <STX>O processing that will change the start of print position.

(IL) Imaging Mode – This command instructs the printer whether to pre-image the label format:

Value	Units / Interpretation	Imaging Mode Definition
м	Multiple Label	The printer images multiple labels as memory permits, achieving the fastest throughput; however, if time-stamping, the time will reflect the moment the label is imaged rather than when actually printed.
S	Single Label	The printer images the next label only after the previous label has been successfully printed. Single processing provides time-stamps that are more accurate, but it slows label throughput time.

(IM) Internal Module – This command sets the number of 1K blocks (or 4K blocks for Non-Display models; see the <STX>KM command) allocated for Module D.

(LA) Label Alignment – This command prevents labels with lengths that are less than the distance between the print head and the Media Sensor from being wasted at power-up. See the appropriate *Operator's Manual* for specific information. Unless otherwise noted, the following information pertains to all Non-Display models:

Value & Mode	Media Type	Description / Operation
N = Disabled	 6.5-inch and greater (≥ 16.51 cm) die-cut, notched, reflective, continuous, and multiple form lengths. 	When disabled, Non-Display models begin printing at the current location, unless equipped with RTC (Real Time Clock); see note below. The EX2 assumes the label position has not moved while power was "Off" and that no system changes have occurred.
A = Auto	6.5-inch or less (≤16.51 cm) die-cut, notched, and	In auto mode, the printer will verify the label position using the provided Alignment Length before printing the first label after power-up. Press and hold the FEED Key four seconds so the printer will measure the length of the label. The EX2 will only measure the label length when new label stock is loaded.
Y = Enabled	reflective	When enabled, the printer will verify the label position using the provided Alignment Length before printing the first label after power-up. Specify the Label Alignment Length using the <stx>KCAL command, or the Setup Menu.</stx>

Table 5-3: Label Alignment Command



The Real Time Clock (RTC) option allows the position-state of the label to be stored, thus eliminating the need for an alignment prior to first label printing (assuming the label has not moved during power off). If the stock has been changed then a Forced Alignment (press and hold FEED 4 seconds) is recommended.

(LE) Legacy Emulation – This command enables the $\langle STX \rangle O$ and $\langle STX \rangle f$ print positioning commands to allow backward compatibility with label formats that were designed for the Allegro[®] Prodigy[®], and Prodigy Plus[®] (If the printer is Display-Equipped, also Prodigy Max[®] emulation).



Use causes the printer to ignore Label commands A, M, n, and T.

(LR) Label Rotation – This command sets label rotation, allowing formats to be flipped 180 degrees.

(LS) Language Select – This command selects the language for the menu system messages and configuration label. Only languages that are resident will be available.



Language name limited to a twenty character maximum.

(LM) Label Store – This command selects the level of stored format recall to include the label-formatting command fields, or the label-formatting command fields and the printer state.

(LW) Label Width – This command sets the maximum limit for the printable width. Objects extending beyond this limit will NOT print; see Appendix K. (For Non-Display models also see the <STX>KW command.)



The EX2 requires this command prior to the start of the label format command (<STX>L).

(MCC) Module Command – This command adjusts the size of Flash module on the optional Expansion Card according to the table below (see Appendix K for appropriate module details):

V	/alue	Module Command Units / Interpretation				
	Zxx	Where <i>xx</i> =	Size: 1 – 7 Mbytes. This is the amount to be allocated to Module Z; any remaining memory will be allocated to Module F.			
	Gxx	Where <i>xx</i> =	Size: $1 - 56$, in 128 Kbytes blocks. This is the amount to be allocated to Module G; any remaining memory will be allocated to Module X.			

Table 5-4: Module Command

(ML) Maximum (Label) Length - See <STX>M for command details.

(MM) Menu Mode – This command sets the menu access level of the printer – where User is a basic listing of menu settings and controls, and Advanced is a full menu listing.

(MT) Media Type – This command selects the printing method: Direct Thermal for use with heat sensitive media or Thermal Transfer for use with media requiring a ribbon to create an image. (For Non-Display models also see the <STX>KD command.)

(MV) Mark Value – This command sets threshold value for the reflective media sensor's "mark" parameter.

(NE) Network Configuration – (for firmware version 14.00 and later) This command configures the printer for an wired or wireless Ethernet connection.

Syntax is:

aa_i[nnn₁,vvvv₁:nnn₂,vvvv₂:...,nnn_n,vvvv_n:XX[...]YY[...]];

where:

aa _i [] , :	Configuration Group Identifier Group Scope Delimiters Item – Value Delimiter Item – Value Pair Delimiter			
nnn _i ,vvvv _i :	Configuration Item – Value pairs nnn _i Decimal Item Numbers from 1 to 9999 , Decimal Item Number Delimiter vvvv _i Item Value (syntax defined later) : Item Value Delimiter			
XX[]	Nested Configuration Sub-Group data stream XX Sub-Group Identifier (1 – N alpha characters) [] Sub-Group Scope Delimiters			
;	Configuration Group Terminator			

The value fields can be represented as one of the following types:

Decimal Value

A decimal value string consisting of an optional leading '+-' character and followed by decimal numeric characters 0 - 9.

Scientific Notation Value A numeric value in scientific notation: (+-)nnnn.mmmE+-XXX. **Hexadecimal Value** A hexadecimal value expressed like '0xb9E23c'. Binary Bit Value A binary bit value expressed like '0b011011' **Boolean Value** A single character from the following set: 'Y, N, T, F, 0, 1' String Value A string of characters delimited by quotes, `...'. The `\' acts as the escape character permitting the following escaped character sequences: \nnewline (0x0a) 0 \rcarriage return (0x0d) 0 \bbackspace 0 \ttab 0 \fform feed 0

- \\backslash
- \'quote
- \dddddd consists of 3 OCTAL DIGITS

Example:

<STX>KcNE[G[1,0:2,'sysadm':]WE[1,N:2,'192.168.10.26':]WIFI[1,Y::DV1[1,0:]]]; <CR>

<stx>Kc</stx>	This is the beginning of command
NE	Network Ethernet group
G	General Network sub-group
1,0	1 = Primary Interface Item, $0 =$ Wired Ethernet Value
2,'sysadm'	2 = Network Password, followed by string password value
WE	Wired Ethernet (802.3) sub-group
1,N	1 = DHCP Enabled, N = Boolean Value for Not Enabled
2,'192.168.10.26'	2 = Static IP Address, followed by IP address string
WIFI	Wireless Ethernet (802.11) sub-group
1,Y	1 = DHCP Enabled, Y = Boolean Value for Enabled
DV1	DPAC Version 1 sub-group defined for WLS sub-group
1,0	1 = DPAC Version 1 Network Type, $0 = Value$ for Infrastructure

Network Configuration Parameters

The two character identifier for the Network Configuration Parameters is **`NE**'. No Item-Value pairs are defined for **`NE**' but there is the following sub-groups:

General Network Configuration Parameters – Identifier **'G'** 802.3 Wired Ethernet Configuration Parameters – Identifier **'WE'** 802.11 Wireless Ethernet (WIFI) Configuration Parameters – Identifier **'WIFI'**. This sub group consits of 4 addtional sub-groups:

- General WIFI Configuration Parameters Identifier 'G'
- DPAC Version 1 Identifier 'DV1'
- DPAC Version 2 Identifier 'DV2'
- Silex Version 1 Identifier 'SV1'

The configuration data stream for the network configuration parameters has the following structure:

NE[G[...]WE[...]WIFI[..]];

General Configuration Parameters – Identifier 'G'

The 'G' sub-group contains network configuration parameters that apply 'globally' or 'generally' to any ethernet interface used. No sub-groups are currently defined for the 'G' sub-group of configuration parameters, only item-value pairs. The 'Item-Value' pairs within the 'G' sub-group are defined by the following table:

Item Number	Name	Available to User (Y/N)	Value Type	Description
1	Primary Interface	Ŷ	Decimal	Indicates the primary or used ethernet interface type. Interface types are Wired Ethernet (802.3) and Wireless Ethernet (802.11). It is called 'Primary' since, in the future if multiple ethernet interfaces would be supported, it would be the PRIMARY interface used.
2	Network Password	Y	String	Provides the network password used for WEB and TELNET sessions.
3	SNMP Enable	Y	Boolean	Enables or Disables the SNMP services.
4	Telnet Enable	Y	Boolean	Enables or Disables the TELNET services.
5	FTP Enable	Y	Boolean	Enables or Disables the FTP Server.
6	HTTP Enable	Y	Boolean	Enables or Disables the HTTP (WEB Pages) Server.
7	LPD Enable	Y	Boolean	Enables or Disables the LPD (Line Printer Daemon) services.
8	NetBIOS Enable	Y	Boolean	Enables or Disables the NetBIOS services.
9	Netcenter Enable	Y	Boolean	Enables or Disables the Netcenter services.
10	Gratuitous ARP Period	Y	Decimal	Value of the Gratuitous ARP Period in seconds. $0 = D$ isabled.
11	Printer TCP Port	Y	Decimal	Value of the TCP Port for Print Services.
12	Default MTU	Ν	Decimal	Provides a Default MTU Size (used internally).
13	Static Primary WINS Server IP Address	Y	String	Static Primary WINS Server IP Address in dotted decimal notation.
14	Static Secondary WINS Server IP Address	Y	String	Static Secondary WINS Server IP Address in dotted decimal notation.
15	Static Primary DNS Server IP Address	Y	String	Static Primary DNS Server IP Address in dotted decimal notation.
16	Static Secondary DNS Server IP Address	Y	String	Static Secondary DNS Server IP Address in dotted decimal notation.
17	SNMP TRAP IP Address	Y	String	SNMP TRAP IP Address in dotted decimal notation.
18	SNMP Server Address	Y	String	SNMP Server IP Address in dotted decimal notation.
19	NetBIOS Name	Y	String	NetBIOS Name for the Printer.
20	Domain Name	Ν	String	Domain Name – Not currently used.
21	Email Address	Ν	String	Email Address – Not currently used.

802.3 – Wired Ethernet Configuration Parameters – Identifier 'WE'

The 'WE' sub-group contains network configuration parameters that apply only to the Wired Ethernet (802.3 Specification) ethernet interface. No sub-groups are currently defined for the 'WE' sub-group of configuration parameters, only item-value pairs. The 'Item-Value' pairs within the 'WE' sub-group are defined by the following table:

Item Number	Name	Available to User (Y/N)	Value Type	Description
1	DHCP Enable	Y	Boolean	Indicates if the DHCP Protocol is to be used to automatically obtain all required network addresses. Formally known as IP Discovery.
2	Static Printer IP Address	Y	String	Static IP Address for the Printer in dotted decimal notation.
3	Static Printer Subnet Mask	Y	String	Static Subnet Mask for the Printer in dotted decimal notation.
4	Static Printer Default Gateway or Router	Y	String	Static Default Gateway (Router) IP Address in dotted decimal notation.
5	PHY Mode	Y	Decimal	Defines the ethernet PHY Mode (Auto, 10BaseT HD, etc.) Auto-Negotiate = 0 10BaseT Half Duplex = 1 10BaseT Full Duplex = 2 100BaseT Half Duplex = 3 100BaseT Full Duplex = 4
6	PHY Advertise Mode	Y	Decimal	Defines the ethernet PHY Advertise mode. Auto = 0 All Capabilities = 1
7	PHY Capabilities to Advertise	Y	Decimal	Defines the ethernet PHY capabilities to advertise. Always = 0
8	MTU	Y	Decimal	Defines the Maximum Transmission Unit size for the wired interface. Defaults to the DEFAULT MTU from the 'G' sub-group.

802.11 – Wireless Ethernet - WIFI Configuration Parameters – Identifier 'WIFI'

The 'WIFI' sub-group contains network configuration parameters that apply only to the Wireless Ethernet (802.11 Specification) ethernet interface. Four (4) sub-groups are currently defined for the 'WIFI' sub-group of configuration parameters and are as follows:

General WIFI Configuration Parameters – Identifier **'G**' DPAC Version 1 – Identifier **'DV1**' DPAC Version 2 (Veyron) – Identifier **'DV2**' SILEX Version 1 – Identifier **'SV1**'

General WIFI Configuration Parameters – Identifier 'G'

The 'G' WIFI sub-group contains the configuration parameters that are generally common to ALL WIFI radio modules used by Datamax-O'Neil. These configuration parameters are universally standard within the WIFI realm and are interpreted commonly by the various WIFI radio modules. The 'Item-Value' pairs within the 'G' sub-group of the 'WIFI' sub-group are defined by the following table:

Item Number	Name	Available to User (Y/N)	Value Type	Description
1	DHCP Enable	Y	Boolean	Indicates if the DHCP Protocol is to be used to automatically obtain all required network addresses. Formally known as IP Discovery.
2	Static Printer IP Address	Y	String	Static IP Address for the Printer in dotted decimal notation.
3	Static Printer Subnet Mask	Y	String	Static Subnet Mask for the Printer in dotted decimal notation.
4	Static Printer Default Gateway or Router	Y	String	Static Default Gateway (Router) IP Address in dotted decimal notation.
5	MTU	Y	Decimal	Defines the Maximum Transmission Unit size for the wired interface. Defaults to the DEFAULT MTU from the 'G' sub-group. Cannot exceed the maximum ethernet packet size!!!
6	Ad-Hoc Channel	Y	Decimal	WIFI Channel Number used when operating in Peer-Peer (Ad-Hoc) mode.
7	Region Code	Y	String	Two (2) character zero terminate Region Code string, such as "US".
8	WEP Key Used	Y	Decimal	A decimal number from 1 to 4 that designates the WEP key used.
9	WEP Key 1	Y	String	10 or 26 digit WEP Key 1
10	WEP Key 2	Y	String	10 or 26 digit WEP Key 2
11	WEP Key 3	Y	String	10 or 26 digit WEP Key 3
12	WEP Key 4	Y	String	10 or 26 digit WEP Key 4
13	Pre-Shared Key or PSK	Y	String	8 to 64 character Pre-Shared Key used by WPA-PSK or WPA2-PSK
14	LEAP Used ID	Y	String	User ID String for LEAP (Cisco) EAP Protocol.
15	LEAP Password	Y	String	Password String for LEAP (Cisco) EAP Protocol.
16	EAP User ID	Y	String	User ID String for other EAP Protocols.
17	EAP Password	Y	String	Password String for other EAP Protocols
18	EAP Realm	Y	String	Realm String for EAP Protocols that utilize a Realm.
19	SSID	Y	String	String that represents the SSID if in Infrastructure mode.
20	WIFI Type	Y	Decimal	WIFI Module type (DPAC1=1, SILEX=2, DPAC2=3)

DPAC Version 1 WIFI Configuration Parameters – Identifier 'DV1'

The 'DV1' WIFI sub-group contains the configuration parameters that are specific to the DPAC Version 1 WIFI radio module used by Datamax-O'Neil. The 'Item-Value' pairs within the 'DV1' sub-group of the 'WIFI' sub-group are defined by the following table:

Item Number	Name	Available to User (Y/N)	Value Type	Description
1	Network Type	Y	Decimal	Value that represents a Valid Network Type for the DPAC Version 1 module. AD-HOC = 0 Infrastructure = 1
2	WIFI Security Type	Y	Decimal	Value that represents the DPAC Version 1 Security Codes supported. Security Disabled = 0 WEP, 64 Bit Key = 1 WEP, 128 Bit Key = 2 WPA-PSK = 3 WPA CISCO LEAP = 4 TKIP+40Bit WEP using EAP (LEAP) = 5 TKIP+40Bit WEP using EAP (LEAP) = 6 TKIP+40Bit WEP using WPA-PSK = 7 TKIP+128Bit WEP using WPA-PSK = 8
3	WIFI Authentication Type	Y	Decimal	Value that represents the DPAC Version 1 Authentication Types supported (Auto, Open, Shared Key). Automatic = 0 Open = 1 Shared Key = 2
4	Static Radio IP Address	Y	String	Static IP Address for the DPAC Version 1 radio module in dotted decimal notation.
5	Static Radio Subnet Mask	Y	String	Static Subnet Mask for the DPAC Version 1 radio module in dotted decimal notation.

DPAC Version 2 WIFI Configuration Parameters – Identifier 'DV2'

The 'DV2' WIFI sub-group contains the configuration parameters that are specific to the DPAC Version 2 (Veyron) WIFI radio module used by Datamax-O'Neil. The 'Item-Value' pairs within the 'DV2' sub-group of the 'WIFI' sub-group are defined by the following table:

Item Number	Name	Available to User (Y/N)	Value Type	Description
1	Network Type	Y	Decimal	Value that represents a Valid Network Type for the DPAC Version 2 module. AD-HOC = 0 Infrastructure = 1
2	WIFI Security Type	Y	Decimal	Value that represents the DPAC Version 2 Security Codes supported. Security Disabled = 0 WEP, 64 Bit Key = 1 WEP, 128 Bit Key = 2 WPA-PSK = 3 WPA CISCO LEAP = 4 TKIP+40Bit WEP using EAP (LEAP) = 5 TKIP+128Bit WEP using WPA-PSK = 7 TKIP+40Bit WEP using WPA-PSK = 7 TKIP+128Bit WEP using WPA-PSK = 8 WPA2-PSK = 9 WPA/WPA2 TLS = 10 WPA/WPA2 TLS = 11 WPA/WPA2 TTLS = 12
3	WIFI Authentication Type	Y	Decimal	Value that represents the DPAC Version 2 Authentication Types supported (Auto, Open, Shared Key, EAP, etc.). Automatic = 0 Open = 1 Shared Key = 2

SILEX Version 1 WIFI Configuration Parameters – Identifier 'SV1'

The 'SV1' WIFI sub-group contains the configuration parameters that are specific to the SILEX Version 1 WIFI radio module used by Datamax-O'Neil. The 'Item-Value' pairs within the 'SV1' sub-group of the 'WIFI' sub-group are defined by the following table:

Item Number	Name	Available to User (Y/N)	Value Type	Description
1	Network Type	Y	Decimal	Value that represents a Valid Network Type for the SILEX Version 1 module. AD-HOC = 0 Infrastructure = 1
2	Encryption Type	Y	Decimal	Value that represents the SILEX Version 1 Encryption Types supported. Security disabled = 0 WEP64 = 1 WEP128 = 2 WPA = 3 WPA2 = 4
3	Authentication Type	Y	Decimal	Value that represents the SILEX Version 1 Authentication Types supported (Auto, Open, Pre-Shared Key, EAP, etc.). Open System = 0 Shared Key = 1 Pre-Shared Key = 2 TTLS = 3 LEAP = 4 PEAP = 5 EAP-FAST = 6 TLS = 7
4	Inner Authentication Type	Y	Decimal	Value that represents the Inner Authentication Type used if a Tunneled EAP method is specified. None = 0 PAP = 1 MSCHAP_V2 = 2
5	Use WPA Group Key	Y	Boolean	Enables or Disables use of the WPA Group Key.

(NT) Network Setup – (for firmware version 13.99 and earlier) This command configures the printer for an Ethernet connection.

Value	Parameter	Interpretation	Default Value [*]
A	x	Is the transmission interval for Gratuitous ARP, where: x = The interval, 0 - 2048, in minutes	0
в	У	Is Network Bios Name, where: y = Up to 16 alphanumeric characters, no spaces	DMX_[and the last 3 octets (in hexadecimal) of the MACM (or MACO) Address]
С	x	 Transmits the printer's Wired network communication capability, where x: 0 = Advertises the DUPLEX CAPABILITY set value. 1 = Advertises all possibilities for DUPLEX CAPABILITY. 	0
D	a	Is Discovery (DHCP or Bootp), where a: Y = Enable N = Disable	Y
E	x	Is the communication capability for the Wired network, where x: 0 = Auto-Negotiate 1 = 10Base-T, Half Duplex 2 = 10Base-T, Full Duplex 3 = 100Base-T, Half Duplex 4 = 100Base-T, Full Duplex	0
F	a	Is FTP enable, where a: Y = Enable N = Disable	Ν
G	xxx.xxx.xxx.xxx	Is the Gateway Address, where: x = 0 to 9	000.000.000.000

(continued)

Value	Parameter	Interpretation	Default Value [*]
I	xxx.xxx.xxx.xxx	Is the IP Address, where: x = 0 to 9	192.168.010.026
m	x	Is MTU packet size, where: x = a range, 512 - 65515, in bytes	1500
N	xxx.xxx.xxx	Is the SNMP Trap Address, where: x = 0 to 9	000.000.000.000
₽	xxxx	Is the destination Port Number, where: x = 0 to 9	9100
s	xxx.xxx.xxx.xxx	Is the Subnet Mask, where: x = 0 to 9	255.255.255.000
т	a	Is SNMP enable, where a: Y = Enable N = Disable	Y
υ	xxx.xxx.xxx	Is the WINS2 Address, where: x = 0 to 9	000.000.000.000
w	a	Is WiFi enable, where a: Y = Enable N = Disable	Ν
W	xxx.xxx.xxx	Is the WINS1 Address, where: x = 0 to 9	000.000.000.000
x	a	Is Telnet enable, where a: Y = Enable N = Disable	Ν
Y	xxx.xxx.xxx.xxx	Is the DNS1 Address, where: x = 0 to 9	000.000.000.000
к	a	Is TCP Keep Alive enable, where a: Y = Enable N = Disable	Ν

(continued)

Value	Parameter	Interpretation	Default Value [*]
Z	xxx.xxx.xxx.xx	Is the DNS2 Address, where: x = 0 to 9	000.000.000.000
\$	xxxxxx	Sets the webpage password, where: x = alphanumeric characters	sysadm

* Prior to the introduction of WiFi, 192.0.0.192 was the IP default value and the Subnet Mask was 0.0.0.0.

Table 5-5: Network Setup

Each octet must be zero-filled to be properly interpreted (e.g., an IP Address of 10.12.0.243 must be sent to the printer as 010.012.000.243).

Example:

<STX>KcNTI010.012.000.243;NTS255.255.000.000;NTG010.012.254.254;NTDN;<CR>

The command string above is typical of a network setup string (where the values meanings are shown in the following table). This configuration setup command string may be included with any other Kc sub-commands.

Sub-commands and Values	Interpretation
NTI010.012.000.243	IP Address: 10.12.0.243
NTS255.255.000.000	Subnet Mask: 255.255.0.0
NTG010.012.254.254	Gateway Address: 10.12.254.254
NTDN	DHCP is disabled

(NR) No **Reprint** – This command controls the label reprint function following the correction of a fault condition. Upon detection of a fault (ribbon out, paper out, etc.), printing stops and a fault indicator is illuminated. After the problem is corrected, the FEED Key must be pressed to clear the fault and resume normal operation. When enabled, the label in process is *not* reprinted.

(NS) Disable Symbol Set Selection – This command prevents the <STX>y and y commands from changing the default single-byte symbol set. When enabled, DPL Symbol Set commands are ignored.



When enabled, the only way to change the current symbol set is with the ${\scriptstyle < STX>KcAS}$ command.

(OF) Option Feedback Mode – This command configures the printer to output the status of the RFID or Scanner option to the active port, as follows.

Value	Option Feedback Mode Units / Interpretation	
	D = Disable	
D, Rx, S	Rx = RFID Enable, where x is the response format: A = ASCII H = Hexadecimal	
	S = Scanner Enable	

Table 5-6: Option Feedback Command



Not supported on the I-4208 printer.

Once enabled, the printer will report information about the results of the last label printed. One response per label is returned to the host (this includes each voided and retried label). The format and contents of the returned information is as follows:

Response format: <A;B;C;D;E;F>[CR]

Where:

- A Device type: R = RFID S = Scanner
 - ^B Resulting status:
 - C = entire label complete
 - F = faulted (failed) label
 - U = unknown
 - C The number of expected reads for bar codes or tags, given in two characters.
 - The number of good reads for bar codes or tags, given in two characters.
 - E The printer's internal Job Identifier and Sub Job Identifier, given in four characters each.
 - F The data read, delimited with semicolons (;) if multiple reads.

RFID response sample differences: Since RFID commands vary in operation, the data returned also differs. Write commands return entire tag data; Write/Verify commands return the data written; and, Read commands return data and length requested in the specified format. (See Appendix S for a listing of commands.)

Write response example:

<R;C;00;00;0013:0001>[CR]

Write/Verify hexadecimal response example:

<R;C;01;01;0012:0001;446174616D61782077726974657320524649442062657374> [CR]

Read hexadecimal response example: <R;C;01;01;0013:0001;446174616D61782077726974657320524649442062657374> [CR]

Write/Verify ASCII response example: <R;C;01;01;0012:0001; Datamax writes RFID best >[CR]

Read ASCII response example:

<R;C;01;01;0013:0001; Datamax writes RFID best >[CR]

Scanner response samples:

A successfully read label example: <S;C;03;03;0002:0001;DATA1;DATA2;DATA3>[CR]

A failed label, successfully retried: <S;F;02;01;0002:0001;DATA1>[CR] <S;C;02;02;0002:0001;DATA1;DATA2>[CR] (PA) Present Adjust – This command fine-tunes the Present Distance setting in dots to compensate for slight mechanical differences sometimes evident if multiple printers share label formats. The EX2 accepts this command for backward compatibility only, limited in range (28-228). <STX>KcQQQ response shows the Present Adjust Fine Tune (PJ) equivalent value.

(PC) Print Contrast – This command adjusts the relative print edge (gray) component of the print quality, which allows fine-tuning for specific media/ribbon mix.

(PD) Present Distance – This command sets the label stop position past the start of print. When the next label format is received, the printer will automatically backfeed to the start position. If the present distance is set to zero, the printer will operate without reversing. (See *Stop Location*, below).

(PE) Peel Mode – This command, when enabled, specifies that a Feed operation be prevented when the label is presented and not removed, or if the printer is to wait for the GPIO start of print signal.

(PJ) Present Adjust Fine Tune – This command fine-tunes the Present Distance setting in dots to compensate for slight mechanical differences sometimes evident if multiple printers share label formats.

(PL) Printer Level – This command is used to upgrade the software feature level of the printer.

(PM) Pause Mode – See <STX>J for command details.

(PO) Paper Empty – This command sets the length of travel before an out of stock condition is declared.

(PP) Parallel Direction – This command controls the parallel port communications settings:

Value	Parallel Direction Units / Interpretation	
xz	x = Port ID: A or B	
	 z = Direction: U (unidirectional – one-way communication); or, B (bidirectional – IEEE 1284 back-channel operation). 	

Table 5-7: Parallel Communications Configuration Command

(PS) Present Sensor Equipped – This command allows the printer to sense the present sensor option. A (or Y) - automatically senses device presence; if undetected, no error will be generated. E - enables the device, where its presence must be detected; otherwise, a fault is generated. N or D - disables device detection. See <STX>V for command details. (Note that the value range for Non-Display models is only Y, or N. Also see the <STX>KD command.)

(pS) Print Speed – See Label Formatting Command Function P for details.

(PT) Tear Position – This command sets the label stopping location at the tear plate on the printer's cover.

Not recommended for use with non-display models, instead see Stop Location (SL).

(PV) Paper Value – This command sets threshold value for the media sensor's "paper" parameter.

(PW) Password Set – This command modifies the numeric password required to access the menu when security is enabled. If security is enabled, enter the *new* password followed by the *old* password (with no spaces) in this form: xxxxxxx

To be activated, the default password (0000) must be changed.

(QQ) Configuration Query – This command requires a parameter of either K or Q. K causes the printer to respond with the Printer Key, used for generating Upgrade Codes. A parameter value of Q causes the printer to respond with the current configuration settings. The <STX>Kc response command stream format is sent to the host computer via the same port as the query containing all parameters controlled by the <STX>Kc command, and may be used for restoring the printer's configuration or for configuring other printers.

(RA) Row Adjust – This command shifts the vertical start of print position (in dots). Note that the EX2 accepts this command for backward compatibility only, limited in range (28-228). <STX>KcQQQ response shows the Row Adjust Fine Tune (RF) equivalent value.

(RE) Ribbon Saver Equipped – This command allows the printer to sense the ribbon saver option. A (or Y) - automatically senses device presence; if undetected, no error is generated. E - enables the device, where its presence must be detected; otherwise, a fault is generated. N or D - disables device detection. See <STX>R for command details.

(RF) Row Adjust Fine Tune – This command shifts the vertical start of print position in dots (see Appendix K) upward or downward.

(RI) RFID Configuration – This command configures the optional RFID interface module, as follows:

Value	Units / Interpretation		RFID Configuration Definition / Function
AI <i>hh</i>	where <i>hh</i> :	2-Chararacter Hex ID	Sets the Application Family Identifier (AFI), HF only.
ALn	and where <i>n</i> :	E = Enable, D = Disable	Allows locking the AFI after writing (HF only).
	where <i>n</i> :	D = Disable	Disables padding or truncating of data (EPC only).
Вп			Nulls are represented as "00". For Hex EPC data a 96-bit tag size is 24 characters and 64-bit is 16. For ASCII EPC data a 96-bit tag size is 12 characters and 64-bit is 8.
		1 = Leading	If the data is less than the selected EPC tag data size, nulls will be added to the front (left); or, if too much data is given, the data will be cut.
		2 = Trailing	If the data is less than the selected EPC tag data size, nulls will be added to the back (right); or, if too much data is given, the data will be cut.
DI <i>hh</i>	where <i>hh</i> :	2-Chararacter Hex ID	Sets the Data Storage Format Identifier (DSFID), HF only.
DL <i>n</i>	and where <i>n</i> :	E = Enable, D = Disable	Allows locking the DSFID after writing (HF only).
En	where <i>n</i> :	E = Enable, D = Disable	Allows erasures of the tag on error (HF only).
Lhh	where <i>hh</i> :	2-Chararacter Hex ID	Sets the Lock Code (Alien UHF only).
	where <i>n</i> :	D = Disable	Disables the RFID module. ("N" is also a valid disabler.)
Мп		H = HF	Enables the RFID module for HF (Securakey).
1*11.1		U = UHF	Enables the RFID module for UHF Class 1 (Alien).
		M = UHF	Enables the RFID module for UHF Multiprotocol.

(continued)

Value	Units / Interpretation		RFID Configuration Definition / Function
Nn	where n:	64 = 64-bit 96 = 96-bit	Sets the UHF tag data size (Multiprotocol UHF only).
Pxxx	where <i>xxx</i> :	3-Digit Value	Sets the tag encoding position: A value of 0.00 causes the print position to be used; or, a value greater than 0 causes the presented position to be used. (Subject to change.)
Rn	where <i>n</i> :	0 - 9	Sets the number of retries for RFID functions.
Shh	where <i>hh</i> :	2-Chararacter Hex ID	Sets the Electronic Article Surveillance (EAS) set, representing the manufacturer's code (HF only).
Tn	where <i>n</i> :	0 = ISO 15693, 1 = Texas Instruments, 2 = Philips, 3 = ST Micro LRI 512, 4 = ST Micro LRI 64	Establishes the tag type (HF only).
Un	where <i>n</i> :	0 = EPC 0 1 = EPC 0+ Matrics 2 = EPC 0+ Impinj 3 = EPC 1 6 = UCODE EPC 1.19* 7 = EM 4022/4222 8 = Gen 2	Sets the UHF tag type (Multiprotocol UHF only).
Vn	where <i>n</i> :	-4 to +4	Adjusts the power, in dBmn (Multiprotocol UHF only).
Wn	where <i>n</i> :	E = Enable, D = Disable	Allows locking the tag after writing.

*Unavailable for A-Class printers.

Table 5-8: RFID Configuration Set Commands

Example: <STX>KcRIMH;RIA11E;RID22E;RIS04;RIR3;RIWE;RIEE;RIP000<CR>

The above example sets the printer to HF, protect after write AFI 11, protect after write DFSID 22, set EAS Bit (Mfg. Code 0x04), allow 3 tries for each read or write attempt, lock after writing, erase the tag if there is an error, and use a position of 0.00.

(RL) *Ribbon Low Diameter* – This command sets the threshold for a low ribbon indication, where nnnn is the diameter in hundredths of inches.

(RM) Rewinder Equipped – This command allows the printer to sense the powered internal rewind option. A (or Y) - automatically senses device presence; if undetected, no error is generated. E - enables the device, where its presence must be detected; otherwise, a fault is generated. N or D - disables device detection.

(RO) Row Offset – See Rnnnn (in Label Formatting Command Functions) for command details.

(RP) *Ribbon Low Pause* – This command (when enabled) pauses the printer when a Ribbon Low Diameter warning is declared; the PAUSE Button must be pressed to continue printing.

(RR) Rewinder Adjust – This command changes the torque applied by the powered rewinder, in percentage points of the nominal force, to minimize TOF registration drift (sometimes evident when using small or narrow media).

(RS) Ribbon Low Signal – This command sets the signal output type for the Ribbon Low Diameter condition when using the optional GPIO (see Appendix J).

(RV) *Reflective Paper Value* – This command sets the threshold value for the reflective media sensor's paper parameter.

(RW) Retract Delay – This command sets a time delay for the retraction of a presented label, where the time specified is multiplied by ten milliseconds.

(SA) SOP Adjust – This command sets the start of print (SOP) location, relative to the top of form. See <STX>O for command details. The EX2 accepts this command for backward compatibility only, limited in range (28-228).

(SC) Scalable Cache – This command sets the number of 1K blocks allocated for the scaleable font engine. Available memory dependent upon model; see Appendix K. (For non-display models see the <STX>KS command.)

(SE) SOP Emulation – This command enables the <STX>O and <STX>f print positioning commands to allow backward compatibility with label formats designed for other printers.

(SF) Save As Filename – This command, which may be sent separately or included as the last command in an <STX>KC command string, saves the effective printer configuration to a file in Flash memory with a .dcm file extension.

(SG) Sensor Gain Value – This command sets the control of the voltage to the LED emitter of the Media Sensor.

(SH) Scalable Heap – This command sets a working "scratch pad space" in DRAM for scalable font construction.

(SI) Security Lock – This command provides the ability to password-protect the User Interface, as follows:

Value	Security Function
Nxxxx	Where xxxx is the current password, this disables Menu protection.
Yxxxx	Where xxxx is a new password, this enables Menu protection and sets a new password.
Txxxx	Where xxxx is a new password, this enables Menu protection, disables Test functions, and sets a new password.

Table 5-9: Security Lock Command



To be activated, the default password (0000) must be changed.

(SL) Stop Location – This command sets the label stopping (and in certain cases the starting) location, as follows:

Value	Stop Location
А	Automatically sets the stop location. Installed options will be "auto-sensed" and the appropriate stop position will automatically be set. Host commands are ignored.
н	Sets stop position according to options installed. If no options are installed the printer sets stop location to the next label's start of print. Host commands will override. The stop location (present distance) may be controlled dynamically by the host using the <stx>f or <stx>kf commands. This selection has the same effect as <stx>KD Ignore Host Distance bit value 0.</stx></stx></stx>
P	Sets the stop location at approximately two millimeters behind the peel bar edge, a nominal peel position. The Present Sensor status and this setting are independent.
С	Sets the stop location to a nominal cut position. For die-cut media, the position is just following the end of the label. The cutter status and this setting are independent.
Т	Sets the stop location at the tear bar.
N	Sets the stop location to the start of the next label, equivalent to setting the KD Ignore Host Distance bit value 1.

Table 5-10: Stop Location Command
(SM) Maximum (Label) Length Ignore – This command controls recognition of the <STX>M command.

(SN) Scanner Configuration – This command configures the linear scanner, as follows:

Values	Scanner Configuration Range / Interpretation		
	Bar Code Type – Specifies the bar code, using two digits, followed by "Y" (to enable) or "N" (to disable) the code, where:		
в	$\begin{array}{llllllllllllllllllllllllllllllllllll$		
	To maximize throughput and decoding integrity, enable only those symbologies that will be read.		
	Bar Code Count – Specifies the number of codes to be read, where:		
С	00 - 99 (00 = Auto [variable] mode, counting those codes present)		
	Do not use Auto Mode with bitmapped codes or codes with certain addendums; see Appendix F.		
н	Min Readable Height – Sets the vertical distance of the code that must have identical reads to pass, where: 1 = 1/16 2 = 2/16 3 = 3/16 4 = 1/4 5 = 1/2		
	0 = Disabled (defaults to Redundancy Level, 2x)		
	Merica The specified distance should not exceed 50% of the measured bar code height.		
	Mode – Enables detection of the scanner by the printer, where:		
М	 A = Auto (automatically senses presence); Y is also a valid enabler. E = Enabled (if not detected a fault is generated). D = Disabled (the scanner is disabled); (N is also a valid disabler.) 		

(continued)

Values	Scanner Configuration Range / Interpretation
	Redundancy Level – An alternative data integrity method, where the selected level sets the number of consecutive, identical decodes required to pass the bar code. If differing values are read, the count is restarted, where:
	0 = Auto Mode 1 = read code 1X
	2 = read code 2X
	3 = read code 3X
	4 = read code 4X
	5 = read code 5X
	6 = read code 6X
	7 = read code 8X
v	8 = read code 10X
	9 = read code 12X
	A = read code 15X B = read code 20X
	B = read code 20X C = read code 25X
	D = read code 30X
	E = read code 35X
	F = read code 40X
	G = read code 45X
	Depending upon the print speed, higher Redundancy Levels may cause erroneous failures when scanning multiple or small bar codes.

Table 5-11: Scanner Configuration Set Command

Example: <STX>KcSNC00H4MAB12YV0<CR>

The example above sets the printer to sense the scanner automatically, to read a variable number of UPC bar codes, and to pass only those codes where a $\frac{1}{4}$ inch zone has identical reads.

Value	Serial Port Range / Interpretation			
xyz	Where:	x = Port Identifier:	y = Function:	z = Setting
		A - Serial A B - Serial B	P - Handshaking Protocol	B - both H - hardware N - none S – software
			p - Parity	E - even N - none O – odd
			D - Data Length	7 - eight bits 8 - seven bits
			S - Stop Bits	1 - one bit 2 - two bits
xyzz	Where:	x = Port Identifier:	y = Function:	zz = Setting:
		A - Serial A B - Serial B	B - Baud Rate	12 - 1200 24 - 2400 48 - 4800 96 - 9600 19 - 19200 28 - 28800 38 - 38400 57 - 57600 15 - 115200

(SP) Serial Port – This command configures the serial communication port(s) as follows:

Table 5-12: Serial Port Configuration Set Command



For EX2 models the data length, parity, and stop bits are fixed at 8, N, and 1 respectively. And, for Applicator Interface Card-equipped models, this command is also used to configure the GPIO Auxiliary port (ID always "B").

Example: <STX>KcSPAPB; SPApN; SPAD8; SPAS1; SPAB19<CR>

The example above configures Serial Port A to use hardware and software handshaking, an eight-bit word, with no parity and one stop bit at 19,200 bits per second.

(SS or sS) Feed Speed – This command controls the rate of label movement between printing areas; see Appendix L.

(ST) Sensor Type – See <STX>e (edge) or <STX>r (reflective) for command details. (For non-display models also see the <STX>KD command.)

(SV) Switch Settings – This command controls recognition of the software switch setting command <STX>V.

(**TB**) **TOF Bias** – This command controls the low-level voltage difference level to recognize a label "gap" or "mark".

(TD) TOF Delta – This command controls the low-level voltage difference level to recognize a label "gap" or "mark".

(TG) TOF Gain – This command controls the voltage to the LED emitter of the Media Sensor.

(TN) No Paper Min – This command sets the media sensor level for the Out of Stock (OOS) condition.

(TP) TOF Precedence – This command instructs the firmware to stop printing at the first top of form mark it detects. The default ("No") prints all of the data (traversing the top of form as necessary) then slews to the next TOF.

(UD) User Label Mode – This command places the printer in standalone operation, which provides menu-driven processes to print user defined files, including .dlb, .dpl, .prn, .txt formats.

(UM) Units of Measure – See <STX>m (metric) or <STX>n (imperial) for command details.

(UT) User Terminator – This command allows word wrapping of long character strings of commands to the next line in a file, for the purposes of readability only. In the <STX>Kc string, the command UTON must fall somewhere before the first line terminator. The last command needs to be END, followed by a line terminator (see the <STX>KcEN command for details).

(VE) Verifier Equipped – This command enables the GPIO for a bar code verifier (see Appendix J). A (or Y) - automatically senses device presence; if undetected, no error is generated. E - enables the device, where its presence must be detected; otherwise, a fault is generated. N or D - disables device detection.

(VT) Verifier Type – This command is reserved for future use.

(WE) WiFi Setup – This command configures the printer for a WiFi connection, as follows:

Value	Parameter	Parameter WiFi Interpretation	
A	У	Is the SSID (Access Point name), where:	MACR
		y = Up to 31 characters, no spaces	
С	x	Is the Channel number (Adhoc only, country dependent), where:	1
		x = 1 to 14	
न	x	Is Enable DHCP Fixed Interval Transmission, where x:	0
-		1 = Fixed 0 = Exponential	
I	xxx.xxx.xxx	Is the IP Address*, where:	192.168.010.001
		x = 0 to 9	
L	x	Is the DHCP Acquire Time Limit, where: x = 0 to 255 seconds	150

(continued)

Value	Parameter	WiFi Interpretation	Default Value
М	x	Is the maximum transmission rate, where x: 0 = 1 Mbps 1 = 2 Mbps 2 = 5.5 Mbps 3 = 11 Mbps	2
N	У	Is the client name, where: y = Up to 31 characters, no spaces	N/A
P	x	Is the WEP Access Point Density, where x: 0 = Low 1= Medium 2 = High	0
R	У	Is the Region, where: y = Two-character code; see Appendix T.	US
Т	x	Is the Mode, where x: 0 = Adhoc 1 = Infrastructure 2 = Unique (SSID = MAC address; and, WiFi type = Adhoc)	2
v	x	Is the DHCP Retransmit Interval, where: x = 1 to 64 seconds	15
x	a	Is MAC Cloning, where a: 0 = Disable 1 = Enable	0

* Each octet must be zero-filled to be properly interpreted (e.g., an IP Address of 10.12.0.243 must be sent to the printer as 010.012.000.243).

Table 5-13 WiFi Setup

Example 1:

<STX>KcNTDN;NTwN;WEI010.012.000.248;WEAEngWAN1;NTI010.012.000.245;NTS25 5.255.000.000;NTG010.012.254.254<CR>

Value	Parameter	WiFi Interpretation	Default Value
	хy	Is the WEP Key, where x: 1 = WEP Key 1 2 = WEP Key 2 3 = WEP Key 3 4 = WEP Key 4 And where y: Is the Key, up to 26 characters with no spaces.	1 (See Note 1)
A	x	Is the Security Authentication, where x: 0 = Auto 1 = Open 2 = Shared	0
ĸ	x	Is the WEP Default Key, where x: 1 = WEP Key 1 2 = WEP Key 2 3 = WEP Key 3 4 = WEP Key 4	1
S	x	Is the Security setting, where x: 0 = Disabled 1 = WEP 64 Bit 2 = WEP 128 Bit 3 = WPA PSK 4 = WPA LEAP 5 = WPA LEAP 64 6 = WPA LEAP 128 7 = WPA PSK+TKIP 64 8 = WPA PSK+TKIP 128	0
L	У	Is the LEAP Password, where y: Is up to 32 characters.	See Note 2
Р	У	Is the WPA Passphrase (Preshared Key), where y: Is 8 to 63 characters with no spaces; or, 64 hex characters.	See Note 3
U	У	Is the LEAP User ID, where y: Is up to 32 characters.	See Note 4

(WS) WiFi Security – This command configures WiFi security.	(WS) WiFi S	Security -	This command	configures	WiFi security.
---	-------------	------------	--------------	------------	----------------

1. Default values for WEP Keys are all zeros (whether 10 digit or 26 digits).

2. The LEAP password is 1 to 32 characters and must match the LEAP password assigned to the LEAP user on the LEAP server. The password cannot contain spaces.

3. The WPA passphrase must match the passphrase on the Access Point.

4. The User ID cannot contain spaces.

Table 5-14 WiFi Security

STX KD Database Configuration (Non-Display Models only)

This command, stored in Flash memory for future power-ups, controls the printer's environment and operates as a pseudo DIP switch. The <STX>KC command is recommended for use over <STX>KD.

Syntax:

<STX>KDwxyz<CR>

Where: w, x, y, and z are binary values with respective bit settings as defined in the following table. (Bit 0 is least significant.)

Sample: <STX>KD@H@@<CR>

The sample above configures 9600 baud, 8-bit words, no parity, with direct thermal printing, gap sensing, standard control characters, and a cutter.



• Ignore Host Distance (see below) disregards <STX>O and <STX>f commands (in case host software sends values that may be inappropriate). Use the <STX>KD command or the Setup Menu to enable this feature.

<stx>KD Parameter</stx>	Bit Number	Function	Value(s)
	0 - 2	BAUD Rate / Set Test Mode	0 = 9600, 1 = 600, 2 = 2400, 3 = 19200, 4 = 4800, 5 = 38400, 6 = 1200, 7 = 9600 Test Mode
w	3	Word Length and Parity	0 = 8 bits, no parity; 1 = 7 bits, even parity
	4 & 5	Unused	Set to 0
	6	Always 1	Set to 1
	7	Always 0	Set to 0
	0	Print Method	0 = direct thermal, 1 = thermal transfer
	1	Present Sensor	0 = not equipped, 1 = equipped
	2	Control Character ^[1]	0 = standard, $1 = $ Alternate characters
x	3	Cutter	0 = disabled, 1 = enabled
	4	Ignore Host Distance	0 = disabled, 1 = enabled (see note above)
	5	Alt-2 Control Codes ^[1]	0 = disabled, 1 = Alternate-2 characters
	6	Always 1	Set to 1
	7	Always 0	Set to 0
	0&1	Sensor Type	0 = gap, 1 = reflective, 2 = continuous
	2	Linerless	0 = not equipped, 1 = equipped
У	3 – 5	Unused	Set to 0
	6	Always 1	Set to 1
	7	Always 0	Set to 0
	0&1	Reserved	Set to 0
	2	Reserved	Set to 0
z	3 – 5	Unused	Set to 0
	6	Always 1	Set to 1
	7	Always 0	Set to 0

• This command will result in a system reset for the EX2.

^[1] Selects the values of the control characters; see Control Code Command Functions.

Table 5-15: Database Configuration Command

STX Kd Set File as Factory Default

This command selects the specified file name as the "factory default" configuration. After execution, subsequent "Select Factory Default" commands will configure the printer to this file's configuration using one of the following methods:

- <STX>KF command;
- Power-up the printer while pressing the PAUSE and CANCEL Keys; or,
- Via the menu SYSTEM SETTINGS / SET FACTORY DEFAULTS entry.

Syntax:	<stx>KdName<cr></cr></stx>	
Where:	<i>Name</i> - The name, up to 16 characters, of the file.	
	<cr> - 0x0d terminates the name.</cr>	
Sample:	<stx>KdPlant1<cr></cr></stx>	
	The sample above selects the configuration file <i>Plant1</i> as the default factory configuration.	

STX KE Character Encoding

This command is provided primarily as a means for users of 7-bit communication and to embed control characters and extended ASCII characters in their data streams. Any character in the DPL data stream may be substituted with a delimited two-character ASCII hexadecimal numeric equivalent. The command allows the delimiting character to be selected, and the encoding to be enabled or disabled. When character encoding is enabled, the printer will decode any ASCII hexadecimal numeric pairs following the delimiter as single-byte values. Character encoding is used where control characters cannot be transmitted or where control characters within data may prematurely terminate a label format record. Although the delimiter may be changed at any time (except within a label format definition), there cannot be more than one defined delimiter, and character encoding must be disabled with <STX>KEN prior to re-enabling regardless of any change in the delimiter.

Syntax:	<stx>KEex<cr></cr></stx>
Where:	 Y – character encoding enabled N – character encoding disabled
	x - Delimiter: one ASCII character (Do not include when $e = N$)
Sample:	<stx>KEN <stx>KEY\ <stx>L<cr> 1u000001200120[)>\1E\01\1D\\04\<cr> E<cr></cr></cr></cr></stx></stx></stx>

The sample above disables, and then enables character encoding with the backslash (\) as the delimiter. A UPS MaxiCode will be formatted using a data string interpreted as follows: [)> $^{R}_{S}$ 01 $^{G}_{S}$... $^{E}O_{T}$ <CR> then formatting is terminated.

Character Encoding Syntax: This syntax requires at least two hexadecimal ASCII digits (0-9, A-F) delimited by the character specified in the <STX>KE command. The number of hexadecimal digits between the delimiter pair must be even; see notes below.

Syntax:	xaa[bbccnn]x	
Where:	x - One byte delimiter, 0 to ff_{16} , leading and trailing.	
	 aa - 2 bytes, ASCII, hexadecimal encoded, range each character – 0-9, A-F 	
	 bb - 2 bytes, ASCII, hexadecimal encoded, range each character – 0-9, A-F (optional) 	
	 - 2 bytes, ASCII, hexadecimal encoded, range each character – 0-9, A-F (optional) 	
	 nn - 2 bytes, ASCII, hexadecimal encoded, range each byte - 0-9, A-F (optional) 	
• A delimiter	pair with no ASCII hexadecimal pairs between (e.g., $)$ will be	
interpreted	d as one byte whose value is that of the delimiting character, allowing the elimiter to be interpreted as itself rather than as the delimiter.	

• A delimited string that contains either a non-valid hexadecimal character (e.g., FX) or an odd number of bytes will be treated as an illegal string and, therefore, not correctly decoded.

Character Encoding Examples: In the following partial datastreams it is assumed that character encoding is enabled and that the selected delimiter, a backslash (\), has been transmitted to the printer (i.e., <STX>KEY\). In each example, the printer has not received an unpaired delimiter prior the example.

Partial Sample Data Stream	Interpretation
AB\\CE	5 bytes AB\CE with values 41_{16} , 42_{16} , $5C_{16}$, 43_{16} , 44_{16}
\ABCDEF\	3 bytes with values AB_{16} , CD_{16} , and EF_{16}
1A\1A\1A	5 bytes 1A _{1A with values 31_{16}, 41_{16}, $1A_{16}$, 31_{16}, 41_{16}. _{represents a single-byte ASCII control character with value $1A_{16}$}}

Alternate Control Codes with an Alternate Line Terminator: Character Encoding can also be used with the Alternate Control Character set. Alternate Control Characters are enabled, depending upon the model, via a Setup Menu or the <STX>KD / <STX>KC commands; see Control Code Command Functions.

STX KF Select Factory Defaults

This command restores the configuration of the printer to the factory default settings. These settings may be default values or the values previously specified by a configuration file (see <STX>Kd).

Syntax:	<stx>KI</stx>	Fn <cr></cr>
Where:	n -	2 = Returns the factory default settings (and, if saved, restoring the Factory Setting File).
	-	3 = Returns the factory default settings, and clears Calibration and Custom Adjustments.
		Calibration will be required.

STX Kf Set Present Distance

This command specifies an additional amount to advance the label after printing. This command has the same effect as the <STX>f command, but specifies a distance to advance relative to the start of print (<STX>O command) of the next label.

Non-Display Models: The printer Option Control must be set (via the menu) to HOST for this command to have effect.

Display-Equipped Models: SOP Emulation selection has no effect on this command.

Syntax:	<stx>Kfnnnn<cr></cr></stx>
Where:	<i>nnnn</i> - A four-digit present distance in inches/100 or mm/10.
Sample:	<stx>Kf0100</stx>
	The sample above represents a one-inch label advance unless in metric mode (see m).

STX KH Dot Check (H-Class & M-Class Mark II only)

This command specifies dot check operations for the printhead elements.

Syntax:	<stx>KHx<cr></cr></stx>	
Where:	<i>x</i> - Specifies the operation, where:	
	 P = Performs dot check; A = Returns the most recent dot check and dot resistance results; and, B = Returns the most recent dot check failed dot results. 	
Sample:	<stx>KHP<cr></cr></stx>	
	The sample above performs dot check with DOTCHECK and a progress bar displayed.	
Sample:	<stx>KHA<cr></cr></stx>	
	The sample above returns results from the last dot check for every element and its resistance up to 1350 ohms [with out of range (bad or suspect) values indicates as ******], the number of dots tested, the total number of bad or suspect dots detected and, the minimum, maximum, and average resistance and variance:	

DOTCHECK RESULTS DOTS TESTED GOOD 830 OF 832 DOT OHMS 0 1148 1 1148 2 1140 • • • 142 1199 143 ***** 144 **** 145 1050 • • • 830 1116 831 1116 832 1116 TOTAL BAD DOTS: 2 MIN MAX AVG VAR 921 1640 1125 719

Sample:

<STX>KHB<CR>

The sample above returns results from the last dot check for the number of elements tested, the number of the bad or suspect dot(s), the total number of bad or suspect dots, and the minimum, maximum, and average resistance and variance:

```
DOTCHECK RESULTS
DOTS TESTED GOOD 830 OF 832
BAD DOT LIST
143
144
TOTAL BAD DOTS: 2
MIN MAX AVG VAR
921 1640 1125 719
```



The process normally adds a few seconds to the power-up sequence; however, if the printhead is invalid or extremely damaged, it could take a minute to complete.

STX KJ Assign Communication Port (MCL Command)

This command assigns a communication port for specific use. When activating MCL, all ports are assigned to MCL; this command allows changes to that assignment.

Syntax:	<stx>KJpf<cr></cr></stx>
Where:	p - Port ID: P = Parallel S = Serial (A) U = USB N = Ethernet L = Wireless A = Serial (B)
	f - Flag: $1 = DPL0 = MCL$
Sample:	<stx>KJN1</stx>

The sample above forces the Ethernet port to bypass MCL and go directly to DPL.

STX KI GPIO Input

This command configures the GPIO input channels of the Applicator Interface Card; see Appendix J for details.

Syntax:	<stx>KIffnspwww<cr></cr></stx>	
Where:	ff	 2 character function name abbreviation (e.g., PS [Print Start], I1 [User Input 1], etc).
	n	- Pin number, where 1 – 8 is the valid range.
	S	 Signal type, where: L = Level; P = Positive Pulse; and N = Negative Pulse
	р	- Polarity, where: $0 = Active Low$; and $1 = Active High$
	WWW	- 3 character filter pulse width, in milliseconds.

STX Kn NIC Reset

This command resets the NIC to factory defaults.

х

Syntax: <STX>Knx

Where:

- Specifies the action, where:

F = Returns the NIC to the factory default settings; or,

H = Reports settings to host (wireless, only).

Address	Default Values Wired Ethernet*	Default Values Wireless Ethernet
IP	192.168.010.026	192.168.010.001
Subnet Mask	255.255.255.000	255.255.255.000
Gateway	000.000.000.000	000.000.000.000

* Prior to introduction of the Wireless Ethernet, 192.0.0.192 was the IP default value and the Subnet Mask was 0.0.0.0.

STX KO GPIO Output

This command configures the GPIO outputs of the Applicator Interface Card; see Appendix J for details.

Syntax:	<stx>KOffnsptd0pw0td1pw1<cr></cr></stx>		
Where:	ff	-	2 character function name abbreviation (e.g., LC [Label Complete], LM [Label Movement], etc).
	n	-	Pin number, where $1 - 8$ is the valid range.
	S	-	Signal type, where: $L = Level$; $P = Positive Pulse$; and $N = Negative Pulse$
	р	-	Polarity, where: $0 = Active Low$; and $1 = Active High$
	td0	-	3 character delay time from function condition "true" to output signal.
	pw0	-	3 character pulse width corresponding to the function condition becoming "true". (Ignored for level-type signals.)
	td0	-	3 character delay time from function condition "false" to output signal.
	pw0	-	3 character pulse width corresponding to the function condition becoming "false". (Ignored for level-type signals.)

STX Kp Module Protection

This command controls memory module protection. When "protected", a module will ignore format, downloads and delete commands. This command can be useful to add data to reserved modules (see Appendix K for a listing of the memory modules). There are two module types: RAM (volatile) and Flash (non-volatile).

- RAM When protected and if power is cycled or if the printer is reset, the module state resets to unprotected.
- Flash When protected, the module can be temporarily unprotected; however, if power is cycled or if the printer is reset, the module state resets to protected.

Syntax:	<stx>Kpmf</stx>
Where:	<i>m</i> - Module ID – Range A to Z (See Appendix K).
	 Flag specifying Enable or Disable protection, where: 0 = disable protection; and, 1 = enable protection.
Sample:	<stx>KpY0</stx>
	The sample above disables protection for Module Y; graphics may now be downloaded to the module and, on subsequent resets, these graphics will be protected.

STX KQ Query Memory Configuration

This command causes the printer to transmit, in a model-dependent format, its memory configuration (i.e., total amount installed, amount available for configuration, and amount currently assigned to specific functions or entities) to the host device.

Syntax:	<stx>KQ<cr></cr></stx>		
Non-Display model response format:	INTERNAL MEMORY <ch VER: aa-cdd.ee mm/ INSTALLED: iiii<ch AVAILABLE: vvvv<ch MODULE: X:xxxx<cr> SCALABLE: ssss<cr> LABEL MEM: LLLL<ch LABEL SIZE: wwww:</ch </cr></cr></ch </ch </ch 	/dd/yy <cr> <> <> > > <></cr>	
Where:	<cr></cr>	- ASCII Carriage Return (0x0D) delimiter.	
	aa-cdd.ee mm/dd/yy	 ASCII string sequence that represents the firmware version number string. 	
	iiii	- The number of 4KB blocks of DRAM memory.	
	vvvv	 The number of 4KB blocks of DRAM available for configuration. 	
	х:	 ASCII character identifying a DRAM module followed by an ASCII colon (:). If no Internal Module is present, this field and its associated legend will not appear. 	
	xxxx	 The number of 4KB blocks of DRAM allocated as an Internal Module. 	
	8888	 The number of 4KB blocks of DRAM assigned to the smooth scalable font processor cache. 	
	LLLL	 The number of 4KB blocks of DRAM assigned to label print buffer. 	
	WWWW	 Current maximum printable label width (in 100^{ths} of an inch or millimeters). 	
	aaaa	 Current printable length (in 100^{ths} of an inch or millimeters), 200 min. / 640 max. 	
	00	 Current label dimension unit's designation: "IN" for inches or "MM" for millimeters. 	

Display-Equipped model response			
format:	Product: I4208 - 01.01 05/21/1999 Installed RAM: 8 MB Label Width: 4.09 IN Print Buffer Size: 272 IN Allocation RAM: 6389 KB Internal Files: 512 KB Font Cache: 232 KB		
Where:	Product	- Printer model, type, and firmware version.	
	Installed RAM	- Total amount of RAM.	
	Label Width	 Size in inches/millimeters of the print head. 	
	Print Buffer Size	 Total number of inches/millimeters of Print Dot Buffers available. (This is not the maximum size of a label, which is limited to 99.99 inches.) 	
	Allocation RAM	 Amount of RAM that can be configured for the Internal Files, Font Cache and the remainder going to the Print Buffer Size. 	
	Internal Files	 Size of the Internal Module used to store downloaded fonts, graphics and label formats. 	
	Font Cache	 Size of the Font Buffer used to temporarily store characters. Increasing this buffer will increase performance if labels have a large variety of font sizes and characters. 	

STX Kq Query Memory Configuration

This command causes the printer to transmit its internal DRAM memory configuration to the host device. The transmitted data provides information regarding the total amount of internal DRAM installed, the amount available for configuration, and the amount currently assigned to specific functions or entities.

Syntax:	<stx>Kq<cr></cr></stx>		
Response format:	Memory Configuration <cr> Product: aaaacdd.ee mm/dd/yy<cr> Installed RAM: iiiiMB<cr> Label Width: vvvvoo<cr> Print Buffer Size: :xxxxoo<cr> Allocation RAM: ssssKB<cr> Internal Files LLLLKB<cr> Font Cache wwww:KB<cr></cr></cr></cr></cr></cr></cr></cr></cr>		
Where:	<cr></cr>	 ASCII Carriage Return (0x0D) record delimiter. 	
	aaaacdd.ee mm/dd/yy	 ASCII string sequence that represents the firmware version number string. 	
	iiii	 The number of megabytes of installed internal DRAM memory. 	
	vvvv	- The length of the Label Width.	
	xxxx	- The length of the Print Buffer.	
	SSSS	 The number of kilobytes of internal memory assigned to the label Print Buffer. 	
	LLLL	 The number of kilobytes assigned to the internal memory module. 	
	wwww	 The number of kilobytes assigned to the Scalable Cache. 	
	00	 Current label dimension unit's designation. "IN" for inches and "MM" for millimeters. 	

STX KR Reset Memory Configuration

This command resets the printer's DRAM configuration to the default settings; see $_{\rm STX>KM}.$

Syntax:

<STX>KR<CR>



This command will result in a system reset for the EX2.

STX Kr Resettable Counter Reset

This command resets the internal counters. Follow this command with an $<_{\rm SOH>U}$ command to retain the reset or the counters will revert to the previous values after cycling power.

Syntax: <STX>Kr<CR>

STX KS Memory Configuration, Scalable Font Cache

(Non-Display Models only)

See the <STX>K command.



This command will result in a system reset for the EX2.

STX KtA Write Application Family Identifier (AFI) to Tag

(Direct Mode – HF [13.56 MHz] ISO15693 Tag Interface)

This command writes the AFI data to the tag.

Syntax:	<stx>KtAabcc</stx>	
Where:	а	- The number of retry attempts, 0-9.
	b	 Lock the Application Family Identifier (AFI) after writing: 0 = No Protection 1 = Write Protect
	CC	- Two character AFI value representing one byte.
Sample:	<stx< td=""><td>>KtA91C3[CR]</td></stx<>	>KtA91C3[CR]
		sample above writes $0xC3$ AFI byte, locking value, retrying times if necessary.

STX KtD Write Data Storage Format Identifier (DSFID) to Tag

(Direct Mode – HF [13.56 MHz] ISO15693 Tag Interface)

This command writes the DSFID data to the tag.

Syntax:	<stx>KtDabcc</stx>	
Where:	a - The number of retry attempts, 0-9.	
	 b - Lock the Data Storage Format Identifier (DSFID) after writing: 0 = No Protection 1 = Write Protect 	
	<i>cc</i> - Two character DFSID value representing one byte.	
Sample:	<stx>KtD91C3[CR]</stx>	
	The sample above writes $0xC3$ DSFID byte, locking value, retrying nine times if necessary.	

STX KtE Write Electronic Article Surveillance (EAS) Bit

(Direct Mode – HF [13.56 MHz] ISO15693 Tag Interface)

This command writes the EAS bit for Philips ISO tags.

Syntax:	<stx>KtEabcc</stx>	
Where:	a - The number of retry attempts, 0-9.	
	 Electronic Article Surveillance (EAS) option: 0 = Set EAS 1 = Reset EAS 2 = Test EAS 	
	 - Two character Manufacturer's Code, representing one byte. 	
Sample:	<stx>KtE9004[CR]</stx>	
	The sample above writes the EAS bit for Philips $(0x04)$, retrying nine times if necessary.	

STX KtH Read and Feedback Tag Information to Host

(Direct Mode – HF [13.56 MHz] ISO15693 Tag Interface)

This command returns the tag info to host.

This command only works when the Data Flag for the tag is $0 \ge 0$ (i.e., when the tag contains DSFID, AFI, VICC and IC data).		
Syntax:	<stx>KtH</stx>	
Sample Feedback:	DATA FLAG: 0x0F TAG ID: E004010000751412 DSFID: 0xE3 AFI: 0x01 NUM BLK: 0x1B BLK SIZ: 0x03 IC REF: 0x01	

STX KtR Read Data from RFID Tag

(Direct Mode – HF [13.56 MHz] ISO15693 Tag Interface)

This command instructs the RFID device to read data from the tag and then put that data into a replaceable field. It is expected that the tag transponder will be within the read / write distance of the RFID programming device; otherwise, "Void" will be printed in the text or bar code label field(s).

Syntax:	<STX>KtRUn ₁ n ₁₆ Haaabbbcdee <cr></cr>		
Where:	Un_1n_{16} - (Optional) Where n_1n_{16} is the Unique Identifier (UID) in hexadecimal format. Must be sixteen characters long.		
	 H - (Optional) Hexadecimal data – "H" may be added directly after "R" to return a two character hex value of the data. Since there are two digits per hex value, replaceable fields should be twice as long than if using ASCII data (e.g., the character "A" would be returned as "41"). 		
	 aaa - Starting block number (000 → maximum block number). Transponder dependent. 		
	bbb - The number of blocks to read (001 \rightarrow maximum block number). Transponder dependent.		
	<i>c</i> - The number of retry attempts, 0-9.		
	<i>d</i> - Reserved. Should be 0.		
	 Field number in which to place the data (must be 01, 02, 03, etc.) matching the order of Label Formatting command, U. 		
	\swarrow A 00 value will send tag data to the host with no printing.		
Sample:	<stx>L 1911A1802000010TEXT U X <stx>KtRUE00700ABCDEF1234H0000015001 <stx>G</stx></stx></stx>		
	The sample above creates a replaceable text field (01), recalls data from the RFID tag block zero (reading only one block, which is attempted nine times), and prints the data in the location		



When using addressed commands and the tag with the specified UID cannot be found, a standard RFID read/write fault will be issued.

specified by replaceable field.

STX KtU Read Unique Serial Number from RFID Tag

(Direct Mode – HF [13.56 MHz] ISO15693 Tag Interface)

This command instructs the RFID device to read the unique serial number data from the tag and then place that data into a replaceable field. It is expected that the tag transponder will be within the read / write distance of the RFID programming device; otherwise, "Void" will be printed in the text or bar code label field(s).

 Image: This is a sixteen character alphanumeric value; the replaceable field must have an adequate length.

 Syntax:
 <STX>KtUabcc<CR>

 Where:
 a
 - The number of retry attempts, 0-9.

 b
 - Reserved. Should be 0.

 cc
 - Field number in which to place the data (must be 01, 02, 03, etc.) matching the order of Label Formatting command, U.

 Image: A 00 value will send the ID to the host with no printing.

STX KtW Write Data to RFID Tag

(Direct Mode – HF [13.56 MHz] ISO15693 Tag Interface)

This command instructs the RFID device to write data to the tag. It is expected that the tag transponder will be within the read / write distance of the RFID programming device; otherwise, a warning will occur and a warning message (Read / Write Fail) will be displayed.

Syntax:	<stx>KtW</stx>	$Wn_1n_{16}Bn_cn_cn_caaabcdeee$
Where:	Un ₁ n ₁₆	 (Optional) Where n₁n₁₆ is the Unique Identifier (UID) in hexadecimal format, sixteen characters in length.
	<i>B</i> n _c n _c n _c	 (Optional) Where n_cn_cn_c is the data byte count, to allow non-printable characters (i.e., characters with hex values less than 0x20) to be encoded.
	aaa	 Starting block number (000 → maximum block number). Transponder dependent.
	b	- The number of retry attempts, 0-9.
	C ·	 Lock block after writing: 0 = No Protection 1 = Write Protect
	d	- Reserved. Should be 0.
	eee	- Data to be encoded on RFID tag.
Sample 1:	<stx>KtWB004000900<0x00><0x01><0x02><0x03>[CR]</stx>	
	Sample 1, above, programs the hex values 0x00, 0x01, 0x02, 0x03 in block zero.	
Sample 2:	<stx>KtWUE00700ABCDEF1234B004000510TEST[CR]</stx>	
	Sample 2, above, programs the data "TEST" to the tag with UID "E00700ABCDEF1234" at block zero then write-protects block zero (attempting to write five additional times if necessary). When write protecting (locking) with UID, the separate lock command will also use the addressed mode and the supplied UID.	

When using addressed commands and the tag with the specified UID cannot be found, a standard RFID read/write fault will be issued.

STX KuB Read Data from Gen2 Tag Section

This command reads a specific block address of a Gen2 tag.

Syntax:	<stx>KuBaaabbb</stx>		
Where:	aaa	 Block address number, where: 000 is kill/access section; 001 is EPC section; 002 is Tag ID; and, 003 is user memory. 	
	bbb	- Data offset in word length.	
Sample:	<stx>KuB(</stx>	001002	
	The sample above reads the block address 1 at offset word 2, which is location of the EPC data.		

STX KuF Send RFID Device Firmware Version

This command instructs the RFID device to return the firmware version.

Syntax:	<stx>KuF<cr></cr></stx>	
Printer response:	DEVICE VERSION:	XXX.XXX.XXX[CR]

STX KuJ Write Data to Gen 2 Tag Section

This command writes a specific block address of a Gen2 tag.

Syntax:	<stx>Ku</stx>	Jaaabbb <data></data>
Where:	aaa	 Block address number, where: 000 is kill/access section; 001 is EPC section; 002 is Tag ID; or, 003 is user memory.
	bbb	- Data offset in word length
	<data></data>	- Hexadecimal data (must be length of multiples of 4)
Sample:	<stx>KuJ</stx>	J001002112233445566778899AABBCC
		ple above writes data "112233445566778899AABBCC" to dress 1 at offset word 2, which is the EPC data.

STX KuR Read Data from RFID Tag

(Direct Mode – UHF Interface – Hexadecimal Data Only)

This command instructs the RFID device to read data from the tag and then place that data into a replaceable field. It is expected that the tag transponder is within the read / write distance of the RFID programming device; otherwise, "Void" will be printed in the text or bar code label field(s).

02, 03, etc.) matching the order of Label Formatt command, U.	Syntax:	<stx>KuRaa<cr></cr></stx>
printing. Sample: <stx>L D11 1911A1801000100 xxxxxxxxxxx U 1A31050002000200 xxxxxxxxxxxx U X <stx>KuR01 <stx>Kur02</stx></stx></stx>	Where:	02, 03, etc.) matching the order of Label Formatting
Sample: <pre></pre>		\swarrow A 00 value will send the ID to the host with no
D11 1911A1801000100 xxxxxxxxxxxx U 1A31050002000200 xxxxxxxxxxxx U X <stx>KuR01 <stx>Kur02</stx></stx>		printing.
	Sample:	D11 1911A1801000100 xxxxxxxxxxx U 1A31050002000200 xxxxxxxxxxx U X <stx>KuR01 <stx>Kur02 <stx>G The sample above creates a replaceable text field (01) and bar code field (02) and then recalls the data from the tag and places it</stx></stx></stx>



Data should be at least 16 or 24 characters in length.

STX KuW Write Data to RFID Tag

(Direct Mode – UHF Interface – Hexadecimal Data Only)

This command instructs the RFID device to write data to the tag. It is expected that the tag transponder will be within the read / write distance of the RFID programming device; otherwise, a warning will occur and a warning message (Read / Write Fail) will be displayed.

Syntax:	<stx>KuWabccc<cr></cr></stx>	
Where:	 The number of attempts to locate, erase and the tag (1 - 9). 	d program
	- Reserved. Should be 0.	
	 Data to be encoded in the ASCII format. Mu sixteen characters in length. The valid chara 0-9, A-F. 	
	Must be 16 or 24 characters long.	
Sample:	<stx>KuW10ABCDEF0102030405[CR]</stx>	
	The cample above programs the data	

The sample above programs the data <0xAB><0xCD><0xEF><0x01><0x02><0x03><0x04><0x05> to the tag, attempting to write one additional time if necessary.

STX KV Verifier Enable/Disable

This command allows a verifier to be enabled and disabled.

Syntax:	<stx>KVa</stx>	<cr></cr>
Where:	a	 Y = verifier enable N = verifier disable

STX KW Memory Configuration, Printable Label Width

See the <STX>K command for details.

V

This command will result in a system reset for the EX2.

STX Kx Delete Configuration File

This command deletes a configuration file.

Syntax:	<stx>KxmName<cr></cr></stx>	
Where:	<i>m</i> – 1	Valid Module ID – Range A to Z.
		The name, up to 16 characters, of the configuration file.
	<cr> -</cr>	0x0d terminates the name.
Sample:	<stx>KxYPla</stx>	ant1
	Module Y. (R	above deletes the configuration file <i>Plant1</i> from Remember to prefix this command with the Module Command <stx>kp.)</stx>

STX KZ Immediately Set Parameter

This command immediately sets the specified parameter.

Syntax:	<stx>KZax<cr></cr></stx>	
Where:	<i>a</i> - Valid parameter identifier, as follows:	
	F = Feed Speed P = Print Speed S = Slew Speed H = Heat Setting	
	 Speed Parameter Range – A to e (see Appendix L). 	
	-or-	
	 Heat Parameter Range – A two-digit value (00-30); see the "H" Label Formatting Command. 	
Sample:	<stx>KZH22</stx>	
	The sample above causes the file currently being executed to assume a Heat Value of 22.	

6 Label Formatting Command Functions

Introduction

The <STX>L command switches the printer from the System-Level Processor to the Label Formatting Processor. All commands following the <STX>L are interpreted as label formatting commands, and can be used to override default parameter values. Selectable parameter value defaults may be also reassigned via the Setup Menu, as defined in the corresponding *Operator's Manual*. Label formats that contain no commands overriding printer default values will assume those defaults.

: Set Cut by Amount

This command allows a predetermined number of labels to be printed before a cut is initiated. This feature is useful when it is necessary to print an uncut strip of labels. Between 1 and 9999 labels may be printed before a cut is made. The amount must be smaller than the quantity of labels printed.

Syntax:	:nnnn
Where:	<i>nnnn</i> - Is a four digit decimal number indicating the number of labels to be printed before a cut is performed.
Sample:	<stx>L<cr> :0005<cr> 141100001000100SAMPLE LABEL<cr> Q0021<cr> E<cr> The sample above instructs the printer to make a cut after 5, 10, and 20 labels have been printed. Label 21 will be cut at the start</cr></cr></cr></cr></cr></stx>
	of a subsequent label format (batch) unless a default (cut by amount) greater than one has been entered.



The cutter must be enabled with all mechanism interlocks closed for operation.

A Set Format Attribute

This command specifies the type of format operation and remains in effect until another format command is specified or another label format has begun (<stx>L). Each label format defaults to Attribute 2 (Transparent Mode).

Syntax:	An
Where:	 Is attribute mode 1, 2, 3, or 5; see table below. The default is 1.
Sample:	<stx>L A3 141100001000100DATAMAX<cr> 141100001100110DATAMAX<cr> E</cr></cr></stx>

The sample above sets the printer to Opaque Mode and produces one label.

n	Attribute	Description	Example
1	XOR Mode	In this mode, the region where text strings, images or bar codes intersect will not be printed. (An odd number of overlapping objects will print.)	DRATEMARX
2	Transparent Mode	This is the default mode; the intersecting regions of text strings, images, and bar codes will print, allowing the user to print fields atop one another.	DATEMARX
3	Opaque Mode	Interacting text is obliterated by the text formatted last. Each character cell is treated as opaque. This mode is effective only in rotation 1. See Record Structure Types.	Datamax
5	Inverse Mode	This mode allows inverse (white on black) printing (e.g., a proportionally sized border and background are printed similar to photographic negative). If text or image fields overlap in this mode, the effect will be similar to the XOR mode.	DATAMAX

Table 6-1: Format Attributes

B Bar Code Magnification

This command provides a mechanism to specify bar codes greater than 36 dots (0 - 9, A - Z in the field record). The value is reset to 1 at the start of every label and stays active for the entire label or set to a new value.

Syntax:	Bnn
Where:	nn - Is a two digit decimal number indicating the magnification value.
Sample:	<stx>L<cr> D11 B01 1a9305000100030ABCD<cr> B03 1a3105000700030ABCD<cr> Q0001 E The cample above instructs the printer to print two bar code</cr></cr></cr></stx>
	The sample above instructs the printer to print two bar code

The sample above instructs the printer to print two bar codes, each 9 dots by 3 dots.

C Set Column Offset Amount

This command allows horizontal adjustment of the point where printing begins. The printer is instructed to print label formats *nnnn* units to the right of the position that the format specifies. This feature is useful when a single format is to be printed on labels containing preprinted information.

Syntax:	Cnnnn	
Where:	 Is a four-digit number for the column offset, inches/100 or mm/10. The default is 0. 	
Sample:	<stx>L C0050 141100001000ATAMAX<cr></cr></stx>	
	The sample above shifts all format data 0.5 inches to the right, unless the printer is in metric mode, (see Label Formatting Command " m'').	

If using preprinted labels where the placement of the preprint data varies from label to label, the printed information may overlap the preprinted data.

c Set Cut by Amount

This command is the same as the ":" command except only a two-digit value can be entered. This command allows a predetermined number of labels to be printed before a cut is initiated. 1 to 99 labels may be printed before a cut is made.

Syntax:	cnn
Where:	 Is a two-digit number indicating the number of labels to be printed before a cut is performed. The default is one.
Sample	<stx>L<cr> c07<cr> 141100001000100SAMPLE LABEL<cr> Q0021<cr> E</cr></cr></cr></cr></stx>
	The sample above instructs the printer to make cuts after labels 7, 14, and 21 have been printed. See Label Formatting Command ":".



The cutter must be enabled and all mechanism interlocks closed for the cut operation.

D Set Dot Size Width and Height

This command is used to change the size of a printed dot, hence the print resolution – dots per inch (DPI) of the print head. By changing the height of a dot, the maximum length of a label can be increased or decreased. For the element sizes see Appendix K.

Syntax:	Dwh	
Where:	W	- Is Dot Width multiplier 1 or 2.
	h	- Is Dot Height multiplier 1, 2, or 3.

D11 is the default value for 300, 400 and 600 DPI printer models, while D22 is the default value for all 203 DPI printer models.

V

E Terminate Label Formatting Mode and Print Label

This command causes the printer, when the processing Label Formatting commands, to terminate the Label Formatting Mode then generate, print, and feed a label. The label generated will be based on whatever data has been received to that point, even if no printable data has been received. (Other termination commands are "X" and "s".) Commands sent to the printer after the Terminate Label command must be of the Immediate, System-Level, or Font Download type.

Syntax:	E	

Sample: <STX>L<CR> 12110000000000Testing<CR> E<CR>

The sample above will print one label.

e Recall Printer Configuration

This command recalls a previously stored printer configuration. It is highly recommended that only one Recall Printer Configuration command be used per label, and that it be used at the beginning of the label; otherwise, unpredictable results will occur. (Printer configurations may be stored using the Extended System-Level Commands or via the printer's menu system.)

Syntax:	eName <cr></cr>	
Where:	<i>Name</i> - The name, up to 16 characters, of the configuration file.	
	<cr> - 0x0d terminates the name.</cr>	
Sample:	<stx>L<cr> ePlant1<cr> 1A221000100000Testing<cr> E<cr></cr></cr></cr></cr></stx>	

The sample above recalls the stored printer configuration, *Plant1*.

F Advanced Format Attributes

These commends extend the text presentation capabilities for Scalable Fonts. The format attribute allows a set of label format records to select Bolding, Italicizing and Underlining. Additional commands allow the specification of line rotation and font changes within a label field. See "Advanced Format Attributes" (Section 8) for details.

f Set Present Speed (Non-Display Models only)

This command controls the rate at which the present distance is positioned, allowing the media movement to be slowed during "presentation" (the distance traveled after printing is completed to the label stop position). This command is used only within the context of a label format. The speed assigned is retained until another label format is received or until power is removed; if a subsequent format does not contain a present speed command then the present speed reverts to the feed speed.

Syntax:	fa
Where:	 Is a single alpha character representing a speed, limited by the feed speed range; see Appendix L. The default is the feed speed.
Sample:	<stx>LD11H30PGSG fA 191100200830165Fixed Data Field 1 E <stx>L 191100200830165Fixed Data Field 1 E The sample above prints two labels; the first label has present</stx></stx>

The sample above prints two labels; the first label has present speed of 1 inch per second, while the second reverts to the feed speed of 4 inches per second.

G Place Data in Global Register

G

The "G" command saves the print data of a print format record in a global register (temporary storage). This data may be retrieved and copied to another record in the same label format using the special Label Formatting Command: <STX>S. Global registers are named in the order received, beginning with Register A, ending at Register P, and incrementing with each instance of the G command use.

Sample:	<stx>L<cr></cr></stx>
•	12110000000000Testing <cr></cr>
	G <cr></cr>
	1A221000100000 <stx>SA<cr></cr></stx>
	E <cr></cr>

The sample above stores, retrieves, and prints the data in global register A. One label is printed with "Testing" in two locations.

Syntax:
Η Enter Heat Setting

This command changes the "on time" of elements of the print head. The default setting is 10 (except in the case of printers with a menu, where the default setting can be changed through the keypad). An increase or decrease in this value results in a change of heat applied by the print head to the media, lightening or darkening the print contrast accordingly. This is helpful when using different media types, each requiring a different amount of heat to properly image the media. The host device can send this command value to correct the heat setting per the application.

Syntax:	Hnn
Where:	nn - Is a two-digit heat value (00-30).
Sample:	<stx>L<cr> H15<cr> 141100001000100SAMPLE LABEL<cr> E</cr></cr></cr></stx>
	The sample above sets the printer for a heat value of 15 and prints one label.



Non-Display models - the "Darkness Potentiometer," while providing subtle changes, is intended to be used to match print contrast levels following print head replacements.

Justification

This command changes the printing justification.

Syntax:	Ja
Where:	 Is a single-digit alpha character: L = left justified (default) R = right justified C = center justified
Sample:	<stx>L<cr> 1911A1801001000TEST1 JR 1911A1801000100TEST2 JC 1911A1802000200TEST3 E</cr></stx>
	The sample above prints "TEST1" one inch up and one inch over going right, "TEST2" one inch up and one inch over going left, and "TEST3" two inches up and over.



Display-Equipped Models – This command is only valid for use with scalable fonts.

M Select Mirror Mode

This command instructs the printer to "mirror" all subsequent print field records, producing fields that are transposed visually.

Syntax:	м
Sample:	<stx>L 161100003200010 NOT MIRRORED<cr> M<cr> 161100003000400 MIRRORED<cr> E</cr></cr></cr></stx>
Printed Result:	NOT MIRRORED ДЭЯОЯЯІМ

m Set Metric Mode

This command sets the printer to measure in metric. When this command is sent, all measurements will be interpreted as metric values, (e.g., a column offset of 0010 will be interpreted as 1.0 mm).

Syntax:	m
Sample:	<stx>L<cr> m 141100001000100SAMPLE LABEL<cr> E</cr></cr></stx>
	The sample above prints the text (SAMPLE LABEL) starting at location coordinates 10.0 mm, 10.0 mm.

n Set Inch (Imperial) Mode

This command sets the printer to measure in inches. When this command is sent, all measurements will change to inches. Default mode, and is menu selectable.

Syntax:	n
Sample:	<stx>L<cr> n 141100001000100SAMPLE LABEL<cr> E The sample above prints the text (SAMPLE LABEL) starting at location coordinates 1.0 inch, 1.0 inch.</cr></cr></stx>

P Set Print Speed

This command sets a print speed for a label or batch of labels.

Syntax:	Ра
Where:	 Is a single character representing a speed; see Appendix L for valid ranges.
Sample:	<stx>L PC 141100001000100LABEL1<cr> E <stx>L 141100001000LABEL2<cr> E</cr></stx></cr></stx>
	The sample above prints two labels, the first at a speed of 2 inches per second (51 mm per second) and the second at the default setting.

p Set Backfeed Speed

This command, typically used in conjunction with the Cut or Peel and Present operations, controls the rate at which the labels will reverse to align to the next start of print position. The setting remains in effect until another backfeed speed command is received or until the printer is reset.

Syntax:	pa	
Where:	a	 Is a single alpha character representing a speed; see Appendix L for valid ranges.
Sample:	<stx>L pF</stx>	

The sample above sets the printer to a backup speed of 3.5 IPS.

Q Set Quantity of Labels to Print

This command sets the number of the label copies to be printed. A one to five digit value is allowed, if the command is delimited by a carriage return <CR>. This permits host applications to generate label quantity commands without the need to pad leading zeros. (A four-digit command value does not need to be <CR> terminated.)

Syntax:	Qnnnnn
Where:	 Is a one to five-digit delimited value setting for the number of labels to be printed. The default value is one.
Sample:	<stx>L 1211000000000Testing<cr> Q0020<cr> E<cr> The sample above will print a batch of 20 identical labels.</cr></cr></cr></stx>



Specifying 9999 as the four-digit quantity results in continuous printing.

R Set Row Offset Amount

This command allows vertical adjustment of the point where printing begins. The printer is instructed to print label formats *nnnn* units above the position that the format specifies. This feature is useful when a single format is to be printed on labels containing preprinted information.

Syntax:	Rnnnn
Where:	nnnn - Is a four-digit number (0000-9999) for the row offset, in inches/100 or millimeters/10. The default is 0.
Sample:	<stx>L R0037<cr> 141100001000100SAMPLE LABEL<cr> E The sample above prints a label with a row offset amount of .37 inches, unless in metric mode.</cr></cr></stx>
	preprinted labels where the placement of the preprint data varies from label the printed information may overlap the preprinted data.
formats)	g near the TOF is important (i.e., on very small labels or in very tight , it may be necessary to use the ROW ADJUST setting to shift the vertical rint position in the negative direction.

r Recall Stored Label Format

This command is used to retrieve label formats stored on a memory module. Embedding recalled labels, up to 6 levels of nesting, within a recall label is also possible.

Syntax:	rnnn			
Where:	<i>nnn</i> - Is a label name, up to 16 characters in length.			
	The samples below explain different ways to recall and print a labe format. (Use W to view a memory module's directory.)			•
		String Sent:	Printer Inte	erpretation:
	Sample 1:	<stx>L<cr> rTEST<cr> Q0002<cr> E<cr></cr></cr></cr></cr></stx>	Quantity r	l format ormat named TEST equested = 2 formatting and print
	Sample 2:	<stx>L<cr> rTEST<cr> X<cr> <stx>G<cr></cr></stx></cr></cr></cr></stx>		l format ormat named test formatting
	Sample 3:	<stx>L<cr> D11<cr> PO<cr> SO<cr> rTEST<cr> E<cr></cr></cr></cr></cr></cr></cr></stx>		1x1 d O
	The sample below explains recall embedding.			
		String Sent:		Printer Interpretation:
	Sample:	<stx>L rLABEL1 19111111111LABE sGLabel1</stx>	CL1FIELD1	Store label 1

<STX>L Store label 2 rLABEL1 19111111111ABEL2FIELD1 sGLabel2

<STX>L Print label 3 rLabel2 1911111111LABEL3FIELD1 E What gots p

What gets printed:

LABEL1 FIELD1 LABEL2 FIELD1 LABEL3 FIELD1

S Set Feed Speed

This command controls the rate at which the label is moved through non-printed areas. The setting remains unchanged unless another feed speed command is received or until the printer is reset.

Syntax:	Sa
Where:	 Is a single alpha character representing a speed; see Appendix L for valid ranges.
Sample:	<stx>L SE 141100001000100LABEL1<cr> E <stx>L 141100001000LABEL2<cr> E</cr></stx></cr></stx>

The sample above sets a 3 IPS feed speed and prints two labels, with the same feed speed for both.

s Store Label Format in Module

This command stores a label format to a specified module as a .dlb file. Supplying the module name will store the label to that module; otherwise, using C will cause the label format to be stored in the selected default module (see <STX>X). In addition, this command terminates the Label Formatting Command.

Syntax:	sannn
Where:	 Is the module designator representing a single character module name; see Appendix K.
	<i>nnn</i> - Represents the name of the label (maximum 16 characters).
Sample:	<stx>L<cr> D11<cr> 19110050100000123456789012<cr> 1911005020000001234567<cr> 1911005000000008ample<cr> 1X11000000000008250250002002<cr> Q0001<cr> sATEST<cr> The sample above stores a format in Memory Module A and names it "TEST". (To recall a label format from the module use the "r" command.)</cr></cr></cr></cr></cr></cr></cr></cr></stx>

T Set Field Data Line Terminator

This command, intended for use with record types that accept binary data (e.g., PDF417), allows binary control codes (e.g., a carriage return) to be embedded in the printed data by setting an alternate data line terminator. Valid only for the next format record, the terminator then defaults back to the carriage return.

Syntax:	Tnn
Where:	 Is an ASCII two-character representation of a HEX code to be used for the end of data terminator.
Sample:	<stx>L<cr> T00<cr> 19110020000000TEST<null> 141100001000100TERMIATOR<cr> Q0001<cr> E<cr></cr></cr></cr></null></cr></cr></stx>
	The sample above sets the a NULL terminator (ASCII NULL: HEX 00) for the data line termination code. The terminator is immediately restored to a carriage return <cr>, as seen in the</cr>

format record containing the text "TERMINATOR".

t Add or subtract date time from the printer date

This command allows the user to print an adjusted date of the printer. This date can be printed using the Special Label Formatting Command <STX>D. This command does not change the printer date.

Syntax:	txnnnn <cr></cr>
Where:	<pre>x= D = adjust by days W = adjust by weeks M = adjust by months Y = adjust by years</pre>
	nnnn = 4 digits to be added or subtracted. An optional '-' may precede the digits to indicate subtraction.
Sample 1:	Assume printer date is set to January 01, 2013 <stx>L tD0005 121100001000100 Expiration Date:<stx>D GHI PQ, RSTU E</stx></stx>
	Sample 1 prints: Expiration Date: JAN 06, 2013

Sample 2:	Assume printer date is set to January 31, 2013 <stx>L tM0001 121100001000100 Expiration Date:<stx>D GHI PQ, RSTU E</stx></stx>
	Sample 2 prints: Expiration Date: FEB 28, 2013
	Note: When advancing from a day at the end of the month with more days than the adjusted date, the printed date will not be greater than the maximum number of days of the adjusted month.
Sample 3:	Assume printer date is set to January 01, 2013 <stx>L tW-0001 121100001000100 Expiration Date:<stx>D GHI PQ, RSTU E</stx></stx>
	Sample 3 prints: DEC 25, 2012

U Mark Previous Field as a String Replacement Field

This command controls the formatting of replacement data. Specifying a field as a string replacement for dynamic, not static, fields will optimize throughput. See <STX>U.

Syntax: <STX>L Sample: D11 12110000100000123456789012<CR> U<CR> 121100002000001234567<CR> U<CR> 1611000000000Sample<CR> 1X11000000000B250250002002<CR> Q0001 Е <STX>U01ABCDEFGHIJKL<CR> <STX>U028901234<CR> <STX>G

υ

The sample above sets the format for register loading and prints two labels. The first two of four format records have been designated replacement fields. The second label is generated with System-Level field-replacement commands and printed.



The length of the original string sets the data string length of any replacement; both must be equal. The data being used when created must be valid for the font type being selected.

X Terminate Label Formatting Mode

х

This command causes the printer, when in label formatting mode, to immediately switch to the system command mode and generate a label format based on the data received at that point. However, unlike the "E" command, it will not print a label. (Other termination commands are the "E" and "s".)

Syntax:

Sample:

<STX>L<CR> 141100001000100SAMPLE<CR> X<CR>

The sample above will result in a label format, but no label will be printed.

y Select Font Symbol Set

This command, like the <STX>y, selects the scalable font symbol set. The selected symbol set remains active until another symbol set is selected; see the <STX>y command for details.

Syntax:	ySxx
Where:	 Byte-size designation; see Appendix H: S = Single byte symbol sets; and, U = Double byte symbol sets.
	xx - Symbol set selection.
Sample:	<stx>L ySSW<cr></cr></stx>
	The sample above selects the Swedish symbol set for use in

format records using scalable fonts.

z Zero (Ø) Conversion to "0"

This command removes the slash zero in fonts 0 to 8, and in the human readable field (if any) of the bar codes A to Z. The command applies only to format records containing those fonts and bar codes, and is effective only for the label format in which it appears.

Syntax:	z
Sample:	<stx>L z 12110000000000Test0000<cr> E</cr></stx>

None of the smooth fonts (i.e., Font 9) use the slash zero convention, and this command will have no effect on scalable fonts.

+ (>)(() Make Last Field Entered Increment

This command, useful in printing sequenced labels, causes the printer to automatically increment a field in a batch of labels. The numeric data in the field will increment by the value assigned after the plus sign (+) each time a label is produced [or the greater than symbol [>] can be substituted to make the field increment alphabetically, or the left parenthesis [(] can be substituted to make the field increment hexadecimal data (valid hexadecimal data is 0-9 or A-F, usually in pairs)]. This command is effective only on the label format record that it follows, and is intended to be used with the Q, <STX>E, or <STX>G commands.

Syntax:	*pii
Where:	 Is + for numeric increment, > for alphanumeric increment, or (for hexadecimal increment.
	 <i>p</i> - Is the fill character for the left-hand character of the field.
	<i>ii</i> - Is the amount by which to increment the field.
Sample:	<stx>L<cr> 132200000000012345<cr> +01<cr> Q0003<cr> E<cr></cr></cr></cr></cr></cr></stx>
	The sample above will generate a single field label format that prints the initial label with a value of 12345, and then increments that number by one for the next two labels.

Embedding

Numeric strings for incrementing may also be embedded between alphabetic characters (e.g., when systems require alphanumeric bar codes with alphabetic prefixes or suffixes).

Sample:

<STX>L<CR> 161100000100010AB0001CD<CR> + 100<CR> Q0003<CR> E<CR>

The sample above will print three labels, incrementing 0001 by 1 on each label with AB and CD remaining untouched: AB0001CD, AB0002CD, AB0003CD. Note that the increment value has one leading blank and two trailing zeros, while the blank is a pad character and the trailing zeroes are placeholders that leave CD unchanged.

- (<)() Make Last Field Entered Decrement

This command, useful in printing sequenced labels, causes the printer to automatically decrement a field in a batch of labels. The numeric data in the field will decrement by the value assigned after the minus (-) sign each time a label is produced [or the less than character [<] can be substituted to make the field decrement alphabetically, or the right parenthesis [)] can be substituted to make the field decrement hexadecimal data (valid hexadecimal data is 0-9 or A-F, usually in pairs)]. This command is effective only on the label format record that it follows, and is intended to be used with the Q, $\langle STX \rangle E$ or $\langle STX \rangle G$ commands.

Syntax:	*pii
Where:	 Is – for numeric decrement, < for alphanumeric decrement, or) for hexadecimal decrement.
	 <i>p</i> - Is the fill character for the leftmost character of the field.
	<i>ii</i> - Is the amount by which to decrement the field.
Sample:	<stx>L<cr> 1322000000000123AB<cr> <01<cr> Q0003<cr> E<cr></cr></cr></cr></cr></cr></stx>
	The sample above will generate a single field label format that prints the initial label with a value of 123AB, and then decrements that number by one for the next two labels.

Embedding

Numeric strings for decrementing may also be embedded between alphabetic characters (e.g., when systems require alphanumeric bar codes with alphabetic prefixes or suffixes).

Sample: <STX>L<CR> 1611000001000101000CD<CR> - 100<CR> Q0003<CR> E<CR>

> The sample above will print three labels: 1000CD, 999CD, and 998CD. Note that the pad character is a placeholder for digits removed from the left side in the subtraction process. When a fixed pitch font is used, the justification of the rightmost character is sustained regardless of the number of digits replaced by the pad character on the left side.

A Set Count by Amount

This command allows applications using the increment / decrement field command to print more than one label with the same field value before the field data is updated. The default is 1.

Syntax:	^ <i>nn</i>
Where:	 May be 0x55 or 0x40; see note below.
	 Is a two-digit value that specifies the number of labels to be generated before incrementing (or decrementing) the field value.
Sample:	<stx>L<cr> 132200000000012345<cr> -01<cr> ^02<cr> Q0006<cr> E<cr> The sample above prints two labels containing the same field value before decrementing the field. Six labels are printed.</cr></cr></cr></cr></cr></cr></stx>



This command can only be issued once per label format. In addition, when alternate Control Codes are enabled, the $^$ character must be replaced by the @ character (hexadecimal 0x40); see Control Code Command Functions.

Special Label Formatting Command Functions

Two Special Label Formatting Commands, the <STX>S and the <STX>T, are entered directly into the data field of label format records. (Do not confuse them with System-Level Commands because the same control character is used.) If alternate control codes are enabled the <STX> becomes "~" (hexadecimal 0x7E); see Control Code Command Functions.

Label Formatting Character	Command Description
<stx>D</stx>	Print adjusted date
<stx>S</stx>	Recall global data and place in field
<stx>T</stx>	Print time and date

STX D Print adjusted date

This command prints the adjusted date generated by the 't' label formatting command. Using string characters, allows the adjusted date data to be selected and printed. In addition, the <STX>D may be preceded by data to be printed/encoded, and/or the string may be terminated by an <STX> command followed by more data, then <CR> terminated. The string characters are not printed; instead, the label will show the corresponding print value.

Syntax: <STX>Dstring<CR>

Where:

string - Is any set of characters, A – Z and a - h; see the table below.

String Characters	Print Values	String Markers	Print Values
А	Week Day (Mon = 1 , Sun = 7)	VW	24-hour time format
BCD	Day Name	XY	12-hour time format
EF	Month Number	Za	Minutes
GHO	Month Name	gh	Seconds
PQ	Day	bc	AM or PM
RSTU	Year	def	Julian Date

Sample 1: Assume printer date is set to January 01, 2013
<STX>L
tD0005
121100001000100 Expiration Date:<STX>D GHI PQ, RSTU
E

Prints: Expiration Date: JAN 06, 2013

Sample 2: Assume printer date is set to January 01, 2013
<STX>L
tD0005
121100001000100 Expiration Date:<STX>D GHI PQ,
RSTU<STX> <<<<
E

Prints: Expiration Date: JAN 06, 2013 <<<<

STX S Recall Global Data and Place in Field

This command, when in the format record data field, places data from a specified global register into the data field. See the G command.

Syntax:	<stx>Sn</stx>
Where:	 Specifies the global register (A P) that contains the data to place into the data field.
Sample:	<stx>L<cr> 1211000000000DMX<cr> G<cr> 1A2210001000000<stx>SA<cr> E<cr></cr></cr></stx></cr></cr></cr></stx>
	The sample above places the string "DMX" into the next available global register (A), and then line 4 is effectively replaced by the data from global register A.

STX T Print Time and Date

This command, using string characters and markers, allows time and date data to be selected and retrieved from the internal clock. In addition, the <STX>T may be preceded by data to be printed/encoded, and/or the string may be terminated by an <STX> command followed by more data then <CR> terminated. The string characters/markers are not printed; instead, the label will show the corresponding print value.

Syntax:	<stx>Tstring<cr></cr></stx>
Jyntax.	

Where: string - Is any set of characters, A - Z and a - h; see the table below.

String Characters	Print Values	String Markers	Print Values
A	Week Day (Mon = 1 , Sun = 7)	VW	24-hour time format
BCD Day Name		XY	12-hour time format
EF	Month Number	Za	Minutes
GHO	Month Name	gh	Seconds
PQ	Day	bc	AM or PM
RSTU	Year	def	Julian Date

Table 6-3: Time and Date String Characters and Markers

		ubstitution, you must ensure the converted string produces valid the selected bar code / font.
Sample	1:	<stx>L<cr> 121100001000100<stx>TBCD GHI PQ, TU<cr> E<cr></cr></cr></stx></cr></stx>
		Sample 1 prints SUN DEC 21, 98.
Sample	2:	<stx>L<cr> 191100100100010<stx>TEF/PQ<cr> E<cr></cr></cr></stx></cr></stx>
		Sample 2 prints 12/21.
Sample	3:	<stx>L<cr> 191100100100010ABC <stx>TEF/PQ<stx> DEF<cr> E<cr></cr></cr></stx></stx></cr></stx>
		Sample 3 prints ABC 12/21 DEF, and illustrates a method of embedding the time string, where the string must be terminated by <stx>.</stx>



The samples above assume a current printer date of December 21, 1998.

7 Font Loading Command Functions

Introduction

The commands used for font loading are usually generated by font creation software; however, the assigned font ID number command must be sent to the printer before the font file. All Font Loading Commands begin with <ESC> (ASCII control character 27 [decimal]).

The downloaded font will be stored in the default module (refer to the <STX>X command) as file type .dbm. The commands in the table below are listed in their order of appearance, top to bottom, during font downloading. The <SOH>D command must be sent prior to downloading a font.

Command	Description
*c###D	Assign Font ID Number
)s#Wnn…n	Font Descriptor
*c#E	Character Code
(s#W	Character Download Data

Table 7-1: Font Loading Commands

*c###D Assign Font ID Number

This command is the first command required for downloading a font to either RAM or Flash Memory modules. ESC represents the ASCII control character 27.

Syntax:	<esc>*c###D</esc>
Syntax.	

Where:	### -	Is the font ID numbers 100-999 (000 – 099 are
		reserved for resident fonts).

)s###W Font Descriptor

This command (typically first data in a font file) contains all of the information about the font contained in the file. Different font generation software will create different length header information, but the initial 64 bytes will remain consistent with the PCL-4 (HP LaserJet II) format.

 Syntax:
 <ESC>)s###wddd...d

 Where:
 ###
 - Is the number of bytes of font descriptor data from 1 to 3 ASCII decimal digits.

 dd...d
 - Is the descriptor.

*c###E Character Code

This code is the ASCII decimal value corresponding to the next downloaded character.

Syntax:	<esc>*c###E</esc>		
Where:	### -	Is the ASCII value of the character, three digits maximum, 0 to 999.	

(s#W Character Download Data

This command contains all of the information for one downloaded character.

Syntax:	<esc>(s###Wnnn</esc>		
Where:	### -	Is the number of bytes of bitmapped data, three digits maximum, from 1 to 999.	
	nnn -	Is the bitmapped data.	

8 Generating Label Formats

Introduction

This section explains the use of the different fields in a print format record.

Format Record Commands

Received label format data (see example below) is processed by the printer sequentially, left to right and top to bottom.

String Sent	Interpretation	
<stx>L<cr></cr></stx>	Begin label format	
D11 <cr></cr>	Set dot size	
12110000050005Home Position <cr></cr>	Format text	
191100602000200ROTATION 1 <cr></cr>	Format text	
291100602000200ROTATION 2 <cr></cr>	Format text	
391100602000200ROTATION 3 <cr></cr>	Format text	
491100602000200ROTATION 4 <cr></cr>	Format text	
1A3104003000260123456 <cr></cr>	Format bar code with text	
2A3104001400300123456 <cr></cr>	Format bar code with text	
3A3104001000140123456 <cr></cr>	Format bar code with text	
4A3104002600100123456 <cr></cr>	Format bar code with text	
1X11000000000B400400003003 <cr></cr>	Format box	
1X110000200000L400003 <cr></cr>	Format line	
1X110000000200L003400 <cr></cr>	Format line	
121100004100010Printhead Location <cr></cr>	Format text	
Q0001 <cr></cr>	Label quantity	
E <cr></cr>	End formatting, begin printing	

Table 8-1: Sample Label Format



The sample above assumes that "inch" mode (<STX>n) is selected, with four inch media.



Figure 8-1: Formatted Sample Label

The first line in the sample format (Table 8-1) is the System-Level Command directing the printer to begin label formatting. (Other System-Level Commands may precede the <STX>L for printer setup.) Lines 2, 14, and 15 are Label Formatting Commands. Line 15 is the exit and print command. The remaining lines (3-13) are print format records, explained in this section.

A record is a data string that contains the information to be printed on the label(s). Records are the building blocks of label formats. Every record must end with a termination character (usually a carriage return, <CR>). Omitting termination characters will result in the concatenation of records. Omitting the carriage return that precedes the termination character E, which is necessary to complete the label formatting and begin printing, will cause the printer to continue interpreting all subsequent data as label print format records.

Generating Records

Every record is made of three parts: (1) a header that is 15 bytes in length, (2) the data to be printed, and (3) a termination character (e.g., <CR>) marking the end of the field. The header is used to select the appearance of the data when printed by choosing rotation, font type, size, and position options. Every header contains similar information, but different types of records may use this information in different ways. The six record types are:

- 1. Internal Bitmapped Font
- 2. Smooth Font (Simulated)
- 3. Scalable Font
- 4. Bar code
- 5. Images
- 6. Graphics

The Structure of a Record

The basic structure of the record is described below. For details regarding the various interpretations of the six types see Record Structure Types.

The third line of the label format example in Table 8-1 consists of the following:

12110000050005HOME POSITION<CR>

This string comprises a complete record, shown below, divided into its three basic component parts.

Header	Data String	Termination Character		
12110000050005	HOME POSITION	<cr></cr>		

Table 8-2: Record Structure Components

The record (with spaces added for readability) conforms to the following fixed field format. Identifying lower case letters have been placed below field values for reference in the following sections:

1 2	1	1	000	0005	0005	HOME POSITION	<cr></cr>
a b	С	d	eee	ffff	aaaa	[hhhh iiii] jj…j	Termination character

Location	Record Type						
Within Record	Internal Bitmapped Font	Smooth Font	Scalable Font	Bar Code	Images	Graphics	
a	Rotation	Rotation	Rotation	Rotation	Rotation	1	
b	Font ID	9	9	Bar Code	Y	х	
С	Width Multiplier	Width Multiplier	Width Multiplier	Wide Bar	Width Multiplier	1	
d	Height Multiplier	Height Multiplier	Height Multiplier	Narrow Bar	Height Multiplier	1	
eee	000	Font Size/ ID	ID	Bar Code Height	000	000	
ffff	Row Position	Row Position	Row Position	Row Position	Row Position	Row Position	
aaaa	Column Position	Column Position	Column Position	Column Position	Column Position	Column Position	
hhhh	N/A	N/A	Font Height	N/A	N/A	N/A	
iiii	N/A	N/A	Font Width	N/A	N/A	N/A	
jj…j	Data String	Data String	Data String	Data String	Image Name	Graphics Specifier	

Table 8-3: Record Type Structure

In Table 8-3, the record structure is shown for each of the record types. The left-most column shows the locations of all characters in the record, and corresponds to the example above the table. Each record structure interprets the characters of the record in its own way, though some of the interpretations of the characters are identical across all record types. For example, the characters ffff are interpreted as Row Position in all record types. While c is a Width Multiplier for Internal Bitmapped Font, Smooth Font, Scalable Font, and Image record types, it has other interpretations for Bar Code and Graphics record types.

The Header Fields

Each of the fields in the record header is generally described below. Please reference the detailed descriptions under Record Structure Types for variations. The field name titles of the following paragraphs are preceded with a reference letter from Table 8-3. All characters sent to the printer within the header fields are ASCII, alphanumeric.

a: Rotation

The first field of a header is a single ASCII character that selects the clockwise degree of rotation for the data to be printed on a label, where:

 $1 = 0^{\circ}$; $2 = 90^{\circ}$; $3 = 180^{\circ}$; and, $4 = 270^{\circ}$.

Figure 8-1 shows the direction and amount of rotation, relative to the print direction, where the bottom left corner is the pivot point.

b: Fonts, Bar Codes, Graphics, and Images

The second field (b) determines how the rest of the fields are interpreted, as shown in the table below.

- Values 0 through 9 select human-readable fonts. 0 through 8 will select standard printer fonts; value 9 selects the CG Triumvirate smooth scalable font (internal) or scalable fonts. When 9 is used to select a scalable font, the font size (font I.D. number) is chosen by entering a value in the height field eee.
- Values A through z select bar codes. Values A through T (uppercase) will print bar codes with human-readable interpretations. Values a through z (lowercase) will print bar codes only.
- Value W requires two additional characters to specify the Bar Code/Font ID.
- A font field value X selects a drawing object (line, box, circle or polygon), and field value Y is used to print an image stored in a module.

b Font Field Value	Interpretation
0-9	Font
A-T	Bar code with human readable text.
a-z	Bar code without human readable text.
Wxx	Bar code/Font expansion
Х	Line, box, polygon, circle
Y	Image

Table 8-4: Font Field Interpretations

c: Width Multiplier

Values 1-9, A-Z, and a-z represent multiplication factors from 1 - 61, respectively. For human-readable fonts, the width multiplier represents the number of times the selected font dot tables are multiplied and has no effect on the character height. For bar codes, this character specifies the wide bar width or ratio at a resolution that is dependent upon the printer model. See Appendix F for default values.

d: Height Multiplier

The height multiplier has the same range and function as the width multiplier (c), but vertical. When used in the context of bar codes, this field is the ratio denominator, or the small bar (module) width. Values 1-9, A-Z, and a-z will give a narrow bar width of one dot (dot size = 1/printhead resolution) to dots. The narrow bar width resolution and range are dependent upon the print head resolution; see Appendix K. A "dot multiplier" command can also be used to change the printed dot size (see Label Formatting Command "D" and Appendix F).

eee: Bar Code Height (Font Size/Selection)

b Font Field Value	eee Field Range	d Range eee Field Interpretation	
0-8	000	Not used – Internal bitmapped font	
9	000-999, A04-A72, S00-S9z, U00-U9z, u00-u9z	Font height; Font selection	
A-T	000-999	Bar code height (with human readable)	
a-z	000-999	Bar code height	
Wxx	000-999	Bar code height (with human readable)	
Х,Ү	000	Not used	

This field has interpretations dependent upon the value of the font b field, as shown below.

Table 8-5: Bar Code Height Field Interpretations

ffff: Row Position

The lower left corner of a label is considered the "home position" (see Figure 8-1). The row position field is a <u>vertical</u> coordinate that determines how far above the home position the data is to be printed. Field data is interpreted in hundredths of an inch or tenths of millimeters.

gggg: Column Position

This field is a <u>horizontal</u> coordinate that determines how far to the right of "home position" the data will be printed. Appendix G lists the maximum values of the gggg field.

hhhh: Optional Scalable Font Height

The height of a scalable font can be specified in two ways: points or dots. To specify the height in points the first character of the field is a "P" followed by the number of points, 004 to 999. To specify the size in dots, all four characters must be numeric. This field must be specified for scalable fonts. (See note below Optional Scalable Font Width.)

iiii: Optional Scalable Font Width

The width of a scalable font can be specified in two ways, points or dots. To specify the width in points, the first character of the field is a "P" followed by the number of points, 004 to 999 points. To specify the size in dots, all four characters must be numeric. This field must be specified for scalable fonts. See note below.



To ensure that the data stream is portable to other Datamax-O'Neil printers, specify the font size in points. If the font is specified in dots, it will output differently on printers with different DPI/MMPI resolutions. There are 72.307 points per 1 inch (2.847 mm).

jj...j: Data Field

The final field contains the data that will actually be printed on the label. A string of data can be up to 255 characters in length (<u>except</u> when using the PDF417 bar code, which may be up to 3000 characters long), ending with a carriage return. Characters placed in the data field will be printed as long as they fall within the physical range of the print head. Consult Appendix K for a listing by printer.

Record Structure Types

Each of the six record types has its own field structure and is described in the following section. The record types allow quick reference to the field types and their valid data inputs for the field. There are similar, but unique, record structures for each: internal, bitmapped fonts, internal smooth fonts, downloaded bitmapped fonts, scalable fonts, bar codes, images, and graphics. The field location identifiers in the tables that follow are the same as those in Table 8-3.

1: Internal Bitmapped Fonts

This record type is used for internal bitmapped fonts (see Appendix C, Tables C-1 through C-5).

When a 0 through 8 is entered in field b, then the height field eee is not used. The bitmapped fonts include 8 different fonts (see Appendix C). The character mapping for these fonts is shown in Appendix A, or a subset thereof.

Field	Valid Inputs	Meaning
a	1, 2, 3 and 4	Rotation
b	0 to 8 (see Appendix C).	Font
С	1 to 9, A to Z, and a to z	Width Multiplier
d	1 to 9, A to Z, and a to z	Height Multiplier
eee	000	N/A
ffff	0000 to 9999	Row
aaaa	0000 to 9999 Dependent upon printer. See Appendix K.	Column
jj…j	Valid ASCII character string up to 255 characters, followed by a termination character.	Data

 Table 8-6: Internal Bitmapped Font Record Structure

2: Smooth Font, Font Modules, and Downloaded Bitmapped Fonts

This record type is used for internal smooth fonts (CG Triumvirate – see Table C-6) or a bitmapped font downloaded to a memory module; see Font Loading Commands.

When a 9 is entered in field b, then the height field eee determines the font. The internal smooth font has up to 13 font sizes (see Appendix C). Values 100 through 999 select individual fonts stored on DRAM, or Flash memory. These include downloaded bitmapped fonts (see Table 8-5). Use eee values of 096 – 099 for Kanji fonts, if equipped (see Appendix I). The character mapping is shown in Appendix A.

Field	Valid Inputs	Meaning
a	1, 2, 3 and 4	Rotation
b	9	Fixed Value
С	1 to 9, A to Z, and a to z	Width Multiplier
d	1 to 9, A to Z, and a to z	Height Multiplier

(continued)

Field	Valid Inputs	Meaning
eee	000 to 999 (000 to 099 Reserved), A04 to A72, $x04 - x72$, Where x is an upper case letter; see Appendix H.	Font / Size
ffff	0000 to 9999	Row
aaaa	0000 to 9999 Dependent upon printer. See Appendix K.	Column
jj…j	Valid ASCII character string up to 255 characters followed by a termination character.	Data

Table 8-7: Smooth Font Record Structure

3: Scalable Fonts

The Smooth Scalable Font Technology is licensed from AGFA. Both Microtype* and TrueType (.TTF) Scalable Font file formats are supported. The eee field identifies the scalable font, and data type – normal (binary) or Hex ASCII. Uppercase S or U – binary, lowercase u – Hex ASCII (see Appendix H). Values S00 to S9z, and U00 to U9z (u00 to u9z), select a scalable font. S00 and S01 are used for the standard internal (resident) fonts on display-equipped models, while S01 is used for the standard internal (resident) font on non-display models.

Field	Valid Inputs	Meaning
a	1, 2, 3 and 4	Rotation
b	9	Fixed Value
С	1 to 9, A to Z, and a to z	Width Multiplier
d	1 to 9, A to Z, and a to z	Height Multiplier
eee	S00 to Szz, U00-Uzz, u00-uzz	Font Data Type
ffff	0000 to 9999	Row
aaaa	Dependent upon printer. See Appendix K.	Column
hhhh	P004-P999, 0016-4163**	Character Height; points, dots
iiii	P004-P999, 0014-4163**	Character Width; points, dots
jj…j	Valid ASCII character string up to 255 characters followed by a termination character.	Data

* I-Class supports Intellifont.

**Character sizes are resolution dependent, as indicated in the following table.

 Table 8-8: Scalable Font Record Structure

Print head	Character	size (dots)
Resolution (DPI)	Width	Height
203	16-2817	16-2817
300	14-4163	16-4163
400	22-5550	22-5550
600	33-8325	33-8325

Table 8-9: Scalable Character Size Ranges

A scalable font cache must be allocated to print. Minimum cache size is 15. The double byte fonts require five units of additional cache.

4: Bar Codes

Valid inputs for the bar code field b are letters: uppercase letters will print a humanreadable text below the bar code; lowercase letters will only print the bar code. For example, entering a "p" in the b field selects the Postnet bar code. Because the Postnet font does not provide human-readable data, the uppercase P is not valid. Other bar codes without a human-readable counterpart include u (MaxiCode) and z (PDF417) – for additional model-specific restrictions see Appendix F.

For module-based bar codes, field d is the narrow bar width in dots (bar code module size). For consistent results in all rotations for bar codes of this type, field d and field c must have the same value. For ratio-based bar codes field c is the wide bar width in dots (the numerator); field d is the narrow bar width in dots (the denominator). See Appendix G for specific bar code information and variations in record format field usage.

The eee height field represents the bar code (symbol) height. The valid range (001 to 999) translates to bar heights ranging from .01 inch (.254 mm) to 9.99 inches (253.7 mm). For bar codes that require additional specified parameters, use the jj...j data field as the location for these parameters. See the specific bar code for details in Appendix G.

Field	Valid Inputs	Meaning
a	1, 2, 3 and 4	Rotation
b [bb]	A to Z and a to z (except P, u, v, z), or Wna where n is 1 to 9 and a is A to S and a to s. No n is an implied 1.	Bar Code
С	1 to 9, A to Z, and a to z	Wide Bar
d	1 to 9, A to Z, and a to z	Narrow Bar

(continued)

Field	Valid Inputs	Meaning
eee	001 to 999	Symbol Height
ffff	0000 to 9999	Row
aaaa	See Appendix K.	Column
jj…j	Valid ASCII character string up to 255 characters followed by a termination character.	Data

Table 8-10: Bar Code Record Structure

Placing 0 (zero) in both c and d will result in the default bar code ratio or module size. Placing 000 (zero) in the symbol height field will result in the default bar code height; see Appendix F for defaults.

5: Images

An image record is used to print an image that is stored in a memory module. Images can be printed only in Rotation 1; see <STX>I.

Field	Valid Inputs	Meaning
a	1	Fixed Value
b	Υ	Image
С	1 to 9, A to Z, and a to z	Width Multiplier
d	1 to 9, A to Z, and a to z	Height Multiplier
eee	000	Fixed Value
ffff	0000 to 9999	Row
aaaa	See Appendix K.	Column
jj…j	ASCII string, up to 16 characters followed by a termination character.	Image Name

Table 8-11: Image Fields

6: Graphics

Using graphics, the printer can produce lines, boxes, polygons, and circles. This function is selected by entering an X in field b. The values entered in the data field determine the sizes and shapes of the objects to be drawn. Forms can be created using shaded boxes, complex logos, or even a simple diagonal line without the need to download a graphics file to the printer. Generate each kind of graphic as described below.

Lines and Boxes

Lines and boxes are drawn by values that determine column and row starting position, length, width, and wall thickness of the line or box (see Appendix K). Depending on the printer's mode, all measurements are interpreted as inches/100 or millimeters/10 (see <STX>m). The data field jj...j is used to describe the line or box dimensions.

Segment	Valid Inputs	Meaning
a	1	Fixed value
b	x	Line / Box
С	1	Fixed Value
d	1	Fixed Value
eee	000	Fixed Value
ffff	0000 to 9999	Row
aaaa	0000-9999; see Appendix K.	Column
jjj	Lhhhvvv lhhhhvvvv Bhhhvvvbbbsss bhhhhvvvbbbbsss	Line* Line** Box*** Box***

Table 8-12: Line and Box Parameters

Line*:	Lhhhvvv
Where:	L = "L" and specifies line drawing; hhh = horizontal width of line; and, vvv = vertical height of line.
Line**:	lhhhhvvvv
Where:	 = "I" and specifies line drawing; hhhh = horizontal width of line; and, vvvv = vertical height of line.
Box***:	Bhhhvvvbbbsss
Where:	B = "B" and specifies box drawing; hhh = horizontal width of box; vvv = vertical height of box; bbb = thickness of bottom and top box edges; and, sss = thickness of box sides.
Box****:	bhhhhvvvvbbbbssss
Where:	 b = "b" and specifies box drawing; hhhh = horizontal width of box; vvvv = vertical height of box; bbbb = thickness of bottom and top box edges; and, ssss = thickness of box sides.



Boxes are hollow, while lines can be understood as filled-in boxes.

Polygons

Polygons are created by defining the positions of the corners, specifying a number of data points that represent the vertices of the object, which can range from a simple line (two points), or a triangle (three points), to any free-form outline. Polygons may be filled with a variety of different patterns. All row/column specifiers are interpreted as inches/100 or millimeters/10 depending on the printer mode, (see <STX>m).

Record structure for a polygon (spaces added for readability):

1 X 11 ppp rrrr cccc P ppp bbbb rrrr cccc rrrr cccc ... <CR>

Where:

1	Rotation (must be 1)	ppp	Fixed Value (001)
х	Graphic field ID	bbbb	Fixed Value (0001)
1	Multiplier (must be 1)	rrrr	Row of point 2
1	Multiplier (must be 1)	cccc	Column of point 2
ppp	Fill pattern #	rrrr	Row of point 3
rrrr	Row of point 1	cccc	Column of point 3
cccc	Column of point 1		Additional points
Р	Polygon ID (Fixed Value)	<cr></cr>	Termination character

Table 8-13: Polygon Record Structure



The points must be specified in the order to be drawn; the last point specified is automatically connected to the first point to close the polygon. If only two points are specified, a single line will be drawn. See Label Formatting Command A.

Circles

A circle is created by defining by its center point and radius. Circles can be filled with a variety of different patterns (see Table 8-15). Row, column, and radius are interpreted as inches (100) or millimeters (10) depending on printer mode.

Record structure for a circle (spaces have been added for readability):

1 X 11 fff rrrr cccc C ppp bbbb rrrr <CR>

Where:

1	Rotation (must be 1)	cccc	Column of the center point
Х	Graphic field	С	Circle ID (Fixed Value)
1	Multiplier (must be 1)	ppp	Fixed Value (001)
1	Multiplier (must be 1)	bbbb	Fixed Value (0001)
fff	Fill pattern number	rrrr	Radius of the circle
rrrr	Row of the center point	<cr></cr>	Termination character

Table 8-14: Circle Record Structure

Fill Patterns			
Pattern Number	Description	Example	
0	No Pattern		
1	Solid Black		
2	6% Black		
3	12% Black		
4	25% Black		
5	38% Black		
6	50% Black		
7	Diamonds		
8	Circles		
9	Right Diagonal Lines		
10	Left Diagonal Lines		
11	Grid		

Table 8-15: Fill Patterns

Examples (with spaces added for readability):

1: Triangle

The record:

```
1 X 11 000 0010 0010 P 001 0001 0040 0025 0010 0040<CR>
```

Produces a triangle with no fill pattern:



(row 0010, column 0010) (row 0010, column 0040)

2: Rectangle with Fill

The record:

1 X 11 004 0010 0010 P 001 0001 0050 0010 0050 0200 0010 0200<CR>

Produces a rectangle filled with pattern 4 (25% Black):



(row 0010, column 0010) (row 0050, column 0200)

3: Circle

The record:

1 X 11 000 0100 0100 C 001 0001 0025<CR>

Produces a circle centered at row 0100, column 0100 with a radius of 0025 and no fill pattern:



4: Circle with Fill

The record:

1 X 11 009 0100 0100 C 001 0001 0025<CR>

Produces a circle centered at row 0100, column 0100 with a radius of 0025 and filled with pattern 9 (right diagonal lines):



Advanced Format Attributes

Two different advanced formatting attributes extend the text presentation capabilities. The first format attribute allows a set of label format records to make a *state change* that modifies the font attributes of any following DPL text records. The second format attribute provides a means of inserting text and font formatting commands directly into the DPL data stream via a *command delimiter structure*. All label formats begin by default with attributes disabled.

The table below represents the current list of font attributes available to the user. Note that these commands are delimited by the $\langle xxx \rangle$ sequence (where xxx is from the list below).

Command	Units	Purpose	Notes	
FB	+/-	Turns on or off font boldfacing.	minue » // in dischlau au	
FI	+/-	Turns on or off font italicization.	minus "-" is disable; or, plus "+" is enable	
FU	+/-	Turns on or off underlining of string.		
FPn	Points	Specifies the vertical point size of the following text relative to the base line.		
FSn	Points	Specifies the horizontal point size of the following text relative to the base line.		
FR[+/-]n	Degrees	Specifies the rotation of the base line, relative to the original print direction of the record.	If a + or – precedes the numeric value, then the direction is relative to the current print direction.	

Table 8-16: Advanced Format Attributes

These commands are only valid for scalable fonts, such as Internal Font 9, S00, S01, or downloaded TrueType scalable fonts. (Some models have limited standard font sets and capabilities; see the notes below for applicability of commands and consult the appropriate *Operator's Manual* for available standard and optional font sets.)

For example, the first format attribute command can be illustrated as follows. The text below and the resulting label (Figure 1) are examples of a current DPL format:

<stx>L</stx>	
D11	
1911S0102600040P018P018Old DPL	World
1911S0102000040P018P018Old DPL	World
1911S0101400040P018P018Old DPL	World
1911S0100800040P018P018Old DPL	World
1911S0100200040P018P018Old DPL	World
E	

Old DPL World		
Old DPL World		
Figure 1		

If the DPL format is modified as follows, the resulting label (Figure 2) is printed:

<stx>L D11</stx>	New DPL World
FA+ FB+ 1911S0102600040P018P018New DPL World FU+I+	<u>New DPL World</u>
1911S0102000040P018P018New DPL World FI-U+B-	
1911S0101400040P018P018New DPL World FU-B+	New DPL World
1911S0100800040P018P018New DPL World FB+I+U+	
1911S0100200040P018P018New DPL World FB-U-I- E	New DPL World
	New DPL World

Figure 2

Note that if all format commands after the first FB+ were deleted the entire label would have been printed with bold scalable fonts. This is what is meant by a *state change*. Once invoked, that command is in affect until turned off or the label format is terminated with the "E" "s" or the "X" command.

The second format attribute command is inserted into the text data stream and delimited by the angle brackets "<>" This structure takes the form of \<*command*>. An example of this command is as follows:

```
<STX>L
D11
A2
FA+
1911S0105000020P018P018DPL allows \<FP36FS36>FONT\<FS10FP10> sizes
\<FS8FP12>in the string
1911S0103500100P018P018\<FR80>D\<FR-5>P\<FR-5>L\<FR-5>\<FR-5>1\<FR-
5>e\<FR->t\<FR-5>s\<FR-5> \<FR-5>y\<FR-5>o\<FR-5>u\<FR-5> \<FR-5>w\<FR-
5>r\<FR-5>i\<FR-5>t\<FR-5>e\<FR-5> \<FR-5>i\<FR-5> \<FR-5>n\<FR-5> \<FR-5>c\<FR-
5>i\<FR-5>r\<FR-5>c\<FR-5>1\<FR-5>e\<FR-5>s\<FR-5> \<FR-5>t\<FR-5>o\<FR-
5>o\<FR-5>!
1911S0102400040P018P018\<FR+45>DPL allows \<FB+>Rotations\<FB-FR-90> in
the string
1911S0102000040P018P018DPL allows \<FB+>BOLD\<FB-> in the string
FU+
1911S0101400040P018P012DPL allows \<FI+>ITALICS\<FI-> in the string
FI+U-
1911S0101000040P018P012DPL allows \<FB+I+>COMBINATIONS\<FB-I-> in the
string
FB+I-
1911S0100600040P018P018DPL allows \<FB+>BOLD\<FB-> in the string
FU+I+
1911S0100200040P018P018DPL allows \<FB+>BOLD\<FB-> in the string
FB-U-T-
E
```

Figure 3 is an example of the output from this DPL command stream. The user has the ability to change the point and set size of the font within the DPL command record. In addition, the angle of the baseline may be specified relative to the current orientation of the record. (For example, the command < R+45> will rotate the baseline forty five degrees in the positive direction from the default print direction.)

Refer to Section 8 for more information regarding the DPL record format for a scalable font text string.



Figure 3
Appendix A

	Char	Dec	Hex									
Ctrl @	NUL	0	00		32	20	@	64	40	`	96	60
Ctrl A	SOH	1	01	!	33	21	А	65	41	а	97	61
Ctrl B	STX	2	02	w	34	22	В	66	42	b	98	62
Ctrl C	EXT	3	03	#	35	23	С	67	43	с	99	63
Ctrl D	EOT	4	04	\$	36	24	D	68	44	d	100	64
Ctrl E	ENQ	5	05	%	37	25	E	69	45	е	101	65
Ctrl F	ACK	6	06	&	38	26	F	70	46	f	102	66
Ctrl G	BEL	7	07	Ô	39	27	G	71	47	g	103	67
Ctrl H	BS	8	08	(40	28	Н	72	48	h	104	68
Ctrl I	HT	9	09)	41	29	Ι	73	49	i	105	69
Ctrl J	LF	10	0A	*	42	2A	J	74	4A	j	106	6A
Ctrl K	VT	11	0B	+	43	2B	К	75	4B	k	107	6B
Ctrl L	FF	12	0C	,	44	2C	L	76	4C	1	108	6C
Ctrl M	CR	13	0D	-	45	2D	М	77	4D	m	109	6D
Ctrl N	SO	14	0E		46	2E	Ν	78	4E	n	110	6E
Ctrl O	SI	15	0F	/	47	2F	0	79	4F	0	111	6F
Ctrl P	DLE	16	10	0	48	30	Р	80	50	р	112	70
Ctrl Q	DC1	17	11	1	49	31	Q	81	51	q	113	71
Ctrl R	DC2	18	12	2	50	32	R	82	52	r	114	72
Ctrl S	DC3	19	13	3	51	33	S	83	53	s	115	73
Ctrl T	DC4	20	14	4	52	34	Т	84	54	t	116	74
Ctrl U	NAK	21	15	5	53	35	U	85	55	u	117	75
Ctrl V	SYN	22	16	6	54	36	V	86	56	v	118	76
Ctrl W	ETB	23	17	7	55	37	W	87	57	w	119	77
Ctrl X	CAN	24	18	8	56	38	Х	88	58	х	120	78
Ctrl Y	EM	25	19	9	57	39	Y	89	59	у	121	79
Ctrl Z	SUB	26	1A	:	58	3A	Z	90	5A	Z	122	7A
Ctrl [ESC	27	1B	;	59	3B	[91	5B	{	123	7B
Ctrl \	FS	28	1C	<	60	3C	\	92	5C		124	7C
Ctrl]	GS	29	1D	=	61	3D]	93	5D	}	125	7D
Ctrl ^	RS	30	1E	>	62	3E	~	94	5E	~	126	7E
Ctrl _	US	31	1F	?	63	3F	_	95	5F		127	7F

ASCII Control Chart

Char	Dec	Hex									
Ç	128	80	á	160	A0		192	C0	Ó	224	E0
ü	129	81	í	161	A1		193	C1	ß	225	E1
é	130	82	ó	162	A2		194	C2	Ô	226	E2
â	131	83	ú	163	A3		195	C3	Ò	227	E3
ä	132	84	ñ	164	A4		196	C4	õ	228	E4
à	133	85	Ñ	165	A5		197	C5	Õ	229	E5
å	134	86	а	166	A6	ã	198	C6	μ	230	E6
Ç	135	87	0	167	A7	Ã	199	C7	þ	231	E7
ê	136	88	ć	168	A8		200	C8	Þ	232	E8
ë	137	89	R	169	A9		201	C9	Ú	233	E9
è	138	8A		170	AA		202	CA	Û	234	EA
ï	139	8B	1/2	171	AB		203	CB	Ù	235	EB
î	140	8C	1/4	172	AC		204	CC	ý	236	EC
ì	141	8D	i	173	AD		205	CD	Ý	237	ED
Ä	142	8E		174	AE		206	CE		238	EE
Å	143	8F	_	175	AF		207	CF		239	EF
É	144	90		176	B0	ð	208	D0		240	F0
æ	145	91		177	B1	Ð	209	D1	±	241	F1
Æ	146	92	2	178	B2	Ê	210	D2		242	F2
ô	147	93	3	179	B3	Ë	211	D3	3/4	243	F3
ö	148	94	,	180	B4	È	212	D4		244	F4
ò	149	95	Á	181	B5		213	D5		245	F5
û	150	96	Â	182	B6	Í	214	D6	÷	246	F6
ù	151	97	À	183	B7	Î	215	D7	ر	247	F7
ÿ	152	98	©	184	B8	Ï	216	D8	0	248	F8
Ö	153	99	1	185	B9		217	D9		249	F9
Ü	154	9A		186	BA		218	DA	•	250	FA
Ø	155	9B	*	187	BB		219	DB		251	FB
£	156	9C		188	BC		220	DC		252	FC
Ø	157	9D	¢	189	BD		221	DD		253	FD
х	158	9E	¥	190	BE	Ì	222	DE		254	FE
f	159	9F		191	BF		223	DF	€	255	FF

Table A-1: ASCII Chart

• For hardware handshake XON/XOFF commands: \mathbf{N}

○ XON =Ctrl Q (DC1)
 ○ XOFF =Ctrl S (DC3)

 The Euro currency character (€) has been added to the table above at 255 (FF) as a Datamax-O'Neil standard for resident bitmapped fonts 0,1,2,3,4,5,6, and 9 (CG Triumvirate).

Appendix B

Sample Programs

"C" Language Program

The following sample ``C'' program is included for reference. Figure B-1 shows the output generated by this program.

```
/* DMX SERIES Sample C program */
 # include <stdio.h>
 main ()
 {
char *pcs = "590";
char *desc = "10K OHM 1/4 WATT";
      fputs ("DMX Printer Test Program\n", stdout);
                                           /* STX L - Enter Label
      fputs ("\x02L\n", stdaux);
                                           Formatting */
                                           /* Enter Heat Setting of 7*/
/* Set Width and Height Dot
      fputs ("H07\n" stdaux);
      fputs ("D11\n", stdaux);
                                             Size */
      fprintf (stdaux, "19110801000025%s\n",desc);/* Select smooth Font
                                             */
      fprintf (stdaux, "la621000000050%sPCS\n", pcs);/* Select Bar code
      type 'a' */
      fputs ("E\n", stdaux);
                                   /* End Label format mode and
      print*/
 }
```



Figure B-1: Sample Label

ASCII text file

The following ASCII text file will also generate the label shown in Figure B-1.

```
^BL
H07
D11
19110080100002510K OHM 1/4 WATT<CR>
1a6210000000050590PCS<CR>
E<CR>
```

VB Application Generating DPL

The following sample is a Visual Basic program that displays a database record on the screen. A user can scroll through the records and then print a selected one. Five bar codes are printed along with data fields and headings.

```
'Printer DPL Controls
  Dim CharSet As String'<STX> byte
   Const StartLabel = "L"
   Const EndLabel = "E"
   Const PrintDensity = "D11"
   'Printer DPL Data to position dynamic information on label
   Const OrderTxt = "191100704150010" 'font 9, 24 pt
   Const OrderBC = "1a6205004200120"
   Const CustomerTxt = "191100603600010"
   Const Item1NO = "191100403250010"
   Const Item1BC = "1a6204002870010"
   Const Item1Txt = "191100402690010"
   Const Item1Qty = "191100603070260"
   'DPL Fixed Items on label
   Const Itml = "191100303400010Item #"
  Const Qty1 = "191100303400250Quantity"
   Const Boxsize = "B065035002002"
   Const BoxPos1 = "1X1100003050240"
   Const Image1 = "1Y3300004750010SLANT1"
  Dim Fixed As String
   'Item Variables
  Dim Item1 As String
  Dim PrintLabel As String
  Dim OrderData As String
'Print label by clicking print button with the mouse
Private Sub cmdPrint_Click()
```

```
'Concatenate all the dynamic data fields with the constant header
strings, terminated with <cr> Chr$(13)
   OrderData = OrderTxt & txtOrderNo.Text & Chr$(13) & OrderBC &
txtOrderNo.Text & Chr$(13) & CustomerTxt & txtCustomer.Text
   Item1 = Item1NO & txtItem1.Text & Chr$(13) & Item1BC &
txtItem1.Text & Chr$(13) & Item1Txt & txtItem1Desc.Text & Chr$(13)
& Item1Qty & txtItem1Qty.Text
'Concatinate entire label format and send out serial port
   PrintLabel = CharSet & MaxLength & Chr$(13) & CharSet &
StartLabel & Chr$(13) & PrintDensity & Chr$(13) & Imagel & Chr$(13)
& OrderData & Chr$(13) & Item1 & Chr$(13) & Fixed & Chr$(13) &
EndLabel
   Comm1.Output = PrintLabelEnd Sub
'Display the record form on the screen
Private Sub Form_Load()
  Fixed = Itml & Chr$(13) & Chr$(13) & Qtyl & Chr$(13) & Chr$(13)
& BoxPosl & Boxsize & Chr$(13)
  CharSet = Chr$(126) 'Alternate <stx> character ~
  MComm.PortOpen = 1'Open the serial port
End Sub
'Exit the program by clicking Exit button with the mouse
Private Sub cmdExit_Click()
  Comm1.PortOpen = 0 Close down the serial port
  End
End Sub
```

VB Application interfacing via Windows Driver

Create a form similar to the one shown here.



```
VERSION 5.00
Begin VB.Form Form1
  Caption
                 =
                      "Datamax Test Print"
                     1065
  ClientHeight
                 =
  ClientLeft
                  =
                      60
  ClientTop
                  =
                      345
  ClientWidth
                 =
                     2325
                     "Forml"
  LinkTopic
                 =
  MaxButton
                  =
                      0
                         `False
  MinButton
                  =
                     0
                         `False
                 = 1065
  ScaleHeight
  ScaleWidth
                 =
                      2325
```

```
StartUpPosition = 3 'Windows Default
   Begin VB.ComboBox cmboFonts
      Height
                      =
                          315
                          90
     Left
                      =
     TabIndex
                          2
                     =
     Text
                      =
                          "Font List"
      qoT
                     =
                         45
      Width
                          2130
                      =
   End
   Begin VB.CommandButton cmdExit
      Caption
                     =
                          "Quit"
     Height
                          465
                      =
     Left
                     =
                          1350
      TabIndex
                     =
                          1
      Тор
                          495
                      =
      Width
                          825
                      =
   End
   Begin VB.CommandButton cmdPrint
      Caption
                          "Print"
                     =
     Height
                      =
                          465
     Left
                     =
                          90
     TabIndex
                          0
                     =
                          495
      Top
                      =
      Width
                          870
                      =
   End
End
Attribute VB Name = "Form1"
Attribute VB_GlobalNameSpace = False
Attribute VB_Creatable = False
Attribute VB_PredeclaredId = True
Attribute VB_Exposed = False
'Print label by clicking print button with the mouse
Private Sub cmdPrint_Click()
'font name as seen in application font list box
'if not found, driver will inform GDI to generate an
'image that will be downloaded
    Printer.FontName = cmboFonts.Text
1,440 twips equals one inch
    Printer.Height = 6480
                                `4.5 inches in twips
    Printer.Width = 5760
                                `4 inches in twips
    Printer.CurrentX = 1440
                                '1 inch (column position)
    Printer.CurrentY = 2160
                                '2 inches (row position)
    Printer.Print "0123456789"
    Printer.EndDoc
End Sub
Private Sub Form_Load()
Dim X As Printer
Dim I As Integer 'Used for the font list
' search for printer queue name / driver name
    For Each X In Printers
    If X.DeviceName = "Datamax I-4206" Then 'printer found
' Set printer as system default.
        Set Printer = X
           For I = 0 To Printer.FontCount - 1 ' Determine number of fonts.
```

cmboFonts.AddItem Printer.Fonts(I)	' Put each font into list
box.	
Next I	
Exit For	
End If	
Next	
End Sub	
'Exit the program and shut down the serial port	
by clicking Exit button with the mouse	
Private Sub cmdExit_Click()	
End	
End Sub	

When the program is run, the combo box should be populated with the available fonts as shown below.



VB Application to Send Raw Data via Printer Driver

This is a sample Visual Basic program that checks for any printer driver attached to "LPT1". If one is installed then a DPL file can be printed via the print driver. **Note that this does not have to be a Datamax-O'Neil DPL print driver. DPL is created by the application and sent to LPT1.

To begin, a global variable called SelPrinter must be defined as a string. Then use the following code to create a .frm file.

```
VERSION 5.00
Object = "{F9043C88-F6F2-101A-A3C9-08002B2F49FB}#1.2#0"; "comdlg32.ocx"
Begin VB.Form Form1
  Caption
                     "Forml"
                 =
  ClientHeight
                 =
                     1290
  ClientLeft
                 _
                     165
  ClientTop
                     735
                 =
  ClientWidth
                =
                     3750
  LinkTopic
                =
                    "Forml"
  MaxButton
                = 0
                         `False
  MinButton
                    0
                         `False
                =
  ScaleHeight = 1290
  ScaleWidth
                = 3750
  StartUpPosition = 3 'Windows Default
  Begin MSComDlg.CommonDialog CommonDialog1
```

Left 1635 = 765 Тор = _ExtentX = 847 _ExtentY 847 = _Version 393216 = End Begin VB.CommandButton cmdClose = -1 'True Cancel Caption "Close" = Height = 372 Left = 2400 TabIndex 3 = Тор = 735 Width = 972 End Begin VB.CommandButton cmdStoreImage Caption = "Print" Default = -1 'True Height 372 = Left = 240 TabIndex = 2 = 735 Тор = 972 Width End Begin VB.TextBox txtFile Height = 288 Left = 120 Left TabIndex = 1 Top = 360 Width = 3492 End Begin VB.Label Label1 "File Name" Caption = Height = 255 Left = 120 = TabIndex 0 135 Тор = Width 1455 = End Begin VB.Menu File Caption = "&File" Begin VB.Menu open Caption = "&Open" End Begin VB.Menu exit Caption = "&Exit" Shortcut = ^Q End End End Attribute VB_Name = "Form1" Attribute VB_GlobalNameSpace = False Attribute VB_Creatable = False Attribute VB PredeclaredId = True Attribute VB Exposed = False Option Explicit `***********************************

#If Win32 Then Private Type DOC_INFO_1 pDocName As String pOutputFile As String pDatatype As String End Type #End If 'WIN32 Types ********* `** Function Declarations: #If Win32 Then Private Declare Function OpenPrinter& Lib "winspool.drv" Alias "OpenPrinterA" (ByVal pPrinterName As String, phPrinter As Long, ByVal pDefault As Long) ' Third param changed to long Private Declare Function StartDocPrinter& Lib "winspool.drv" Alias "StartDocPrinterA" (ByVal hPrinter As Long, ByVal Level As Long, pDocInfo As DOC_INFO_1) Private Declare Function StartPagePrinter& Lib "winspool.drv" (ByVal hPrinter As Lonq) Private Declare Function WritePrinter& Lib "winspool.drv" (ByVal hPrinter As Long, pBuf As Any, ByVal cdBuf As Long, pcWritten As Long) Private Declare Function EndDocPrinter& Lib "winspool.drv" (ByVal hPrinter As Long) Private Declare Function EndPagePrinter& Lib "winspool.drv" (ByVal hPrinter As Long) Private Declare Function ClosePrinter& Lib "winspool.drv" (ByVal hPrinter As Long) #End If `WIN32 Dim ch As String * 1, f1 As Integer, loadfile As String Private Sub cmdOpenFile_Click() On Error GoTo ErrHandler ' Set Filters CommonDialog1.Filter = "All Files (*.*) |*.*" 'Specify Default Filter CommonDialog1.FilterIndex = 1 'Display Open dialog box CommonDialog1.ShowOpen loadfile = CommonDialog1.FileName Label2.Caption = loadfile Exit Sub ErrHandler: Exit Sub End Sub Private Sub cmdStoreImage_Click() Dim hPrinter& Dim jobid& Dim res& Dim written& Dim printdata\$ Dim docinfo As DOC INFO 1 loadfile = Form1.txtFile.Text If loadfile = "" Then

```
MsgBox "You must Open a file to send", vbExclamation
        Exit Sub
    End If
    ' Open file.
    f1 = FreeFile
    Open loadfile For Binary As f1
    ' Open printer for printing
    res& = OpenPrinter(SelPrinter, hPrinter, 0)
    If res = 0 Then
        MsgBox "Unable to open the printer"
        Exit Sub
    End If
    docinfo.pDocName = "MyDoc"
    docinfo.pOutputFile = vbNullString
    docinfo.pDatatype = vbNullString
    jobid = StartDocPrinter(hPrinter, 1, docinfo)
    Call StartPagePrinter(hPrinter)
   Call WritePrinter(hPrinter, ByVal printdata$, Len(printdata$), written)
    While Not EOF(1)
        Get #f1, , ch
        printdata$ = ch
        Call WritePrinter(hPrinter, ByVal printdata$, Len(printdata$),
written)
   Wend
    Call EndPagePrinter(hPrinter)
   Call EndDocPrinter(hPrinter)
   Call ClosePrinter(hPrinter) ' Close when done
    ' Close file
   Close #1
   MsgBox "File sent to print spooler.", vbExclamation
End Sub
Private Sub cmdClose_Click()
    Unload Me
End Sub
Private Sub exit_Click()
    End
End Sub
Private Sub Form Load()
Dim X As Printer
' search for printer queue name / driver name
    For Each X In Printers
        If X.Port = "LPT1:" Then 'printer found
        ' Set printer as system default.
            SelPrinter = X.DeviceName
            Exit For
        End If
   Next
End Sub
Private Sub lpt2_Click()
```

```
End Sub
Private Sub open_Click()
    CommonDialog1.ShowOpen
    loadfile = CommonDialog1.FileName
    txtFile.Text = loadfile
End Sub
Private Sub Printer_Click()
    CommonDialog1.ShowPrinter
End Sub
```

This will create the form pictured below:

🕞 Form1	×
<u>F</u> ile	
This program will copy the file	
entered below to the default	
printer via the windows printer	
driver	
File Name	
Print Close	



It may be necessary to remove and reinsert the common dialog control due to $\mathsf{Windows}^{\texttt{®}}$ registry issues.

Appendix C

Available Fonts – Sizes, References, and Samples

All character bitmapped fonts available on the printers are described in this section. Each font has a name (Font ID) associated with it for use in programming. Use the Font Number (in the left column of Table C-1) in field b of the Format Record header to cause the printer to use the corresponding font.

Fonts 0 through 8 use the slash zero (\emptyset) conventions for distinguishing between the zero and the alphabetic O. The slash can be removed with the label formatting command z. These fonts are non-proportional (monospaced). Therefore, all of the characters take up the same amount of space when printed. This is helpful when using variable data in a fixed area. The sizes of these fonts are shown on the following pages.

The CG Triumvirate font number 9 is a proportional font. Each character will take up a different amount of space when printed. For example, the letter W will be wider than the letter I.

Font Number	Valid ASCII Characters (decimal)	Use with Record Structure Type	
0	32-127, 255		
1	32-168, 171, 172, 225, 255		
2	32-168, 171, 172, 225, 255		
3	32, 35-38, 40-58, 65-90, 128, 142-144, 146, 153, 154, 156, 157, 165, 168, 225, 255		
4	32, 35-38, 40-58, 65-90, 128, 142-144, 146, 153, 154, 156, 157, 165, 168, 225, 255	Internal Bitmapped	
5	32, 35-38, 40-58, 65-90, 128, 142-144, 146, 153, 154, 156, 157, 165, 168, 225, 255	Fonts	
6	32, 35-38, 40-58, 65-90, 128, 142-144, 146, 153, 154, 156, 157, 165, 168, 225, 255		
7	32-126		
8	32, 48-57, 60, 62, 67, 69, 78, 83, 84, 88, 90		
9	Dependent upon selected symbol set; see Appendix H.	Scalable Font	

Table C-1: Valid Human-Readable Font (Internal) ASCII Characters

Font sizes are dependent upon the print head resolution of the printer used. The tables below contain a listing of the font sizes by resolution with dimensions given in dots.

Font	Height	Width	Spacing	Point Size
Font 0	7	5	1	2.5
Font 1	13	7	2	4.6
Font 2	18	10	2	6.4
Font 3	27	14	2	9.6
Font 4	36	18	3	12.8
Font 5	52	18	3	18.4
Font 6	64	32	4	22.7
Font 7	32	15	5	11.3
Font 8	28	15	5	9.9

Table C-2: Font Sizes @ 203 DPI Resolution

Font	Height	Width	Spacing	Point Size
Font 0	10	7	1	2.4
Font 1	19	10	3	4.6
Font 2	27	15	3	6.5
Font 3	40	21	3	9.6
Font 4	53	27	4	12.7
Font 5	77	27	4	18.5
Font 6	95	47	6	22.8
Font 7	47	22	7	11.3
Font 8	41	22	7	9.8

Table C-3: Font Sizes @ 300 DPI Resolution

Font	Height	Width	Spacing	Point Size
Font 0	14	10	2	2.5
Font 1	26	14	4	4.6
Font 2	36	20	4	6.4
Font 3	54	28	4	9.6
Font 4	72	36	6	12.8
Font 5	104	36	6	18.4
Font 6	128	64	8	22.7
Font 7	64	30	10	11.3
Font 8	56	30	10	9.9

Table C-4: Font Sizes @ 406 DPI Resolution

Font	Height	Width	Spacing	Point Size
Font 0	20	14	2	2.4
Font 1	38	20	6	4.6
Font 2	54	30	6	6.5
Font 3	80	42	6	9.6
Font 4	106	54	8	12.7
Font 5	154	54	8	18.5
Font 6	190	94	12	22.8
Font 7	94	44	14	11.3
Font 8	82	44	14	9.8

Table C-5: Font Sizes @ 600 DPI Resolution

Internal Smooth Font 9 (Smooth Font) Point Size Specifiers

Label format records with font code 9 (in Format Record header field b) can specify any of the font sizes in the leftmost column of the table below. The corresponding specification in either column labeled Ann or Onn is used in the font size/selection (eee height) field to select the desired font size. Optional font sets may contain subsets of those described here. For an optional font set that generates these fonts via scalable font technology, the character mapping for this font is the selected scalable symbol set (see Appendix E).

In the sample format below, a 300 DPI printer will use 4-point smooth font to produce a printed label with the words "four point font". Sample format:

<STX>L<CR> 1911A0400100010four point font<CR> E<CR>

	Smooth Fo	nt 9 Font Size Specification Sy	ntax		
Point Size					
	203 DPI ^[1]	300, 400, & 600 DPI ^[2]	Onn		
4	-	A04	-		
5	-	A05	000 [3]		
6	A06	A06	001		
8	A08	A08	002		
10	A10	A10	003		
12	A12	A12	004		
14	A14	A14	005		
18	A18	A18	006		
24	A24	A24	007		
30	A30	A30	008		
36	A36	A36	009		
48	A48	A48	010		
72	-	A72	-		

^[1] All fonts greater than A36 are created from multiples of smaller fonts, 2x or 3x, as available.

^[2] All fonts greater than A24 are created from multiples of smaller fonts, 2x or 3x, as available. ^[3] Available at 300 DPI and greater print resolutions only.

Table C-6: Internal Bitmapped (Smooth Font) 9 Size Chart

Internal Bitmapped and Smooth Font Samples

The identifying number is used in the Format Record header field b to cause the printer to use the corresponding font.



The Euro currency character (\in) has been added to Fonts 0 – 6.

- 0: Identifies a 96-character alphanumeric font, uppercase and lowercase.
 - Font 0 175528-(58+)-,2 0123456789-(4972 ABECEFGHIJKLMNDP DRSTUUKM72(5)-1 abcdefshijklmndp Perstuukw72(5)~
- 1: Identifies a 145-character uppercase and lowercase alphanumeric font that includes desenders and ascenders.



2: Identifies a 138-character alphanumeric upper and lowercase font.



3: Identifies a 62-character alphanumeric uppercase font.

FONT 3: ***\$%**()*****+.-,/0123456789: ABCDEFGHIJKLMNOPQRSTUVWXYZ ÇÄAÉÖÜ£0Ñ¿ß

4: Identifies a 62-character alphanumeric uppercase font.



5: Identifies a 62-character alphanumeric upper case font.



6: Identifies a 62-character alphanumeric uppercase font.

FONT 6: #\$%&()*+ - ./ 0123456789: ABCDEFGHIJKL MNOPORSTUVWXYZ ÇÄÅÉÖÜ£ØÑ¿ß

7: Identifies a font that prints OCR-A, size I.

Font 7: !"#\$%&'()*+a-./ Ol23456789:i<=>?@ ABCDEFGHIJKLMNO P&RSTUVWXYZE\1AH abcdefghijklmno pqrstuvwxyz{|}]

8: Identifies a font that prints OCR-B, size III.

Font 8: 0123456789 <>CENSIXZI 9: Identifies the Internal CG Triumvirate font. Point sizes are selected by the number in the Format Record header eee height field; see Table C-6.



Appendix D

Reset Codes

The most common transmitted error codes are:

Uppercase "R"

This code is sent every time the printer is turned "On," signaling a hardware reset.

Uppercase "T"

This code signals a software reset. A software reset is made by sending the command sequence to the printer or by performing a reset using the front panel keys.

Lowercase "v"

There is an input buffer overflow situation, caused when an overflow of data is sent to the printer.

Appendix E

Single Byte Symbol Sets

The following tables include some of the sixty-six standard symbol sets. Not all of these symbol sets can be used with every font. Symbol sets containing the Euro currency character are W1, WE, WG, WL, WT, WR, and PM; see Appendix I, and the <STX>y command.



The following sets were produced using a Windows -based PC-compatible with a United States keyboard properties layout. Results may vary if printing this document using a different input locale.

	(DN) ISO 60: Danish / Norwegian Symbol Set															
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20			"	#	\$	%	&	١	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	Е	F	G	Н	I	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	Æ	Ø	Å	^	
60	`	а	b	с	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	æ	ø	å	_	

						(DT)) Desl	стор 9	Symbo	ol Set						
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	#	\$	%	&	١	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9		;	<	=	>	?
40	@	Α	В	С	D	Е	F	G	Н	Ι	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\]	^	-
60	١	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	{		}	~	
80																
90																
A0		¶	§	+	+	©	R		c/o	¢	-	—		fi	fl	
B0	"	"	μ	‰		•	0	0	þ				`	٦		=
C0	-	±	×					1⁄4	1⁄2	3⁄4	1	2	3	/		
D0	()	«	*	,	"	`	i	ć	Pt	ł	£	¥	¤	f	ß
E0	а	0	æ	Æ	ð	Ð	ij	IJ	ł	t	œ	Œ	ø	Ø	þ	Þ
F0	`	``	^		2	>	2	11	0	*		,	,	•		

					(E1) ISO	8859	/1 Lat	tin 1 S	Symbo	ol Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20			v	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9		;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	-
60	`	а	b	С	d	е	f	g	h	i	j	k	1	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	{		}	~	
80																
90																
A0		i	¢	£	¤	¥	1	§		©	а	*	Г	-	R	
B0	0	±	2	3	,	μ	9	•	4		1	*	1⁄4	1⁄2	3⁄4	ć
C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D0	Ð	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	Ý	Þ	ß
E0	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
F0	ð	ñ	ò	ó	ô	õ	Ö	÷	ø	ù	ú	û	ü	ý	þ	ÿ

						(E2)	ISO 8	859/2	2 Latir	1 2 Se	t					
	0	1	2	3	4	5	6	7	8	9	А	В	С	D	Е	F
00																
10																
20		!	"	#	\$	%	&	Ň	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	-
60	`	а	b	С	d	е	f	g	h	i	j	k		m	n	0
70	р	q	r	S	t	u	v	w	х	У	Z	{		}	~	
80																
90																
A0			v	Ł	¤			§			Š			•	ž	
B0	0			ł	,			•	ر	1	š			"	ž	
C0		Á	Â		Ä			Ç		É		Ë		Í	Î	
D0	Ð			Ó	Ô		Ö	×	Ø		Ú		Ü	Ý		ß
E0		á	â		ä			Ç		é		ë		í	î	
FO				ó	ô		ö	÷			ú		ü	ý		

						(E5)	ISO 8	859/5	5 Latir	n 5 Se	t					
	0	1	2	3	4	5	6	7	8	9	А	В	С	D	Е	F
00																
10																
20			"	#	\$	%	&	١	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\]	^	-
60	`	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	s	t	u	v	w	х	У	z	{		}	~	
80																
90																
A0		i	¢	£	×	¥	1	§			а	*	٦	-		_
B0	0	±	2	3	,	μ	¶	•		1	0	*	1⁄4	1/2	3⁄4	ć
C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D0		Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü			ß
E0	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
F0		ñ	ò	ó	ô	õ	ö	÷	Ø	ù	ú	û	ü	Ι		ÿ

					(F	R) IS	0 69:	Frend	ch Syr	nbol s	Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
00																
10																
20		!	"	£	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	à	Α	В	С	D	E	F	G	Н	I	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	0	ç	§	^	_
60	μ	а	b	с	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	Х	У	Z	é	ù	è		

					(G	R) IS	0 21:	Germ	an Sy	mbol	Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20			w	#	\$	%	&	,	()	*	+		-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	§	Α	В	С	D	E	F	G	Н	Ι	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	Ä	Ö	Ü	^	_
60	`	а	b	с	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	V	W	Х	у	Z	ä	ö	ü	ß	

					()	IT) IS	0 15:	Italia	n Syn	nbol S	jet					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	£	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	§	Α	В	С	D	E	F	G	Н	Ι	J	К	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	0	ç	é	^	
60	ù	а	b	с	d	е	f	g	h	i	j	k		m	n	0
70	р	q	r	s	t	u	v	w	х	У	Z	à	ò	è	ì	

						(L	G) Le	gal Sy	mbol	Set						
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;		=	¢	?
40	@	Α	В	С	D	Е	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[]		_
60	0	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	V	W	х	у	Z	§	¶	†	тм	

						(MC)	Maci	ntosh	Symb	ol Set	t					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	w	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	I	J	К	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	_
60	`	а	b	С	d	е	f	g	h	i	j	k	-	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	{		}	~	
80	Ä	Å	Ç	É	Ñ	Ö	Ü	á	à	â	ä	ĩa	°a	ç	é	è
90	ê	ë	í	ì	î	ï	ñ	ó	ò	ô	Ö	õ	ú	ù	û	ü
A0	+	0	¢	£	§	•	¶	ß	R	©	тм	,			Æ	Ø
B0	8	Ŧ	۷I	≥	¥	μ		Σ		П		а	0	Ω	æ	Ø
C0	ć	i	٦	\checkmark	f	8		«	*			À	Ã	Õ	Œ	œ
D0	-	—	w	w	١	١	÷		ÿ	Ÿ	/	Ħ	<	>	fi	fl
E0	+	`	,	"	‰	Â	Ê	Á	Ë	È	Í	Î	Ï	Ì	Ó	Ô
F0		Ò	Ú	Û	Ù		^	~	_	0	•	0	ŗ		L.	×

					(PC)	PC-8	Code	Page	437	Symb	ol Set					
	0	1	2	3	4	5	6	7	8	9	А	В	С	D	Е	F
00		\odot						•		0			ð	Ŷ	1	٥
10	•	•	¢	!!	¶	§	=	<u><u></u></u>					L			▼
20		!	"	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\mathbf{i}]	~	
60	`	а	b	С	d	е	f	g	h	i	j	k	Ι	m	n	0
70	р	q	r	s	t	u	v	w	х	У	z	{		}	~	
80	Ç	ü	é	â	ä	à	å	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	¢	£	¥	Pt	f
A0	á	í	ó	ú	ñ	Ñ	а	0	ć	F	٦	1⁄2	1⁄4	i	*	»
B0			##		-	=	-	П	٦	ł		٦	Ŀ	F		Г
C0	L	Т	т	F	_	+	=	┠	Ľ	Г	Щ	Т	F	=	#	<u> </u>
D0	ш	F	F	L	ш	F	Г	#	+		Г					
E0	а	ß	L	П	Σ	σ	μ	Т	ф	Θ	Ω	δ	8	φ	ϵ	\cap
F0	Ш	±			Î	J	÷	*	0	•	•	\checkmark	n	2		

				(PE)) PC-	8 D/I	N, Coc	le Pag	je 43 2	7N Sy	mbol	Set				
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
00		\odot						•		0			ð	Ŷ	1	¢
10	•	•	¢	!!	¶	§	-	<u>‡</u>					L	·		▼
20		!	"	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	۷	=	>	?
40	0	Α	В	С	D	Е	F	G	Н	Ι	J	К	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\]	^	_
60	`	а	b	с	d	е	f	g	h	i	j	k	-	m	n	0
70	р	q	r	s	t	u	v	w	х	У	z	{		}	~	
80	Ç	ü	é	â	ä	à	å	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	ж	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	ø	£	Ø	Ŀ	ŀ
A0	á	í	ó	ú	ñ	Ñ	õ	Õ	ż	ã	Ã	ł	'n	i	3	×
B0			Ħ		-	=	-	П	٦			٦	-l	Ш	4	Г
C0	L	1	Т	-		+	=	┠	L	Г	<u>_</u>	Т		-	#	
D0	4	T	Ħ	L	F	F	Г	+	+		Г					
E0	а	ß	L	П	Σ	σ	μ	Т	ф	Θ	Ω	δ	8	φ	ϵ	\cap
F0	Ш	H			ſ	J	÷	ĸ	0	•	•	\checkmark	n	2		

					(P	E) PC	-852	Latin	2 Syn	nbol S	Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
00		\odot						•		0			ð	Ŷ	5	٥
10	•	•	¢	!!	Ţ	ŝ		<u></u>					L			▼
20		!	"	#	\$	%	&	١	()	*	+	,	-	•	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	Е	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\]	^	_
60	ì	а	b	С	d	e	f	g	h	i	j	k	I	m	n	0
70	р	q	r	s	t	u	v	w	х	У	z	{		}	~	\triangle
80	Ç	ü	é	â	ä			ç	ł	ë			î		Ä	
90	É			ô	ö					Ö	Ü			Ł	×	
A0	á	í	ó	ú			Ž	ž							«	*
B0			Ħ		-	Á	Â			ł		٦	L			٦.
C0	L	Ţ	Т	F	_	+			Ľ	Г	Ш	Т	ŀ	=	÷	×
D0	ð	Ð		Ë			Í	Î		Ĵ	Г					
E0	Ó	ß	Ô				Š	š		Ú			ý	Ý		,
F0	-	"		~	>	§	÷	د	0		,					

						(PI)	PI Fo	ont Sy	ymbo	l Set						
	0	1	2	3	4	5	6	7	8	9	А	В	С	D	E	F
00																
10																
20			"	,	w	w	`	`			тм	SM			(M)	
30	_	2	×	-	7	И	R	R		⊳		\bigtriangledown	«	§	*	¶
40	::	_					f		ħ				L	ł		
50	s		R									E		l	<	>
60	Г	L	C	ر	+	F	_		U	Π	F	L		\$		
70	٦	L))	Т	-	1			Π	П	F		•		

			(PM) PC-	850 M	lultilir	ngual	Symb	ol Se	t (Defa	ault Sy	/mbol	Set)			
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
00		\odot		•	•	ŧ	•	•		0		ð	ę		Ъ	٢
10		◄	÷		¶	ş		ŧ	1	*	>	÷	J	ŧ		▼
20		!	"	#	\$	%	&	١	()	*	+	,		•	/
30	0	1	2	3	4	5	6	7	8	9	:	;	۷	=	>	?
40	@	Α	В	С	D	Е	F	G	Н	Ι	J	К	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	
60	ì	а	b	С	d	е	f	g	h	i	j	k	-	m	n	0
70	р	q	r	s	t	u	v	w	х	У	z	{		}	~	\triangle
80	Ç	ü	é	â	ä	à	°a	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	Ö	ò	û	ù	ÿ	Ö	Ü	Ø	£	Ø	×	f
A0	á	í	ó	ú	ñ	Ñ	а	0	ć		-	1⁄2	1⁄4	i	«	»
B0			Ħ		-	Á	Â	À	©	4		٦	Ŀ	¢	¥	7
C0	L	1	т	⊢		+	ã	Ã	Ŀ	F		76	F	_	₽	Ħ
D0	ð	Ð	Ê	Ë	È	I	Í	ľ	Î		7				Ì	
E0	Ó	ß	Ô	Ò	õ	Õ	μ	þ	Þ	Ù	Û	Ú	ý	Ý		'
F0	-	±	=	3⁄4	¶	§	÷	,	0	"		1	3	2	-	€

				(PT) PO	C-8 TK	(, Cod	e Pag	e 437	T Sym	bol S	et				
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00		\odot		*	•	*	*	•		0		්	Ŷ		Ъ	٥
10	•	▼	÷		¶	§		ŧ	4	¥	→	+	L	ŧ		
20		!		#	\$	%	&	١	()	*	+	,	-	•	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	K	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z]	\]	^	
60	`	а	b	с	d	е	f	g	h	i	j	k		m	n	0
70	р	q	r	s	t	u	v	w	х	У	Z	{		}	2	\triangle
80	Ç	ü	é	â	ä	à	å	ç	ê	ë	è	ï	î	ì	Ä	Å
90	É	æ	Æ	ô	ö	ò	û	ù	ÿ	Ö	Ü	¢	£	¥	Pt	f
A0	á	í	ó	ú	ñ	Ñ	а	0	L	7	1⁄2	1⁄4	i	i	«	»
B0			###		-	=		П	٦	Ę		ח	Ŀ	F	Ę	Ъ
C0	L		Т	ŀ	—	+	=	┠	Ľ	Г	⊥	TF	┣	=	÷	⊥
D0	Ш	〒	π	L	E	F	Г	₩	+		Г					
E0	а	ß	L	П	Σ	σ	μ	Т	ф	Θ	Ω	δ	œ	ф 2	ϵ	\cap
F0	≡	±			ſ	J	÷	≈	0	-	•	\checkmark	n	2	-	

						(R8)	Rom	an-8 S	Symbo	ol Set						
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	#	\$	%	&	١	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	-
60	`	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	{		}	~	
80																
90																
A0		À	Â	È	Ê	Ë	Î	Ï	•	`	^	w	~	Ù	Û	£
B0	-	Ý	ý	0	Ç	Ç	Ñ	ñ	i	ć	¤	£	¥	§	f	¢
C0	â	ê	ô	û	á	é	ó	ú	à	è	ò	ù	ä	ë	ö	ü
D0	Å	î	Ø	Æ	°a	Í	ø	æ	Ä	ì	Ö	Ü	É	Ï	ß	Ô
E0	Á	Ã	ã	Ð	ð	Í	Ì	Ó	Ò	Õ	õ	Š	š	Ú	Ÿ	ÿ
F0	Þ	þ	•	μ	¶	3⁄4	—	1⁄4	1⁄2	а		«		»	±	

					(S	P) IS) 17:	Spani	sh Sy	mbol	Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	£	\$	%	&	,	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	§	Α	В	С	D	E	F	G	Н	Ι	J	К	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	i	Ñ	ć	^	
60	`	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	У	Z	0	ñ	ç	~	

					(S)	N) IS	0 11:	Swed	ish Sy	mbol	Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	#	×	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	^	?
40	É	А	В	С	D	E	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	Ä	Ö	Å	Ü	_
60	é	а	b	с	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	ä	Ö	å	ü	

						(TS) PS 1	ext S	ymbo	l Set						
	0	1	2	3	4	5	6	7	8	9	А	В	С	D	E	F
00																
10																
20		!	w	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	Е	F	G	Н	Ι	J	K	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\]	^	
60	`	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	s	t	u	v	w	х	У	z	{		}	~	
80																
90																
A0		i	¢	£	/	¥	f	§	¤	`	"	«	<	>	fi	fl
B0		-	+	+			Ţ	•	,	"	"	*		‰		ć
C0		`	,	^	~	—	2	•			0	ر		w	L.	v
D0	—															
E0		Æ		а					Ł	Ø	Œ	0				
F0		æ							ł	ø	œ	ß				

					(UK) 1	ISO 4 :	: Unite	ed Kin	gdom	Sym	bol Se	t				
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	£	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	Е	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\]	^	
60	`	а	b	с	d	е	f	g	h	i	j	k	-	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	{		}	_	

						(US) I	SO 6:	ASCI	I Sym	bol Se	et					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	"	#	\$	%	&	Ň	()	*	+	,	•	•	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	-
60	`	а	b	с	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	s	t	u	v	w	х	У	Z	{		}	~	

					(VI)	Ventu	ira Int	ternat	ional	Symb	ol Set					
	0	1	2	3	4	5	6	7	8	9	А	В	С	D	E	F
00																
10																
20		!	w	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	А	В	С	D	E	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	_
60	`	а	b	с	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	у	z	{		}	~	
80																
90													→	Ш		
A0	"	À	Â	È	Ê	Ë	Î	Ï			тм	<	>	Ú	Û	
B0	‰	"	"	0	Ç	ç	Ñ	ñ	i	ż	×	£	¥	§	f	¢
C0	â	ê	ô	û	á	é	ó	ú	à	è	ò	ù	ä	ë	ö	ü
D0	Å	î	Ø	Æ	°a	í	Ø	æ	Ä	ì	Ö	Ü	É	ï	ß	Ô
E0	Á	Ã	ã			Í	Ì	Ó	Ò	Õ	õ	Š	š	Ú	Ÿ	ÿ
F0	Œ	œ	¶	+	+	—	-			а	0	«		»		

						(VU)	Ventu	ıra US	Syml	bol Se	t					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	w	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	I	J	K	L	М	N	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	_
60	`	а	b	С	d	е	f	g	h	i	j	k		m	n	0
70	р	q	r	S	t	u	v	w	х	У	Z	{		}	~	
80																
90													\rightarrow			
A0	"										тм					
B0	‰	w	N	0										§		¢
C0																
D0																
E0																
F0			¶	+	+	_	-									

					(W1)) Wine	dows	3.1 La	ntin 1	Symb	ol Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
00																
10																
20		!	"	#	\$	%	&	`	()	*	+	,	-	•	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	К	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\]	~	
60	`	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	У	z	{		}	~	
80	€		,	f	"		+	+	^	‰	Š	<	Œ			
90		`	`	w	"	•	_		~	тм	š	>	œ			Ϋ́
A0		i	¢	£	×	¥		§		©	а	×	٦	-	R	_
B0	0	±	2	3	'	μ	Ţ		ر	1	0	*	1⁄4	1⁄2	3⁄4	ć
C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D0	Ð	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	Ý	Þ	ß
E0	à	á	â	ã	ä	å	ж	ç	è	é	ê	ë	ì	í	î	ï
F0	ð	ñ	ò	ó	ô	õ	ö	÷	ø	ù	ú	û	ü	ý	þ	ÿ

					(WE) Win	dows	3.1 La	atin 2	Symb	ol Set					
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20		!	w	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	
60	`	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	S	t	u	v	w	х	У	Z	{		}	~	
80	€		,		"		+	+		‰	Š	<			Ž	
90		6	`	w	w		-	—		тм	š	>			ž	
A0		~	2	Ł	×		-	§				«	٦	-		
B0	0	±	L.	ł	,	μ	¶		ر			*		"		
C0		Á	Â		Ä			Ç		É		Ë		Í	Î	
D0	Ð			Ó	Ô		Ö	×			Ú		Ü	Ý		ß
E0		á	â		ä			Ç		é		ë		í	î	
F0				ó	ô		ö	÷			ú		ü	ý		

	(WO) Windows 3.0 Latin 1 Symbol Set															
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
00																
10																
20		!	"	#	\$	%	&	١	()	*	+	,	1	•	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	Ι	J	К	L	Μ	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	
60	``	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	s	t	u	v	w	х	У	z	{		}	~	
80																
90		ì	,													
A0		i	¢	£	Ħ	¥		§			а	*	٦	-		_
B0	0	±	2	3	,	μ	¶	•		1	0	*	1⁄4	1/2	3⁄4	Ś
C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D0	Ð	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	Ý	Þ	ß
E0	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
F0	ð	ñ	ò	ó	ô	õ	ö	÷	Ø	ù	ú	û	ü	ý	þ	ÿ

	(WT) Windows 3.1 Latin 5 Symbol Set															
	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F
00																
10																
20			ŧ	#	\$	%	&	`	()	*	+	,	-		/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	Α	В	С	D	E	F	G	Н	I	J	K	L	М	Ν	0
50	Р	Q	R	S	Т	U	V	W	Х	Y	Z	[\backslash]	^	
60	ì	а	b	С	d	е	f	g	h	i	j	k	I	m	n	0
70	р	q	r	s	t	u	v	w	x	У	z	{		}	~	
80	€		,	f	"		+	+	^	‰	Š	<	Œ			
90		`	`	"	w		-	—	~	тм	š	>	œ			Ÿ
A0		i	C	£	¤	¥	1	§		©	а	«	٦	-	R	_
B0	0	±	2	3	,	μ	¶	•	,	1	0	»	1⁄4	1⁄2	3⁄4	ć
C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D0		Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü			ß
E0	à	á	â	ã	ä	å	æ	Ç	è	é	ê	ë	ì	í	î	ï
F0		ñ	ò	ó	ô	õ	ö	÷	Ø	ù	ú	û	ü			ÿ

Appendix F

Bar Code Summary Data

Bar code fonts have alpha names (left column, below). Uppercase alpha names will print bar codes with human-readable interpretations, if supported. Lowercase alpha names will print bar codes only. Place the ID in field b of the Format Record header to cause the printer to encode the data field using the associated symbology; see Appendix G for details. See Table F-2 for default values. The column labeled "Linear Scanner Supported" provides an indication that printers equipped with a Linear Scanner are capable of recognizing the associated symbology.

	Bar Code Characteristics										
Bar Code ID	Symbology	Symbology Length Checksum Valid ASCII Characters, dec representation		Valid ASCII Characters, decimal value representation	Linear Scanner Supported						
A / a	Code 39	Varies	No	32, 36, 37, 42, 43, 45-57, 65-90	\checkmark						
B / b	UPC-A	11	Yes	48-57 Numeric only. Option V used in the 6th & 7th position	~						
C / c	UPC-E	6	Yes	48-57 Numeric only	\checkmark						
D / d	Interleaved 2 of 5 (I2 of 5)	Varies	No	48-57 Numeric only	\checkmark						
E / e	Code 128	Varies	M-103	32-127	\checkmark						
F / f	EAN-13	12	Yes	48-57 Numeric only. Option V used in 7th & 8th position	~						
G / g	EAN-8	7	Yes	48-57 Numeric only	✓						
H / h	HBIC	Varies	M-43	32, 36-39, 42, 43, 45-57, 65-90	\checkmark						
I / i	Codabar	Varies	No	36, 43, 45-58, 65-68	\checkmark						

Bar Code ID	Symbology	Length	Checksum	Valid ASCII Characters, decimal value representation	Linear Scanner Supported
J/j	Interleaved 2 of 5 w/ a modulo 10 checksum	Varies	M-10	48-57 Numeric only	~
K / k	Plessey	Up to 14	M-10	48-57 Numeric only. Option + is last character for 2 nd M-11 chksum	~
L/I	Interleaved 2 of 5 w/ modulo 10 checksum & bearer bars	13	M-10	48-57 Numeric only	~
M / m	2 digit UPC addendum	2	Yes	48-57 Numeric only	[1]
N / n	5 digit UPC addendum	5	Yes	48-57 Numeric only	[1]
0 / o	Code 93	Varies	No	35-38, 42-58, 65-90, 97-122	~
р	Postnet	Varies	Yes	48-57 Numeric only	
Q / q	UCC/EAN 128	19	Yes	48-57 Numeric only	~
R / r	UCC/EAN 128 K-Mart non-EDI	18	Yes	48-57 Numeric only	~
S / s	UCC/EAN 128 Random Weight	34 +	Yes	48-57 Numeric only	~
T/t	Telepen	Varies	Yes	All ASCII characters	
U	UPS MaxiCode	84	Yes	Alphanumeric	
u	UPS MaxiCode w/ Byte Count	Specified	Yes	Alphanumeric	
v	FIM	1	No	A, B, C, D	
Z	PDF417	Varies	Yes	All	
Z	PDF417 w/ Byte Count	Specified	Yes	All	
W1c	DataMatrix	Varies	Yes	All 8-bit values	

Bar Code ID	Symbology	Length	Checksum	Valid ASCII Characters, decimal value representation	Linear Scanner Supported
W1C	DataMatrix w/ Byte Count	Specified	Yes	All 8-bit values	
W1d	QR Code – Auto format	Varies	Yes	Alphanumeric	
W1D	QR Code – Manual format	Varies	Yes	Single-byte or Kanji double-byte	
W1f	Aztec	Varies	Yes	All 8-bit values	
W1F	Aztec w/ Byte Count	Specified	Yes	All 8-bit values	
W1G / W1g	USD-8 (Code 11)	Varies	Yes	45, 48-57	
W1I	EAN 128 w/auto subset switching [2]	Varies	Yes	32-127	~
W1J	Code 128 w/auto subset switching	Varies	Yes	32-127	~
W1k	GS1 DataBar (six types) [2]	Varies	Yes	Numeric / Alphanumeric (type dependent)	
W1L	Planet Code	Varies	Yes	48-57 Numeric only	
W1M / W1m	Australia Post 4-State Bar Code	Varies	Yes	Numeric / Alphanumeric (type dependent)	
W1N / W1n	Industrial 2 of 5	Varies	M-10	48-57 Numeric only	
W1p	Intelligent Mail Barcode (IMB)	Varies	No	48-57 Numeric only	
W1q	CODABLOCK	Varies	Yes	32, 36, 37, 42, 43, 45-57, 65-90 / All ASCII characters (type dependent)	
W1R	UCC/EAN Code 128 K-MART NON EDI	18	Yes	48-57 Numeric only	
W1S / W1s	Standard 2 of 5	Varies	M-10	48-57 Numeric only	
W1t	TCIF Linked 3 of 9 (TLC39)	Varies	Yes	Alphanumeric	

Bar Code ID	Symbology	Length	Checksum	Valid ASCII Characters, decimal value representation	Linear Scanner Supported
W1Y / W1y	Code 16K	Varies	Yes	All ASCII characters	
W1z	MicroPDF417	Varies	Yes	All 8-bit values	
W1Z	MicroPDF417 w/ Byte Count	Specified	Yes	All 8-bit values	

^[1]Readable when using "Barcode Count" method (see <STX>KCSN for details). ^[2]Available for display-equipped and EX2 models only.

Table F-1: Bar Code Characteristics

Bar Code Default Widths and Heights

	Bar Code Default Data											
	203 DPI I	Resolutions	300 DPI R	Resolutions	400 DPI I	Resolutions	600 DPI Resolutions					
Font	Height (inches)	Ratio/ Module Size	Height (inches)	Ratio/ Module Size	Height (inches)	Ratio/ Module Size	Height (inches)	Ratio/ Module Size				
А	.40	6:2	.40	9:4	.40	12:4	.40	18:6				
В	.80	3	.80	4	.80	6	.80	9				
С	.80	3	.80	4	.80	6	.80	9				
D	.40	5:2	.40	9:4	.40	10:4	.40	15:6				
E	.40	2	.40	4	.40	4	.40	6				
F	.80	3	.80	4	.80	6	.80	9				
G	.80	3	.80	4	.80	6	.80	9				
Н	.40	6:2	.40	9:4	.40	12:4	.40	18:6				
Ι	.40	6:3	.40	9:4	.40	12:6	.40	18:6				
J	.40	5:2	.40	9:4	.40	10:4	.40	15:6				
	203 DPI Resolutions		300 DPI I	Resolutions	400 DPI Resolutions		600 DPI Resolutions					
----------	---------------------	-----------------------	--------------------	-----------------------	---------------------	-----------------------	---------------------	-----------------------				
Font	Height (inches)	Ratio/ Module Size	Height (inches)	Ratio/ Module Size	Height (inches)	Ratio/ Module Size	Height (inches)	Ratio/ Module Size				
K	.40	5:2	.40	9:4	.40	10:4	.40	15:6				
L	1.30	5:2	1.30	9:4	1.30	10:4	1.30	15:6				
М	.90	3	.90	4	.90	6	.90	9				
N	.80	3	.80	4	.80	6	.80	9				
0	.40	6:3	.40	8:4	.40	12:6	.40	18:9				
р	.08	N/A	.08	N/A	.08	N/A	.08	N/A				
Q	1.40	2	1.40	4	1.40	4	1.40	6				
R	1.40	2	1.40	4	1.40	4	1.40	6				
S	1.40	2	1.40	3	1.40	4	1.40	6				
Т	.80	1	.80	1	.80	2	.80	3				
U/u	1.00	N/A	1.00	N/A	1.00	N/A	1.00	N/A				
v	.5	1	.5	1	.5	2	.5	3				
z	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A				
Z/z	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A				
W1C/W1c	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A				
W1D/W1d	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A				
W1F/W1f	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A				
W1G/W1g	.5	5:2	.5	7:3	.5	9:4	.5	14:6				
W1I	.40	2	.40	4	.40	4	.40	6				
W1J	.40	2	.40	4	.40	4	.40	6				
W1k	N/A	2	N/A	3	N/A	4	N/A	6				
W1L	0.80	N/A	0.80	N/A	0.80	N/A	0.80	N/A				
W1M/W1m	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A				
W1N/ W1n	0.40	6:2	0.40	9:4	0.40	12:4	0.40	18:6				

(continued)

203 DPI Resolutions		300 DPI Resolutions		400 DPI Resolutions		600 DPI Resolutions		
Font	Height (inches)	Ratio/ Module Size						
W1p	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
W1q	.40	2	.40	4	.40	4	.40	6
W1R	1.40	2	1.40	4	1.40	4	1.40	6
W1S/W1s	0.40	6:2	0.40	9:4	0.40	12:4	0.40	18:6
W1t	.40	6:2	.40	9:4	.40	12:4	.40	18:6
W1Y/ W1y	.40	2	.40	4	.40	4	.40	6
W1Z/W1z	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

Table	F-2:	Bar	Code	Default	Data
-------	------	-----	------	---------	------



Some bar codes will be sensitive to Label Command "D"; see Label Formatting Commands for details.

Appendix G

Bar Code Details

Unless otherwise noted all bar codes depicted in this section were produced using the ratio/module values of 00 and height fields of 000 to cause the printer to produce symbols using default bar widths and height fields. See Appendix F for the default values.

A: Code 3 of 9

Valid Characters: 0-9, A-Z, - . * / + % and the space character.

Variable Length.

Valid bar widths: The expected ratio of wide to narrow bars can range from 2:1 to 3:1.

The following example prints a 3 of 9 bar code with a wide to narrow bar ratio of 3:1:

```
<STX>L
D11<CR>
1A0000001501000123456789<CR>
121100000000100Barcode A<CR>
E
```



Barcode A

B: UPC-A

Valid Characters: 0-9

Length: 12 digits. If the user provides 11 digits, the printer will compute the checksum. If the user provides the checksum, the printer will check that it matches the expected checksum. If it does not match, the printer will print out all zeros and the expected checksum. See Appendix O.

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width).

The following example prints a UPC-A bar code:

<STX>L D11<CR> 1B000000015010001234567890<CR> 121100000000100Barcode B<CR> E



Barcode B

C: UPC-E

Valid Characters: 0-9

Length: Seven digits. If the user provides six digits, the printer will compute the checksum. If the user provides the checksum, the printer will check that it matches the expected checksum. If it does not match, the printer will print out all zeros and the expected checksum.

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width).

The following example prints a UPC-E bar code:

<STX>L D11<CR> 1C000000150100012345<CR> 12110000000100Barcode C<CR> E



D: Interleaved 2 of 5 (I 2 of 5)

Valid Characters: 0-9

Variable Length.

Valid bar widths: The expected ratio of wide to narrow bars can range from 2:1 to 3:1.

The following example prints an Interleaved 2 of 5 bar code with a wide to narrow bar ratio of 3:1:

```
<STX>L
D11<CR>
1D00000015010001234567890<CR>
12110000000100Barcode D<CR>
E
```



Barcode D

E: Code 128

Valid Characters: The entire 128 ASCII character set.

Variable Length

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times the narrow bar width, 3 times the narrow bar width, and 4 times the narrow bar width).

This printer supports the Code 128 subsets A, B, and C. The printer can be selected to start on any code subset and switch to another within the data stream. The default code subset is B; otherwise, the first character (A, B, C) of the data field determines the subset. Subset switching is only performed in response to code switch command. These commands are placed in the data to be encoded at appropriate locations; see Table G-1.



The use a B as the first character is recommended to prevent an A or C from changing the subset.

Subset A: Includes all of the standard uppercase alphanumeric keyboard characters plus the control and special characters. To select Code 128 Subset A, place an ASCII A (DEC 65, HEX 41) before the data to be encoded.

Subset B: Includes all of the standard uppercase alphanumeric keyboard characters plus the lowercase alphabetic and special characters. To select Code 128 Subset B, place an ASCII B (DEC 66, HEX 42) before the data to be encoded. If no start character is sent for the Code 128 font, Code 128 Subset B will be selected by default.

Subset C: Includes the set of 100 digit pairs from 00 through 99 inclusive, as well as special characters. Code 128 Subset C is used for double density encoding of numeric data. To select Code 128 Subset C, place an ASCII C (DEC 67, HEX 43) before the data to be encoded. Subset C can only encode an even number of numeric characters. When the data to be encoded includes an odd number of numeric characters, the last character causes the printer to automatically generate a "switch to subset B" and encode the last character appropriately in subset B.

Special Character Handling: Characters with an ASCII value greater than 95 are considered special characters. To access these values, a two-character reference table is built into the printer (see below).

For example, to encode FNC2 into a Code 128 Subset A bar code, send the ASCII "&" (DEC 38, HEX 26) followed by the ASCII "B" (DEC 66, HEX 41).

Sample: ATEST&B123 \rightarrow Encoded: TEST<FNC2>123

ASCII	2 CHAR	CODE A	CODE B	CODE C
96	&A	FNC3	FNC3	-NA-
97	&B	FNC2	FNC2	-NA-
98	&C	SHIFT	SHIFT	-NA-
99	&D	CODEC	CODEC	-NA-
100	&E	CODEB	FNC4	CODEB
101	&F	FNC4	CODEA	CODEA
102	&G	FNC1	FNC1	FNC1

Table G-1: Special Character Handling

Control Codes: By sending these control codes, control characters can be encoded into a Code 128 Subset A bar code (e.g., ABC{DE will be encoded as ABC<ESC>DE):

Control Code in the Bar Code Data Stream	Encoded Control Character Result
x	NUL
a through z	1 - 26
{	ESC
	FS
}	GS
~	RS
ASCII 127	US

The following example prints a Code 128 bar code:

```
<STX>L
D11<CR>
1E00000015010001234567890<CR>
121100000000100Barcode E<CR>
E
```



Barcode E

F: EAN-13

Valid Characters: 0-9

Length: 13 digits. If the user provides 12 digits, the printer will compute the checksum. If the user provides the checksum, the printer will check that it matches the expected checksum. If it does not match, the printer will print all zeros and the expected checksum. See Appendix O.

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width).

The following example prints an EAN-13 bar code:

```
<STX>L
D11<CR>
1F000000150100012345678901<CR>
12110000000100Barcode F<CR>
E
```



Class Series 2 Programmer's Manual

G: EAN-8

Valid Characters: 0-9

Length: 8 digits. If the user provides 7 digits, the printer will compute the checksum. If the user provides the checksum, the printer will check that it matches the expected checksum. If it does not match, the printer will print all zeros and the expected checksum.

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width).

The following example prints an EAN-8 bar code:

```
<STX>L
D11<CR>
1G0000001501000123456<CR>
121100000000100Barcode G<CR>
E
```



H: Health Industry Bar Code (HBIC)

Valid Characters: 0-9, A-Z, -\$ /. %

Variable Length.

Valid bar widths: The expected ratio of wide to narrow bars can range from 2:1 to 3:1.

The host must supply leading "+"'s

The following example prints a HBIC bar code with a wide to narrow bar ratio of 3:1:

```
<STX>L
D11<CR>
1H000000150050+0123456789<CR>
121100000000100Barcode H<CR>
E
```



Barcode H

I: Codabar

Valid Characters: 0-9, A-D, -, ., \$, :, /, + (comma is not valid)

Variable Length but requires at least three characters.

Valid bar widths: The expected ratio of wide to narrow bars can range from 2:1 to 3:1.

Valid Codabar symbols require start and stop characters (A–D). These characters should be placed in the data field along with other data to be included in the symbol.

The following example prints a Codabar bar code with a wide to narrow bar ratio of 3:1:

```
<STX>L
D11<CR>
1163040001501000A1234567890D<CR>
121100000000100Barcode I<CR>
E
```



Barcode I

J: Interleaved 2 of 5 (with a Modulo 10 Checksum)

Valid Characters: 0-9

Variable Length.

Valid bar widths: The expected ratio of wide to narrow bars can range from 2:1 to 3:1.

The following example prints an Interleaved 2 of 5 bar code with a modulo 10 checksum added and with a wide to narrow bar ratio of 3:1:

```
<STX>L
D11<CR>
1J000000015010001234567890<CR>
121100000000100Barcode J<CR>
E
```



Barcode J

K: Plessey

Valid Characters: 0-9

Length: 1 to 14 digits

Valid bar widths: The expected ratio of wide to narrow bars can range from 2:1 to 3:1.

If a + character is the last data character, an additional MSI checksum will be added to the bar code in place of the + character.

The following example prints a Plessey bar code with a wide to narrow bar ratio of 3:1:

```
<STX>L
D11<CR>
1K000000015010001234567890<CR>
121100000000100Barcode K<CR>
E
```



Barcode K

L: Interleaved 2 of 5 (with a Modulo 10 Checksum and Bearer Bars)

Valid Characters: 0-9

Variable Length: For the bearer bars to be printed, 13 characters are required.

Valid bar widths: The expected ratio of wide to narrow bars can range from 2:1 to 3:1.

The following example prints an Interleaved 2 of 5 bar code with a modulo 10 checksum with a wide to narrow bar ratio of 3:1 and bearer bars:

```
<STX>L
D11<CR>
1L00000001501000123456789012<CR>
121100000000100Barcode L<CR>
E
```



0 12 34567 89012 8 Barcode L

M: 2-Digit UPC Addendum

Valid Characters: 0-9

Length: 2 digits.

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width). Human readable characters for this bar code symbology are printed above the symbol.

The following example prints a 2 digit UPC bar code addendum:

```
<STX>L
D11<CR>
1M000000015010042<CR>
121100000000100Barcode M<CR>
E
```



N: 5-Digit UPC Addendum

Valid Characters: 0-9

Length: 5 digits.

Valid bar widths: The width multiplier is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width). Human readable characters for this bar code symbology are printed above the symbol.

The following example prints a 5 digit UPC bar code addendum:

```
<STX>L
D11<CR>
1N00000015010001234<CR>
121100000000100Barcode N<CR>
E
```



O: Code 93

Valid Characters: 0-9, A-Z, -.\$/+% and the space character.

Variable Length.

Valid bar widths: The width multiplier is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width).

The following example prints a Code 93 bar code:

```
<STX>L
D11<CR>
10000000150100Datamax42<CR>
121100000000100Barcode O<CR>
E
```



Barcode O

p: Postnet

Valid Characters: 0-9

Length: 5, 9 or 11 digits

Valid bar widths: The width and height multiplier values of 00 will produce a valid Postnet symbol.

Usage: The bar code height field is ignored since the symbol height is United States Postal Service specific. This bar code is to display the zip code on a letter or package for the US Postal Service.

The following example prints a Postnet bar code:

<STX>L D11<CR> 1p00000015010032569<CR> 12110000000100Barcode p<CR> E I.II...I.I.I.I.II.I.I.I.I.I.I Barcode P

Q: UCC/EAN Code 128

Valid Characters: 0-9

Length: 19 digits.

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width). Human readable characters for this bar code symbology are printed above the symbol.

The printer spreads a weighted module 103 check sum.

The following example prints a UCC/EAN Code 128 bar code:

```
<STX>L
D11<CR>
1Q0000001501000123456789012345678<CR>
121100000000100Barcode Q<CR>
E
```



arcode O

R: UCC/EAN Code128 K-MART NON EDI

Valid Characters: 0-9

Length: 18 digits

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width). Human readable characters for this bar code symbology are printed above the symbol. (See W1R for an alternate.)

This bar code is set up according to K-MART specifications.

The following example prints a KMART bar code.

```
<STX>L
D11<CR>
1R000000150100012345678901234567<CR>
121100000000100Barcode R<CR>
E
```



Barcode R

S: UCC/EAN Code 128 Random Weight

Valid Characters: 0-9

Length: At least 34 digits.

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width).

This bar code is commonly used by the food and grocery industry.

The following example prints a UCC/EAN Code 128 Random Weight bar code:

```
<STX>L
D11<CR>
1S00000015005001100736750292601193042032020018002110123456<CR>
121100000000100Barcode S<CR>
E
```

01 10073675029260 11 930420 3202 001800 21 10123456

Barcode S

T: Telepen

Valid Characters: All ASCII characters.

Variable Length

Valid bar widths: The fourth character of the record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times, 3 times, and 4 times the narrow bar width).

The following example prints a Telepen bar code:

<STX>L D11<CR> 1T0000000150100ABCDEF<CR> 121100000000100Barcode T<CR> E



Barcode T

u: UPS MaxiCode, Modes 2 & 3

The printer supports MaxiCode as defined in the AIM Technical Specification. The following examples illustrate various label format record message syntaxes for encoding data as MaxiCode. In the following examples, special formatting is used to denote special ASCII characters as shown:

Symbol	Hexadecimal Value	
R S	1E	
G	1D	
^E O _T	04	(Printer message syntax allows for $^{E}O_{T}$ to be substituted with <cr> or the use of both $^{E}O_{T}$ and <cr>.)</cr></cr>

UPS Modes 2 & 3 Explicit

The data stream can force Mode 2 or 3 encoding by placing #2 or #3, respectively, before the data, as shown in the example below. If this is not specified, the printer chooses the best mode.

 $1u0000001200120 \texttt{H3}[) > {}^{R}_{s}01{}^{G}_{s}96 \texttt{123456}{}^{G}_{s}068{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}1Z12345675{}^{G}_{s}\text{UPSN}{}^{G}_{s}12345E{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}_{s}001{}^{G}$

This example will print encoding the MaxiCode symbol in Mode 3.

```
<STX>L
D11<CR>
1u0000001200120#3[)><sup>R</sup>s01<sup>G</sup>s96123456<sup>G</sup>s068<sup>G</sup>s001<sup>G</sup>s1Z12345675<sup>G</sup>sUPSN<sup>G</sup>s12345E<sup>G</sup>s089<sup>G</sup>s<sup>G</sup>s1/
1<sup>G</sup>s10.1<sup>G</sup>sY<sup>G</sup>s<sup>G</sup>s<sup>G</sup>sUT<sup>R</sup>s<sup>E</sup>O<sub>T</sub>
121100000000100Barcode u<CR>
E
```

Where:

#3 [)> ^R _S 01 ^G _S 96 123456	Forces Mode 3 encoding Message Header Maximum 9 alphanumeric ASCII, postal code	Primary Message	7.0
068 001 ^G s1Z1	Country Code Class	Secondary	Barcode u
•••T ^R _S ^E O _T		Message	

Examples

In the UPS 3.0 protocol examples that follow, Primary Message control characters ${}^{G}{}_{S}$ will not be encoded in the MaxiCode symbol. All characters, the Secondary Message, with the exception of the leading ${}^{G}{}_{S}$, in are encoded.

A UPS 3.0 zip + 4 with Message data format and message header:

```
1 u 0000001200120[) >^{\rm R}_{\rm S} 01^{\rm G}_{\rm S} 96841706672^{\rm G}_{\rm S} 840^{\rm G}_{\rm S} 001^{\rm G}_{\rm S} 1Z12345675^{\rm G}_{\rm S} UPSN^{\rm G}_{\rm S} 12345E^{\rm G}_{\rm S} 089^{\rm G}_{\rm S}^{\rm G}_{\rm S} 1/10.1^{\rm G}_{\rm S} Y^{\rm G}_{\rm S}^{\rm G}_{\rm S} UT^{\rm R}_{\rm S}^{\rm E} O_{\rm T}
```

Where:

[)> ^R _S 01 ^G _S 96 841706672 840 001	Message Header Maximum 9 alphanumeric ASCII, postal code Country Code Class	Primary Message
^G _S 1Z1 T ^R _S ^E O _T		Secondary Message

A UPS 3.0 international postal "V6C3E2" with Message data format and message header: $1u0000001200120[) > {}^{R}_{S}01{}^{G}_{S}96$ v6C3E2 ${}^{G}_{S}001{}^{G}_{S}1Z12345675{}^{G}_{S}UPSN{}^{G}_{S}12345E{}^{G}_{S}089{}^{G}_{S}{}^{G}_{S}1/1{}^{G}_{S}$ $10.1{}^{G}_{S}Y{}^{G}_{S}{}^{G}_{S}UT{}^{R}_{S}{}^{E}O_{T}$

Where:

[)> ^R _S 01 ^G _S 96	Message Header	
V6C3E2	Maximum 6 alphanumeric ASCII, international zip code	Primary
068	Country Code	Message
001	Class	2
^G s1Z1		Secondary
••• $T^{R}{}_{S}{}^{E}O_{T}$		Message

A UPS 3.0 international zip "V6C3E2" without Message data format and message header: 1u000001200120120V6C3E2^G_S068^G_S001^G_S1Z12345675^G_SUPSN^G_S12345E^G_S089^G_S^G_S1/1^G_S10.1 ^G_SY^G_S^G_S^G_S_SUT^R_S^EO_T

Where:

V6C3E2 068 001		Primary Message
^G _S 1Z1 T ^R _S ^E O _T	_	Secondary Message

A UPS 3.0 zip + 4 "32707-3270" without Message data format and message header:

 $1 u 0000001200120327073270^{\rm G}{}_{\rm S}068^{\rm G}{}_{\rm S}001^{\rm G}{}_{\rm S}1212345675^{\rm G}{}_{\rm S}{\rm UPSN}^{\rm G}{}_{\rm S}12345E^{\rm G}{}_{\rm S}089^{\rm G}{}_{\rm S}{}^{\rm G}{}_{\rm S}1/1^{\rm G}{}_{\rm S}10.1^{\rm G}{}_{\rm S}{\rm Y}^{\rm G}{}_{\rm S}$

Where:

32707	5 digit ASCII, Zip code	Primary
3270	4 digit ASCII, +4 Zip code (not required)	Message
068	Country Code	5
001	Class	
^G _S 1Z1		Secondary
••• $T^{R}{}_{S}{}^{E}O_{T}$		Message

U: UPS MaxiCode, Modes 2 & 3 with Byte Count Specifier

Specified Length – The upper case U identifies a UPS MaxiCode bar code with a 4-digit string length specifier. This allows values 0x00 through 0xFF to be included within the data strings without conflicting with the DPL format record terminators. The four-digit decimal data byte count immediately follows the 4-digit column position field. This value includes all of the data following the byte count field, but does not include itself.

```
<STX>L
D11<CR>
1U00000010001000051327895555840666this package<0x0D>is going to Datamax<CR>
121100000000100Barcode U<CR>
E
```

From the example above, the bar code's data stream,

1U0000001000100**0051**327895555840666this package<0x0D>is going to Datamax

includes a Byte Count Specifier (the portion in bold), where 0051 equals the four-digit decimal data byte count and includes all bytes that follow until the end of the bar code data. Field termination is set by the byte count. <STX>, <CR>, and <0x0D> all represent single byte values of hexadecimal 02, 0D, and 0D, respectively. The UPS MaxiCode bar code produced encodes "327895555840666this package<CR> is going to Datamax", and prints a line of text: Barcode U.



Barcode U

v: FIM

Valid Characters: A, B, C, or D

Length: 1 character

Valid bar widths: The width and height multiplier works the same as for fonts on this bar code.

This bar code is used to display the Facing Identification Mark (FIM) that is carried on certain types of letter mail for the U S Postal Service:

- FIM A: Courtesy reply mail with Postnet.
- FIM B: Business reply, penalty or franked mail without Postnet.
- FIM C: Business reply, penalty or franked mail with Postnet.
- FIM D: OCR readable mail without Postnet (typically for envelopes with a courtesy reply window).

The following example prints an FIM A bar code:

```
<STX>L
D11<CR>
1v0000000150100A<CR>
121100000000100Barcode v<CR>
E
```



z: PDF-417

Valid Characters: All ASCII characters.

Variable Length – This two dimensional bar code holds large amounts of data in a small area, while providing a high level of redundancy and error checking, if specified.

```
<STX>L
D11<CR>
1z000000150100F1000000PDF417<CR>
121100000000100Barcode z<CR>
E
```



Barcode z

The example above prints a normal, security level one, PDF-417 bar code with a 1:2 aspect ratio and best-fit rows and columns. The (bolded) bar code's data stream 1z0000000150100**F1000000PDF417<CR>** decodes as follows:

Example Data	Explanation
F	1-character specifying a normal or truncated bar code (T to truncate, F for normal).
1	1-digit security level ranging from 0 to 8.
0 0	2-digit aspect ratio specified as a fraction, with the first digit being the numerator and the second digit the denominator. Use "00" for the default ratio of 1:2. Valid range is from "00" to "99."
00	2-digit number specifying the number of rows requested. Use "00" to let the printer find the best fit. Valid range is from "03" to "90". Row values less than 3 are set to 3, while row values greater than 90 are set to 90.
00	2-digit number specifying the number of columns requested. Use "00" to let the printer find the best fit. Valid range is from "01" to "30". Column values greater than 30 are set to 30.
PDF417	The data stream to be encoded.
<cr></cr>	Terminates the data stream.



Format Record header fields c and d should both be zero.

Z: PDF-417 with Byte Count Specifier

Specified Length – The upper case Z identifies a PDF-417 bar code with a string 4-digit length specifier. This allows values 0x00 through 0xFF to be used within the data strings without conflicting with the DPL format record terminators. The four-digit decimal data byte count immediately follows the 4-digit column position field. This value includes all of the data following the byte count field, but does not include itself.

<STX>L D11<CR> 1Z0000001501000015F1000000pdf<0x0D>417<CR> 121100000000100Barcode Z<CR> E



Barcode Z

From the example above, the bar code's data stream,

1Z000000150100**0015**F1000000pdf<CR>417

includes a Byte Count Specifier (the portion in bold), where 0015 equals the four-digit decimal data byte count and includes all bytes that follow until the end of the bar code data. Field termination is set by the byte count. <STX>, <CR>, and <0x0D> all represent single byte values of hexadecimal 02, 0D, and 0D, respectively. The PDF-417 bar code produced encodes "pdf<CR>417", and prints a line of text: Barcode Z.

W1c: DataMatrix

Valid Characters: Any 8-bit byte data

Variable Length

DataMatrix is a two-dimensional matrix symbology, which is comprised of square modules arranged within a perimeter finder pattern. There are two basic types: ECC 000-140 and ECC 200.

ECC 000 - 140 symbols:

These square symbols can be any odd size from 9x9 to 49x49, which may be specified in fields jjj and kkk. If an ECC 000-140 symbol is specified with even numbers of rows or columns, the next largest odd value will be used. Input values greater than 49 or less than 9 will cause the symbol to be automatically sized for the input character stream. The record format is shown here, expanded with spaces.

a W b[b] c d eee ffff gggg hhh i jjj kkk ll…l

Where:

Field	Valid Inputs	Meaning	
a	1,2,3, and 4	Rotation	
W	W	Fixed value, extended bar code set	
b[b]	c, 1c	Selects the DataMatrix bar code - the two differing values have no other significance.	
С	1 to 9, A to Z, and a to z	Module size horizontal multiplier	
d	1 to 9, A to Z, and a to z	Module size vertical multiplier	
eee	000 to 999	No effect; Must be numeric	
ffff	0000 to 9999	Label position, row	
aaaa	0000 to 9999	Label position, column	
hhh	000, 050, 080, 100, 140	 A 3-digit convolutional error correction level. If any number other than one of these options is entered then the nearest lesser value from the valid entries is used. Example: Selecting an ECC value of 099 will cause the actual ECC value of 080 to be used. 	
i	0 - 6	 digit format identification: Automatically choose the encodation scheme based on the characters to be encoded. Numeric data. Upper-case alphabetic. Upper-case alphanumeric and punctuation characters (period, comma, hyphen, and slash). Upper-case alphanumeric. ASCII, the full 128 ASCII character set. Any 8-bit byte. If a format identifier is selected which will not encode the input character stream then the bar code symbol will not be printed. Auto-encodation format identification is recommended since it will select the best possible encodation scheme for the input stream. 	
jjj	9, 11, 13 49. ECC 140 minimum is 15.	A 3 digit odd number (or 000) of rows requested. 000 causes rows to be automatically determined. If the rows and columns do not match, the symbol will be sized to a square using the greater of the two values.	
kkk	9, 11, 13 49. ECC 140 minimum is 15.	A 3 digit odd number (or 000) of columns requested. 000 causes columns to be automatically determined. If the rows and columns do not match, the symbol will be sized to a square using the greater of the two values.	
111	8-bit data, followed by a termination character.	Data to be encoded.	

Table G-2: DataMatrix	ECC 000 – 14	0 Record Structure
-----------------------	---------------------	--------------------

ECC 200 symbols:

There are 24 square symbol sizes available, with both row and column dimensions, which may be specified in fields jjj and kkk, measured in modules as indicated in the following list - 10, 12, 14, 16, 18, 20, 22, 24, 26, 32, 36, 40, 44, 48, 52, 64, 72, 80, 88, 96, 104, 120, 132, and 144. If an ECC 200 symbol is specified with odd numbers of rows or columns, the next largest even value will be used. Input values greater than 144 or less than 10 will cause the symbol to be automatically sized for the input character stream. The record format is shown here, expanded with spaces.

a W b[b] c d eee ffff gggg hhh i jjj kkk ll…l

Field	Valid Inputs	Meaning
a	1,2,3, and 4	Rotation
W	W	Fixed value, extended bar code set
b[b]	c, 1c	Selects the DataMatrix bar code - the two differing values have no other significance.
С	1 to 9, A to Z, and a to z	Module size horizontal multiplier
d	1 to 9, A to Z, and a to z	Module size vertical multiplier
eee	000 to 999	No effect; Must be numeric
ffff	0000 to 9999	Label position, row
aaaa	0000 to 9999	Label position, column
hhh	200	ECC 200 uses Reed-Solomon error correction.
i	0	Fixed value, not used
ijj	10, 12, 14, 16, 18, 20, 22, 24, 26, 32, 36, 40, 44, 48, 52, 64, 72, 80, 88, 96, 104, 120, 132, 144	A 3 digit even number (or 000) of rows requested. 000 causes rows to be automatically determined. The symbol will be sized to a square if the rows and columns do not match by taking the larger of the two values.
kkk	10, 12, 14, 16, 18, 20, 22, 24, 26, 32, 36, 40, 44, 48, 52, 64, 72, 80, 88, 96, 104, 120, 132, 144	A 3 digit even number (or 000) of columns requested. 000 causes columns to be automatically determined. The symbol will be sized to a square if the rows and columns do not match by taking the larger of the two values.
111	8-bit data	Data to be encoded in the symbol

Where:

Table G-3: DataMatrix ECC 200 Record Structure

Example:

<STX>L D11<CR> 1W1c4400001000100200000000DATAMAX<CR> 121100000000100Barcode W1c<CR> E



Barcode W1c

W1C: DataMatrix with Byte Count Specifier

Specified Length – The upper case C identifies a DataMatrix bar code with a string 4digit length specifier. This allows values 0x00 through 0xFF to be included within the data strings without conflicting with the DPL format record terminators. The four-digit decimal data byte count immediately follows the four-digit column position field. This value includes all of the data following the byte count field, but does not include itself.

<STX>L D11<CR> 1W1C44000010001000029200000000Datamax<0x0D>prints best<CR> 121100000000100Barcode W1C<CR> E

From the example above, the bar code's data stream,

1W1C4400001000100**0029**2000000000 Datamax<0x0D>prints best

includes a Byte Count Specifier (the portion in bold), where 0029 equals the four-digit decimal data byte count and includes all bytes that follow until the end of the bar code data. Field termination is set by the byte count. <STX>, <CR>, and <0x0D> all represent single byte values of hexadecimal 02, 0D, and 0D, respectively. The DataMatrix bar code produced encodes "Datamax<CR>prints best," and prints a line of text: Barcode W1C.



Barcode W1C

W1d / W1D: QR Code

Valid Characters: Numeric Data, Alphanumeric Data, 8-bit byte data, and Kanji characters

Variable Length: The two-dimensional bar code (as documented in AIM, Version 7.0).

Syntax (spaces added for readability): a W1 b c d eee ffff gggg hh...h

Where:

Field	Valid Inputs	Meaning
a	1,2,3 and 4	Rotation
Wl	W1	Fixed value, extended bar code set
b	D and d	 Selects the QR bar code formatting mode, where: D = Manual formatting. Allows the data string (hhh) to be entered with a comma (,) as a field separator; fields are optional per QR Code specifications, and the first field indicates Model 1 or Model 2 QR Code (Model 2 is the default). d = Automatic formatting. Allows the data string (hhh) to be data only.
с	1 to 9, A to Z, and a to z	Module size horizontal multiplier Each cell in the bar code is square, therefore "c" and "d" must be equal. Depending on the conversion mode (<stx>n or <stx>m), each unit indicates a cell dimension of .01 inch or .1 mm.</stx></stx>
d	1 to 9, A to Z, and a to z	Module size vertical multiplier. (See explanation for "c", above.)
eee	000 to 999	No effect; must be numeric
ffff	0000 to 9999	Label position, row
aaaa	0000 to 9999	Label position, column (see Appendix J)
hhh	Valid ASCII character string, followed by (a) termination character(s)	QR Code data string (see Generation Structure, below).

Generation Structure

The data input structure (hh...h) is as follows:

Auto Format (W1d)

With bar code identifier "d", the data begins after the last character of the column position field, and does not include any command characters. The data string is terminated with a termination character, usually a 0x0d hex that occurs twice in succession. The bar code symbol will have the following characteristics:

- 1. Model 2
- 2. Error Correction Code Level = "M" (Standard Reliability Level)
- 3. Mask Selection = Automatic
- 4. Data Input Mode = Automatic^[1]

Example:

```
<STX>L
D11<CR>
1W1d4400000100010This is the data portion<CR><CR> <sup>[3]</sup>
121100000000100Barcode W1D<CR>
E (2 termination
characters required.)
```

Manual Formatting (W1D)

With bar code identifier "D", minor changes allow flexibility for data entry. (Spaces have been added for readability.)

[q,] [e [m] i,] cdata cdata cdata...cdata term ^[2]

Where:

Field	Valid Inputs	Meaning	
q	1, 2	QR Code Model number, optional. Model 2 is the default.	
e	H, Q, M, L	Error Correction Level (Reed-Solomon) – Four levels allowing recovery of the symbol code words: H = Ultra Reliability Level (30%) Q = High Reliability Level (25%) M = Standard Reliability Level (15%) L = High Density Level (7%)	
m	0 – 8, none	Mask Number, optional: None = Automatic Selection 0-7 = Mask 0 to Mask 7 8 = No Mask	
I	A, a, M, m	Data Input Mode: A = Automatic setting, ASCII ^[1] a = Automatic, hex-ASCII ^[1] M = Manual Setting, ASCII ^[2] m = manual, hex-ASCII ^[2]	
cdata	N, A, B, K immediately followed by data	Character Mode: N = Numeric, N data A = Alphanumeric, A data B = Binary , Bnnnn data (where nnnn = data byte- count, 4 decimal digits; byte-count /2 for hex- ASCII K = Kanji, K data	
term	<cr>, <cr><cr> ^[3]</cr></cr></cr>	The data string is terminated with a termination character, generally a 0x0d hex, but can be changed by the operator. If the Data Input Mode is Automatic, the data string is terminated with two successive termination characters.	

^[1]When Data Input Mode = Automatic, Kanji data cannot be used; Manual data input required.
 ^[2]When using manual formatting, commas are required between format fields and data types.
 ^[3]<CR> represents the line termination character as defined by the current control code set or after use of Txx, line field terminator label format command.

If HEX/ASCII mode is selected in manual Data Input Mode, only the data for Kanji or Binary data types will be converted, therefore the other data types and all command characters must be entered in ASCII format. If HEX/ASCII is selected in automatic Data Input Mode, all of the data must be entered in HEX/ASCII format.

Data Append Mode String Format, Manual Formatting – Bar Code W1D

D aa tt pp I

Where:

Field	Valid Inputs	Meaning	
D	D	Data Append Mode String Format indicator	
aa	00, 99	QR Code Number in Append Series, 2 decimal digits	
tt		The total number of QR Codes in series, 2 decimal digits	
pp		Value of Parity, 2 digits, 8 LSBs of data parity	
е	H, Q, M, L	As above	
m	0 – 8, none	As above	
i	A, a, M, m	As above	
cdata	N, A, B, K immediately followed by data	As above	
term	<cr>, <cr><cr></cr></cr></cr>	As above	

Characteristics

Models:

Model 1 (original version), bar code versions 1 through 14

- A. ECC Levels "H", "M", "Q", and "L"
- B. Mask Selection Automatic or 0 through 8
- C. Data Input Modes Automatic and Manual
- D. Data Append Mode

Model 2 (enhanced version), bar code versions 1 through 40

- A. ECC Levels "H", "M", "Q", and "L"
- B. Mask Selection Automatic or 0 through 8
- C. Data Input Modes Automatic and Manual
- D. Data Append Mode

Representation of data:

Dark Cell = Binary 1 Light Cell = Binary 0

Symbol Size (not including quiet zone, 4 cells on each of the 4 sides):

Model 1: 21 X 21 cells to 73 X 73 cells (Versions 1 to 14, increase in steps of 4 cells per side)

Model 2: 21 X 21 cells to 177 X 177 cells (Versions 1 to 40, increase in steps of 4 cells per side)

Data Characters per symbol (maximum for symbol size):

Numeric Data Model 1; Version 14; ECC = L: 1,167 characters Model 2; Version 40; ECC = L: 7,089 characters

Alphanumeric Data Model 1; Version 14; ECC = L: 707 characters Model 2; Version 40; ECC = L: 4,296 characters

Binary Data Model 1; Version 14; ECC = L: 486 characters Model 2; Version 40; ECC = L: 2,953 characters

Kanji Data Model 1; Version 14; ECC = L: 299 characters Model 2; Version 40; ECC = L: 1,817 characters

Code Type: Matrix

Orientation Independence: Yes

Example

```
<STX>L
D11<CR>
1W1D44000001000102HM,AThis is the data portion also with
binary,B0003<0xfe><0xca><0x83><0x0D>
121100000000100Barcode W1D<CR>
E
```



Barcode W1D

Where:

QR Code bar code, Cell Size = 0.1 inch square, positioned at X = .1'' and Y = .1'', ECC=H, Mask = Automatic, Data Input Mode = Manual.

Other Examples:

DPL field record, QR Code bar code, Cell Size = 0.04 inch square, positioned at X = .1'' and Y = .1'', ECC = H, Mask = 3, Data Input Mode = Manual:

1W1D4400000100010H3M,AThis is the data portion also with binary,B0003<0xfe><0xca><0x83><0x0D>

DPL field record, QR Code bar code, Cell Size = 0.08 inch square, positioned at X = .1'' and Y = .1'', ECC = L, Mask = Automatic, Data Input Mode = Manual - Kanji:

lWlD88000001000102,LM,K<0x81><0x40><0x81><0x41><0x81><0x42><0x0D>

DPL field record, QR Code bar code, Cell Size = 0.04 inch square, positioned at X = .1'' and Y = .1'', ECC = L, Mask = Automatic, Data Input Mode = Manual - Kanji (in Hex/ASCII format):

1W1D4400000100010L8m,K814081418142<0x0D>

DPL field record, QR Code bar code, Cell Size = 0.01 inch square, positioned at X = .1'' and Y = .1'', ECC = M, Mask = Automatic, Data Input Mode = Automatic:

1W1d1100000100010Pallet 35FGA, Box 55367, Datamax Corp, Orlando, Florida 32707<0x0D><0x0D>

W1f / W1F: Aztec

Valid Characters: All ASCII characters, depending upon the selected options.

Variable Length (W1f): This two dimensional bar code holds a large amount of data in a small area and can provide a high level of error checking.

Specified Length (W1F): With a string four-digit length specifier, values 0x00 through 0xFF to be included within the data strings without conflicting with the DPL format record terminators.

Syntax (spaces added for readability): a W1 b c d eee ffff gggg [hhhh] i jjj kk...k

Where:

Field	Valid Inputs	Meaning	
a	1,2,3, and 4	Rotation	
Wl	W1	Fixed value, extended bar code set	
b	f and F	Lowercase selects the Aztec bar code, variable length. Uppercase selects the Aztec bar code with a Byte Count Specifier	
с	1 to 9, A to Z, and a to z	Module size horizontal multiplier, 0 = default size. The c/d module size parameters should be equal to produce a square symbol. When the label command (Dwh) is used to generate larger text, then c and d may be used to compensate and ensure a square symbol.	
d	1 to 9, A to Z, and a to z	Module size vertical multiplier, 0 = default size (See explanation for "c", above.)	
eee	000	No Effect	
ffff	0000 to 9999	Label position, row	
aaaa	0000 to 9999	Label position, column	
[hhhh]	0000 to 9999	Optional string length specifier. Field termination is set by this byte count. This decimal value includes all of the data following this byte count field, but does not include itself.	
i	0, 1	Extended Channel Interpretation (ECI) mode; $0 = D$ isabled, $1 = E$ nabled	
ijj	000 to 300	Error Correction (EC) / Amount (see table below), where: 000 – Default EC, approximately 23% 001 – 099 EC fixed value, expressed as a percent. 101 – 104 Compact core, 1 to 4 layers respectively. 201 – 232 Full size core, 1 to 32 layers respectively. 300 – Rune format, encodes three ASCII decimal digits 0- 256; scanner decode output is decimal number 0- 256	
kk…k	8-bit data, followed by a termination character	Data to be encoded.	

The error correction or size selection determines the symbol size and other characteristics of the symbol, as shown in the following table. Attempting to encode more data that has been made available will result in no symbol printed.

Error Correction (EC) / Size Implications					
ijj	Symbol Size ^[1]	Symbol Format	Maximum ^[2] Binary Data Bytes	Maximum ^[2] Alphabetic Characters	Maximum ^[2] Numeric Characters
000	variable	data dependent	1914	3067	3832
001 to 099	variable	data and EC dependent	1914	3067	3832
101	15	compact	6	12	13
102	19	compact	19	33	40
102	19	compact	19	33	40
103	23	compact	33	57	70
104	27	compact	53	89	110
201	19	full size	8	15	18
202	23	full size	24	40	49
203	27	full size	40	68	84
204	31	full size	62	104	128
205	37	full size	87	144	178
206	41	full size	114	187	232
207	45	full size	145	236	294
208	49	full size	179	291	362
209	53	full size	214	348	433
210	57	full size	256	414	516
211	61	full size	298	482	601
212	67	full size	343	554	691
213	71	full size	394	636	793
214	75	full size	446	718	896
215	79	full size	502	808	1008
216	83	full size	559	900	1123
217	87	full size	621	998	1246
218	91	full size	687	1104	1378
219	95	full size	753	1210	1511
220	101	full size	824	1324	1653
221	105	full size	898	1442	1801
222	109	full size	976	1566	1956
223	113	full size	1056	1694	2116
224	117	full size	1138	1826	2281
225	121	full size	1224	1963	2452
226	125	full size	1314	2107	2632
227	131	full size	1407	2256	2818
228	135	full size	1501	2407	3007
229	139	full size	1600	2565	3205
230	143	full size	1702	2728	3409
231	147	full size	1806	2894	3616
232	151	full size	1914	3067	3832
300	11	Rune	1	1	1

^[1]Measured in module size x, assuming default module size (cd=00). ^[2]Maximum sizes are approximate and data dependent, and may be less than indicated.

Table G-4: Aztec Characteristics Index

Error Correction

Size 001 to 099: This value specifies the percent of symbol code words to be used for error correction. Actual error correction word percentage will vary depending on data. The default value, approximately 23%, is recommended. Any other value may be selected to meet the user's needs. Some minimum-security code word may be generated depending on the data sent for encoding, particularly when the volume of that data is small. It the data capacity is exceeded no symbol is printed.

Size 101 to 104: Values 101 through 104 results in 1 through 4 layers (two modules thick) respectively, around the center finder pattern. Data volume constraints apply as indicated in the table above. Symbols will be of the compact form. All available code word will be used for error correction. It the data capacity is exceeded no symbol is printed.

Size 201 to 232: Values 201 through 232 result in 1 through 32 layers (two modules thick) respectively, around the center finder pattern. Data volume constraints apply as indicated in the table above. Symbols will be of the full-size form. All available codewords will be used for error correction. It the data capacity is exceeded no symbol is printed.

Size 300: Value 300 informs the printer that the data, which follows will be used to encode one RUNE symbol. The data consists of one to three ASCII digits with value range of 0 to 256. The data may include leading zeros. Data streams longer than three digits or data that includes non-numeric characters may have unpredictable results.

Extended Channel Interpretation Mode: A value of 1 provides for extended channel codewords to be inserted into the bar code symbol, using escape sequences in the datastream. This mode also provides for effective Code 128 and UCC/EAN 128 emulations, when used in with appropriately configured bar code readers. The valid values for escape sequences are of the form <ESC>n, where:

<ESC> - 1 byte with value $27_{10} = 1B_{16}$ n - 1 ASCII digit, range 0 through 6

These escape sequences are encoded as FLG(n) character pairs described in the International Symbology Specification – Aztec Code, AIM, 1997-11-05, and the meanings of the values for n are the same in both.

<ESC>0 - Is encoded as FLG(0), and interpreted as FNC1 or <^G_S> depending on its location in the data stream. The printer does not validate <ESC>0 locations in the data stream.

When <ESC>0 is the leading data in the stream, it is interpreted as a FNC1 as used in the Code 128 symbology, and specifically for UCC/EAN 128 applications. For appropriately configured scanners this will be interpreted/transmitted as a]C1 symbology identifier preamble. The printer does not validate UCC/EAN 128 data syntax.

When <ESC>0 follows a single alphabetic or two numeric characters respectively, then it also interpreted as a FNC1. For appropriately configured scanners this would be interpreted/transmitted as a]C2 symbology identifier preamble, and the alpha or numeric characters

preceding the FNC1 are Application Indicators assigned by AIM International. The printer does not check AI validity.

When <ESC>0 is anywhere else in the data stream, a < $^{G}_{S}$ > replaces it in the bar code symbol, as with UCC/EAN 128 field separators.

- <ESC>n Is encoded as FLG(n), and is interpreted as signaling Extended Channel Interpretation. When the value of n is from 1 to 6, it signals that the following n digits comprise an extended channel identifier for use with ECI compliant bar code scanners. An erroneous bar code symbol may result from failing to follow <ESC>n with n digits. Any <ESC>0 following <ESC>n and not within the n digits will be encoded as FLG(0). In the context of a FLG(n), any backslash "\" (92₁₀) will be interpreted by the scanner as two backslashes "\\".
- Example 1: The variable length example encodes "AZTEC" with no ECI input, and 23% error correction, and prints the bar code. A line of text is also printed.

<STX>L
D11<CR>
1w1f0000000150100000AZTEC<CR>
121100000000100Barcode W1f<CR>
E



Example 2: The specified length example includes a byte count field for all bytes that follow until the end of the bar code data. The byte count is 17. The symbology encodes "AZTEC<CR>barcode", and prints the bar code. Notice that a <CR> does not terminate the bar code format record. A line of text is also printed.

<STX>L D11<CR> 1W1F000000015010000170000AZTEC<0x0D>barcode 121100000000100Barcode W1F<CR> E



Barcode W1F

Functions Not Supported

- Structured Append
- Reader Initialization Symbol Generation
- Module shaving

W1g / W1G: USD-8 (Code 11)

Valid Characters: 0-9,-

Bar Code Data String Length: Variable, typical max 41 characters

Human Readable: W1G; and, Non-Human Readable: W1g

USD-8 (Code 11) is a bar code that encodes the ten digits and the dash (-) character. An additional character serves as the start and stop indicator. Each character has three bars and two spaces for a total of five elements. Of these five elements, two are of medium width and three are narrow, except for the "0", "9", and "-" characters, which have only one wide element and four narrow elements.

The narrow bar size is specified in DPL by the narrow bar parameter, the medium is specified in DPL by the wide bar parameter and the wide bar is fixed at 2 times the medium bar minus the narrow bar.

DPL calculates two checksum characters, C and K, and automatically places them prior to the stop character. The following example prints a Code11 bar code:

<STX>L D11 1W1G00000015001500123456789-<CR> 121100000000100Barcode W1G<CR> E



Barcode W1G

W1I: EAN128 (with Auto Subset Switching)

Valid characters: The entire 128 ASCII character set.

Variable length, minimum 4 characters

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times the narrow bar width, 3 times the narrow bar width, and 4 times the narrow bar width).

This printer supports the Code 128 subsets A, B, and C. If the data begins with at least four numeric characters the default start code is subset C. If there is a non-numeric in the first four characters then the default start code is subset B. The next character after start is always FNC1. Subset switching between B and C is performed based on rules as below:

- 1. If in subset C and there are an odd number of numeric digits, subset B will be set prior to the last digit.
- 2. If four or more numeric digits appear consecutively while in subset B, the character code C will be set prior to the digits.
- 3. When in subset C and a non-numeric occurs, subset B will be inserted prior to the character.

Note that there is no auto-switching from or to Subset A. Standard switches are still used (see table below).

Subset A: Includes all of the standard uppercase alphanumeric keyboard characters plus the control and special characters.

Subset B: Includes all of the standard uppercase alphanumeric keyboard characters plus the lowercase alphabetic and special characters.

Subset C: Includes the set of 100 digit pairs from 00 through 99 inclusive, as well as special characters. EAN128 Subset C is used for double density encoding of numeric data.

Special Character Handling: Characters with an ASCII value greater than 95 are considered special characters. To access these values, a two-character reference table is built into the printer; see table below. As an example, to encode FNC2 into an EAN128 Subset A bar code, send the ASCII & (DEC 38, HEX 26) followed by an ASCII B (DEC 66, HEX 41). Code FNC2 will be encoded.

ASCII	2 CHAR	CODE A	CODE B	CODE C
96	&A	FNC3	FNC3	-NA-
97	&B	FNC2	FNC2	-NA-
98	&C	SHIFT	SHIFT	-NA-
99	&D	CODEC	-NA-	-NA-
100	&E	CODEB	FNC4	-NA-
101	&F	FNC4	CODEA	CODEA
102	&G	FNC1	FNC1	FNC1

Table G-5: Special Character Handling

Control Codes: Control character encoding into Code 128 Subset A by sending these control codes:

The following example prints an EAN128 bar code:

```
<STX>L
D11<CR>
1W1I000000025002512345&G10Z2133021AK<CR>
121100000000100Barcode W1I<CR>
E
```



Barcode W1I

When scanned this bar code will decode as follows:

[C][FNC1]1234[B]5[F1]10Z[C]213302[B]1AK(81)

W1J: Code 128 (with Auto Subset Switching)

Valid characters: The entire 128 ASCII character set.

Variable length

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2 times the narrow bar width, 3 times the narrow bar width, and 4 times the narrow bar width).

This printer supports the Code 128 subsets A, B, and C. If the data begins with at least four numeric characters the default start code is subset C. If there is a non-numeric in the first four characters or there are less than four then the default start code is subset B. Subset switching between B and C is based on the following rules:

- 1. If in subset C and there are an odd number of numeric digits, subset B will be set prior to the last digit.
- 2. If four or more numeric digits appear consecutively while in subset B, the character code C will be set prior to the digits. If there is an odd number of numerics already in B, the first numeric will be placed in B with the others in C.
- 3. When in subset C and a non-numeric occurs, subset B will be inserted prior to the character.

Note that there is no auto switching from, or to, subset A. Standard switches are still used. See table below.

Subset A: Includes all of the standard uppercase alphanumeric keyboard characters plus the control and special characters.

Subset B: Includes all of the standard uppercase alphanumeric keyboard characters plus the lowercase alphabetic and special characters.

Subset C: Includes the set of 100 digit pairs from 00 through 99 inclusive, as well as special characters. Code128 Subset C is used for double density encoding of numeric data.

Special Character Handling: Characters with an ASCII value greater than 95 are considered special characters. To access these values, a two-character reference table is

built into the printer; see table below. As an example, to encode FNC2 into a Code128 Subset A bar code, send the ASCII & (DEC 38, HEX 26) followed by an ASCII B (DEC 66, HEX 41). Code FNC2 will be encoded.

ASCII	2 CHAR	CODE A	CODE B	CODE C
96	&A	FNC3	FNC3	-NA-
97	&B	FNC2	FNC2	-NA-
98	&C	SHIFT	SHIFT	-NA-
99	&D	CODEC	-NA-	-NA-
100	&E	CODEB	FNC4	-NA-
101	&F	FNC4	CODEA	CODEA
102	&G	FNC1	FNC1	FNC1

Table G-6: Special Character Handling

Control Codes: Control character encoding into Code 128 Subset A by sending these control codes:

`	=	NUL
a through z	=	1 - 26
{	=	ESC
	=	FS
}	=	GS
~	=	RS
ASCII 127	=	US

The following example prints a Code128 Auto bar code:

<STX>L D11<CR> 1W1J000000025002512345&G10Z2133021AK<CR> 121100000000100Barcode W1J<CR> E



Barcode W1J

When scanned this bar code will decode as follows:

[C]1234[B]5[F1]10Z2 [C]133021[B]AK(95)

W1k: GS1 DataBar (previously "Reduced Space Symbology RSS")

Valid Characters: Type dependent

Bar Code Data String Length: Type dependent

GS1 DataBar is a continuous, linear symbology used for identification in EAN.UCC systems. There are six different types:

GS1 DataBar Type	Overview*
GS1 DataBar GS1 DataBar Truncated GS1 DataBar Stacked GS1 DataBar Stacked Omni-Directional	 Encodes a full 14-digit EAN.UCC item identification within a linear symbol that can be scanned omni-directionally. The encodable character set is 0 through 9. The maximum numeric data capacity is the application identifier plus 14-digit numeric item identification. Error detection is mod 79 checksum.
GS1 DataBar Limited	 Encodes a 14-digit EAN.UCC item identification with indicator digits of zero or one within a linear symbol. The encodable character set is 0 through 9. The maximum numeric data capacity for is the application identifier plus 14-digit numeric item identification. Data must begin with indicator 0 or 1. Any higher number results in discarded data. Error detection is mod 89 checksum.
GS1 DataBar Expanded	 Encodes EAN.UCC item identification plus supplementary AI element strings. The encodable character is a subset of ISO 646, consisting of upper and lower case letters, digits and 20 selected punctuation characters, plus the special function character FNC1, (#). The maximum numeric data capacity is 74 numeric or 41 alphanumeric. Error detection is mod 211 checksum.

*Additional data can be encoded in a two-dimensional composite as per specification (see AIM Spec ITS/99-001 for more details).

Syntax for GS1 DataBar (spaces added for readability):

a W1 k c d eee ffff gggg h i j m n...n | p...p

Where:

Field	Valid Inputs	Meaning		
a	1,2,3, and 4	Rotation		
Wl	W1	Fixed value, extended bar code set		
k	k	Selects GS1 bar code		
С	1 to 9, A to Z, and a to z	Wide bar ratio, default = 2		
d	1 to 9, A to Z, and a to z	Narrow bar ratio, default = 2		
eee	000	No effect		
ffff	0000 to 9999	Label position, row		
aaaa	0000 to 9999	Label position, column		
h	R, T, S, D, L	GS1 Type: R = GS1 DataBar Omnidirectional, T = GS1 DataBar Truncated, S = GS1 DataBar Stacked, D = GS1 DataBar Stacked Omni-Directional, L = GS1 DataBar Limited		
i	1-9	Pixel Multiplier		
j	0 to (i-1)	X pixels to undercut		
m	0 to (i-1)	Y pixels to undercut		
nn	0 to 9	Numeric linear data, length 13 [1]		
	(optional)	Vertical bar separates primary linear data from secondary 2-D data		
pp	2-D data (optional)	Additional 2-D data ^[2]		

^[1] The application identifier is not encoded in the symbol nor is the last check digit; the user should enter in a 13-digit value. The decoding system will display the application identifier and calculate the check digit.

^[2] The separator row height for two-dimensional composite is fixed at one times the pixel multiplier.

Table G-7: GS1 DataBar Record Structures

Examples:

The following example prints an GS1 DataBar bar code:

```
<STX>L
D11
1W1k0000001500150R1002001234567890
121100000000100Barcode W1k<CR>
E
```



The following example prints an GS1 DataBar bar code with 2-D data:

```
<STX>L
D11
1W1k0000001500150R1002001234567890|123456-99/99/99
121100000000100Barcode W1k<CR>
E
```

The following example prints an GS1 DataBar Truncated bar code:

```
<STX>L
D11
1W1k0000001500150T1002001234567890
121100000000100Barcode W1k<CR>
E
```

The following example prints an GS1 DataBar Stacked bar code:

<STX>L D11 1W1k0000001500150S1002001234567890 121100000000100Barcode W1k<CR> E

The following example prints an GS1 DataBar Stacked Omni-Directional bar code:

```
<STX>L
D11
1W1k0000001500150D1002001234567890
121100000000100Barcode W1k<CR>
E
```

The following example prints an GS1 DataBar Limited bar code:

```
<STX>L
D11
1W1k0000001500150L1001501234567890
121100000000100Barcode W1k<CR>
E
```

Syntax for the GS1 DataBar Expanded bar code (spaces added for readability):

a W1 k c d eee ffff gggg h i j m nn p...p | q...q

Where:



Barcode W1k

Barcode W1k

Barc		ŇĨ N1	

Barcode W1k
Field	Valid Inputs	Meaning
a	1,2,3, and 4	Rotation
Wl	W1	Fixed value, extended bar code set
k	k	Selects GS1 bar code
С	1 to 9, A to Z, and a to z	Wide bar ratio, default = 2
d	1 to 9, A to Z, and a to z	Narrow bar ratio, default = 2
eee	000	No effect
ffff	0000 to 9999	Label position, row
aaaa	0000 to 9999	Label position, column
h	E	GS1 Type: E= GS1 DataBar Expanded
i	1-9	Pixel Multiplier
j	0 to (i-1)	X pixels to undercut
m	0 to (i-1)	Y pixels to undercut
nn	2-22, even only ^[2]	Segments per row
pp	0 to 9	Subset of ISO646, including alphanumerics
	(optional)	Vertical bar separates primary linear data from secondary 2-D data
d."d	2-D data (optional)	Additional 2-D data ^[1]

^[1]Separator row height for two-dimensional composite is fixed at one times the pixel multiplier. ^[2]When using additional 2-D composite data, the sequence width must be at least 4.

Table G-8: GS1 DataBar Expanded Record Structure

Example:

The following example prints an GS1 DataBar Expanded bar code.

```
<STX>L
D11
1W1k0000001500150E100022001234567890
121100000000100Barcode W1k<CR>
E
```



W1L: Planet Code

Valid Characters: 0-9

Variable length, minimum one digit

Example:

The following example prints a Planet Code bar code:

```
<STX>L
D11
1W1L4405001000100123456789
E
```



W1m / W1M: Australia Post 4-State Bar Code

Length: 37, 52, or 67 bars

Usage: This symbol is used for processing mail in the Australia Post System. The symbol is 37, 52 or 67 bars in length, and the height and ratios are fixed according to the specification (see "Customer Barcoding Technical Specifications" from Australia Post for more information).

Syntax for the Australia Post 4-State Bar Code (spaces added for readability):

a W1 m c d eee ffff gggg hh iiiiiiii j...j

Field	Valid Inputs	Meaning					
a	1,2,3, and 4	Rotation					
Wl	W1	Fixed value, exter	nded bar code set				
m	m and M	uppercase selects	Lowercase selects the Australia Post bar code, and uppercase selects the Australia Post bar code with a human readable field.				
С	0	Not used.					
d	0	Not used.					
eee	000	Not used.					
ffff	0000 to 9999	Label position, ro	w				
aaaa	0000 to 9999	Label position, co	lumn				
		Format Control Code (FCC):					
		FCC Value	Resulting Format				
		11	Standard Customer Bar Code				
.,	11, 87, 45, 92, 59, 62,	87	Routing Bar Code				
hh	44	45	Reply Paid Bar Code				
		92	Redirection Bar Code				
		59	Customer Bar Code 2				
		62	Customer Bar Code 3				
		44	Reserved				
iiiiiiii	0000000-99999999	8-digit Delivery P	oint Identifier (DPID)				
jj	0-9, a-z, A-Z, #, space	Optional – Customer information, Bar Code 2 or 3 (Bar Code 2 has a maximum of 8 digits or 5 alphanumeric characters, while Bar Code 3 has a maximum of 15 digits or 10 alphanumeric characters), where if all numeric then data will be encoded in N-type; otherwise, C-type will be used.					

Where:

Example 1:

The following example prints a standard Customer Bar Code using a DPID of "39987520":

<STX>L D11<CR> 1WM0000005000501139987520<CR> E

11 39987520 50 25 52 50

Barcode W1M

Note that the human readable shows the format control code, sorting code and the generated Reed Solomon error correction parity values.

Example 2:

The following example prints a Customer Bar Code 2 using a DPID of "32211324" and customer information "A124B":

<stx>L</stx>	Եհրիկիիկինինիինենինեն
D11 <cr> 1Wm0000005001505932211324A124B<cr></cr></cr>	Barcode W1m
E	Barcode Willi

W1n / W1N: Industrial 2 of 5

Industrial 2 of 5 is a discrete, self-checking, continuous numeric bar code. All of the information is contained in the bars, either wide or narrow, typically in a 3:1 ratio. The space is equal to the width of the narrow bar.

Valid Characters: 0-9

Variable length, minimum one digit

Human Readable: W1N; and, Non-Human Readable: W1n

Example:

The following example prints an Industrial 2 of 5 with a human readable field:

<STX>L D11 1W1N8305001000100123456 E



Barcode W1N

W1p: Intelligent Mail Barcode (IMB)

Valid Characters: 0-9

Length: 20, 25, 29 or 31 digits

Valid bar widths: The width and height multiplier values of 00 will produce a valid IMB symbol.

Usage: The bar code height field is ignored since the symbol height is United States Postal Service specific. This bar code represents a 20 digit tracking code and a zero, five, nine, or eleven digit routing code on a letter or package for the USPS.

Example:

The following example prints an IMB bar code:

Արիլիսիսիինիսիինըստիինըստիինըստի Barcode W1p

```
<STX>L
D11<CR>
1W1p000000050005001234567094987654321012345678
91<CR>
E
```

W1q: CODABLOCK

CODABLOCK is a two-dimensional, multi-row, stacked bar code. CODABLOCK A uses the Code 39 character set and supports variable ratios. CODABLOCK E and F use the Code 128 character set and support only fixed ratios, while CODABLOCK E also adds FNC1 automatically to the beginning of the data.

Valid Characters: CODABLOCK A: 0-9, A-Z, - . * \$ / + % and the space character; and, CODABLOCK E and F: All ASCII characters.

Variable length

Syntax (spaces added for readability): a Wlq b c ddd eeee ffff g h ii jj k...k

Field	Valid Inputs	Meaning				
a	1,2,3, and 4	Rotation				
Wlq	W1q	Fixed value, extended bar code set, selects CODABLOCK				
b	1 to 9, A to Z, and a to z	Horizontal multiplier* (0 = default size)				
С	1 to 9, A to Z, and a to z	Vertical multiplier* (0 = default size)				
ddd	001 to 999	Individual row height				
eeee	0000 to 9999	Label position, row				
ffff	0000 to 9999	Label position, column				
g	A, E, F	CODABLOCK Mode – A, E, or F				
h	0,1	Whether to generate and add checksum				
ii	01-44	Number of rows to encode				
jj	02-62	Number of characters per row				
k…k	ASCII chars	Data				

Where:

* Only CODABLOCK A supports variable ratios.

Example:

The following example prints a CODABLOCK E bar code with 4 rows, 2 characters per row:

<STX>L D11 1W1q2202501000100E0040212345678 E



Barcode W1q

W1R: UCC/EAN Code 128 K-MART NON EDI

Valid Characters: 0-9

Length: 18 digits

Valid bar widths: The fourth character of record is the width of the narrow bar in dots. All other bars are a ratio of the narrow bar (2, 3, or 4 times the narrow bar width). Human readable characters for this bar code are printed above the symbol.

This produces the same symbology as bar code ID "R", except that the human readable field has been modified to print underneath the bar code (see below).

Example:

The following example prints a KMART bar code:

```
<STX>L
D11<CR>
1W1R0000000150100012345678901234567<CR>
121100000000100Barcode W1R<CR>
E
```



34 567890 123 4567 Barcode W1R

W1s / W1S: Standard 2 of 5

Standard 2 of 5 is a discrete, self-checking, continuous numeric bar code. All of the information is contained in the bars. Bars are either wide or narrow, typically in a 3:1 ratio. The space is equal to the width of the narrow bar.

Valid Characters: 0-9

Variable length, minimum one digit

Human Readable: W1S; and, Non-Human Readable: W1s

Example:

The following example prints a Standard 2 of 5 bar code:

```
<STX>L
D11
1W1S8305001000100123456
E
```



Barcode W1S

W1t: TCIF Linked 3 of 9 (TLC39)

Valid Characters: All ASCII characters.

Variable Length: Encodes a 25-character alphanumeric number in MicroPDF417 symbol.

Specified Length: Encodes a six-digit sequence in a standard Code 39 followed by a link flag character in Code 3 of 9.

Syntax (spaces added for readability): a W1 t c d eee ffff gggg hhhhhh ; ii...i

Where:

Field	Valid Inputs	Meaning				
a	1,2,3, and 4	Rotation				
Wl	W1	Fixed value, extended bar code s	set			
t	t	Selects TLC39 bar code				
С	1 to 9, A to Z, and a to z	Wide bar of Code 39, ratio of wid between 2:1 and 3:1.	de to narrow must be			
d	1 to 9, A to Z, and a to z	Narrow bar of Code 39				
eee	001 to 999	Height of Code 39				
ffff	0000 to 9999	Label position, row				
aaaa	0000 to 9999	Label position, column				
hhhhhh	ECI Data	Six digit ECI number				
;	Fixed	Parses data. (If the seventh character is not a semi colon then only a six-digit code 39 will print.)				
i…i	S/N Data	Up to 25 alphanumeric serial number characters to be encoded in the MicroPDF417 symbol. This symbol is fixed at four columns. The number of rows is determined by th amount of data, as follows:				
		Character Count	Row Count			
		1-14	4			
		15-22	6			
		23-25	8			

The link flag is the character "T" in Code 39 without a start/stop indicator. The flag location is based on the ECI code location, length, and height. The location of the MicroPDF417 symbol is based on the location of ECI bar code. The symbol's module width and height are fixed at the default. The following example prints a TLC39 bar code:

```
<STX>L
D11
1Wt0000001500150123456;ABCD12345678901234
1911A0801300170A1B2C3DAAA
121100000000100Barcode W1t<CR>
E
```



Barcode W1t

W1y / W1Y: Code 16K

Code 16K is a multi-row bar code.

Valid Characters: All ASCII characters

Variable length

Human Readable: W1Y; and, Non-Human Readable: W1y

Example:

The following example prints a Code 16K:

```
<STX>L
D11
1W1Y3305001000100ABC123
E
```



Barcode W1Y

W1z: MicroPDF417

MicroPDF417 is a 2 dimensional bar code capable of holding large amounts of data in a small area. It provides a high level of redundancy and error checking.

Valid Characters: All ASCII characters, depending on the selected options.

Variable Length

Syntax (spaces added for readability): a W z c d eee ffff gggg h i j k 0 m...m

Where:

Field	Valid Inputs	Meaning
a	1,2,3, and 4	Rotation
Wl	W1	Fixed value, extended bar code set.
z	Z	Selects the MicroPDF417 bar code.
С	1 to 9, A to Z, and a to z	Module size horizontal multiplier, 0 – default size.
d	1 to 9, A to Z, and a to z	Module size vertical multiplier, 0 – default size.
eee	000	No Effect
ffff	0000 to 9999	Label position, row
aaaa	0000 to 9999	Label position, column
h	1 to 4	Number columns
i	0 to 9 and A	Row / Error Correction index
j	0, 1	Byte Compaction Mode, 1 - best binary data compression
k	0, 1	Macro Character Substitution, 1 - disable
0	0	Fixed ASCII digit 0. Reserved for future use.
m m	8-bit data	Data to be encoded.

The following example prints a MicroPDF417 bar code, default module size (cd = 00), with 1 column, 24 rows, error correction of 33%, no byte compaction, macro character substitution enabled.

```
<STX>L
D11<CR>
1W1z000000015010014000PDF417<CR>
121100000000100Barcode W1z<CR>
E
```



Barcode W1z

The number of columns (h) and row / error correction index (i) combine to form the selection index (hi), which determines other symbol characteristics as shown below:

	Row/Column/Error Correction Selection Index (hi) Implications										
hi	Columns	Rows	Max Errors Corrected	Symbol Width [2]	Symbol Height	Max Binary Data Bytes ^[3]	Max Alpha Characters	Max Numeric Characters			
10	1	11	4	40	24	3	6	8			
11	1	14	4	40	30	7	12	17			
12	1	17	4	40	36	10	18	26			
13	1	20	5	40	42	13	22	32			
14	1	24	5	40	50	18	30	44			
15	1	28	5	40	58	22	38	55			
20	2	8	5	57	18	8	14	20			
21	2	11	6	57	24	14	24	35			
22	2	14	6	57	30	21	36	52			
23	2	17	7	57	36	27	46	67			
24	2	20	8	57	42	33	56	82			
25	2	23	10	57	48	38	67	93			
26	2	26	12	57	54	43	72	105			
30	3	6	9	84	14	6	10	14			
31	3	8	11	84	18	10	18	26			
32	3	10	13	84	22	15	26	38			
33	3	12	15	84	26	20	34	49			
34	3	15	18	84	32	27	46	67			
35	3	20	23	84	42	39	66	96			
36	3	26	29	84	54	54	90	132			
37	3	32	35	84	66	68	114	167			
38	3	38	41	84	78	82	138	202			
39	3	44	47	84	90	97	162	237			
40	4	4	5	101	10	8	14	20			
41	4	6	9	101	14	13	22	32			
42	4	8	11	101	18	20	34	49			
43	4	10	13	101	22	27	46	67			
44	4	12	15	101	26	34	58	85			
45	4	15	18	101	32	45	76	111			
46	4	20	23	101	42	63	106	155			
47	4	26	29	101	54	85	142	208			
48	4	32	35	101	66	106	178	261			
49	4	38	41	101	78	128	214	313			
4A	4	44	47	101	90	150	250	366			
[1] Ca	$\frac{4}{1}$ Can be any combination of 1 erasures + 2 substitutions (e.g. 13 maximum number of errors corrected										

^[1] Can be any combination of 1 erasures + 2 substitutions (e.g. 13 maximum number of errors corrected might include 7 erasures and 3 substitutions).

^[2] Includes 1 module width of quiet zone on either side.

^[3] Assumes the module height is 2 module width, and includes one module width quiet zones on top and bottom.

^[3] Assumes Binary Compaction.

^[5] Assumes Text Compaction.

In the table above, row/column/error correction selection index (hi) values increasingly large do not necessarily result in the ability to encode more data.

Byte Compaction Mode (j = 1)

A value of 1 forces Byte Compaction. The compaction ratio is six 8-bit bytes of data compressed into a 5-symbol codeword. See the table above for the maximum data allowed for any row/column/error correction selection index (hi).

Macro Character Substitution Disable (k=1)

By default Macro Character Substitution is enabled (k=0). When enabled, Byte Compaction has priority over Macro Character Substitution. When Macro Character Substitution is enabled, the data stream header and trailer are compacted when they conform to the following forms:

$$[) >_{S}^{R} 05_{S}^{G} data_{S}^{R} e_{T}$$

$$or$$

$$[) >_{S}^{R} 06_{S}^{G} data_{S}^{R} e_{T}$$

where:

data may not contain adjacent bytes with values ${}^{R}{}_{S}$ or ${}^{G}{}_{S}$

($^{\rm R}_{\rm ~S}$ = 30_{10} , 1E_{16} and $^{\rm G}_{\rm ~S}$ = 29_{10} , 1D_{16} and $^{\rm E}o_{\rm T}$ = 4_{10} , 4_{16})

Functions Not Supported

- General Purpose Extended Channel Interpretations, including Code-128 emulations
- Structured Append
- Reader Initialization Symbol Generation
- Module shaving

W1Z: Micro PDF417 with Byte Count Specifier

Specified Length – The upper case Z identifies a Micro PDF417 bar code with a 4-digit string length specifier. This allows values 0x00 through 0xFF to be included within the data strings without conflicting with the DPL format record terminators. The four-digit decimal data byte count immediately follows the four-digit column position field. This value includes all of the data following the byte count field, but does not include itself.

```
<STX>L
D11<CR>
1W1Z0000000150100001214000pdf<0x0D>417
121100000000100Barcode W1Z<CR>
E
```



Barcode W1Z

From the example, the bar code's data stream,

1W1Z000000150100**0012**14000PDF<0x0D>417,

includes a Byte Count Specifier (the portion in bold), where 0012 equals the four-digit decimal data byte count and includes all bytes that follow until the end of the bar code data. Field termination is set by the byte count. <STX>, <CR>, and <0x0D> all represent single byte values of hexadecimal 02, 0D, and 0D, respectively. The Micro PDF417 bar code produced encodes "pdf<CR>417", and prints a line of text: Barcode W1Z.

Appendix H

Single and Double Byte Character Font Mapping

Label format records with font code 9 in the b field of the Format Record header can specify any of the following bitmapped or scalable fonts with the associated specification in the font size/selection (eee height) field, as shown in the tables on the following pages.

Example: 1911u4000100010A0215134<CR>

The example above will produce a printed string consisting of the two Kanji characters referenced by the two HEX ASCII pairs A0, 21, and 51, 34, on appropriately equipped printers.

Example: 1911U4001000100P012P012<0x38><0x77><0x00>

The above example will produce a printed string consisting of the one 12 point Kanji character referenced by the byte pair with hex values 38 and 77 on appropriately equipped printers.

Double byte hex representation character strings terminate with two null bytes and a <CR>, i.e., 0x 00 00 0D. The Hex-ASCII representation is terminated with <CR>.

The alphanumeric portion (nn) of the scalable font specifiers, Snn, Unn, unn, numbering system is a base 62 numbering system, 0, 1, 2...8, 9, A, B, C...X, Y, Z, a, b, c...x, y, z. For scalable fonts the S designation signifies single byte characters and U designates double byte. The lower case U counterpart signifies that print data in the label format record is in a hex-ASCII format. Fonts that have been downloaded with designators of the form nn, where nn are alphanumeric, as seen in the font size specifier (eee height) column below, may be referenced in label format records by their upper or lower case specifiers as available. However, fonts created for double-byte access cannot be accessed using Snn as the font designator, and vice versa, single-byte fonts cannot be accessed using Unn or unn.



V

Downloading scalable fonts require specifying the font ID, a two character alphanumeric. The S, or U, u used in referencing the font within label format records is not used in the download specification. Attempting to utilize a scalable font with an inappropriate byte-size designation (e.g. S on double byte or U, u on single byte) will have unpredictable results.

Font 9, Font Specifications (eee Height) and Associated Characteristics									
Font Name	Character Mapping	Font Size Specifier (eee Height)	Point Size						
Font 9 Bitmapped Downloaded Fonts									
User-downloaded typeface	Single Byte	100 - 999	user defined						
	Font 9 Scalable Reside	ent Fonts Specificatio	ns						
CG Triumvirate Bold Condensed [1] [2]	Single Byte	S00	scalable						
CG Triumvirate ^{[1] [2]}	Single Byte	S01	scalable						
F	ont 9 Scalable Resident F	onts Specifications (o	ptional)						
CG Times ^[2]	Single Byte	SA0	scalable						
CG Times Italic ^[2]	Single Byte	SA1	scalable						
CG Times Bold ^[2]	Single Byte	SA2	scalable						
CG Times Bold ^[2] Italic	Single Byte	SA3	scalable						
Gothic B Kanji	Double Byte (Binary)	U40	scalable						
Gothic B Kanji	Double Byte (Hex ASCII)	u40	scalable						
GB Simplified Chinese	Double Byte (Binary)	UC0	scalable						
GB Simplified Chinese	Double Byte (Hex ASCII)	uC0	scalable						
Korean Hangul	Double Byte (Binary)	UH0	scalable						
Korean Hangul	Double Byte (Hex ASCII)	uH0	scalable						
Font 9 Scalable Downloaded Fonts									
User-downloaded typeface	Single Byte (Binary)	S50 - S5z, S90 - S9z	scalable						
User-downloaded typeface	Double Byte (Binary)	U50,U5z, U90U9z	scalable						
User-downloaded typeface	Double Byte (Hex ASCII)	u50,u5z, u90u9z	scalable						

^[1] I-4208 Standard font ^[2]All Printers except Ex2 and E-Class

Table H-1: Font 9 Specifications

Appendix I

Symbol Sets and Character Maps

Symbol Set Selection

Scalable fonts are mapped through a symbol set sometimes referred to as a "code page". This mapping allows the host application to select a variety of characters to match the application. For example in the code page (CP), character code 0xE4 causes character to be printed. In CP E7, the character code 0xE4 causes to be printed. Each of the CPs allows the host application to "emulate" a character set for their application. Datamax-O'Neil printers that support scalable fonts contain either a standard or an enhanced group of CPs as defined below. The CP (symbol set) is selected using a DPL Command, <STX>ySxx, where xx is the two letter CP Identifier.



In the following table, the checkmark symbol () is used to indicate a full compliment of characters, while "Part" indicates a partial compliment of characters and "X" indicates an absence of characters for the given code page.

	Single Byte Code Pages								
Code P	age								
Identi	fier	Intellifor	nt ^[1]	MicroTyp	e ^[2]	True	Description		
Datamax	HP (PCL)	CG Triumvirate	CG Times	CG Triumvirate	CG Times	Туре	Description		
AR	8V	Х		Х		[1]	Arabic-8		
CP	3R	Part		Part		[1]	PC Cyrillic		
Dl	11L	х	Х	х	Х		ITC Zapf Dingbats/100		
D2	12L	х	Х	х	Х		ITC Zapf Dingbats/200		
D3	13L	х	х	х	Х		ITC Zapf Dingbats/300		
DN	0D	Part	Part	Part	Part		ISO 60 Danish / Norwegian		
DS	10L	Х	Х	Х	Х		PS ITC Zapf Dingbats		
DT	7J						DeskTop		
El	0N						ISO 8859/1 Latin 1		
E2	2N	Part					ISO 8859/2 Latin 2		
E5	5N						ISO 8859/9 Latin 5		

(continued)

				le Byte Code P ont Format	ages		1
Code P Identi		Intellifor			-		
Datamax	HP (PCL)	CG Triumvirate	CG Times	MicroTyp CG Triumvirate	CG Times	True Type	Description
E6	6N	Part					ISO 8859/10 Latin 6
E7	12N	Part		х	Х		ISO 8859/7 Latin/Greek
E9	9N	х	Х	[1]	[1]	[1]	ISO 8859/15 Latin 9
EG	12N	Part		Part		[1]	ISO 8859/7 Latin/Greek
EH	7н	Part		Part		[1]	ISO 8859/8 Latin/Hebrew
ER	10N	Part		Part		[1]	ISO 8859/5 Latin/Cyrillic
FR	1F	Part	Part	Part	Part		ISO 69: French
G8	8G	Part		Part		[1]	Greek-8
GK	12G	Part		Part		[1]	PC-8 Greek
GR	1G	Part	Part	Part	Part		ISO 21: German
но	0н	Part		Part		[1]	Hebrew-7
Н8	8н	Part		Part		[1]	Hebrew-8
IT	ΟI						ISO 15: Italian
L\$ ^[1]	14L			х	Х		HP4000 ITC Zapf Dingbats
LG	1U						Legal
M8	8M						Math-8
MC	12J			[3]		[3]	Macintosh
MS	5М				[3]	[3]	PS Math
P9 ^[1]	13U	х	Х		[3]	[3]	PC-858 Multilingual
PB	6J	Part	Part	Part	Part		Microsoft Publishing
PC	10U						PC-8, Code Page 437
PD	11U						PC-8 D/N, Code Page 437N
PE	17U	Part					PC-852 Latin 2
PG	10G	Part		Part		[1]	PC-851 Latin/Greek

(continued)

Code Page			F				
Identi	fier	Intellifont [1]		MicroTyp	e ^[2]	True	Description
Datamax	HP (PCL)	CG Triumvirate	CG Times	CG Triumvirate	CG Times	Туре	Description
PH	15H					[1]	PC-862 Latin/Hebrew
PI	15U	Part	Part	Part	Part		Pi Font
PM	12U			[3]	[3]	[3]	PC-850 Multilingual
PR	10V						PC-864 Latin/Arabic
PT	9т						PC-8 TK, Code Page 437T
PU	9J						PC-1004
PV	26U	Part					PC-775 Baltic
PX	12U			Х	Х		PTXT3000
РҮ	3Y	х	Х	х	х	[1]	Non-UGL, Generic Pi Font
R8	8U						Roman-8
R9 ^[1]	4U	Х	Х		[3]	[3]	Roman-9
SP	2S						ISO 17: Spanish
SW	0S						ISO 11: Swedish
SY	19M	х	Х	х	Х		Symbol
TK	8T			х	Х		Turkish-8
TS	10J						PS Text
UK	1E						ISO 4: United Kingdom
US	0U						ISO 6: ASCII
U8	-	х	Х				UTF8
VI	13J						Ventura International
VM	6М					[1]	Ventura Math
VU	14J	Part	Part	Part	Part		Ventura US
W1 ^[3]	19U	Part					Windows 3.1 Latin 1
WA	9V	Part				[1]	Windows Latin/Arabic

(continued)

Code Page			F				
Identifier		Intellifont [1]		MicroType ^[2]		Turne	Description
Datamax	HP (PCL)	CG Triumvirate	CG Times	CG Triumvirate	CG Times	True Type	Description
WD	579L	х	Х	х	Х		Wingdings
WE ^[3]	9E	Part					Windows 3.1 Latin 2
WG ^[3]	9G	Part		Part		[1]	Windows Latin/Greek
WL ^[3]	19L	Part					Windows 3.1 Baltic (Latv, Lith)
WN	9U			х	х		Windows
WO	9U			[3]	[3]	[3]	Windows 3.0 Latin 1
WR ^[3]	9R	Part		[3]		[1]	Windows Latin/Cyrillic
WT ^[3]	5т						Windows 3.1 Latin 5

^[1]Supported in the EX2 model.

^[2]Supported in the A-Class, H-Class, I-Class, and EX2 models.

^[3]Contains the Euro currency symbol (\notin).

Table I-1: Single Byte Code Pages

Double-Byte Symbols, Chinese, Kanji, and Korean

Character Map Selection

Double byte scalable fonts are mapped through a "character map". This mapping allows the host application to select a variety of characters to match the application. Each of the code pages allows the host application to emulate a character set for the application.

Double Byte Character Map			
Character Map ID	TrueType Font	Description	
в5		BIG 5 (Taiwan) Encoded [*]	
EU		EUC (Extended UNIX Code)	
GB		Government Bureau Industry Standard; Chinese (PRC); default	
JS		JIS (Japanese Industry Standard); default	
SJ		Shift JIS	
UC		Unicode (including Korean)	

*Unavailable for the EX2.

Table I-2: Double Byte Character Map

The double-byte symbol set is selected using <STX>yUxx command. The single-byte symbol set is selected using the same command, <STX>ySxx. Each affects an independent database selection and has no impact on the other.

Appendix J

General Purpose Input Output (GPIO) Port Applications

GPIO-equipped printers can interface with most external controlling devices. Operational preferences can be stored for subsequent power-ups using the printer menu, or via <STX>KC commands. Functions and connections vary, as discussed below.



- When a label is ready to print but awaiting a Start of Print signal, the prompt differs slightly depending upon equipment:
- Non-Display Models The STOP LED will flash.
- Display-Equipped Models The display will indicate WAITING FOR SIGNAL.



Always wear a wrist strap and follow ESD prevention measures when handling the GPIO or Applicator Interface Card. For specification information, reference the printer's Maintenance Manual.

Applicator Interface Card (Type 1)

The Applicator Interface Card (Type 1) is equipped with a GPIO Port, an Auxiliary (Serial B) Port and two LEDs as detailed below.



Applicator Interface Card (Type 1) Location and Connector Pin Outs



Applicator Interface Card (Type 1) Jumper Locations

The **GPIO Port** allows printer integration. Functions can be configured using the menu system or via <STX>KC commands. All configuration settings are saved in non-volatile memory. Jumper settings are critical:

- Jumper settings allow internal or external power distribution to the applicator circuitry.
- Jumper settings allow + 5 or +24 VDC output signal levels.



Failure to configure the card for the device(s) you are connecting may result in damage to the printer and/or the applicator.

The table below details the GPIO Port functions, and configurable settings:

Applicator Interface Card (Type 1) GPIO Port (J2) Overview						
Pin Number	Signal Name	Signal Direction	Active Setting	Jumper Placement	Function / Description	
Ground	Ground	Ground	Ground	JMP 7 "On"	Printer chassis ground is used	
1	(Configurable)	Open	Open	JMP 7 "Off"	Ground return must be supplied	
	+5 VDC	Output	+5 VDC	JMP 8 "On"	Printer +5 VDC is used (.5 amp max.)	
2	(Configurable)	Open	Open	JMP 8 "Off"	+5 VDC must be supplied	
3	Start Of Print ^[3]	Input	Programmable			
4	Slew Label	Input	Programmable			
5	Pause Toggle	Input	Low		N/A	
6	Reprint ^[2]	Input	Low	N/A		
7	+24 VDC (1.0 amp max.)	Output	+24 VDC			
8	Ground	Ground	Ground			
9	Ribbon Low	Output	Programmable		When inactive, all output pins will be pulled up to	
10	Service Required ^[1]	Output	Low	JMP 9:	the voltage determined by this jumper setting.	
11	End Of Print	Output	Programmable	Pins 1 & 2 = +5 VDC		
12	Media Out	Output	Low	- OR -	configure the card for the device(s) you	
13	Ribbon Out	Output	Low	Pins 2 & 3 = +24 VDC	are connecting may result in damage to	
14	Data Ready (DRDY)	Output	Low		the printer and/or the applicator.	
15	Spare	Output	N/A	N/A	N/A	

^[1] Evoked by occurrences listed under "Fault Messages" in the A-Class Operator's Manual.

^[2] Reprints the last label exactly, with no increment or time stamp changes; use it for error conditions. Always keeping this signal LOW will result in non-stop printing.

^[3] If active with no current print job, "WAITING FOR DATA" is displayed. Specifying a quantity of 9999 while always keeping this signal "On" will cause non-stop label printing, except in single label mode (see Imaging Mode, Section 4.2.5 of the *A-Class Operator's Manual*), which will cause the printer to stop between labels.

The **Start of Print Circuit** depends upon the applicator system's requirements:

• For direct inputs –

For isolated inputs -

right.

Use the printer's +5VDC and Ground to supply the devices interfacing to the GPIO inputs (as shown, right).

Supply an external +5 VDC and ground, remove JMP 7 and JMP 8 from the Applicator

Interface Card and follow the schematic shown



Vcc = 5 VDC External Power Source



The **Auxiliary Port (J1)** is an RS-232 interface. Serial data transfer settings (such as baud rate, word length, and parity) can be made using <STX>KcSP commands. These settings must match the device that you are connecting. Jumpers JMP 1 – JMP 4 should be in installed.

Applicator Interface Card (Type 1) Auxiliary Data Port				
Pin Number(s) Signal				
1	+5 VDC (0.5 Amp)			
2	RX			
3	TX			
4	DTR			
5	Ground			
6 & 9	N/C			
7	RTS			
8	CTS			

Indicators: The LEDs provide a visual indication of printer/applicator signal activity:

Applicator Interface Card (Type 1) Indicators			
Yellow LED	Flash at power-up and when the outputs change state.		
• Green LED	Flash at power-up and when the inputs change state.		

Applicator Interface Card (Type 2)

The Applicator Interface Card (Type 2) has two GPIO Ports, two Auxiliary Ports (Serial C & D) and two indicator LEDs as detailed below.







Applicator Interface Card (Type 2) Hardware Jumper Locations

GPI/O A (J1)

Four dedicated inputs are available for control of printer functions. These inputs require no external pull-ups, are designed to interface to open-collector outputs and accept totem pole outputs from +4.5 to + 26 VDC. Optical isolators are available to provide isolation. Two print control circuit examples are given below.

• For direct inputs –

Use the printer's +5VDC and Ground to supply the devices interfacing to the GPI/O A inputs (as shown, right).





• For isolated inputs –

To provide galvanic isolation for the GPI/O A inputs, remove jumper JMP 9 then supply an external +5VDC source voltage to Pin 2, and remove jumper JMP 8 then supply an external Ground to Pin 1 (as shown, right).

Seven dedicated outputs are available for control, warning, and error functions. These open-collector outputs are slew-limited. Optional 10K ohm pull-up resistors, tied to a common point for use at either +5 or +24 VDC, are available via jumper JMP 1.

To avoid damage if external pull-up resistors are used (that is, without jumper JMP1 installed), ensure that the external voltage does not exceed +30VDC.

The table below details the GPI/O A pin assignments, settings and functions:

V



Failure to properly configure the GPIO Port can result in damage to the printer and / or connected devices.

	Applicator Interface Card (Type 2) GPI/O Port A Overview					
Pin Number	Signal Name	Signal Direction [1]	Jumper	Position	Function / Description	
1	Ground		JMP 8	Installed	Printer chassis is used.	
	Ground			Removed	Ground must be supplied.	
		N/A			Printer +5VDC is used (.5 amp maximum)	
2	+5 VDC		JMP 9	Installed	\swarrow Drawing more than .5 amps can cause unreliable printer operation.	
				Removed	+5VDC must be supplied.	
3	Start Of Print				Programmable	
4	Slew Label	Input N/A			Programmable	
5	Toggle / Pause			The printer pauses when the signal is taken LOW.		
6	Reprint		N/A	N/A	The last label is reprinted exactly, with no increment or time stamp changes; recommended for use during error conditions. Keeping this signal LOW results in non-stop printing.	
7	+24 VDC	NI / A			Printer +24 VDC (1.5 amp maximum)	
8	Ground	N/A			Printer chassis.	
9	Ribbon Low			When inactive, outputs will	Programmable ^[1] . Signifies a RIBBON LOW DIAMETER warning.	
10	Service Reguired				be pulled up to a voltage determined by this jumper	Evoked by occurrences listed under "Fault Messages."[1] Active LOW.
11	End Of Print			setting, where:	Programmable ^[1] . Signifies the End of Print (EOP) process.	
12	Media Out			• Pins 1 – 2 = +5VDC;	Evoked during an Out of Stock condition. Active LOW.	
13	Ribbon Out	Output	JMP 1	• Pins 2 - 3 = +24VDC; or,	Evoked during an Out of Ribbon condition. Active LOW.	
14	Data Ready			 None = A common external voltage (not to exceed +30VDC) via external pull- ups (providing a 20K ohm 	Evoked when a label is waiting to be printed. Then after the printer receives the Start of Print signal, printing will begin. For synchronization with the print cycle, the End Of Print signal indicates the completion of the print process. Active LOW.	
15	Option Fault			feedback path through any two outputs).	Evoked during a Linear Scanner or RFID fault condition. Active LOW.	

^[1] Signal directions are given relative to the printer.
 ^[2] If active with no current print job, "WAITING FOR DATA" will be displayed. Specifying a quantity of 9999 while keeping this signal "On" will cause non-stop label printing, except in single label "Imaging Mode", which will cause the printer to stop between labels.

GPI/O B (J2)

Six unassigned inputs are designed to interface to open-collector outputs. These inputs require no external pull-ups and blocking diodes allow the use of totem pole outputs from +4.5 to + 26 VDC. Optical isolators are available to provide isolation. Two print control interface circuit examples are given below.

• For direct inputs –

Use the printer's +5VDC and Ground to supply the devices interfacing to the GPI/O B inputs (as shown, right).



• For electrically-isolated inputs –

To provide galvanic isolation for the GPI/O B inputs, remove jumper JMP 11 then supply an external +5VDC source voltage to Pin 1, and remove jumper JMP 10 then supply an external Ground to Pin 6 (as shown, right).



Six unassigned outputs are programmable and slew-limited. Optional 10K ohm pull-up resistors, one for each of the output lines, can be used at either +5 or +24 VDC via jumpers JMP 2 – 7.

To avoid damage if external pull-up resistors are used (that is, when Jumpers JMP 2 - 7 are not installed), ensure that the external voltage does not exceed +30VDC.

The table below details the GPI/O B pin assignments, settings and functions:



Failure to properly configure the GPIO Port can result in damage to the printer and / or connected devices.

	Applicator Interface Card (Type 2) GPI/O Port B Overview					
Pin Number	Signal Name / Direction ^[1]	Jumper	Position	Function / Description		
				Printer +5VDC is used (.5 amp maximum).		
1	+5 VDC	JMP 11	Installed	Z Drawing more than .5 amps can cause unreliable printer operation.		
			Removed	+5VDC must be supplied.		
2	Input 6	N/A	N/A	Programmed input function.		
3	Input 3	N/A	N/A	Programmed input function.		
			Installed: Pins 1 – 2	Programmed output function pulled-up to +5VDC.		
4	Output 6	JMP 7	Installed: Pins 2 – 3	Programmed output function pulled-up to +24VDC.		
			Removed	An external voltage via external pull-ups determine this level, not exceed +30VDC.		
			Installed: Pins 1 – 2	Programmed output function pulled-up to +5VDC.		
5	Output 3	JMP 4	Installed: Pins 2 – 3	Programmed output function pulled-up to +24VDC.		
			Removed	An external voltage via external pull-ups determine this level, not exceed +30VDC.		
6	Cround	JMP 10	Installed	Printer chassis is used.		
0	Ground	JMP 10	Removed	Ground must be supplied.		
7	Input 5	N/A	N/A	Programmed input function.		
8	Input 2	N/A	N/A	Programmed input function.		
			Installed: Pins 1 – 2	Programmed output function pulled-up to +5VDC.		
9	Output 5	JMP 6	Installed: Pins 2 – 3	Programmed output function pulled-up to +24VDC.		
			Removed	An external voltage via external pull-ups determine this level, not exceed +30VDC.		
			Installed: Pins 1 – 2	Programmed output function pulled-up to +5VDC.		
10	Output 2	JMP 3	Installed: Pins 2 – 3	Programmed output function pulled-up to +24VDC.		
			Removed	An external voltage via external pull-ups determine this level, not exceed +30VDC.		
11	+24 VDC	N/A	N/A	Printer +24 VDC (1.5 amp maximum).		
12	Input 4	N/A	N/A	Programmed input function.		
13	Input 1	N/A	N/A	Programmed input function.		
			Installed: Pins 1 – 2	Programmed output function pulled-up to +5VDC.		
14	Output 4	JMP 5	Installed: Pins 2 – 3	Programmed output function pulled-up to +24VDC.		
			Removed	An external voltage via external pull-ups determine this level, not exceed +30VDC.		
			Installed: Pins 1 – 2	Programmed output function pulled-up to +5VDC.		
15	Output 1	JMP 2	Installed: Pins 2 – 3	Programmed output function pulled-up to +24VDC.		
			Removed	An external voltage via external pull-ups determine this level, not exceed +30VDC.		

^[1] Signal directions are given relative to the printer.

COM C (J4)

Serial Port C functions as an RS-232 interface or as a dedicated device interface, according to jumper setting configurations indicated below:

COM C Jumper Setting Functions					
Function	Position				
Function	JMP 12	JMP 13	JMP 14	JMP 15	
RS-232 Communications	On	On	On	On	
RFID	Off	On	On	On	
Linear Scanner	On	Off	On	On	
Remote Display	On	On	Off	On	



Jumper settings will override most printer menu settings; however, if COM C jumpers are set for RS-232 communications with both the RFID and Linear Scanner options menu-enabled the printer will automatically assign the Linear Scanner to COM C (J4).

COM D (J3)

Serial Port D is an RS-232 communications interface.

Indicators:

Real-time incoming (IN) and outgoing (OUT) signal activity can be observed via LEDs on the card bracket. Sampled every millisecond, color change occurs with a corresponding change of signal state.



Unused, non-connected inputs and outputs will have an indeterminate state and assume a value of 1 or 0.



I-Class GPIO

	I-Class GPIO Overview						
Pin Number	Signal Name	Signal State	Signal Direction*	Description			
1	Vcc	+5 VDC	Output	+5 VDC power supply.			
2	Ribbon Fault	Low	Output	Goes low when a ribbon out condition is detected.			
3	Paper Fault	Low	Output	Goes low when an out of stock condition is detected.			
4	Printer Fault	Low	Output	Goes low when any printer fault is detected.			
5	Ribbon Low	Programmable	Output	Goes high (or low) when a low ribbon supply is detected.			
6	End of Print	Programmable	Output	Goes high (or low) when printing is complete, typically monitored to initiate the next Start of Print sequence.			
7	Backup Label	Programmable	Input	When received, will position a presented label for printing, provided that the programmed present distance is greater than zero.			
8	Start of Print Signal (SOP)	Programmable	Input	When received, begins printing. (If the printer awaits the SOP signal, WAITING FOR SIGNAL will be displayed).			
9	Signal Ground	Ground	N/A	Ground return.			

I-Class GPIO functions are detailed in the table below:

GPIO pin configuration (illustrated right), as viewed from the rear of the printer:



M-Class II GPIO

MII GPIO Overview						
Pin Number	Signal Name	Signal State	Signal Direction*	Description		
1	Vcc	+5 VDC	Output	Printer: Max +5 VDC, 100mA		
2	Printer Fault	Low	Output	Goes low upon printer detection of a fault condition. Max +5 VDC, 100mA		
3	Spare	Reserved	Input	Must be pulled high with 1k Ohm resistor (see sample SOP circuit, below).		
4	Start of Print (SOP)	Programmable	Input	When active, will begin print. Recommend only setting this signal to ACTIVE LOW. When ready to print a label, the applicator should hold this signal low for at least 50ms – or until EOP goes not active. See sample SOP circuit, below. Max +3.27 VDC, +/- 5mA		
5	End of Print (EOP)	Programmable	Output	Signifies the end of the print process. Can be monitored to initiate next Start of Print sequence. Minimum signal time 30ms. Max +5 VDC, 100mA		
6 & 8	Signal Ground	Ground	N/A	Ground		
7	+24 VDC	500mA	Output	Printer: Max +24 VDC, 500mA		

MII GPIO functions are detailed in the table below:

^[1]Given relative to the printer.

^[2]Port operation is configuration dependent: Disable all unused optional functions (e.g., Present Sensor or Cutter) and set GPIO to "YES" (or on display-equipped models, to APPLICATOR). Use the Configuration Set command (<STX>KC); or program the selections for non-display models via the "Printer Setup Menu List" and for display-equipped models via the menu.

The GPIO signals can be accessed via the front Option Port connector (Molex, P/N 44300-800), or via the Main PCB J6 connector (AMP, P/N 640456-8), where the pin-outs (as viewed when facing the printer) are as follows:

Option Port		Main PCB (J6)
8 6 4	2	
7 5 3	1	1 2 3 4 5 6 7 8

MII Sample SOP Circuit				
Pin 3 should be pulled to +5VDC. In additional, connections for the external Start of Print control can either be directly made to Pin 4 of the Option Port (or Main PCB connector) using a TTL-level input, or via an interface circuit (similar to the one shown). For more information, see the table below.	GPIO Connector Pin Number Vcc 1 Spare 3 SOP 4 Gnd 8			

Appendix K



The tables in this section use the following standards: X = Supported; ND = Non-Display

Maximum Field & Character Values

Printer	Maximum Format Fields [1]	Total Characters All Fields
I-4206 & I-4208	500	32768
All others	700	

^[1] When the product of the number of fields and characters in each field exceeds the available printer memory (the limiting factor), portions of the label may not print.

Table K-1: Maximum Label Format Fields & Characters

Model	Print Resolution		Dot Dimensions (nominal)		Maximum	Print Width	Maximum "gggg" Value			
Hoder	DPI	DPMM	Inches	Millimeters	Dots	Millimeters	Inch	Metric		
A-4212	203	8.0	.0043 x .0052	.11 x .13	832	104.1	410	1041		
A-4310	300	11.8	.0027 x .0043	.07 x .11	1248	105.7	416	1057		
A-4408	406	16.0	.0013 x .0018	.03 x .05	1664	104.1	410	1041		
A-4606	600	23.6	.0008 x .0015	.02 x .04	2496	105.7	416	1057		
A-6212	203	8.0	.0043 x .0052	.11 x .13	1344	168.1	662	1680		
A-6310	300	11.8	.0027 x .0043	.07 x .11	1920	162.6	640	1626		
EX2	203	8.0	.0043 x .0052	.11 x .13	832	104.1	410	1041		
E-4205e & E-Class Mark III (203DPI)	203	8.0	.0043 x .0052	.11 x .13	864	108.0	425	1080		
E-4304e & E-Class Mark III (300DPI)	300	11.8	.0027 x .0043	.07 x .11	1248	105.7	416	1046		
MP Compact MarkII	203	8.0	.0043 x .0052	.11 x .13	864	108.0	425	1080		
MP Compact MarkII	300	11.8	.0027 x .0043	.07 x .11	1248	105.7	416	1046		
H-4212 & H-4212X	203	8.0	.0043 x .0052	.11 x .13	832	104.1	410	1041		
H-4310 & H-4310X	300	11.8	.0027 x .0043	.07 x .11	1248	105.7	416	1046		
H-4408	406	16.0	.0013 x .0018	.03 x .05	1664	104.1	410	1041		
H-4606 & H-4606X	600	23.6	.0008 x .0015	.02 x .04	2496	105.7	416	1057		
H-6210 & H-6212X	203	8.0	.0043 x .0052	.11 x .13	1344	168.1	662	1680		
H-6308 & H-6310X	300	11.8	.0027 x .0043	.07 x .11	1920	162.6	640	1626		
H-8308X	300	11.8	.0027 x .0043	.07 x .11	2560	216.7	853	2167		
I-4206, I-4208, I-4210 & I-4212	203	8.0	.0043 x .0052	.11 x .13	832	104.1	410	1041		
I-4308	300	11.8	.0027 x .0043	.07 x .11	1248	105.7	416	1046		
I-4406	406	16.0	.0013 x .0018	.03 x .05	1664	104.1	410	1041		
I-4604	600	23.6	.0008 x .0015	.02 x .04	2496	105.7	416	1057		
M-Class 4206 & 4210 Mark II	203	8.0	.0043 x .0052	.11 x .13	864	108.0	425	1080		
M-Class 4308 Mark II	300	11.8	.0027 x .0043	.07 x .11	1248	105.7	416	1046		

Print Resolutions and Maximum Width & Record Column Values

Table K-2: Print Widths, Resolutions, and Record Column Field Values

Column, Present, & Row Adjust Fine Tune Range

Printer Resolution (DPI)	Column Adjust Fine Tune Parameter Range (+/- dots)	Row & Present Adjust Fine Tune Parameter Range (+/- dots)					
203	-100 – 100 dots	-100 – 2030 dots					
300	-150 – 150 dots	-150 – 3000 dots					
400	-200 – 200 dots	-200 – 4060 dots					
600	-300 – 300 dots	-300 – 6000 dots					

Table K-3: Adjust Range per Print Resolution

Memory Module Identifiers and Allocations

•		Printer									
Module ID	Description	E-Class Mark III (Basic &Adv)	E-Class Mark III (Pro)	A-Class	MP Compact Mark II	EX2	E-Class & Mark II	I-Class	H-Class	M-4206 Mark II	M-4210 & 4308 Mark II
А	DRAM (512 KB - default size)					Х	Х				
B ^[1]	Flash (512 KB available to user)					Х	Х				
С	Default, as assigned by <stx>x</stx>			Х	Х	Х	Х	Х	Х	Х	Х
	DRAM (512 KB - default size), configurable.					Х				X ^[6]	
D	DRAM (default 1MB), configurable.	Х	Х	Х	Х		Х	Х	Х		Х
F	SDIO			X ^[8]					Х		
Г	4 MB Flash option (as equipped) ^[4]							Х			
	256 KB Flash, Main CCA ^[2]					Х		Х			
	512 KB Flash, Main CCA, configurable up to 6.5 MB with Flash option $^{\left[3,4\right] }$			Х							
	\approx 1.0 MB Flash, Main CCA ^[4, 5]				Х		Х			Х	
	\approx 4.0 MB Flash, Main CCA ^[4, 5]					X ^[7]	X ^[7]		Х	X ^[7]	Х
	48 MB, Main CCA										
Н	USB Host Ports (as equipped)		Х	X ^[8]					Х		Х
I	USB Host Ports (as equipped)			X ^[8]					Х		Х
J	64 MB option (as equipped)	X ^[5]									Х
Х	ILPC Module, configurable 256 KB to 4 MB (as equipped).		X ^[5]	X ^[3,4]		X ^[5]	X ^[5]		X ^[5]	X ^[5]	X ^[5]
Y	64 KB Flash – Menu / EFIGS – protected							Х			
	128 KB Flash – Menu / EFIGS – protected	X ^[5]	X ^[5]	Х	X ^[5]	X ^[5]	X ^[5]		X ^[5]	X ^[5]	X ^[5]
Z ^[4]	^[4] 4 MB Flash – Option ILPC – protected							Х			

[1] ≈100,000 writes for semi-or-permanent data storage, dependent upon options and available memory; see the configuration label or <STX>KC.

^[2] Not available for the I-4206 and I-4208.

^[3] Modules G and X are partitioned to equal the sum of the total space available.

^[4] Configurable; see <STX>KcMCC.

^[5] Modules X and Y are factory allocated and locked; memory is shared with Module G.

^[6] Reduced to 128KB when MCL equipped.
 ^[7] Size dependant on main board flash and options installed, up to 4MB.
 ^[8] Optional for A-Class Mark II models only.

Table K-4: Memory Module Identifiers and Default Memory Allocations
Appendix L

Speed Ranges

	Speed	d Value:
Printer Speed Command*	Inches per Second	Millimeters per Second
A	1.0	25
В	1.5	38
С	2.0	51
D	2.5	63
Е	3.0	76
F	3.5	89
G	4.0	102
Н	4.5	114
I	5.0	127
J	5.5	140
ĸ	6.0	152
L	6.5	165
М	7.0	178
N	7.5	191
0	8.0	203
Р	8.5	216
Q	9.0	227
R	9.5	241
S	10.0	254
Т	10.5	267
υ	11.0	279
V	11.5	292
W	12.0	305
Х	13.0	330
Y	14.0	356
Z	15.0	381
a	16.0	406
b	17.0	432
с	18.0	457
d	19.0	483
e	20.0	508

*Applicable speed values are printer dependent. See Table L-2, below.

Table L-1: Speed Command Values

	Print Speed		Feed Speed		Reverse Speed		Slew Speed	
Model	Range	Default	Range	Default	Range	Default	Range	Default
A-4212	C – W	0	C – W	0	C - I	G	C – a	0
A-4310	C – S	0	C – W	0	C - I	G	C – a	0
A-4408	C - 0	K	C – S	К	C - I	G	C – a	К
A-4606	С – К	G	C - 0	G	C - I	G	C – a	G
A-6212	C – W	0	C – W	0	C - I	G	C - Y	0
A-6310	C – S	0	C – W	0	C - I	G	C - Y	0
EX2	A – G	G	A – G	G	A – E	С	N/A	N/A
E-4205e	A - I	G	A - I	G	С	С	N/A	N/A
E-4304e	A – G	Е	A – G	G	С	С	N/A	N/A
E-Class Mark III (Basic)	C - G	G	C - G	G	С	С	G	G
E-Class Mark III (Adv.)	C - I	G	C - I	G	С	C	G	G
E-Class Mark III (Pro)	С – К	G	С – К	G	С	С	G	G
E-Class Mark III (Pro 300DPI)	C - I	G	C - I	G	С	С	G	G
H-4212 & H- 4212X	C – W	0	C – W	0	C – G	G	C – a	0
H-4310 & H- 4310X	C - S	0	C – W	0	C – G	G	C – a	0
H-4408	C - 0	K	C - S	К	C - G	G	C – a	K
H-4606 & H- 4606X	С – К	G	C – O	G	C – G	G	C – a	G
H-6210	C - S	K	C – W	K	C - G	G	C – W	K
H-6212X	C – W	0	C – W	0	C – G	G	C – Y	0
H-6308	C – O	K	C - S	K	C – G	G	C – S	K
H-6310X	C - S	0	C – W	0	C - G	G	C – Y	0
H-8308X	C - 0	K	C - S	К	C - G	G	C – W	K
I-4206	С – К	К	C - 0	К	C - G	G	С – К	K
I-4208	C - 0	0	C - 0	0	C - G	G	C - 0	0
I-4210	C – S	0	C - S	0	C - G	G	C - W	0
I-4212	C – W	0	C – W	0	C - G	G	C - W	0
I-4308	C - 0	K	C - O	К	C - G	G	C - 0	K
I-4406	С – К	I	С – К	I	C - G	G	С – К	I
I-4604	C - G	E	C - G	E	C - G	G	C - G	Е
4206 Mark II	С – К	K	С – К	к	C – G	G	С – К	К
4210 Mark II	C - S	0	C – S	0	C – G	G	C – S	0
4308 Mark II	C - 0	K	C – O	K	C – G	G	C - 0	к
MP Compact II	A - I	G	A - I	G	С	С	N/A	N/A

Table L-2: Speed Ranges and Defaults

Appendix M

Commands by Function

Commands by Function				
Function	Command			
Backup speed	pa			
Batch quantity request	<soh>E</soh>			
Cancel	<soh>C</soh>			
Character bitmapped data	<esc>(snnnWdata</esc>			
Character code	<esc>*cnnnE</esc>			
Character dump mode	<stx>P</stx>			
Column offset amount	Cnnnn			
Configuration label and dot pattern print	<stx>Z</stx>			
Configuration Set (See Table 5-1 for individual listings)	<stx>Kc</stx>			
Continuous paper length	<stx>cnnnn</stx>			
Count by	^nn			
Cut	<stx>0</stx>			
Cut by	:nnnn			
Cut by	cnn			
Decrement alphanumerically	<fii< td=""></fii<>			
Decrement numerically	- fii			
DIP switch, host controlled settings	<stx>Vn</stx>			
Dot size height and width	Dwh			
Edge sensor enable	<stx>e</stx>			
Feed rate	<stx>Sa</stx>			
Feedback characters enable	<stx>a</stx>			
Field data line terminator	Tnn			
File delete from module	<stx>xmfname</stx>			
Firmware version request	<stx>v</stx>			
Font descriptor	<esc>)snnnW</esc>			
Font ID number	<esc>*cnnnD</esc>			
Form feed	<stx>F</stx>			
Set Present Distance	<stx>Kfnnnn</stx>			
Format attribute	An			
Graphics image download	<stx>labfname^cr</stx>			
Heat setting	Hnn			
Inches	<stx>n</stx>			
Increment alphanumerically	>fii			
Increment numerically	+fii			
Label format field replacement	<stx>Unnstring</stx>			
Label formatting start	<stx>L</stx>			
Label length maximum	<stx>Mnnnn</stx>			

Function	Command
Memory query	<stx>KQ</stx>
Memory query (new format)	<stx>Kq</stx>
Metric	<stx>m</stx>
Metric	m
Mirror	М
Module clear	<stx>qm</stx>
Module, compress	<stx>zm</stx>
Module, directory request	<stx>Wa</stx>
Module, set default	<stx>Xm</stx>
Module, FLASH memory Test	<stx>w</stx>
Module, RAM memory Test	<stx>t</stx>
Modules, clear all	<stx>Q</stx>
Pause for each label	<stx>J</stx>
Pause toggle	<soh>B</soh>
Pause, controlled	<stx>p</stx>
Place data in global register	G
Print last label format	<stx>G</stx>
Print speed	Pa
Print time and date	<stx>Tstring</stx>
Print head dot pattern test label	<stx>T</stx>
Quantity labels printed	<stx>Ennnn</stx>
Quantity of labels	Qnnnn
Recall global data and place in field	<stx>Sa</stx>
Recall stored label	rname
Reflective sensor select	<stx>r</stx>
Replacement field tag	U
Reset	<soh>#</soh>
Resettable counters reset	<stx>Kr</stx>
Ribbon saver	<stx>Rx</stx>
Row offset amount	Rnnnn
RS-232 port test	<stx>k</stx>
Scalable font download	<stx>imtaabbbb^crxxxxxxffff</stx>
Sensor values request	<stx>Y</stx>
Feed speed	Sa
Status ASCII string request	<soh>A</soh>
Status byte request	<soh>F</soh>
Store label in module & terminate formatting	smname
Symbol set select	<stx>ySaa</stx>
Symbol set select	ySaa
Terminate formatting - print label format	E
Terminate label formatting, do not print label	Х
Time and date request	<stx>B</stx>
Time and date set	<stx>AwMMddyearhhmmjjj</stx>
Update system database with current database	<soh>U</soh>
Zero (Ø) conversion to "0"	Z
	-

Table M-1: Commands Listed by Function

Appendix N

Image Loading

The printer will accept four types of image files: .BMP, .IMG, .PCX and a special Datamax 7bit ASCII file (as defined in this section). Use of the Datamax 7-bit ASCII format will require at least twice as much data transmission time as the other formats, (see <STX>I). The Datamax ASCII image file format is made up of a set of records with identical formats, each representing a dot row of the image; a terminator follows the last of these records.

Dot-row record

Dot-row record Terminator

Each dot-row record has the following format:

- Syntax: 80nndd...d<CR>
- Where:
 nn
 Is the number of character pairs in dd...d, represented in ASCII hex.

dd...d - Is dot data, character pairs, ASCII hex, 00-FF.

Duplicate records may be encoded using a repeat data record, following the data record that needs duplicating. The repeat data record format is:

Syntax: 0000FFnn<CR>

Where: *nn* - Is the number of duplicates, ASCII hex, 00-FF.

The terminator, last record, at the image download is: FFFF<CR>

^BIAAFLOGO(CR) 8030FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	
8030FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	
8030FFC0000007FFC0003FFFFC001FC0001FC0003FFFFC0018000FFC001FF8000C0003FF	
8030FFC0000000FFC0003FFFFC001FC0001FC0003FFFFC0018000FFC001FF800040001FF	
8030FFC00000003FC0001FFFFC001FC0001FC0001FFFFC0018000FFC001FF800040001FF	
8030FFC00000000FC0001FFFFC001FE0001FE0001FFFFC00180007FC000FF800060001FF	
8030FFE000000007E0001FFFFC001FE0001FE0001FFFFC00180007FC000FFC00060000FF	
8030FFE000000003E0000FFFFC001FE0000FFFFC00180007FC0007FC00020000FF	
8030FFE0000000001E0000FFFFC001FE0000FFFC001C0007FC0007FC00030000FF	FFE0010000FFF80003FFFFF0000(CR)
8030FFE00000000000000FFFC001FE0000FF0000FFFC001C0007FC0007FC00030000FF	FFE00180007FF80007FFFFF0000(CR)
8030FFE00000000000700007FFFC001FF0000FF80007FFFC001C0007FC0003FC000380007F	FFE00180007FF80007FFFFF0000(CR)
8030FFF000000000380007FFFC001FF0000FF80007FFFC001C0003FC0003FE000380007F	FFE001C0003FF80007FFFFF0000(CR)
8030FFF000000000380007FFFC001FF0000FF80007FFFC001C0003FC0003FE000380007F	FFE001E0003FF80007FFFFF0000(CR)
8030FFF000000000180003FFFC001FF00007FC0003FFFC001C0003FC0001FE0001C0003F	FFE001E0001FF0000FFFFFF0000(CR)
8030FFF0000000001C0003FFFC001FF00007FC0003FFFC001E0003FC0001FE0001C0003F	FFE001F0000FF0000FFFFFF0000(CR)
8030FFF00007C00000C0003FFFC001FF00007FE0003FFFC001E0003FC0000FF0001E0003F	FFE001F0000FF0000FFFFFF0000(CR)
8030FFF80007F80000E0001FFFC001FF80007FE0001FFFC001E0003FC0000FF0001E0001F	FFE001F80007F0000FFFFFF0000(CR)
8030FFF80007FC0000E000000001FF80007FE000000001E0001FC0000FF0001E00000	
8030FFF80007FE00006000000001FF80003FF000000001E0001FC00007F0000F00000	
8030FFF80003FF00007000000001FF80003FF000000001F0001FC00007F0000F00000	
8030FFF80003FF000070000000001FF80003FF000000001F0001FC00007F8000F00000	
8030FFFC0001FFC0003C00000001FFE0001FFE000000001F8000FC0000FC0007E0000	
8030FFFE0001FFC0001E000000001FFE00001FFE000000001F80000FC00007E0000	
8030FFFE0001FFC0001E000000001FFE0001FFE000000001F8000FC0000FC0007F0000	
8030FFFE0000FFC0001F000000001FFE00000FFF00000001F8000FC00007C0003F0000	
8030FFFE0000FFC0001F000000001FFE00000FFF000000001FC0007C00007E0003F0000	
8030FFFE0000FFE0001FF0001FFC001FFE0000FFF8001FFC001FC0007C000003E0003F8000	
8030FFFE0000FFE0000F8001FFC001FFF0000FF8000FFC001FC0007C000003E0003F8000	
8030FFFF0000FFE0000F8000FFC001FFF0000FFF8000FFC001FC0007C000003E0003F8000 8030FFFF0000FFE0000F8000FFC001FFF00007FFC000FFC001FC0007C000001F0001F	
8030FFFF00007FE0000FC000FFC001FF00007FC0007FC001FC0007C002001F0001FC000	
8030FFFF00007FE0000FC000FC001FF00007FE0007FC001FE0007C002001F0001FE000 8030FFFF00007FF0000FC0007FC001FF00007FE0007FC001FE0003C002001F0001FE000	
8030FFFF00007FF0000FE0007FC001FFF80007FFE0007FC001FE0003C003000F0001FE000	
8030FFFF80007FF00007E0007FC001FFF80007FE0003FC001FE0003C003000F0001FE000	
8030FFFF80007FF00007E0003FC001FFF80003FFF0003FC001FE0003C00300078001FF000	
8030FFFF80003FF00007F0003FC001FFF80003FFF0003FC001FE0003C00380078000FF000	
8030FFFF80003FF80007F0003FC001FFF80003FFF0001FC001FF0003C00380078000FF800	
8030FFFF80003FF80007F0001FC001FFF80003FFF8001FC001FF0001C003C0038000FF800	
8030FFFFFFC000000007FFC000001F8000000000000001FFF0000003FFE0000007FFC	000001FFFC0003F80007FFF0000(CR)
8030FFFFFFE00000000FFFC000001F800000000FE0000001FFF8000003FFE0000007FFE	000001FFFC0003FC0003FFF0000(CR)
8030FFFFFFF00000000FFFE000001F800000000FE000001FFF8000003FFF0000007FFE	000001FFFC0003FC0003FFF0000(CR)
8030FFFFFFC0000000FFFE000001FC0000000FE000001FFF8000003FFF0000007FFE	000001FFFC0003FE0001FFF0000(CR)
8030FFFFFFE0000000FFFE000001FC000000007F0000001FFF8000003FFF0000007FFF	
8030FFFFFFFF0000001FFFF000001FC00000007F0000001FFF8000003FFF8000007FFF	
8030FFFFFFFFC0000001FFFF000001FC000000007F0000001FFF8000003FFF8000003FFF	800001FFF80007FF0000FFF0000(CR)
8030FFFFFFFFE0000003FFFF800001FC000000007F800001FFFC000003FFF8000003FFF	
8030FFFFFFFF0000007FFFF800001FC0000000007F800001FFFC000003FFFC000003FFF	
8030FFFFFFFF800000FFFFF800001FE000000003FC00001FFFC000003FFFC000003FFF	
8030FFFFFFFFE00001FFFFC00001FE000000003FC00001FFFC000003FFFE000003FFF	
8030FFFFFFFF600007FFFFFC00001FE000000003FC00001FFFC000003FFFE000003FFF	
8030FFFFFFFF8003FFFFFC00001FE00000003FE00001FFFC000003FFFF000003FFF	
8030FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	
8030FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	
8030FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	
8030FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	
8030FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	
FFFF(CR)	errererererererererererererererererere
^BL(CR)	
1Y11000000000LOGO(CR)	

1Y1100 E(CR)

^BqA(CR)

Figure N-1: Sample Datamax 7-Bit ASCII File Image



Figure N-2: Sample Label

Appendix O

UPC-A and EAN-13: Variable Price/Weight Bar Codes

The EAN/UPC standard allows for an additional checksum to be generated in the middle of the bar code based on the data. This is used when the price or weight of an item is embedded into the bar code data (commonly used in the food industry).

For the printer to generate this checksum, a "V" must be placed in the data stream in the position the checksum is requested. If the "V" is placed in the 6th position for UPC-A or the 7th position for EAN-13, a checksum will be generated using the next five digits in the data stream. If the "V" is placed in the 7th position for UPC-A or the 8th position for EAN-13, a checksum will be generated using the next four digits in the data stream. The checksum is generated per the EAN/UPC bar code standard.

Examples:

1B110000200020012345V01199

Prints the UPC-A bar code with the variable price checksum in the sixth position.

1B1100002000200123456V0150

Prints the UPC-A bar code with the variable price checksum in the seventh position.

1F1100002000200123456V01199

Prints the EAN-13 bar code with the variable price checksum in the seventh position.

1F11000020002001234567V0150

Prints the EAN-13 bar code with the variable price checksum in the eighth position.

Appendix P

International Language Print Capability (ILPC) Programming Examples

ILPC (if equipped) allows the printing of non-English character sets, available with European language support (CG TIMES), KANJI language support, Chinese language support (SIMPLIFIED GB) and Korean Hangul. All of the features are embedded in the printer resident firmware and accessible through DPL thus eliminating excessive download time of bitmapped characters. Using scalable technology licensed from AGFA, this firmware allows users to print smooth characters in sizes from 4pt (1.4 mm) to 999pt (350 mm) in over 40 languages. Consult Appendix I for code page selections. Specific details regarding which characters are supported in each option can be obtained through Datamax-O'Neil Technical Support.

ILPC - CG TIMES

The CG Times is a single-byte scalable font consisting of four typefaces in 38 Western European languages. This contains over 900 unique characters in each of the four typefaces from the CG Times typeface family, Normal, Italic, Bold, and Bold Italic. Single-byte scalable fonts are selected using a print format record (see Generating Label Formats and Appendix H for details).

Scalable CG TIMES Font Code ("eee" field):

SA0 -CG TIMES
SA1 -CG TIMES ITALIC
SA2 - CG TIMES BOLD
SA3 - CG TIMES BOLD ITALIC

Sample DPL file (Greek) and resulting label:

```
<02>L<CR>
D11<CR>
D11<CR>
ySWG<CR>
1911SA003600020P020P020(WG) Greek Characters from<CR>
1911SA003000085P020P020the internal Symbol Set,<CR>
1911SA003000085P020P020font code SA0<CR>
1911SA001500050P020P020<ca><e1><eb><f9><f3><ef><f1><df><f3><e1><f4><e5><20><cda><f5><ed><dd><e4><f1><e9><ef><20><CR>
1911SA001100100P020P020<f4><f9><e3><20><c5><f4><e1><df><f1><f9><e3><20><f4><<e7><f2><CR>
1911SA000700140P020P020Datamax<CR>
1X1100000100020B365190005005<CR>
Q0002<CR>
E<CR>
```

(WG) Greek Characters from

the internal Symbol Set,

font code SA0

Καλωσορίσατε Συνέδριο τωγ Εταίρωγ της

Datamax



The notation "<xx>'' in this DPL file should be interpreted by the reader as representing the hexadecimal value of the character sent to the printer.

ILPC - Kanji

The Kanji Option is a double byte scalable font supporting Kanji Gothic B. In the double byte format, the printer recalls one character printed from every two 8-bit bytes sent from the host. Double byte scalable fonts are selected using a print format record (see Generating Label Formats and Appendix H for details).

	Scalable Double-Byte Font Map - KANJI								
eee (Font Code)	Scalable Font Type	Font Name	Binary Addressing	Hex ASCII Addressing	Code Pages				
U40	Scalable Resident	HG-Gothic-B Kanji Scalable			EUC, JIS, SJIS, UC				
u40	Scalable Resident	HG-Gothic-B Kanji Scalable			EUC, JIS, SJIS, UC				
UK1	Scalable Resident	HG-Gothic-E Kanji Scalable			EUC, JIS, SJIS				
uK1	Scalable Resident	HG-Gothic-E Kanji Scalable			EUC, JIS, SJIS				
u50 - u5z u90 - u9z	Scalable Non-Resident (download)	User defined							
U50 - U5z U90 - U9z	Scalable Non-Resident (download)	User defined							



Not all fonts contain an entire compliment of character codes for a given character map.

Sample Kanji Gothic B DPL file (binary addressing) and the resulting label:

```
<02>L<CR>
D11<CR>
ySPM<CR>
1911S0003100010P020P015Scalable Kanji Gothic B Available<CR>
1B110000020017001234567890<CR>
yUJS<CR>
1X1100001900010b0392011000020002<CR>
112200002800030JIS CHARACTER'S IN ALL 4 ROTATION'S<CR>
112200002600030Rotation 1<CR>
1911U4002650150P012P012<4D><3F><21><21><21><4D><4F><21><21><21><4D>
<5F><21><21><21><4D><6F><00><CR>
112200002400030Rotation 2<CR>
2911U4002600150P012P012<4D><3F><00><CR>
2911U4002600205P012P012<4D><4F><00><CR>
2911U4002600250P012P012<4D><5F><00><CR>
2911U4002600300P012P012<4D><6F><00><CR>
112200002200030Rotation 3<CR>
3911U4002330315P012P012<4D><6F><21><21><21><4D><5F><21><21><21><4D>
<4F><21><21><21><4D><3F><00><CR>
112200002000030Rotation 4<CR>
4911U4001950165P012P012<4D><3F><00><CR>
```

```
4911U4001950215P012P012<4D><4F><00><CR>
4911U4001950265P012P012<4D><5F><00><CR>
4911U4001950315P012P012<4D><6F><00><CR>
1X1100001100010b0392007500020002<CR>
112200001650030SCALING JIS CHARACTER'S<CR>
1911U4001200020P010P020<21><6F><00><CR>
1911U4001200050P020P020<21><6F><00><CR>
1911U4001200080P030P020<21><6F><00><CR>
1911U4001200110P040P020<21><6F><00><CR>
1911U4001200145P040P030<21><6F><00><CR>
1911U4001200190P040P040<21><6F><00><CR>
1911U4001200250P040P050<21><6F><00><CR>
1911U4001200320P040P060<21><6F><00><CR>
11220000050010NORMAL
                        INVERSE<CR>
11220000050245 NORMAL
                         MIRROR<CR>
1911U4000250010P040P040<21><6F><00><CR>
1911U4000250245P040P040<4B><30><CR>
A5<CR>
1911U4000250090P040P040<21><6F><00><CR>
A1<CR>
M<CR>
1911U4000250390P040P040<4B><30><CR>
M<CR>
E<CR>
```



The notation "<xx>'' in this DPL file should be interpreted by the reader as representing the hexadecimal value of the byte sent to the printer.

Sample Kanji Gothic E DPL file (Hex-ASCII addressing) and resulting label:

<02>L<CR> D11<CR> ySPM<CR> 1911S0003100010P020P015Scalable Kanji Gothic E Available<CR> 1B110000020017001234567890<CR> yUJS<CR> 1X1100001900010b0392011000020002<CR> 112200002800030JIS CHARACTER'S IN ALL 4 ROTATION'S<CR> 112200002600030Rotation 1<CR> 1911uK102650150P012P0124D3F212121214D4F212121214D5F212121214D6F<CR> 112200002400030Rotation 2<CR> 2911uK102600150P012P0124D3F<CR> 2911uK102600205P012P0124D4F<CR> 2911uK102600250P012P0124D5F<CR> 2911uK102600300P012P0124D6F<CR> 112200002200030Rotation 3<CR> 3911uK102330315P012P0124D6F212121214D5F212121214D4F212121214D3F<CR> 112200002000030Rotation 4<CR> 4911uK101950165P012P0124D3F<CR> 4911uK101950215P012P0124D4F<CR> 4911uK101950265P012P0124D5F<CR> 4911uK101950315P012P0124D6F<CR> 1X1100001100010b0392007500020002<CR> 112200001650030SCALING JIS CHARACTER'S<CR> 1911uK101200020P010P020216F<CR> 1911uK101200050P020P020216F<CR> 1911uK101200080P030P020216F<CR> 1911uK101200110P040P020216F<CR> 1911uK101200145P040P030216F<CR> 1911uK101200190P040P040216F<CR> 1911uK101200250P040P050216F<CR> 1911uK101200320P040P060216F<CR> 112200000050010NORMAL INVERSE<CR> 11220000050245 NORMAL MIRROR<CR> 1911uK100250010P040P040216F<CR> 1911uK100250245P040P0404B30<CR> A5<CR> 1911uK100250090P040P040216F<CR> A1<CR> M < CR >1911uK100250390P040P0404B30<CR> M<CR> E<CR>

Scalable Kanji G	iothic	E Avai	ilable		
JIS CHARACTER Rotation 1	与	RLL 4 溶	欲	ION 酪	'S
Rotation 2	μ	家	袋	盟	
Rotation 3	雪	客	始	題	
Rotation 4	与	胦	欲	郶	
SCALING JIS C ¥¥¥¥¥	¥	¥	¥	_	¥
¥¥			飽	ļ	飽
NORMAL INVERSE	Ξ	 Model (19) 	NORME	ΊL	MIRROR

ILPC - Chinese

The Chinese Option is a double byte scalable font supporting Simplified GB Chinese. In the double byte format the printer recalls one character printed from every two 8-bit bytes sent from the host. Double byte scalable fonts are selected using a print format record (see Generating Label Formats and Appendix H for details).

DPL Big 5 Encoding Support: With the ILPC Chinese option, the printer firmware supports font files that are encoded for the GB Character Map and the Big 5 Character Map. The resident Asian font in the printer is encoded in the GB Character Map. To utilize the Big 5 Character Map, the user must download a font file that is Big 5 encoded. The font file downloaded must be of a size compatible with the internal module size available or of a size compatible with an external (plug in) module where applicable. Printing characters from the Big 5 encoded font file is accomplished by:

- 1. Setting the character mapping with a System Command or Label Format Command (<STX>yUB5 or yUB5, respectively).
- 2. Setting the "b" field = "9" and "eee" field = "Unn", where "nn" is equal to the Font ID number selected for the Big 5 encoded font file downloaded.
- 3. Selecting string data corresponding to the Big 5 Character Map.

	Scalable Double-Byte Font Map - CHINESE								
eee (Font Code)	Scalable Font Type	Font Name	Binary Addressing	Hex ASCII Addressing	Code Pages				
UC0	Scalable Resident	Simplified GB Chinese			GB				
uc0	Scalable Resident	Simplified GB Chinese			GB				
U50 - U5z U90 - U9z	Scalable Non-Resident (download)	Big 5			В5				
u50 - u5z u90 - u9z	Scalable Non-Resident (download)	Big 5			В5				
U50 - U5z U90 - U9z	z Scalable Non-Resident				-				
u50 - u5z u90 - u9z	Scalable Non-Resident (download)	User defined			-				

Sample Simplified GB Chinese DPL file (binary addressing) and resulting label:

```
<02>L<CR>
D11<CR>
ySPM<CR>
1911S0003100010P020P015Scalable Chinese Available in GB Character Set<CR>
1B110000020017001234567890<CR>
yUGB<CR>
1X1100001900010b0392011000020002<CR>
112200002800030GB CHARACTER'S IN ALL 4 ROTATION'S<CR>
112200002600030Rotation 1<CR>
1911UC002650150P012P012<BD><D0>A1><A1><A1><A1><BD><D1><A1><A1><A1><<BD>
<D2><A1><A1>
<A1><A1><BD><D3><00><CR>
112200002400030Rotation 2<CR>
2911UC002600150P012P012<BD><D0><CR>
2911UC002600205P012P012<BD><D1><00><CR>
2911UC002600250P012P012<BD><D2><00><CR>
2911UC002600300P012P012<BD><D3><00><CR>
112200002200030Rotation 3<CR>
<D1><A1><A1><A1><BD><D0><CR>
112200002000030Rotation 4<CR>
4911UC001950165P012P012<BD><D0><CR>
```

```
4911UC001950215P012P012<BD><D1><00><CR>
4911UC001950265P012P012<BD><D2><00><CR>
4911UC001950315P012P012<BD><D3><O0><CR>
1X1100001100010b0392007500020002<CR>
112200001650030SCALING GB CHARACTER'S<CR>
1911UC001200020P010P020<BA><D0><CR>
1911UC001200050P020P020<BA><D0><CR>
1911UC001200080P030P020<BA><D0><CR>
1911UC001200110P040P020<BA><D0><CR>
1911UC001200145P040P030<BA><D0><CR>
1911UC001200190P040P040<BA><D0><CR>
1911UC001200250P040P050<BA><D0><CR>
1911UC001200320P040P060<BA><D0><CR>
11220000050010NORMAL
                       INVERSE<CR>
11220000050245 NORMAL
                         MIRROR<CR>
1911UC000250010P040P040<BD><E0><00><CR>
1911UC000250245P040P040<BD><E1><00><CR>
A5<CR>
1911UC000250090P040P040<BD><E0><00><CR>
A1<CR>
M<CR>
1911UC000250390P040P040<BD><E1><00><CR>
M<CR>
E<CR>
```



The notation "<xx>'' in this DPL file should be interpreted by the reader as representing the hexadecimal value of the byte sent to the printer.

ILPC - Korean

The Korean Option is a double-byte scalable font supporting Korean Hangul. In the doublebyte format, the printer recalls one character printed from every two 8-bit bytes sent from the host. Double-byte scalable fonts are selected using a print format record (see Generating Label Formats and Appendix H for details).

	Scalable Double-Byte Font Map - KOREAN								
eee (Font Code)	Scalable Font Type	Font Name	Binary Addressing	Hex ASCII Addressing	Code Pages				
UHO	Scalable Resident	Korean Hangul			UC				
uh0	Scalable Resident	Korean Hangul			UC				
u50 - u5z u90 - u9z	Scalable Non-Resident (download)	User defined							
U50 - U5z U90 - U9z	Scalable Non-Resident (download)	User defined							



Not all fonts contain an entire compliment of character codes for a given character map.

Sample Korean Hangul DPL file (binary addressing) and the resulting label:

```
<02>L<CR>
D11<CR>
ySPM<CR>
1911S0003100010P020P015Scalable Korean Available in UC Character Set<CR>
yUUC<CR>
1B110000020017001234567890<CR>
1X1100001900010b0392011000020002<CR>
112200002800030HANGUL CHARACTER'S IN ALL 4 ROTATIONS<CR>
112200002600030Rotation 1<CR>
1911UH002620150P012P012<AC><00><CR>
1911UH002620205P012P012<AC><65><00><CR>
1911UH002620250P012P012<AC><69><00><CR>
1911UH002620300P012P012<AC><DF><00><CR>
112200002400030Rotation 2<CR>
2911UH002550150P012P012<AC><00><CR>
2911UH002550205P012P012<AC><65><00><CR>
2911UH002550250P012P012<AC><69><00><CR>
2911UH002550300P012P012<AC><DF><00><CR>
```

```
112200002200030Rotation 3<CR>
3911UH002330165P012P012<AC><00><CR>
3911UH002330220P012P012<AC><65><00><CR>
3911UH002330265P012P012<AC><69><00><CR>
3911UH002330315P012P012<AC><DF><00><CR>
112200002000030Rotation 4<CR>
4911UH001950165P012P012<AC><00><CR>
4911UH001950215P012P012<AC><65><00><CR>
4911UH001950265P012P012<AC><69><00><CR>
4911UH001950315P012P012<AC><DF><00><CR>
1X1100001100010b0392007500020002<CR>
112200001650030SCALING HANGUL CHARACTERS<CR>
1911UH001200020P010P020<AC><AC><00><CR>
1911UH001200050P020P020<AC><AC><00><CR>
1911UH001200080P030P020<AC><AC><00><CR>
1911UH001200110P040P020<AC><AC><00><CR>
1911UH001200145P040P030<AC><AC><00><CR>
1911UH001200190P040P040<AC><AC><00><CR>
1911UH001200250P040P050<AC><AC><00><CR>
1911UH001200320P040P060<AC><AC><00><CR>
112200000200010NORMAL
                        INVERSE<CR>
112200000200245 NORMAL
                          MIRROR<CR>
1911UH000450010P040P040<AC><4D><00><CR>
1911UH000450245P040P040<AC><15><00><CR>
A5 < CR >
1911UH000450090P040P040<AC><4D><00><CR>
A1<CR>
M<CR>
1911UH000450390P040P040<AC><15><00><CR>
M<CR>
E<CR>
```





The notation (xx)' in this DPL file should be interpreted by the reader as representing the hexadecimal value of the byte sent to the printer.

Appendix Q

Plug and Play IDs

MFG; CMD; MDL; CLS; DES

Where:

- MFG = Datamax-Oneil
- CMD = Fixed string: "DPL"
- MDL = Model: (Valid designations are A4212, A4310, A4408, A4606, A6212, A6310, E4205e, E-4304e, EX2, H4212, H4310, MP Compact4 Mark II 203, MP Compact4 Mark II 300, I4206, I4208, I4308, I4210, I4212, I4406, I4604, 4206MII, 4210MII, and 4308MII.)
- CLS = Fixed string: "PRINTER"
- DES = Description (subject to change with the application [firmware] revision and printer model)

Example: Datamax-Oneil 4208 Label Printer Version 06.06 07/09/2001

Appendix R

Line Mode

Line Mode allows the printer to respond to raw data from a device that may not be able to send a complete DPL file. In Line Mode raw data is directed into replaceable fields in formats or templates stored in the printer.

The printer can be placed in Line Mode via the front panel, as explained in the printer's *Operating Manual*, or by using the <STX>KCEM command (see Extended System-Level Command Functions), where:

<STX>KcEM0 will enter standard DPL Mode; and,

<STX>KCEM1 will enter Line Mode.

- A reset will follow a change of mode.
- While in Line Mode, the printer will also respond to DPL commands; however, special download types (such as firmware updates) should only be sent when the printer is in DPL mode.

Line Mode Specifics

- Raw data sent to the printer must be terminated by a carriage return [0x0D].
- The host timeout setting (see <STX>KCHT) will determine the maximum waiting period between data sent. If the timeout value is reached, the label will print using the data received before timeout occurred.
- A form feed command [0x0C] may be sent to terminate processing and print the data that has been received.
- Issuing the <STX>Ennnn command (where nnnn represents the print count), allows quantities of the same label to be printed.
- The printer must have a template program loaded. A template is a standard DPL file that ends in a store format command, instead of the print command (E). The template name must be either DMXFRM or DMXFRMxx. Using DMXFRMxx, allows multiple templates to be available.

Sample Template 1:

The following sample uses DMXFRM as the template name and stores it to the default module. (The default module is printer model dependent.)

To print a label, the attached device now only has to send the data. Sample data in this example is as follows:

The sample data will print the following label (layout and font are approximations):

TEST DATA AAAAAAAAAAAAAAAAAAAAAAAAAAAA

If multiple labels are needed, data for the labels can be sent at the same time. Sample data for two labels:

The sample data will print the following two labels (layout and typeface are approximations):

Label 1:

TEST DATA AAAAAAAAAAAAAAAAAAAAAAAAAAAAAA

FIXED FIELD #2 TEST DATA CCCCCCCCCCCCCCCCCCCCCCC

Label 2:

TEST DATA DDDDDDDDDDDDDDDDDDDDDDDDD

FIXED FIELD #1 TEST DATA EEEEEEEEEEEEEEEEEEEEEEE

FIXED FIELD #2 TEST DATA FFFFFFFFFFFFFFFFFFFFFFFFFF

Sample Template 2:

If a template in the form of DMXFRMxx is used, the data must be preceded by the value of xx. Below is a sample template for DMXFRMxx:

Sample data for DMXFRMxx type templates:

Appendix S

RFID Overview

The printer has two different operational modes for the programming of RFID tags: Direct, and Label Formatting.

The RFID programming data can be entered in one of two formats: ASCII, or Hexadecimal. Data in the ASCII format is entered conventionally, while data in the hexadecimal format is entered as the hexadecimal-pairs equivalent of the ASCII character(s). For example, to program the word "TEST" in the ASCII format, the data is entered as TEST; alternately, in the hexadecimal format the word is entered as 54455354. The other important consideration is the data format byte count. Compared to the ASCII format, hexadecimal formats use twice the number of bytes. Returning to the example above, in the ASCII format "TEST" has a byte count of four, while the hexadecimal format equivalent has a byte count of eight.

To send information about the results of tag printing back to the host, refer to the <STX>KcOF command for option feedback.

Direct Mode

Direct Mode allows the user (host) to directly control the reading and writing of RFID tags. This mode contains both a generic Read / Write Interface and a high level HF / UHF Tag Interface. In Direct Mode, each RFID tag is individually processed with status and data responses. Typically these commands are used for diagnostics or custom applications.

Generic Read/Write Interface

The Generic Read/Write Interface allows the Host Application to send generic commands for RFID operations by utilizing the printer's database for specific parameters. Requiring no knowledge of the tag types being used (except the data format), these commands consist of simple read and write operations. See the <STX>KaR and <STX>KaW commands for details.

HF (13.56 MHz) ISO15693 Tag Interface

The ISO15693 Tag Interface allows the Host Application to perform specific operations pertaining to HF-type (13.56 MHz) tags. Since these commands override the printer's database by interfacing directly to the tag module, knowledge of HF tags and their operation is required. See the <STX>KtA, <STX>KtD, <STX>KtE, <STX>KtH, <STX>KtU, <STX>KtR, and <STX>KtW commands for details.

UHF Interface

This interface allows the Host Application to perform specific operations pertaining to UHF-type tags. Since these commands override the printer's database by interfacing directly to the tag module, knowledge of UHF protocols and their operation is required. See the <STX>KuR and <STX>KuW commands for details.

Label Formatting Mode

Label Formatting Mode utilizes the current printer configuration to process all reading, writing, and exception processing for each tag printed. (For exception processing and fault handling; see the <STX>KCFH command.) The specification for RFID programming is contained in the data fields of the DPL label format, which instructs the printer to write and read data. Two Label Formatting Modes for RFID are available. While each supports auto increment and decrement commands for numeric (+/-), alphanumeric (>/<), or hexadecimal ((/)) data, they differ when a byte count specifier is added. Both RFID Label Formatting commands are detailed below.



Up to six RFID operations per label are allowed.

Wx / W1x: RFID

Syntax for RFID (spaces added for readability):

a bbb c d eee ffff gggg jj...j

Where:

Field	Valid Inputs	Meaning			
a	1, 2, and 3	Operation to perform, where: 1 = Read (report to host) 2 = Write 3 = Write w/ Read back and Verify			
bbb	Wnx	RFID Hexadecimal Operation, where no "n" is an implied 1.			
С	0	Not Used, should be 0			
d	0	Not Used, should be 0			
		 HF: Lock after write, where: x = 0 - Use printer setup to determine if lock is performed. x = 1 - Lock after write. yy = Not Used 			
eee	хуу	 UHF EPC Gen2: Lock after write, where: x = 0 - Use printer setup to determine if lock is performed. x = 1 - Lock after write. yy = Lock state where "01" is permalock, "10" is pwd-write lock or "11" is both states 			
		UHF other tag types: Not Used, should be 000			
		HF: Starting block number to write.			
ffff	0000 - 9998	UHF EPC Gen2: Block address where "0001" is EPC data, "0002" is Tag ID or "0003" is user memory. Using "0000" is for EPC data also (for backwards compatibility).			
		UHF other tag types: Not Used, should be 0000			
		HF: Not Used, should be 0000			
aaaa	0000	UHF EPC Gen2: Data word offset – currently only used for read operation			
		UHF other tag types: Not Used, should be 0000			
jj…j	Valid hexadecimal pairs per character followed by a termination character.	Data to write to the tag. <i>M</i> UHF data length must be 16 or 24 for EPC, 16 for Tag ID or multiples of four for user memory sections.			

Example 1: The following example encodes an HF tag , starting at block 001, with "Datamax writes RFID best":

```
<STX>L
D11<CR>
2W1x0000000010000446174616D61782077726974657320524649442062657374<CR>
E
```

Example 2: The following format encodes a UHF Gen2 tag with EPC data "112233445566778899AABBCC" and user memory data "1111222233334444".

<STX>L D11 2W1x00000001000012233445566778899AABBCC 2W1x00000000300001111222233334444 E

Example 3: The following format reads a UHF Gen2 tag with data from address 1, offset 2nd word (EPC data), Tag ID from address 2, and user data from address 3. Note that the length of the data in the record determines how much data is read.

With Option Feedback enabled, the format above would return data, such as:

<R;C;03;03;0002:0001;112233445566778899AABBCC;E20060010128FF33;11112222333
34444>

Where, "112233445566778899AABBCC" is the EPC data, "E20060010128FF33" is the Tag ID and "1111222233334444" is the user memory data. See Option Feedback Mode (<STX>KcOF) for more information on the response format.

WX / W1X: RFID with Byte Count Specifier

Specified Length – The upper case X identifies an RFID data string with a string 4-digit length specifier. The length specifier allows values 0x00 through 0xFF to be included within the data strings without conflicting with the DPL format record terminators. The four-digit decimal data byte count immediately follows the four-digit column position field. This value includes all of the data following the byte count field, but does not include itself.

Syntax for RFID with Byte Count Specifier (spaces added for readability):

a bbb c d eee ffff gggg hhhh jj…j

Where:

Field	Valid Inputs	Meaning			
a	1, 2, and 3	Operation to perform, where: 1 = Read (report to host) 2 = Write 3 = Write / Verify			
bbb	Wnx	RFID Hexadecimal Operation, where no "n" is an implied 1.			
С	0	Not Used, should be 0			
d	0	Not Used, should be 0			
eee	хуу	<pre>HF: Lock after write, where: x = 0 - Use printer setup to determine if lock is performed. x = 1 - Lock after write. yy = Not Used UHF EPC Gen2: Lock after write, where: x = 0 - Use printer setup to determine if lock is performed. x = 1 - Lock after write. yy = Lock state where "01" is for permalock, "10" for pwd- write lock or "11" for both states UHF other tag types: Not Used, should be 000</pre>			
fff	0000 - 9998	HF: Starting block number to write.UHF EPC Gen2: Block address where "0001" is EPC data, "0002" is Tag ID or "0003" is user memory. Using "0000" is for EPC data also (for backwards compatibility).UHF other tag types: Not Used, should be 0000			
ਰਰਰਰ	0000	HF: Not Used, should be 0000 UHF EPC Gen2: Data word offset – currently only used for read operation UHF other tag types: Not Used, should be 0000			
hhhh	Four-digit decimal data byte count.	Number of bytes to follow (to include all bytes that follow until the end of the data). Ø UHF data length must be 8 or 12 for EPC, 8 for Tag ID or multiples of 2 for user memory sections.			
jj…j	Valid ASCII character string followed by a termination character.	Data to write to the tag. UHF data length must be 8 or 12 for EPC, 8 for Tag ID or multiples of 2 for user memory sections.			

Example1: The following example encodes a HF tag, starting at block 001, with "Datamax <CR> writes RFID best." It includes a Byte Count Specifier (the portion in bold), where 0024 equals a four-digit decimal data byte count and includes all bytes that follow until the end of the data. Field termination is set by the byte count.

<STX>L D11<CR> 2W1X0000000010000**0024**Datamax<CR> writes RFID best<CR> E

Example 2: The following format encodes a tag with EPC data "1122334455667788" with byte count shown in bold. Note that the field data is entered as the hex value for the ASCII character.

GEN2 Kill/Access Passwords

Gen2 tags are capable of storing a 4-byte kill password and a 4-byte access password. The kill password is stored at address 0, word offset 0 and access password is stored at address 0, word offset 2. The default for these passwords is typically 0.

To write these to the tag it is necessary to store the desired password value in the printer database:

To write the database for the kill password the command is <STX>KcRIKnnnnnnn, where nnnnnnnn represents the 4-byte value in hexadecimal pairs; and,

To write the database for the access password the command is <STX>KcRICnnnnnnn, where nnnnnnn represents the 4-byte value in hexadecimal pairs.

These can also be viewed or modified via the printer's display under RFID OPTIONS / UHF SETTINGS. If the stored value for either or both of these passwords is non-zero and a label formatting command to write EPC data is issued, then these passwords will be written also.

GEN2 Lock States

Gen2 supports a lock state of permalock, pwd-lock or both for any of the data sections of the tag. This includes access/kill passwords, EPC data, Tag ID or user memory. To store these states in the printer database the command is <STX>KCRIGn, where: 1 is permalock; 2 is pwd-lock; 3 is both; and, 0 is none (default). When a section of the tag is written via label formatting command and the stored lock state and lock after write are enabled, the section will be locked.

Appendix T

	Region Country Codes						
Code	Country	Code	Country	Code	Country		
AF	Afghanistan	GH	Ghana	PK	Pakistan		
AX	Åland Islands	GI	Gibraltar	PW	Palau		
AL	Albania	GR	Greece	PS	Palestinian Territory		
DZ	Algeria	GL	Greenland	PA	Panama		
AS	American Samoa	GD	Grenada	PG	Papua New Guinea		
AD	Andorra	GP	Guadeloupe	PY	Paraguay		
AO	Angola	GU	Guam	PE	Peru		
AI	Anguilla	GT	Guatemala	РН	Philippines		
AQ	Antarctica	GN	Guinea	PN	Pitcairn		
AG	Antigua and Barbuda	GW	Guinea-Bissau	PL	Poland		
AR	Argentina	GY	Guyana	PT	Portugal		
AM	Armenia	НТ	Haiti	PR	Puerto Rico		
AW	Aruba	НМ	Heard Island and McDonald Islands	QA	Qatar		
AU	Australia	VA	Holy See (Vatican City State)	RE	Réunion		
AT	Austria	HN	Honduras	RO	Romania		
AZ	Azerbaijan	нк	Hong Kong	RU	Russian Federation		

WiFi Region Country Codes

Code	Country	Code	Country	Code	Country
BS	Bahamas	HU	Hungary	RW	Rwanda
BH	Bahrain	IS	Iceland	SH	Saint Helena
BD	Bangladesh	IN	India	KN	Saint Kitts and Nevis
BB	Barbados	ID	Indonesia	LC	Saint Lucia
BY	Belarus	IR	Iran, Islamic Republic of	PM	Saint Pierre and Miquelon
BE	Belgium	IQ	Iraq	VC	Saint Vincent and the Grenadines
BZ	Belize	IE	Ireland	WS	Samoa
BJ	Benin	IL	Israel	SM	San Marino
BM	Bermuda	IT	Italy	ST	Sao Tome and Principe
BT	Bhutan	JM	Jamaica	SA	Saudi Arabia
BO	Bolivia	JP	Japan	SN	Senegal
BA	Bosnia and Herzegovina	JO	Jordan	CS	Serbia and Montenegro
BW	Botswana	KZ	Kazakhstan	SC	Seychelles
BV	Bouvet Island	KE	Kenya	SL	Sierra Leone
BR	Brazil	KI	Kiribati	SG	Singapore
IO	British Indian Ocean Territory	KP	Korea, Democratic People's Republic of	SK	Slovakia
BN	Brunei Darussalam	KR	Korea, Republic of	SI	Slovenia
BG	Bulgaria	KW	Kuwait	SB	Solomon Islands
BF	Burkina Faso	KG	Kyrgyzstan	SO	Somalia

Code	Country	Code	Country	Code	Country
BI	Burundi	LA	Lao People's Democratic Republic	ZA	South Africa
КН	Cambodia	LV	Latvia	GS	South Georgia and the South Sandwich Islands
СМ	Cameroon	LB	Lebanon	ES	Spain
CA	Canada	LS	Lesotho	LK	Sri Lanka
CV	Cape Verde	LR	Liberia	SD	Sudan
КY	Cayman Islands	LY	Libyan Arab Jamahiriya	SR	Suriname
CF	Central African Republic	LI	Liechtenstein	SJ	Svalbard and Jan Mayen
TD	Chad	LT	Lithuania	SZ	Swaziland
CL	Chile	LU	Luxembourg	SE	Sweden
CN	China	МО	Масао	СН	Switzerland
CX	Christmas Island	MK	Macedonia	SY	Syrian Arab Republic
CC	Cocos (Keeling) Islands	MG	Madagascar	TW	Taiwan (Republic of China)
CO	Colombia	MW	Malawi	TJ	Tajikistan
KM	Comoros	MY	Malaysia	ΤZ	Tanzania, United Republic of
CD	Congo, The Democratic Republic of the	ML	Mali	TL	Timor
CK	Cook Islands	MT	Malta	TG	Тодо
CR	Costa Rica	MH	Marshall Islands	TK	Tokelau
CI	Côte d'Ivoire	MQ	Martinique	TO	Tonga
HR	Croatia	MR	Mauritania	TT	Trinidad and Tobago

Code	Country	Code	Country	Code	Country
CU	Cuba	MU	Mauritius	TN	Tunisia
CY	Cyprus	YT	Mayotte	TR	Turkey
CZ	Czech Republic	MX	Mexico	ТМ	Turkmenistan
DK	Denmark	FM	Micronesia, Federated States of	TC	Turks and Caicos Islands
DJ	Djibout	MD	Moldova, Republic of	TV	Tuvalu
DM	Dominica	MC	Monaco	UG	Uganda
DO	Dominican Republic	MN	Mongolia	UA	Ukraine
EC	Ecuador	MS	Montserrat	AE	United Arab Emirates
EG	Egypt	MA	Morocco	GB	United Kingdom
SV	El Salvador	MZ	Mozambique	US	United States
GQ	Equatorial Guinea	MM	Myanmar	UM	United States Minor Outlying Islands
ER	Eritrea	NA	Namibia	UY	Uruguay
EE	Estonia	NR	Nauru	UZ	Uzbekistan
ET	Ethiopia	NP	Nepal	VU	Vanuatu
FK	Falkland Islands (Malvinas)	NL	Netherlands		Vatican City State - see Holy See
FO	Faroe Islands	AN	Netherlands Antilles	VE	Venezuela
FJ	Fiji	NC	New Caledonia	VN	Viet Nam
FI	Finland	NZ	New Zealand	VG	Virgin Islands, British
FR	France	NI	Nicaragua	VI	Virgin Islands, U.S.
GF	French Guiana	NE	Niger	WF	Wallis and Futuna

Code	Country	Code	Country	Code	Country
PF	French Polynesia	NG	Nigeria	EH	Western Sahara
TF	French Southern Territories	NU	Niue	YE	Yemen
GA	Gabon	NF	Norfolk Island		Zaire - see Congo, The Democratic Republic of the
GM	Gambia	MP	Northern Mariana Islands	ZM	Zambia
GE	Georgia	NO	Norway	ZW	Zimbabwe
DE	Germany	OM	Oman		

Table T-1: Region Country Codes

Appendix U

Graphics Display Icon Key

Display Size		Description					
Large	Small	Description					
	$\mathbf{\mathcal{G}}$	Initialization, typically brief (but a damaged or invalid printhead can delay the process).					
		Display large fonts; see Section 4.1.2.					
DI	2	Input Mode – DPL; see Section 4.2.4.					
	NE	Input Mode – LINE; see Section 4.2.4.					
PL	-Z)	Input Mode – PL-Z; see Section 4.2.4.					
RF	ID	RFID detected.					
S	D	SD memory card detected.					
	SB	USB memory (or keyboard) detected.					
₽ ₽ ₽		Wired network detected.					
- 191		Server inaccessible.					
P		WLAN associated with Access Point.					
₽₽ ₽₽		WLAN not associated with Access Point.					
Q		WLAN ADHOC Mode.					
		Receiving data.					
STOP	• *	Paused.					
		Faulted, see Section 6.1.2.					

*LED

Control Panel Button Sequences

Three Button / Three LED Control Panel				
Function	Printer Mode	Button Sequence		
Pause	Idle	PAUSE		
Feed / Clear Fault	Idle	FEED		
Cancel	Idle	CANCEL		
Soft Reset	Idle	PAUSE & CANCEL (or Long CANCEL)		
Print Test Label	Idle	PAUSE & FEED		
Print Configuration Label	Idle	FEED & CANCEL		
Print Network Label	Idle	PAUSE, FEED, & CANCEL		
Quick Calibration	Idle	Long FEED		
Empty Calibration	Idle	Long PAUSE & FEED		
Media Calibration	*	CANCEL		
Reset Database to Configuration File	*	PAUSE & FEED		
Menu / Setup	*	PAUSE		
Reset firmware (but not Ethernet parameters)	*	PAUSE, FEED, & CANCEL		
Reset firmware (and Ethernet parameters)	*	FEED & CANCEL		
Hex Dump Mode	Power-Up	Hold FEED		
Enter Boot Mode	Power-Up	Hold PAUSE & CANCEL		

*Power "On" the printer then when the LEDs illuminate press and hold indicated the Button Sequence until the LEDs extinguish.

Seven Button Control Panel				
Function	Printer Mode	Button Sequence		
Pause	Idle	PAUSE		
Feed / Clear Fault	Idle	FEED		
Cancel	Idle	CANCEL		
Soft Reset	Idle	PAUSE & CANCEL (or Long CANCEL)		
Print Test Label	Idle	PAUSE & FEED		
Print Configuration Label	Idle	FEED & CANCEL		
Print Network Label	Idle	PAUSE, FEED, & CANCEL		
RFID Calibration	Idle	Long FEED & TEST		
Quick Calibration	Idle	Long FEED		
Empty Calibration	Idle	Long PAUSE & FEED		
Menu / Setup	Idle	MENU		
Reset Database to Configuration File	Power-Up	PAUSE & FEED		
Reset Firmware (but not Ethernet parameters)	Power-Up	Hold PAUSE, FEED, & CANCEL		
Reset Firmware (and Ethernet parameters)	Power-Up	Hold FEED & CANCEL		
Hex Dump Mode	Power-Up	Hold FEED		
Enter Boot Mode	Power-Up	Hold PAUSE & TEST (or PAUSE & CANCEL)		
Display Magnification	Idle	DOWN ARROW		

Appendix V

Bar Code Symbology Information Resources

American National Standards Institute (ANSI) 1819 L Street, NW

Washington, DC 20036 USA Phone: 202-293-8020 Fax: 202-293-9287 http://www.ansi.org/

Association for Automatic Identification and Mobility, Inc.

125 Warrendale-Bayne Road Warrendale, PA 15086 USA Phone: 724-934-4470 Fax: 724-934-4495 http://www.aimglobal.org/

Automotive Industry Action Group

26200 Lahser Rd., Suite 200 Southfield, MI 48034-7100 USA Phone: 248-358-3570 Fax: 248-358-3253 http://www.aiag.org/

Computing Technology Industry Association

1815 S. Meyers Road, Suite 300 Oakbrook Terrace, IL 60181-5228 USA Phone: 630-678-8300 Fax: 630-268-1384 http://www.comptia.org/

GS1 (International Article Numbering Association) Blue Tower Avenue Louise 326 - Bte 10 1050 Brussels - Belgium Phone: 32(0)2-788 78 00 Fax: 32(0)2-788 78 99 http://www.gs1.org/

Health Industry Business Communications Council (HIBCC)

2525 E Arizona Biltmore Circle, Suite 127 Phoenix, Arizona 85016 USA Phone: 602-381-1091 Fax: 602-381-1093 http://www.hibcc.org/

Uniform Code Council, Inc.

7887 Washington Village Drive, Suite 300 Dayton, OH 45459 USA Phone: 937-435-3870 Fax: 937-435-7317 http://www.uc-council.org/

U.S. Government Printing Office

732 North Capitol St. NW Washington, DC 20401 USA Phone: 202.512.0000 Fax: 202-512-1293 http://www.gpo.gov/

Glossary

alphanumeric Consisting of alphabetic, numeric, punctuation and other symbols.

- **backing material** The silicon-coated paper carrier material to which labels with adhesive backing are affixed. Also referred to as "liner".
- **bar code** A representation of alphanumeric information in a pattern of machine-readable marks. The basic categories are divided into one-dimensional (UPC, Code 39, Postnet, etc.) and two-dimensional bar codes (Data Matrix, MaxiCode, PDF417, etc.).
- **boot loader** The resident program that loads the application from Flash memory, decompresses it into the DRAM, and starts operations.
- **burn line** The row of thermal elements in the print head.
- **calibration** The process through which Media Sensor readings are entered into the printer for correct sensor function (for example, detection of a given media type) and top of form positioning.
- character set The entire complement of alphanumeric symbols contained in a given font.
- **checksum** An alphanumeric error detection method used in many bar code symbologies for informational security.
- **continuous media** An uninterrupted roll or box of label or tag stock media that contains no gap, slit, notch, or black mark to separate individual labels or tags.
- **cutter** A mechanical device with a rotary or guillotine type blade used to cut labels or tags following printing.
- **defaults** The functional setting values returned following a factory reset of the printer.
- diagnostics Programs used to locate and diagnose hardware problems.
- **die-cut media** Media that has been cut into a pattern using a press, where the excess paper is removed leaving individual labels, with gaps between them, attached to a backing material.
- **direct thermal** The printing method that uses a heat sensitive media and only the heat of the thermal print head to create an image on the label.
- **direct thermal media** Media coated with special chemicals that react and darken with the application of heat.
- **DPI (dots per inch)** A measurement of print resolution, rated in the number of thermal elements contained in one inch of the print head. Also referred to as "resolution."

DPL (Datamax-O'Neil Programming Language) programming commands used specifically for control of and label production in Datamax-O'Neil printers.

fan-fold Media that is folded and stacked.

- **feed speed** The rate at which the media moves under the print head in non-printed areas or when the FEED Key is pressed.
- **Flash memory** Non-volatile memory (does not require printer power to maintain data) that can be erased and reprogrammed, used to hold the printer's operating program.
- font A set of alphanumeric characters that share a particular typeface.
- gap A space between die-cut or notched labels used to sense the top-of-form.
- **IPS (inches per second)** Imperial measurement of printer speeds.
- **label** A paper or synthetic printing material, typically with a pressure sensitive adhesive backing.
- **label length** The distance from the top of the label to the bottom of the label as it exits the printer.
- label repeat The distance from the top of one label to the top of the next label.
- **label tracking** Excessive lateral (side to side) movement of the media as it travels under the print head.
- label width The left to right measurement of the label as it exits the printer.
- **media** Generalized term for all types of printing stocks, including: roll fed, continuous, butt-cut, die-cut, reflective, and fanfold.
- media hub Device in the printer used to support roll media.
- **media sensor** An electronic device equipped with photosensors to detect media and the top-of-form on die-cut, notched or reflective media.
- MMPS (millimeters per second) Metric measurement of printer speeds.
- **notched stock** Media, typically tag stock, with holes or notches in the material that is used to signal the top-of-form. The printer must be set to "gap" to use this media type.
- **perforation** Small cuts extending through the backing and/or label material to facilitate their separation. Also referred to as "perf".
- preprinted media Label stock that contains borders, text, or graphics, floodcoating, etc.
- **present sensor** An electronic sensor that provides a signal to the printer firmware that a label is present, typically located beyond the print head, where the labels exits the printer.

- **print speed** The rate at which the media moves under the print head during the printing process.
- **reflective media** Media imprinted with carbon-based black marks on the underside of the material, which is used to signal the top-of-form when the "reflective" Media Sensor is enabled.
- **registration** Repeatable top to bottom alignment of printed labels.
- **reverse speed** The backward rate of media motion into the printer during tear-off, peel and present and cutting operations for positioning the label at the start of print position.
- **ribbon** An extruded polyester tape with several layers of material, one of which is ink-like, used to produce an image on the label. Also referred to as "foil".
- **roll media** A form of media that is wound upon a cardboard core.
- **slew** The moving of media using the GPIO function.
- start of print The position on the label where the printing actually begins.
- **tag stock** A heavy paper or synthetic printing material, typically featuring a notch or black mark for top of form and no adhesive backing.
- **thermal transfer** The printing method that creates an image by transferring ink from a ribbon onto the media using the heat from the thermal print head.
- **TOF (top-of-form)** The start of a new label as indicated by a label gap, notch, mark or programming.