### Honeywell



## Model 1104 to 1107

# Standard Rotating Shaft Torque Sensor

### **DESCRIPTION**

A line of rotary slip ring torque sensors primarily designed for a multitude of general test and measurement applications, such as motor testing. Can be used to monitor start up, running, and stall torque levels. Capacity range from 100 in-lb to 100000 in-lb for shaft mounting configurations.

### **FEATURES**

- 100 in-lb to 100000 in-lb capacity range
- 0.1 % non-linearity and hysteresis
- Manual brush lifter (standard)
- Speed sensor and/or foot mount options
- Lower cost for general "in-line" applications
- Can be used with almost all existing dc and ac signal conditioning instrumentation

### Model 1104 to 1107

### PERFORMANCE SPECIFICATIONS

Characteristic	Measure				
Torque range	100 lb-in to 3000K lb-in				
Non-linearity	±0.1 % of rated output				
Hysteresis	±0.1 % of rated output				
Repeatability	±0.05 % of rated output				
Output @ rated capacity	±2 mV/V (nominal)				


### **ENVIRONMENTAL SPECIFICATIONS**

Characteristic	Measure				
Temperature, operating	-29 °C to 93 °C [-20 °F to 200 °F]				
Temperature, compensated	21 °C to 77 °C [70 °F to 170 °F]				
Temperature effect, zero	±0.002 % of rated output/°F				
Temperature effect, output	±0.002 % of reading/°F				

### **ELECTRICAL SPECIFICATIONS**

Characteristic	Measure				
Excitation (maximum)	20 Vdc or Vac RMS				
Insulation resistance	> 5000 mOhm @ 50 Vdc				
Bridge resistance	350 ohm (nominal)				
Number of bridges	1				
Zero balance	±1.0 % of rated output				
Electrical termination	MS-3102E-14S-5P				

### TYPICAL SYSTEM DIAGRAM



\* XX represents length in feet 100ft maximum \*\* XX represents length in feet 20ft maximum

## Honeywell


## Standard Rotating Shaft Torque Sensor

### **MECHANICAL SPECIFICATIONS**

Model	lb-in	N-m	Max speed RPM	Overload capacity (% of nominal capacity)	Torsional stiffness lb-in/rad	Rotating inertia lb-in sec <sup>2</sup>	Weight (lb)
1104	100	10	9000	150	6430	3.93 x 10 <sup>-3</sup>	11
1104	200	20	9000	150	17000	3.96 x 10 <sup>-3</sup>	11
1104	500	55	9000	150	45200	4.11 x 10 <sup>-3</sup>	11
1104	1000	115	9000	150	103000	4.11 x 10 <sup>-3</sup>	11
1104	2000	225	9000	150	182500	4.14 x 10 <sup>-3</sup>	11
1105	5000	565	8500	150	475000	9.29 x 10 <sup>-3</sup>	28
1105	10000	1130	8500	150	750000	1.06 x 10 <sup>-2</sup>	28
1106	20000	2250	4500	150	2610000	3.93 x 10 <sup>-2</sup>	42
1107	50000	5650	4000	150	7220000	0.14	74
1107	100000	11300	4000	150	12450000	0.15	74

### **MOUNTING DIMENSIONS**

Model	C	L	N	P	U	K	A	B	D	E	F	H
	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]
1104 (100	25,40	14,76	5,32	10,16	1,91	0,46 sq.	12,07	8,89	5,40	5,08	3,49	0,71
lb to 200 lb)	[10]	[5.81]	[2.09]	[4]	[0.75]	[0.18 sq]	[4.75]	[3.50]	[2.13]	[2.0]	[1.38]	[0.28]
1104 (> 200	25,40	14,76	5,32	10,16	2,54	0,64 sq.	12,07	8,89	5,40	5,08	3,49	0,71
lb)	[10]	[5.81]	[2.09]	[4]	[1.0]	[0.25 sq.]	[4.75]	[3.50]	[2.13]	[2.0]	[1.38]	[0.28]
1105	32,39	18,42	6,99	11,99	3,81	0,95 sq.	16,51	10,16	6,35	6,67	3,81	1,03
	[12.75]	[7.25]	[2.75]	[4.72]	[1.50]	[0.38 sq.]	[6.25]	[4]	[2.50]	[2.63]	[1.50]	[0.41]
1106	37,15 [14.63]	17,46 [6.88]	9,84 [3.88]	13,47 [5.50]	5,72 [2.25]	1,27 sq. [0.50 sq.]	18,42 [7.25]	13,34 [5.25]	7,62 [3]	7,62 [3]	5,08 [2]	1,35 [0.53]
1107	48,26 [19]	19,05 [7.5]	14,61 [5.75]	16,51 [6.50]	7,62 [3.0]	1,91 sq. [0.75 sq.]	21,59 [8.50]	13,97 [5.50]	8,89 [3.50]	8,89 [3.50]	5,08 [2]	1,35 [0.53]



### Model 1104 to 1107

#### Find out more

Honeywell serves its customers through a worldwide network of sales offices, representatives and distributors. For application assistance, current specifications, pricing or name of the nearest Authorized Distributor. contact your local sales office. To learn more about Honeywell's test and measurement products, call +1-614-850-5000, visit http://measurementsensors.

Sensing and Control Honeywell 1985 Douglas Drive North Golden Valley, MN 55422 USA

honeywell.com, or e-mail inquiries to info.tm@honeywell.com

honeywell.com

### Standard Rotating Shaft Torque Sensor

Warranty. Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.



### **WARNING**

#### **PERSONAL INJURY**

• DO NOT USE these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury.

Failure to comply with these instructions could result in death or serious injury.



### **A** WARNING

### **MISUSE OF DOCUMENTATION**

- The information presented in this datasheet is for reference only. DO NOT USE this document as product installation information.
- Complete installation, operation and maintenance information is provided in the instructions supplied with each product.

Failure to comply with these instructions could result in death or serious injury.

