

Model 1228/1248

Flange Drive Torque Sensor





DESCRIPTION

A line of flange-drive, rotary slip ring torque sensors primarily designed for a multitude of general test and measurement applications, such as drive line testing. Can be used to monitor start up, running, and stall torque levels. Capacity range from 2000 in-lb to 20000 in-lb.

FEATURES

- 2000 in-lb to 20000 in-lb capacity
- 0.15 % non-linearity and hysteresis
- Short drive length
- High stiffness for increased frequency response

Model 1228/1248

PERFORMANCE SPECIFICATIONS

Characteristic	Measure			
Torque range 1228 1248	2000, 5000, 10000 lb-in 20000 lb-in			
Non-linearity	±0.15 % of rated output			
Hysteresis	±0.15 % of rated output			
Repeatability	±0.05 % of rated output			
Output @ rated capacity	±2 mV/V (nominal)			


ENVIRONMENTAL SPECIFICATIONS

Characteristic	Measure		
Temperature, operating	-29 °C to 93 °C [-20 °F to 200 °F]		
Temperature, compensated	21 °C to 77 °C [70 °F to 170 °F]		
Temperature effect, zero	±0.002 % of rated output/°F		
Temperature effect, output	±0.002 % of reading/°F		

ELECTRICAL SPECIFICATIONS

Characteristic	Measure			
Excitation (maximum)	20 Vdc or Vac RMS			
Insulation resistance	> 5000 mOhm @ 50 Vdc			
Bridge resistance	350 ohm (nominal)			
Number of bridges	1			
Zero balance	±1.0 % of rated output			
Electrical termination	MS3102E-14S-5P			

TYPICAL SYSTEM DIAGRAM



Honeywell


Flange Drive Torque Sensor

MECHANICAL SPECIFICATIONS

Model	lb-in	N-m	Max speed RPM	Overload capacity (% of nominal capacity)	Torsional stiffness lb-in/rad	Rotating inertia lb-in sec ²	Weight (lb)
1228	2000	225	5000	150	1035000	1.13 x 10 ⁻²	8
1228	5000	565	5000	150	2141000	1.14 x 10 ⁻²	8
1228	10000	1130	5000	150	2820000	1.19 x 10 ⁻²	8
1248	20000	2250	5000	150	4657000	4.02 x 10 ⁻²	17

MOUNTING DIMENSIONS

Model	C cm [in]	N cm [in]	P cm [in]	F cm [in]	J cm [in]	U cm [in]	H cm [in]	A cm [in]
1228	8,41 [3.31]	0,95 [0.38]	12,22 [4.81]	7,94 [3.13]	[1/4-28]	8,89 [3.50]	0,32 [0.13]	n/a
1248	10,95 [4.31]	1,43 [0.56]	14,30 [5.63]	9,21 [3.63]	[3/8-24]	10,80 [4.25]	0,79 [0.31]	n/a



For reference only

Model 1228/1248

Flange Drive Torque Sensor

Warranty. Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.



WARNING

PERSONAL INJURY

• DO NOT USE these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury.

Failure to comply with these instructions could result in death or serious injury.



A WARNING

MISUSE OF DOCUMENTATION

- The information presented in this datasheet is for reference only. DO NOT USE this document as product installation information.
- Complete installation, operation and maintenance information is provided in the instructions supplied with each product.

Failure to comply with these instructions could result in death or serious injury.

Find out more

Honeywell serves its customers through a worldwide network of sales offices, representatives and distributors. For application assistance, current specifications, pricing or name of the nearest Authorized Distributor. contact your local sales office. To learn more about Honeywell's test and measurement products, call +1-614-850-5000, visit

http://measurementsensors. honeywell.com, or e-mail inquiries to info.tm@honeywell.com

Sensing and Control Honeywell 1985 Douglas Drive North Golden Valley, MN 55422 USA

