

HCFC Air Conditioning Retrofit Guidelines

HCFC-22 to Genetron[®] 422D

Safety Tips

1. Never mix refrigerants in a refrigeration system or recovery cylinder. Any refrigerant mixing creates a non-reclaimable mixture that will cost you or your customer more money in disposal fees.
2. Never leak-test a system using air, oxygen or other oxidizing materials. When combined with HFCs and HFC/Hydrocarbon Blends under pressure, these mixtures can become combustible.
3. Always read the label and Material Safety Data Sheet (MSDS) before working with the refrigerant(s).
4. Never “top-off” a system with a refrigerant other than what is already in that system. If you aren’t sure what’s in a system, either recover the full charge or have the refrigerant tested.
5. Always make sure systems you work on are properly labeled with the refrigerant and oil when you leave.
6. Do not store refrigerant cylinders in direct sunlight or in areas where temperatures could exceed 125° F or 51.7° C.
7. Keep smaller cylinders from becoming a rolling hazard by keeping them in their cartons while storing or transporting them.
8. Always recover the contents of non-refillable refrigerant cylinders to 0 psig or less before disposing of them. Whenever possible, recycle non-refillable cylinders at a local metal recycling center or scrapyard.

Table of Contents

Introduction.....	3
Genetron® HFC Refrigerants	3
Genetron 422D is a Replacement	3
Retrofit Procedure.....	4, 5, 6, 7
Retrofit Checklist.....	8
Genetron Temperature/Pressure Tables	9

Preface

HCFC-22 is a high capacity, efficient refrigerant employed in a significant number of air conditioning systems. The majority of these systems utilize mineral oil lubricants. Due to the phase-out of HCFCs, facility owners are considering retrofitting their mechanical systems to alternative refrigerant blends. The selection of a retrofit fluid depends, in part, upon retrofit objectives that may include factors such as efficiency, first cost, global warming potential and capacity. By following equipment manufacturer's recommendations and Honeywell's guidelines outlined in this publication, service technicians can readily retrofit many existing air conditioning systems to Genetron 422D.

Introduction

As the air conditioning industry continues to move away from the use of HCFCs, refrigerant service personnel will play a key role in the transition to HFC alternatives through retrofitting. Honeywell has produced this guide to help service technicians better understand the various technical and operational aspects of carrying out retrofit procedures using Honeywell Genetron® 422D.

Although this information can be helpful as a general guide, it should not be used as a substitute for the equipment manufacturer's specific recommendations. Also, retrofitting should be considered system specific. Since systems can differ in condition and configuration, retrofit actions applied to one system will not necessarily result in the same level of success in another system.

For this reason, Honeywell strongly recommends contacting the equipment manufacturer for detailed information on retrofitting the specific model under consideration. Also, refer to the Material Safety Data Sheet (MSDS) for safety information on the specific Genetron® refrigerant you will use.

Genetron HFC Refrigerants

Genetron 422D is an HFC refrigerant and is not scheduled for phaseout under current law. Descriptive information including refrigerant type, ASHRAE number, constituents and applications appear in the table below.

Genetron Refrigerant	Type	Replaces	Applications	Comments
R-422D 125/134a/600a	Blend	HCFC-22	Unitary Air Conditioning Chillers without flooded heat-exchangers	Use of POE oil will enhance oil return, if required

Genetron 422D is a replacement

Genetron 422D is an HFC-based refrigerant. The mass flow differences as well as the slightly different operating pressures should be evaluated. Check with the compressor manufacturer to determine if the existing lubricant is acceptable. The retrofit procedures listed here have been developed by Honeywell to address these issues and to help technicians perform successful retrofits of HCFC-22 systems utilizing positive-displacement (reciprocating, rotary and scroll) compressors.

Retrofit Procedures

In retrofitting an existing air conditioning system, material compatibility and the condition of the existing seals and gaskets must be taken into account. It is recommended to change any O-rings, seals and other elastomers used in the system, (as expected in any retrofit to HFC). In most air conditioning and heat pump systems this only applies to the Schrader valve seal and cap seal material.

1. Record Baseline Data

Before making any hardware changes, compare current system operating data with normal operating data. Correct any deficiencies and record final data as a performance baseline. Data should include temperature and pressure measurements throughout the system including the evaporator, compressor suction and discharge, condenser and expansion device. These measurements will be useful when adjusting the system with an alternative refrigerant.

2. Isolate R-22 Refrigerant Charge

The HCFC refrigerant charge should be removed from the system using an approved recovery machine capable of meeting or exceeding the required levels of evacuation. The charge must be collected in a recovery cylinder.

DO NOT VENT THE REFRIGERANT

Knowing the recommended R-22 refrigerant charge size for the system is helpful. If it is not known, weigh the entire amount of refrigerant removed. This amount can be used as a guide for the initial quantity of alternative Honeywell refrigerant to be charged to the system.

3. Choose Compressor Lubricant

In most instances, the lubricant in use with R-22 is mineral oil or alkyl benzene. Genetron 422D retrofit of a system with short connecting lines typically will not require an oil change or modification. Honeywell recommends using a miscible lubricant approved by the compressor manufacturer. Differences among lubricants make it difficult to assume that they are interchangeable. Check with the compressor manufacturer for the correct viscosity grade and brand for the compressor in the system being retrofitted. If the lubricant is contaminated or an acid test indicates high levels of acidity, then a lubricant change is warranted.

Field trials have indicated that a simple HVAC system will work with 100% mineral oil. On more complex systems oil return can be enhanced by adding 15% -20% synthetic POE oil. Systems with receivers or low-side accumulators (heat pumps) will require a higher ratio of POE to mineral oil.

4. Evaluate the Expansion Device and relief valves

Honeywell recommends consulting with the equipment manufacturer before retrofitting. Most HCFC-22 A/C systems with either expansion valves or capillary tubes will operate satisfactorily with Genetron 422D.

When retrofitting from R-22 to R-422D the relief valve size (if equipped) may need to be increased.

Please refer to manufactures literature for sizing guidelines. Honeywell does recommend replacing the relief valves in any case to ensure they are in good working order.

	R-422D
Expansion Valve G Valve	No adjustment anticipated
Capillary Tube	Need to optimize charge superheat@ evaporator outlet to prevent liquid floodback (compressor)

5. Replace the Filter Drier

Following system maintenance, a recommended service practice is to replace the filter drier. There are two types of filter driers commonly used in refrigeration equipment: loose-fill and solid-core.

Check with your wholesaler to make sure the replacement filter drier is compatible with the Honeywell refrigerant being used.

When changing to an HFC-miscible lubricant, particularly to a more polar lubricant such as polyol ester, it may be beneficial to add a suction line filter.

6. Reconnect the System and Evacuate

Use normal service practices to reconnect and evacuate the system. To remove air and other non-condensables, Honeywell recommends evacuating the system to a full vacuum of 1,000 microns or less from both sides of the system. However, attempting to evacuate a system with the pump connected only to the low-side of the system will not adequately remove moisture and non-condensables such as air. Use a good electronic gauge to measure the vacuum. An accurate reading cannot be made with a refrigeration gauge.

7. Check the System for Leaks

Check the system for leaks using normal service practices.

8. Charge System with Genetron HFC Refrigerant

When replacing HCFC-22 with Genetron® 422D, use the same charging procedures that you would use for the refrigerant being replaced. When working with Genetron 422D it is important to remember that these are blend refrigerants. It is essential that blend refrigerants be charged by removing only liquid from the cylinder. A throttling valve should be used to control the flow of refrigerant to the suction side to ensure that the liquid is converted to vapor prior to entering the system.

NOTE: *To prevent compressor damage, do not charge liquid into the suction line of the unit.*

Never vapor charge the system with vapor from a 400-series refrigerant cylinder. Vapor-charging may result in the wrong refrigerant composition and could damage the system.

Systems being charged with Genetron 422D require a slightly smaller charge size than HCFC-22.

For expansion valves or optimized capillary tube systems, the typical charge size relative to the HCFC-22 being replaced appears below.

Relative Charge Size		
Genetron Refrigerant	HCFC-22	100%
422D		4% - 5% less

As part of general procedure, Honeywell recommends initially charging the system with 85 percent by weight of the original system charge and then adding refrigerant as necessary in 5% increments to obtain equal baseline performance.

9. Check System Operation

Start the system and allow conditions to stabilize. If the system is undercharged, add refrigerant in increments of 5 percent by weight of the original charge. Continue until desired operating conditions are achieved.

It may be necessary to reset the pressure cutouts to compensate for the different pressures of the replacement refrigerant. This procedure should be done carefully to avoid exceeding the recommended operating limits of the compressor and other system components. The use of an unoptimized capillary tube will make the system more sensitive to charge and/or operating conditions. As a result, system performance will change more quickly if the system is overcharged (or undercharged). To avoid overcharging, it is best to charge the system by first measuring the operating conditions (including discharge and suction pressures, suction line temperature, compressor amps, superheat) instead of using the liquid line sight glass as a guide.

For blend refrigerants, pressure-temperature data will include bubble pressure and dew pressure data. To determine superheat, use the dew pressure column. To determine subcooling, use the bubble pressure column. To find average evaporating or condensing temperature, find the measured pressure in both the bubble and dew columns and take the average of the two corresponding temperatures.

10. Label Components and System

After retrofitting the system with Genetron® 422D, label the system components to identify the specific refrigerant and specify the type of lubricant (by brand name) in the system. This will help ensure that the proper refrigerant and lubricant will be used to service the equipment in the future.

Unit Charge labels are available through your Honeywell Refrigerants wholesaler.

Recommended Retrofit Checklist

<p>1. Record baseline data on original system performance.</p>	<input type="checkbox"/>	<p>11. Evaluate and replace all elastomer seals including Schrader valves.</p>	<input type="checkbox"/>
<p>2. Recover refrigerant charge using appropriate recovery equipment.</p>	<input type="checkbox"/>	<p>12. Replace filter driers and suction filters.</p>	<input type="checkbox"/>
<p>3. Record the amount of refrigerant recovered.</p>	<input type="checkbox"/>	<p>13. Leak check the system.</p>	<input type="checkbox"/>
<p>4. Choose compressor lubricant. Consult the compressor manufacturer's data to verify that the same synthetic grade and weight is suitable for use with R-422D.</p>	<input type="checkbox"/>	<p>14. Evacuate the system.</p>	<input type="checkbox"/>
<p>5. R-422D: Use of POE will enhance oil return if required.</p>	<input type="checkbox"/>	<p>15. Charge the system with the new refrigerant. In the case of R-422D remove only liquid from the charging cylinder.</p>	<input type="checkbox"/>
<p>6. If required, drain the existing lubricant from the compressor's separators and oil reservoirs.</p>	<input type="checkbox"/>	<p>16. Initial charge should be approximately 85% of the R-22 charge by weight record the amount of refrigerant charged.</p>	<input type="checkbox"/>
<p>7. Measure amount (volume) of lubricant removed.</p>	<input type="checkbox"/>	<p>17. Check system operation and adjust operating controls. The discharge pressure of R-422D is slightly higher and condenser fan and ambient controls may require adjustment.</p>	<input type="checkbox"/>
<p>8. Change lubricant filters if present.</p>	<input type="checkbox"/>	<p>18. Adjust refrigerant charge if necessary in increments of 5 percent of original charge weight.</p>	<input type="checkbox"/>
<p>9. Recharge the system with polyol ester lubricant, use the same amount (volume) that was removed.</p>	<input type="checkbox"/>	<p>19. Label components and the system with the type of refrigerant and lubricant.</p>	<input type="checkbox"/>
<p>10. Evaluate the expansion devices: consult the valve manufacturers for recommendations. No change is necessary in most cases.</p>	<input type="checkbox"/>		

Genetron® 422D

Compatibility: Plastics and Elastomers

Neoprene (Chloroprene)	S
EPDM	S
Butyl Rubber	D

S: Suitable D: Suitability dependent on formulation

Honeywell Refrigerants Pressure-Temperature Charts

Pressure (psig)	Genetron 422D			Genetron 22
	Temperature (°F)			Temperature (°F)
	Average	Bubble	Dew	
0	-41.4	-45.8	-37.0	-41.5
10	-20.8	-24.8	-16.7	-20.4
20	-5.9	-9.7	-2.1	-5.2
30	5.9	2.3	9.6	6.9
40	15.9	12.4	19.4	17.1
45	20.4	17.0	23.8	21.7
50	24.6	21.2	27.9	26.0
55	28.5	25.2	31.8	30.0
60	32.3	29.0	35.5	33.9
65	35.9	32.7	39.1	37.5
70	39.3	36.1	42.4	41.0
75	42.5	39.4	45.6	44.3
80	45.6	42.6	48.7	47.5
85	48.6	45.6	51.6	50.6
90	51.5	48.5	54.5	53.5
95	54.3	51.4	57.2	56.4
100	57.0	54.1	59.9	59.1
105	59.6	56.7	62.4	61.8
115	64.6	61.8	67.4	66.9
125	69.3	66.6	72.0	71.7
135	73.7	71.1	76.4	76.2
145	78.0	75.4	80.5	80.6
155	82.0	79.5	84.5	84.7
165	85.9	83.4	88.3	88.7
175	89.6	87.2	92.0	92.5
185	93.2	90.8	95.5	96.2
195	96.6	94.3	98.9	99.7
205	99.9	97.7	102.1	103.1
210	101.5	99.3	103.7	104.8
215	103.1	100.9	105.3	106.4
220	104.7	102.5	106.8	108.0
225	106.2	104.1	108.4	109.6
230	107.7	105.6	109.8	111.1

Pressure (psig)	Genetron 422D			Genetron 22
	Temperature (°F)			Temperature (°F)
	Average	Bubble	Dew	
235	109.2	107.1	111.3	112.7
240	110.7	108.6	112.8	114.2
245	112.1	110.1	114.2	115.7
250	113.6	111.5	115.6	117.1
255	115.0	113.0	117.0	118.6
260	116.3	114.4	118.3	120.0
265	117.7	115.8	119.7	121.4
270	119.1	117.1	121.0	122.8
275	120.4	118.5	122.3	124.2
280	121.7	119.8	123.6	125.5
285	123.0	121.2	124.9	126.9
290	124.3	122.5	126.1	128.2
295	125.6	123.7	127.4	129.5
300	126.8	125.0	128.6	130.8
305	128.0	126.3	129.8	132.1
310	129.3	127.5	131.0	133.3
315	130.5	128.7	132.2	134.6
320	131.7	130.0	133.4	135.8
325	132.8	131.1	134.5	137.0
330	134.0	132.3	135.6	138.2
335	135.1	133.5	136.8	139.4
340	136.3	134.7	137.9	140.6
345	137.4	135.8	139.0	141.8
350	138.5	137.0	140.1	142.9
355	139.6	138.1	141.2	144.1
360	140.7	139.2	142.2	145.2
365	141.8	140.3	143.3	146.3
370	142.8	141.4	144.3	147.5
375	143.9	142.5	145.4	148.6

HCFC-22 For Reference

Worldwide Sales Offices

United States

Honeywell International
115 Tabor Road
Morris Plains, NJ 07950
Phone: 800-631-8138

Latin America/Caribbean

Honeywell Chemicals Mexico
Constituyentes 900
Col. Lomas Atlas
C.P. 950, Mexico DF
Mexico
Phone: 52-55-5549-0303
Fax: 52-55-5544-9803

Canada

Honeywell Asca. Inc.
3333 Unity Drive
Mississauga, Ontario
L5L 3S6
Phone: 905-608-6325
Fax: 905-608-6327

Asia-Pacific

Honeywell (China) Co., Ltd.
No 430, Li Bing Road
Zhang Jiang Hi-Tech Park
Pudong New Area, Shanghai 201203
China
Phone: 86-21-2894-2000
Fax: 86-21-5855-2719

Honeywell Japan Inc.
New Pier Takeshiba
South Tower Building, 20th Floor
1-16-1 Kaigan, Minato-ku,
Tokyo 050022, Japan
Phone: 81-3-6730-7000
Fax: 81-3-6730-7221

Honeywell Chemicals, Korea
6F Janghakjaedan, B/D 44-1
Bangpo-Dong, Seocho-Ku
Seoul 137040, Korea
Phone: 8-22-595-0204
Fax: 8-22-595-4964

Honeywell Specialty Chemicals
(Singapore) Pte. Ltd.
17 Changi Business Park Central 1
Honeywell Building
Singapore 486073
Phone: 65-6355-2828
Fax: 65-6783-2947

Honeywell International
71 Queens Road,
Ground Floor
Melbourne, Victoria 3004
Australia
Phone: 61-3-9529-1411
Fax: 61-3-9510-9837

Northern and Central Europe

Honeywell Belgium NV
Haasrode Research Park
Grauwmeer 1
3001 Heverlee
Belgium
Phone: 32-16-391-212
Fax: 32-16-391-371

Southern Europe, Middle East and Africa

Honeywell Fluorine Products Italia Srl
V. Le Milanofiori El
20090 Assago - MI - Italia
Phone: 0039-02-89259601
Fax: 0039-02-57500815

Customer Service

To place an order from
anywhere in the Continental United
States, Hawaii
and the Caribbean:
Phone: 800-522-8001
Fax: 800-458-9073

Canada:
Phone: 800-553-9749
Fax: 800-553-9750

Northern and Central Europe
Phone: +32-16-391-209
Phone: +32-16-391-216
Fax: +32-16-391-235

Southern Europe,
Middle East and Africa
Phone: +39-02-9379-6777
ext. 24 / 25 and 26
Fax: +39-02-9379-6761

Outside these areas:
Phone: 1-973-455-6300
Fax: 1-973-455-2763

For more information:
www.honeywell-refrigerants.com

Honeywell Refrigerants
115 Tabor Road
Morris Plains, NJ 07950
Phone: 1-800-631-8138

Although Honeywell International Inc. believes that the information contained herein is accurate and reliable, it is presented without guarantee or responsibility of any kind and does not constitute any representation or warranty of Honeywell International Inc., either expressed or implied. A number of factors may affect the performance of any products used in conjunction with user's materials, such as other raw materials, application, formulation, environmental factors and manufacturing conditions among others, all of which must be taken into account by the user in producing or using the products. The user should not assume that all necessary data for the proper evaluation these products are contained herein. Information provided herein does not relieve the user from the responsibility of carrying out its own tests and experiments, and the user assumes all risks and liabilities (including, but not limited to, risks relating to results, patent infringement, regulatory compliance and health, safety and environment) related to the use of the products and/or information contained herein.

Genetron and Solstice are registered trademarks of Honeywell International Inc.



122 Ref v8 | September 2018
© 2018 Honeywell International Inc.

Honeywell