







Product Family 4000 Series Flat Fold Respirator (AS/NZS)

Individually packaged flat fold respirators for convenient pocket storage. The 4000 Series feature a Willtech boomerang seal and a colour coded nose bridge. Available for P1 or P2 protection.

Honeywell

Product Numbers & Ordering Information

	Product Numbers	Details
	1007716	4110 P1 flatfold, unvalved P1 flatfold disposable respirator, unvalved with yellow nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134
	1007717	4111 P1 flatfold, valved P1 flatfold disposable respirator, valved with yellow nose bridge. Willtech® boomerang seal. 1 box of 10. Certified to AS/NZS 1716:2012 Lic 1134
	1007718	4210 P2 flatfold, unvalved P2 flatfold disposable respirator, unvalved with green nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134
	1007720	4211 P2 flatfold, valved P2 flatfold disposable respirator, valved with green nose bridge. Willtech® boomerang seal. 1 box of 10. Certified to AS/NZS 1716:2012 Lic 1134

Additional Information

Available in P1 - For use against mechanically generated particulates and P2 - for use against mechanically and thermally generated particulates. Valved and unvalved versions available.

Overview

Key Features

Honeywell Flat Fold respirators provide workers with an alternative to the cup shape disposable respirator. Individually packaged, the flat fold respirator, as its name suggests, folds flat, making it easy and convenient to store in your pocket when not being used. Its unique fold and hold mechanism, prevents contamination between use. The flat fold has lower breathing resistance and encourages longer wear time by improving wearer comfort. No staples makes this product perfect for applications in the food industry.

Recommended Industries/Use

- Construction
- Fire Protection
- Food Services
- Forestry
- Government
- Manufacturing
- Medical
- Mining
- Municipal Services
- Oil and Gas
- Pharmaceutical
- Steel and Metals
- Utilities
- Welding

Hazards

- Airborne Particulates
- Contamination
- Fire
- Gas, Vapors, Smoke

Regulations

- Approved to AS/NZS 1716:2012 Lic 1134

Historical Brand

Willson, Sperian

Specifications

Seal

- Fitted with half-face seal (PES knit, PU foam, PU film).

Attachment Information

- Twin elastics attached outside of the filter media

Outer Shell

- 120g/m² polyester non-woven.

Filter Media

- Polypropylene non-woven fibers electrostatically loaded making them attractive to particles.

Nose Bridge

- Galvanised iron wire coated with polypropylene (contains no aluminium).

Weight

- 10g

Shelf Life

- 5 years from date of manufacture.

Literature & Documents

1007716 4110 4000 Series P1 AUSNZ

[http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_\(Disposable\)_Respirators/4294998815/1033.aspx](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998815/1033.aspx)

1007717 4111 4000 Series P1 with Valve AUSNZ

[http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_\(Disposable\)_Respirators/4294998816/1033.aspx](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998816/1033.aspx)

1007718 4210 4000 Series P2 AUSNZ

[http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_\(Disposable\)_Respirators/4294998817/1033.aspx](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998817/1033.aspx)

1007720 4211 4000 Series P2 with Valve AUSNZ

[http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_\(Disposable\)_Respirators/4294998818/1033.aspx](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998818/1033.aspx)

Training & Proper Use

Please review the instruction leaflet provided with the product, prior to use. Also refer to AS/NZS 1715 Selection, Use and Maintenance of Respiratory Devices.

Technical Support

Australia/New Zealand

Ph Aus: 1300 139 166

Ph NZ: 0800 322 200

Email: hlshspamarketing@Honeywell.com

RELATED PRODUCTS

© Honeywell International Inc.