



Produktfamilj

SmartFit Multiple-Use Earplug

Delivers superior comfort and a truly personalized fit



Product Numbers &



8030273

SMARTFIT BOX OF 2 PAIRS IN INDIVIDUAL STORAGE CASE - SNR 30 DB

Product emphasized in an effective packaging designed for a self-service environment.



1011239

SmartFit

SNR 30 H - 32 M - 27 L - 23

Översikt

Viktigaste egenskaperna

- Patented Conforming Material Technology uses body heat to adapt to the individual shape of each wearer's ear canal
- Delivers superior comfort and a truly individual fit
- Simplifies inventory control – a single product fits almost every wearer
- Detachable cord system and HearPack storage case

Rekommenderade branscher/rekommenderat användningsområde

- Jordbruk
- Kemi
- Byggingusti
- Brandskydd
- Skogsvård
- Myndigheter
- Polis

Risker

- Buller

Föreskrifter

- 29 CFR 1910.95 - OSHA Occupational Noise Exposure (US)
- ANSI S3.19-1974 - Attenuation Test Protocol (US)
- Part II, (R.S.C. 1985, c. L-2) - Canada Labour Code
- Z94.2-1994 - Attenuation Test Protocol (CAN)
- 2003/10/EC - EU Hearing Directive

- 89/686/EEC - EU Directive/PPE
- Category II - EC Category/PPE
- EN 352-2:2002 - EU Standards
- NOHSC: 1007 (2000) - National Standard for Occupational Noise (AUS/NZ)
- NR 15 - Security and Health of Work, Annexes 1 and 2, n°3.214/1978 - Occupational Noise Regulations (BR)
- ANSI S12.6/1997 - Method B - Attenuation Test Protocol (BR)

Tidigare varumärke

Howard Leight

Specifikationer

Color

- Orange

Shape

- 3 Flange

Material

- TPE

Packaging Options

- HearPack

Cord Options

- Detachable Nylon Cord

NRR

- 25

Canada Class

- A(L)

SNR

- 30

SLC80

- 20 dB / Class 3

EU Certifications

- European Directives – 89/686/EEC
- EC Category PPE – Category II
- Standards – EN 352-2:2002
- EC Certification Number – 1134
- EC Attestation Number – 030649; 040809 & 040950
- Laboratory – INSPEC

AUS Certifications

- Standardsmark License #1133/1

Certifieringarna

EU Certification Report - SmartFit

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_Protection/Earplugs/20056/1033.aspx

EU Certification Report - SmartFit

Trycksaker & dokument

SmartFit Multiple-Use Earplug

Instruction Manual - SmartFit, SmartFit Blue, Detectable, Process Industry (global)

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/4294986725/1033.aspx

Data Sheet Smartfit Earplug SMF-30A, SMF-30W-PA - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/15939/1033.aspx

<12\$%EktCertification12\$%> False ► ► ► SMARTFIT™ MULTIPLE USE EARPLUG PRODUCT INFORMATION Ears are like people, each one is unique and different. That is what makes SmartFit such a marvel of user-friendly design. SmartFit is the only multiple-use earplug with Conforming Material Technology™ providing the ultimate cust

Earplug Instruction Poster - EN

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/19799/1033.aspx

Earplug Instruction Poster - ES

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/19802/1033.aspx

Earplug Instruction Poster - FR

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/Earplugs/19800/1033.aspx

Noise Thermometer Poster - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/24933/1033.aspx

Earplug Fitting Poster - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/24934/1033.aspx

Care & Maintenance of Earplugs and Earmuffs - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection/24936/1033.aspx

Training & Proper Use

1. While holding the stem, reach a hand over your head and gently pull top of your ear up and back.
2. Insert the earplug so all flanges are well inside your ear canal.
3. If properly fitted, the tip of the earplug stem may be visible to someone looking at you from the front.
4. Proper Fit – If either or both earplugs do not seem to be fitted properly, remove the earplug and reinsert.
5. Removal – Gently twist earplug while slowly pulling in an outward motion for removal.
6. Acoustical Check – In a noisy environment, with earplugs inserted, cup your hands over your ears and release. Earplugs should block enough noise so that covering your ears with your hands should not result in a significant noise difference.

Ytterligere informasjon

CARE + MAINTENANCE

- INSPECT – Prior to fitting, examine your earplugs for dirt, damage, deformation or extreme hardness—discard immediately if compromised.
- CLEAN – Wash Multiple-Use earplugs with mild soap and warm water only. Pat dry with a towel and store in a case when not in use. Do not treat with any other substances, as the earplugs may degrade and compromise use.

SmartFit Multiple-Use Earplug

- HYGIENE – With proper maintenance, Multiple-Use earplugs can last for 2-4 weeks.

RELATERADE PRODUKTER

© Honeywell International Inc.