Honeywell

Application Note Honeywell Sensing and Control Flexible Heaters Meet Medical Industry Autoclave Requirements

Background

Honeywell Sensing and Control flexible heaters have been tested to meet standard steam autoclave sterilization practices commonly used in medical applications that utilize equipment such as respirators, ventilators, dialysis machines, infusion machines, sterilizers, nebulizers, and more. After multiple exposures to extreme steam temperatures and soakings, the flexible heaters continued to meet Honeywell's high performance standards for electrical integrity and functionality.

Key benefits:

- Customization: Honeywell's flexible heater line can be customized to meet any need, without worry of performance due to exposure to autoclave environments. Honeywell's design engineers create each flexible heater per customer requirements, taking into account such parameters as color, connector, lead wire exits, geometry, technical specifications, wattage zones, and autoclave requirements.
- **Simplicity:** No extra sterilization steps are required other than the standard autoclave, saving both time and costs.



Application Note

Honeywell Sensing and Control Flexible Heaters Meet Medical Industry Autoclave Requirements

Macro view of an autoclave's stainless steel basket.



The Test

Honeywell's flexible heaters were placed in a stainless steel basket and subjected to steam temperatures up to 132 °C at a pressure of 29 psi within a sealed autoclave. The heaters were soaked in this harsh condition for 30 minutes and then cooled to room temperature for 10 minutes. This process was repeated five times, on the same flexible heaters, to complete each test cycle.

Results

After the cycle was completed, the flexible heaters were tested for electrical integrity and functionality. All components performed within Honeywell's originally specified product parameters.

This same testing cycle was completed 50 times and the dielectric strength and insulation resistance (IR) of the flexible heaters was maintained after each cycle.

Industry Solutions

Honeywell Sensing and Control is committed to turning challenges into value-added solutions for customers within the medical industry, and customization and flexibility features have long defined Honeywell products.

"By confirming Honeywell flexible heaters meet customers' autoclave requirements, we are able to provide greater application flexibility in applications such as ventilators," said Robert Ward, Honeywell Sensing and Control application engineer. "For example, Honeywell heating assemblies can be custom fit to the exhalation valve cover to dry condensation and prevent pooling at the airflow sensing point. This helps to provide a more comfortable breathing environment for patients. It may also be used to warm water for delivering heated and humidified air to patients."

"Meeting the steam autoclave sterilization testing provides customers with the reassurance that Honeywell's flexible heating products are built to work and to last even during the harshest conditions."

More information on Honeywell's flexible heaters can be found at **sensing.honeywell.com** or by contacting Robert Ward, Honeywell S&C application engineer, at 401-739-1712.

Potential Applications

- Respiratory equipment
- Ventilator equipment
- Dialysis equipment
- Infusion equipment
- Sterilization equipment
- Nebulizers
- Paraffin wax bath heaters
- Blood analysis equipment

Find out more

Honeywell serves its customers through a worldwide network of sales offices, representatives and distributors. For application assistance, current specifications, pricing or name of the nearest Authorized Distributor, contact your local sales office. To learn more about Honeywell's sensing and control products, call **+1-815-235-6847 or 1-800-537-6945**, visit **sensing.honeywell.com**, or email inquiries to **info.sc@honeywell.com**

Sensing and Control Honeywell 1985 Douglas Drive North Golden Valley, MN 55422 honeywell.com Warranty. Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.



009079-1-EN IL50 GLO Printed in USA. July 2013 Copyright © 2013 Honeywell International Inc. All rights reserved.