www.firelite.com

July 12, 2004

DF-51267 • A3-200

# **MS-5024(E) Fire Alarm Control Panel** with built-in DACT

Section: Control/Communicators

### **GENERAL**

The Fire Lite MS-5024 is a 24-volt, five-zone fire alarm control panel with built-in communicator. The integral communicator transmits event information (alarms, troubles, supervisories, faults, etc.) to a UL-Listed central station. The MS-5024 may be used in a variety of cost-effective applications, including: local fire alarm control panel (communicator disabled), fire alarm control panel/communicator, stand-alone sprinkler supervisory communicator or slave communicator to a UL-Listed host fire alarm panel (requires N.O. dry contacts to trigger five channels). Selectable transmission formats allow the MS-5024 to communicate to virtually all central stations.

### **FEATURES**

- Five programmable Initiating Device Circuits (zones). Each zone may be programmed for:
  - ✓ Two-wire smoke detectors.
  - ✓ N.O. contact devices (pull, heat).
  - ✓ Four-wire smoke detectors.
  - ✓ Waterflow operation.
  - ✓ Supervisory operation.
  - ✓ Auto-reset supervisory operation.
- Two built-in, Class B (Style Y) Notification Appliance Circuits (NACs).
- Notification Appliance Circuits may be programmed:
  - ✓ Silenceable.
  - ✓ Non-Silenceable (a strobe circuit can keep flashing after the panel is silenced).
  - ✓ Auto-Silence (program 5 to 30 minutes).
  - ✓ Silence Inhibit (60 seconds).
  - ✓ Coding (March Time, Temporal, California).
- 3.0 Amps of Notification Appliance power.
- Two built-in, fully programmable, Form-C relays.
- Dual-line rotary- or Touch-Tone®-dial DACT interfaces to public telephone network (leased phone lines are not required).
- 24-Volt operation.
- · Built-in voltmeter measures:
  - ✓ Zone voltage.
  - ✓ Primary AC line voltage.
  - ✓ Battery voltage.
  - ✓ Notification Appliance Circuit(s) voltage.
  - ✓ Resettable 24-volt power.
- Surface Mount Technology (SMT).
- Fully programmable via built-in keypad (no costly external programmers necessary).
- Complies with NFPA 72 (Local, Central Station and Remote Station [DACT only — not polarity reversal] Fire Alarm Systems).



MEA 131-94-E



California State Fire Marshal 7165-0075:175

1W6USA-20004-AL-E

S624 (MS-5024. MS-5024E)



MS-5024

- · Reporting Formats include:
  - √ 3+1, 4+1, 4+2 Standard + Expanded.
  - √ 4+1, 4+2, Ademco Express.
- · Integral battery charger for up to 60 hours of standby power.
- Fuseless, power-limited technology meets UL power-limiting requirements.
- Programmable Alarm Presignal Timer, Alarm Verification Timer and Optional Trouble Reminder.
- Single-person walk test.
- · Fire drill function.
- · Zone disable capability (software).
- 32-Event history buffer with time and date stamp.
- · Accurate real-time clock.
- · Extensive built-in transient protection.
- Electronics and operational controls fully enclosed in lockable cabinet capable of housing batteries up to 7 AH.
- 230 VAC, 50 Hz international version available.

## Fire Lite® Alarms is a Honeywell company.

This document is not intended to be used for installation purposes. We try to keep our product information up-to-date and accurate. We cannot cover all specific applications or anticipate all requirements. All specifications are subject to change without notice.

For more information, contact Fire Lite Alarms, One Fire-Lite Place, Northford, Connecticut 06472. Phone: (800) 627-3473, Toll-Free FAX: (877) 699-4105.





## **SPECIFICATIONS**

- Single PC board design using Surface Mount Technology (SMT).
- Two modular telephone jacks for connection to RJ31X/ Modules.

#### **AC Power**

- 120 VAC, 50/60 Hz, 1.3 amps.
- 230 VAC, 50 Hz, 0.68 amps ("E" suffix).
- Wire size: minimum 14 AWG (2.0 mm²) with 600-volt insulation.
- · Built-in brownout circuitry.
- · Built-in voltmeter.

## **Communicator**

- · One line-active indicator for each of two phone lines.
- "Kiss-Off" signal LED.
- Dual "low telephone voltage detect" circuitry.
- Programmable event codes per each format.
- Up to 58 transmitted events/messages.
- Selectable/deselectable transmissions of 58 events.
- Five zones may be configured to five channels as a slave communicator (channels are auto-resettable).

## **Communication Formats**

Express formats allow complete transaction to be communicated in under five seconds.

- 20 PPS, 3+1 standard and expanded.
- 20 PPS, 4+1 standard and expanded.
- 20 PPS, 4+2 standard and expanded.
- 4+1 and 4+2 Ademco Express.

# **Initiating Device Circuits (zones)**

The MS-5024 includes five programmable Initiating Device Circuits (zones). Circuits 1, 2, 4, and 5 are Style B (Class B). Circuit 3 is Style D (Class A). Use the CAC-5F, Class A converter module, to convert **all** Class B IDCs to Class A.

Each zone may support two-wire smoke detectors. Programming options include:

- Waterflow-Silenceable/Non-Silenceable.
- · Supervisory-Standard/Auto-Reset.
- · Pull Station.
- · Normally Open Contact device.

All circuits are power-limited and also fully supervised. They allow up to 100 ohms of line resistance and allow for use of 12 to 18 AWG (3.1 to 0.78 mm²) wire.

# **Notification Appliance Circuits**

- Two Style Y (Class B) @ 1.5 amps each.
- All circuits are fully power-limited and meet UL power-limiting requirements using fuseless technology.

# **Auxiliary Outputs**

- Resettable four-wire smoke detector power @ 300 mA.
- Non-resettable power @ 300 mA.

**NOTE:** Use of auxiliary power outputs does not derate available 3 amps of NAC power.

• Two fully programmable Form-C relays.

## **CABINET SPECIFICATIONS**

The cabinet is red with a dark blue overlay. Knockouts on the top, sides, and back provide ease of wire entry. The cabinet can be surface or semi-flush mounted and is compact in design.

#### Dimensions:

**Door:** 14.75" high x 12.75" wide

(37.465 cm high x 32.385 cm wide).

**Backbox:** 14.5" high x 12.5" wide x 3.0" deep

(36.83 cm high x 31.75 cm wide x 7.62 cm

deep).

Trim Ring: Part # TR-3-R

17.625" high x 15.625" wide (44.768 cm high x 39.688 cm wide).

## PRODUCT LINE INFORMATION

MS-5024 Five-zone, 24-volt, Fire Alarm Control Communicator. Includes backbox, transformer, technical manual, and a frame & post operating instruction sheet.

**MS-5024E** Same as above with 230 VAC, 50 Hz transformer (UL Listed).

**RZA-5F** Five-zone Remote Annunciator mounts to a single-gang box (requires ADM-24).

ADM-24 Annunciator Driver Module.

CAC-5F Class A Converter Module. Converts *all* Class B Initiating Device Circuits (zones) to Class A.

NACA-2F Class A Converter module. Converts both Class B Notification Appliance Circuits (NAC) to Class

DP-5024 Internal Dress Panel.

MCBL-7 DACT phone cord, 7 feet long, (two required).

**BB-17F** UL listed battery backbox. Required for batteries over 7 AH.

TR-3-R Trim ring.

BAT-1242 Battery, 12-volt, 4.2 AH (two required).

BAT-1270 Battery, 12-volt, 7.0 AH (two required).

**BAT-12120** Battery, 12-volt, 12.0 AH (two required, requires BB-17F backbox).

**BAT-12170** Battery, 12-volt, 17.0 AH (two required, requires BB-17F backbox).

5024RB Replacement motherboard.

# ${f UL} ext{-LISTED}$ RECEIVERS compatible with the MS-5024

	0000 00# (00000000 16 & 42)	<b>0000 00</b> <b>685</b> (1)	0 <b>000</b> 00 9000	<b>IIII</b> <b>III-4000</b> (3)	000 0022000	0 00000 0000 00 0 0000 1 & 2	<b>6000/6500</b> (5)	<b>3000</b> (7)	0000000 000-2 (9)
0	4+1 0000 00 000000	<b>V</b>			<b>V</b>				<b>V</b>
1	4+2 0 000 00 0 000000	~			<b>~</b>	<b>√</b> (8)			~
2	3+1/000000/1800/2300	<b>V</b>	<b>√</b> (2)	<b>/</b>	<b>✓</b> (4)	<b>'</b>	<b>√</b> (5 <b>,</b> 6)	<b>✓</b>	<b>V</b>
3	3+1,00000001/1800/2300	~	<b>(</b> 2)	<b>/</b>	<b>✓</b> (4)	<b>/</b>		<b>✓</b>	~
4	3+1 / 0 0 0 0 0 0 0 / 1 9 0 0 / 1 4 0 0	<b>V</b>	<b>√</b> (2)		<b>✓</b> (4)	<b>/</b>		<b>/</b>	<b>'</b>
5	3+1,00000001400	~	<b>(</b> 2)		<b>✓</b> (4)	>		<b>V</b>	~
6	4+1 <b>/100000</b> /1800/2300	<b>V</b>	<b>√</b> (2)	<b>/</b>	<b>✓</b> (4)	<b>&gt;</b>	<b>(</b> 5)	<b>/</b>	<b>'</b>
7	4+1,00000001/1800/2300	~	<b>(</b> 2)		<b>✓</b> (4)	<b>/</b>		<b>✓</b>	~
8	4+1 /1 11 11 11 11 11 11 11 11 11 11 11 11	~	<b>√</b> (2)		<b>✓</b> (4)	<b>V</b>		<b>✓</b>	~
9	4+1,00000001400	<b>V</b>	<b>√</b> (2)		<b>✓</b> (4)	<b>/</b>		<b>✓</b>	<b>/</b>
0	4+2 <b>/J 🗓 🗓 🗓 🗓</b> /1800/2300	~	<b>(</b> 2)	<b>/</b>	<b>✓</b> (4)	<b>&gt;</b>	<b>✓</b> (5)	<b>✓</b>	~
	4+2/00000001/1800/2300	~	<b>√</b> (2)		<b>✓</b> (4)	<b>/</b>		<b>✓</b>	7
	4+2 <b>/J 🗓 🗓 🗓 🗓</b> 🗸 /1 900 /1 400	<b>V</b>	<b>√</b> (2)		<b>✓</b> (4)	<b>&gt;</b>		<b>/</b>	<b>V</b>
	4+2/00000001/1900/1400	<b>V</b>	<b>√</b> (2)		<b>✓</b> (4)	<b>V</b>		<b>V</b>	<b>V</b>
	(000000)								
	(000000)								54007M #

51267t1.tbl

### KEY:

- (1) With 685-8 Line Card with Rev. 4.4d software.
- (2) With 9002 Line Card Rev. 9035 software or 9032 Line Card with 9326A software.
- (3) Rev. 4.0 software.
- **(4)** FBI CP220FB Rec-11 Line Card with Rev. 2.6 software and a memory card with Rev. 3.8 software.
- (5) Model 6500 with Rev. 600 software.
- (6) Model 6000 with Rev. 204 software.
- (7) With Rev. B control card at Rev. 1.4 software and Rev. C line card at Rev. 1.5 software.
- (8) Model 2 only.
- (9) Version 1.62 software.