

### UNAMP,4-COND,5-COND,6-COND,4-PIN,5-PIN,6-PIN

4-PIN		5-PIN		6-PIN	
PIN	FUNCTION	PIN	FUNCTION	PIN	FUNCTION
A	(+) EXC.	A	(+) EXC.	A	(+) EXC.
B	(+) SIG.	B	(+) SIG.	B	(+) SIG.
C	(-) SIG.	C	(-) SIG.	C	(-) SIG.
D	(-) EXC.	D	(-) EXC./	D	(-) EXC.
			TEDS GND	E	TEDS GND
		E	TEDS DATA	F	TEDS DATA

\* USE TEDS CONNECTIONS WHEN REQUIRED

001-LWR-100

IF THIS IS A PAPER COPY IT IS UNCONTROLLED. VERIFY REVISION BEFORE USE.

PROPRIETARY RIGHTS NOTICE: THIS DRAWING COVERS A PROPRIETARY ITEM AND IS THE PROPERTY OF HONEYWELL. THIS DRAWING IS NOT TO BE COPIED OR USED WITHOUT THE PERMISSION OF HONEYWELL.

UNLESS OTHERWISE SPECIFIED: ALL DIMENSIONS IN INCHES. INTERPRET PER ASME Y14.100-2000 OTHER HONEYWELL STDS MAY APPLY. ALL FILLETS & CORNERS .005R MAX DEBURR & BREAK SHARP CORNERS		A 7/18/2006	PIN E WAS "TEDS DATA", PIN F WAS "TEDS GND" FOR 6 PIN CONN	MGJ	RJG	MGF
		-	INITIAL RELEASE TO PRODUCTION			
REV	DESCRIPTION	REV BY	CHK BY	APV BY		
DRW:	DURKIN 12/15/05	CHK:	VICARS 05/09/2006	MFG:	-	ENG: OSMITH 05/03/2006
AUTOCAD						
REV HIST	DO NOT SCALE	<div style="display: flex; justify-content: space-between;"> <div style="font-size: 2em; font-weight: bold;">Honeywell</div> <div style="font-size: x-small;">                     HONEYWELL SENSOTEC                      2080 ARLINGATE LANE                      COLUMBUS, OHIO 43228  <a href="http://www.honeywell.com/sensing">www.honeywell.com/sensing</a> </div> </div>				
PCB DWG & REV:	.X ±.1					
CHECKOUT PROCED:	.XX ±.01					
SCHEMATIC:	.XXX					
LAYOUT:	±.005					
DRILL PATTERN:	±1/2"					
		CODE IDENT NO. <b>51518</b>		DOCUMENT NUMBER		
		SHEET 1 OF 1	SIZE A	001-LWR-100		



EXTERNAL WIRING CODE  
UNAMP, 5 & 6-COND, 5 & 6-PIN

100  
1  
R