

## Displacement Accessories

---

### Test & Measurement Sensors



#### DESCRIPTION

Honeywell provides a wide range of accessories for our test and measurement sensor products, which are designed to meet additional requirements for most customer applications.

Accessories available to complement Honeywell's test and measurement displacement sensors include mounting blocks, displacement tips, and more.

If you don't see exactly what you need listed below, or have special requirements for your particular application or operating environment, please contact Honeywell for assistance.


#### MOUNTING BLOCK FEATURES

- Designed for use with Honeywell displacement and miniature displacement transducers (LVDTs)

#### DISPLACEMENT TIP FEATURES

- Replacement domed and rolling tips

# Displacement Accessories




## MOUNTING BLOCKS

Order Code	Description
AA937	Block for body diameter of 20 mm [0.8 in] or 32 mm [1.25 in] and stroke length of $\pm 12,7$ mm [0.5 in] or longer
AA945	Block for body diameter of 8 mm [0.31 in] or 9,5 mm [0.37 in]



## DISPLACEMENT TIPS

Part Number	Order Code	Description	Drawing	T dimension	D dimension
032-0457-01	AA947	Rolling tip for displacement transducer	A	1,52 mm to 4,06 mm [0.06 in to 0.16 in] nom.	7,11 mm to 8,38 mm [0.28 in to 0.33 in] nom.
032-0744-00	AA946	Flat small tip for displacement transducer	B	2,54 mm [0.10 in]	6,1 mm [0.24 in]
032-0378-00	AA948	Flat medium tip for displacement transducer	B	2,54 mm [0.10 in]	9,9 mm [0.39 in]
032-1403-00	AA949	Flat large tip for displacement transducer	B	2,54 mm [0.10 in]	24,89 mm [0.98 in]
032-1404-00	AA950	Extension small tip for displacement transducer	C	14,99 mm [0.59 in]	5,08 mm [0.20 in]
032-1405-00	AA962	Extension medium tip for displacement transducer	C	29,93 mm [1.18 in]	5,08 mm [0.20 in]
032-1406-00	AA963	Extension large tip for displacement transducer	C	70,10 mm [2.76 in]	5,08 mm [0.20 in]



**Warranty.** Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. **The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.**

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

## **WARNING**

### **PERSONAL INJURY**

- DO NOT USE these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury.

**Failure to comply with these instructions could result in death or serious injury.**

## **WARNING**

### **MISUSE OF DOCUMENTATION**

- The information presented in this datasheet is for reference only. DO NOT USE this document as product installation information.
- Complete installation, operation and maintenance information is provided in the instructions supplied with each product.

**Failure to comply with these instructions could result in death or serious injury.**

### **Find out more**

Honeywell serves its customers through a worldwide network of sales offices, representatives and distributors. For application assistance, current specifications, pricing or name of the nearest Authorized Distributor, contact your local sales office. To learn more about Honeywell's test and measurement products, call **+1-614-850-5000**, visit **[www.honeywell.com/sensotec](http://www.honeywell.com/sensotec)**, or e-mail inquiries to **[info.tm@honeywell.com](mailto:info.tm@honeywell.com)**

Sensing and Control  
Honeywell  
1985 Douglas Drive North  
Golden Valley, MN 55422  
**[www.honeywell.com](http://www.honeywell.com)**

# Honeywell